

EASA Part Nº ES.145.046

FAA Nº E4UY980J

TCCA Nº 816-04

CAA UK Nº UK.14501563

CAAC Nº F03400940

PECAL-2010.7058-07-02-01

PERAM 145 Nº ES.PERAM145 / 7058 / 18

AEG Aerospace Engineering Group Spain

Bilbao

Madrid

Sevilla

www.aeg.aero

c.navajas@aegurope.net

PN	Description	Manufacturer	Aircraft Types	ATA	AEG Spain Shop
102	Pitch Feel Trim Assembly			27-32-01	AEG Sevilla
244	Fire Detection Cable				AEG Sevilla
244	Fire Detection Cable				AEG Sevilla
294	Fire Detection Cable				AEG Sevilla
394	Crew Seats				AEG Sevilla
644	Fire Detection Cable				AEG Sevilla
744	Fire Detection Cable				AEG Sevilla
750	Airman Headset			23-50-06	AEG Sevilla
760	Airman Headset			23-50-06	AEG Sevilla
1272	INDICATOR, HEIGHT	SIERRA NETWORKS	UNK		AEG Sevilla
1462	BALLAST UNIT	GE	UNK	72-09-03	AEG Sevilla
1827	D.C. Power Supply, Dimmable			33-10-03	AEG Sevilla
1849	Hydraulic Relief Valve				AEG Sevilla
2107	Attendant Seats				AEG Sevilla
2113	CASING / STATOR ASSY	ELGIN	Dash 8,DHCB	31	AEG Sevilla
2489	Flight Station Door Lock Assembly			52-50-13	AEG Sevilla
2530	Temperature Switch and Associated valves				AEG Sevilla
2634	Hydraulic Bleed / Relief Valve			29-13-33	AEG Sevilla
2640	Valve, Pressure Relief				AEG Sevilla
2758	AIRCRAFT BATTERY	SAFT BATTERIES	A310A300A321A319A320A320-221A320-232A320-200	24-38-51	AEG Sevilla
4131	Valve, Solenoid, 3- Way, 2-Position, Normally Closed			32-41-15	AEG Sevilla
4307	Lock Assembly			52-50-19	AEG Sevilla
4323	Lock Assembly			52-50-12	AEG Sevilla
4538	HYDRAULIC PRIORITY RELIEF CARTRIDGE VALVE	PNEUDRAU	B737-800,MD-90,B737-600,B737-600,B737-400,B737-800	32-30-02	AEG Sevilla
4620	Executive Aircraft Toilets			MM4620	AEG Sevilla
4622	Free Reverse Flow, Stained Outlet, Reset Valve			32-30-04	AEG Sevilla
4750	BALLAST	AVTECH	UNK	22	AEG Sevilla
5059	VALVES, HYDRAULIC SHUTTLE	PNEUDRAULICS	B737-200,B737-500,B737-400,B737-300,B737-900,B737-800,B737-700,B737-600,MD-80-83,B737	32	AEG Sevilla
5060	Audio Integrating System			23-50-07	AEG Sevilla
5061	Audio Integrating System			23-50-07	AEG Sevilla
5062	Audio Integrating System			23-50-07	AEG Sevilla
5063	Audio Integrating System			23-50-07	AEG Sevilla
5064	Audio Integrating System			23-50-07	AEG Sevilla
5079	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
5082	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
5083	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
5088	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
5089	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
5115	BALLAST	AVTECH	UNK	33-21-17,33	AEG Sevilla
5115	BALLAST	TRIUMPH ACCESSORY SERVICES	UNK	5115	AEG Sevilla
5283	Interphone Handset			23-30-05	AEG Sevilla
5287	Attendant No. 2 Control Unit			23-30-12	AEG Sevilla
5289	Attendant No. 1 Control Unit			23-30-13	AEG Sevilla
5774	Floor Mounted Electroluminescent Eel System			33-50-01	AEG Sevilla
5880	Floor Mounted Electroluminescent Eel System			33-50-01	AEG Sevilla
6252	FUSE, HYDRAULIC QUANTITY MEASU	PNEUDRAU	B737-600,B737-100,B737-500,B737-400,B737-300,B737-800,A310,A320,B737	36-27-05	AEG Sevilla
6252	Hydraulic Quantity Measuring Fuse With Bypass CMM			32-40-03	AEG Sevilla
6257	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	B737-600,B737-500,B737-400,B737-300,A310,A300,B737	36-27-05	AEG Sevilla
6271	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	B737-500,B737-400,B737-300,DC-10,B777,B737	36-27-07	AEG Sevilla
6362	Hydraulic Fuse, Volumetric, With Bypass Fire and Overheat Detection System Control Mechanism			32-41-05	AEG Sevilla
6504	Temperature Switch and Associated valves				AEG Sevilla
7301	Temperature Switch and Associated valves				AEG Sevilla
8200	Nose Landing Gear Drag Strut Assembly			32-20-02	AEG Sevilla
8300	Nose Landing Gear Retraction Actuator Assembly			32-30-05	AEG Sevilla
8400	NLG Drag Strut Actuator			32-30-06	AEG Sevilla
8402	STEAM OVEN	HEYCO PRODUCTS	A319-A320-A330		AEG Bilbao
8414	Linear Actuator			49-14-16	AEG Sevilla
8454	HSTA			27-42-02	AEG Sevilla
8600	Nose Landing Gear Shock Strut Assembly			32-20-01	AEG Sevilla
8960	Centering Mechanism			32-50-07	AEG Sevilla
9849	Electronic Faucet Assembly, Relay Timed			38-20-16	AEG Sevilla
9851	Lavatory Potable Water System			38-12-14	AEG Sevilla
10013	Fuel Quantity Primary Indicator			28-41-56	AEG Sevilla
10014	Fuel Quantity Repeater Indicator			28-41-55	AEG Sevilla
10048	Fuel Quantity Primary Indicator			28-41-56	AEG Sevilla
10049	Fuel Quantity Repeater Indicator			28-41-55	AEG Sevilla
10091	Fuel Quantity Primary Indicator			28-41-56	AEG Sevilla
10092	Fuel Quantity Repeater Indicator			28-41-55	AEG Sevilla
10100	Shock Strut			32-10-01	AEG Sevilla
10100	Main Landing Gear Shock Strut Assembly			32-10-06	AEG Sevilla
10115	Fuel Quantity Primary Indicator			28-41-56	AEG Sevilla
10116	Fuel Quantity Repeater Indicator			28-41-55	AEG Sevilla
10190	Main Landing Gear Shock Strut Assembly			32-10-07	AEG Sevilla
10200	Main Landing Gear Drag Strut Assembly			32-10-02	AEG Sevilla
10200	Main Landing Gear Drag Strut Assembly			32-10-08	AEG Sevilla
10200	Main Landing Gear Drag Strut Assembly			32-10-12	AEG Sevilla
10300	Main Landing Gear Yoke Assembly			32-10-03	AEG Sevilla
10300	Main Landing Gear Yoke Assembly			32-10-09	AEG Sevilla
10300	Main Landing Gear Yoke Assembly			32-10-14	AEG Sevilla
10400	Main Landing Gear Stabilizer Stay Assembly			32-10-04	AEG Sevilla
10400	Main Landing Gear Stabilizer Stay Assembly			32-10-13	AEG Sevilla
10600	MLG Auxiliary Actuator			32-30-02	AEG Sevilla
10700	MLG Stabilizer Actuator			32-30-03	AEG Sevilla
11000	Rudder Damper Assembly			27-70-01	AEG Sevilla
11200	Rudder Actuator			27-20-01	AEG Sevilla
11300	Main Landing Gear Uplock Assembly			32-30-21	AEG Sevilla
12300	Executive Aircraft Toilets			MM4620	AEG Sevilla
14100	Shock Strut			32-10-01	AEG Sevilla
14200	Shock Strut			32-10-01	AEG Sevilla
15475	Cart				AEG Sevilla
15838	Water Level And Monitoring System			38-18-03	AEG Sevilla
17279	MLG Uplock And Actuator Assembly			32-30-15	AEG Sevilla
20022	Fuel Quantity Units			28-40-51	AEG Sevilla

229432	SUMERGED FUEL BOOSTER PUMP	INOI	F100,F70,F28	28.28-06-50	AEG Sevilla
233400	Rudder Actuator Assembly			27-20-36	AEG Sevilla
237400	Rudder Pressure-Off Damper			27-20-41	AEG Sevilla
237900	Rudder Dual-Pressure Regulator			27-20-56	AEG Sevilla
240300	Fight Spoiler Lift Dump Signal Solenoid Valve Assembly			27-14-21	AEG Sevilla
273104	Cable Tension Regulator			27-31-04	AEG Sevilla
273302	Centering Spring Cartridge			27-33-02	AEG Sevilla
341983	NOSE LANDING GEAR UNLOCK ASSEMBLY	LOCKHEED	C-130	16L3-3-10	AEG Sevilla
360900	SWITCH		UNK		AEG Sevilla
37380	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS AEROSPACE	B737-700,C-130,MID80,DC-8,B737-300,CRJ-900,DC-10,B727-300,B737-400	29-10-18	AEG Sevilla
37688	FUEL CONTROL UNIT	HONEYWELL INTERNATIONAL			AEG Sevilla
381785	ROTOR	EATON AEROSPACE	727, 737	29-10-49	AEG Bilbao
390500	Rudder Power Control Unit (PCU) Assembly			27-21-04	AEG Sevilla
390600	Elevator Power Control Unit (PCU) Assembly			27-31-02	AEG Sevilla
390700	Power Control Unit(PCU) Spoiler Actuator Assembly			27-60-04	AEG Sevilla
390780	Spoiler Toggle Link Assembly			27-60-05	AEG Sevilla
394324	FLOW DIVIDER AND DRAIN		UNK		AEG Sevilla
394390	FLOW DIVIDER AND DRAIN		UNK		AEG Sevilla
395800	Spoiler Lift Dump signal solenoid Valve Assembly			27-66-03	AEG Sevilla
396900	Elevator Power Control Unit(PCU) Compensator Assembly			27-32-04	AEG Sevilla
396000	Spoiler Unload Valve Assembly			27-66-04	AEG Sevilla
396362	ELECTRIC MOTOR ASSEMBLY	EATON / 62983	A300, DC-10, MD-80	29-21-08	AEG Sevilla
396800	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	707, E3, E8, E6	75	AEG Sevilla
398500	Flight Control System Electronic Control Unit			27-00-01	AEG Sevilla
399200	Pitch Feel Trim Assembly			27-32-01	AEG Sevilla
399300	Pitch Feel, Electromechanical Linear actuator			27-32-02	AEG Sevilla
399600	Rudder Feel Trim Unit Assembly			27-22-01	AEG Sevilla
399600	Rudder Trim, Electromechanical Linear Actuator			27-22-02	AEG Sevilla
399700	Aileron Trim Centering Assembly				AEG Sevilla
399800	Aileron Trim, Electromechanical Linear Actuator				AEG Sevilla
406300	Steering Control Unit			32-50-03	AEG Sevilla
406330	Pilot Hand Control Assembly			32-50-04	AEG Sevilla
410022	Ni-Cd Aircraft Battery 23378	TEAM		24	AEG Sevilla
410075	Ni-Cd Aircraft Battery 1608-1	SAFT		24	AEG Sevilla
410089	Ni-Cd Aircraft Battery 40208-2	SAFT	A320	24	AEG Sevilla
410090	Ni-Cd Aircraft Battery 4078-1	SAFT	A320	24	AEG Sevilla
41018	Ni-Cd Aircraft Battery 40209-2	SAFT	A320	24	AEG Sevilla
410138	Ni-Cd Aircraft Battery 4079-1	SAFT	A320	24	AEG Sevilla
410231	Ni-Cd Aircraft Battery 1658-2	SAFT		24	AEG Sevilla
410378	Ni-Cd Aircraft Battery 1656-5	SAFT		24	AEG Sevilla
410385	Ni-Cd Aircraft Battery 1658	SAFT		24	AEG Sevilla
410407	Ni-Cd Aircraft Battery 1608	SAFT		24	AEG Sevilla
410421	Ni-Cd Aircraft Battery 4078-5	SAFT	A320	24	AEG Sevilla
410422	Ni-Cd Aircraft Battery 40408	SAFT		24	AEG Sevilla
410426	Ni-Cd Aircraft Battery 23491	SAFT		24	AEG Sevilla
410530	Ni-Cd Aircraft Battery 2371-4	SAFT	A320	24	AEG Sevilla
410677	Ni-Cd Aircraft Battery 40208-4	SAFT	A320	24	AEG Sevilla
410687	Ni-Cd Aircraft Battery 40208-5	SAFT	A320	24	AEG Sevilla
410689	Ni-Cd Aircraft Battery 606	SAFT		24	AEG Sevilla
410696	Ni-Cd Aircraft Battery 2371-6	SAFT	A320	24	AEG Sevilla
410705	Ni-Cd Aircraft Battery 666	SAFT		24	AEG Sevilla
410766	Ni-Cd Aircraft Battery 615	SAFT		24	AEG Sevilla
410860	Ni-Cd Aircraft Battery 40576	BENDIX	C-130	9H4-4-2-1	AEG Sevilla
410861	Ni-Cd Aircraft Battery 23491-3	SAFT	A320	24	AEG Sevilla
410868	Ni-Cd Aircraft Battery 2778-5	SAFT	A320	24	AEG Sevilla
411003	Ni-Cd Aircraft Battery 16156-1	TEAM		24	AEG Sevilla
411005	Ni-Cd Aircraft Battery 16158	SAFT		24	AEG Sevilla
411146	Ni-Cd Aircraft Battery 616	SAFT		24	AEG Sevilla
411179	Ni-Cd Aircraft Battery 40142	SAFT		24	AEG Sevilla
412000	Ni-Cd Aircraft Battery 40042	EATON	C-130,B727,B737	29-10-18	AEG Sevilla
41247	Ni-Cd Aircraft Battery 2371-5	SAFT	A320	24	AEG Sevilla
41248	Ni-Cd Aircraft Battery 4008-1	SAFT		24	AEG Sevilla
41282	Ni-Cd Aircraft Battery 27278-2	SAFT		24	AEG Sevilla
41289	Ni-Cd Aircraft Battery 40278-2	SAFT	A320	24	AEG Sevilla
41393	Ni-Cd Aircraft Battery 40371	SAFT		24	AEG Sevilla
41431	Ni-Cd Aircraft Battery 16258	SAFT		24	AEG Sevilla
414621	Ni-Cd Aircraft Battery 2708-1	SAFT	A320	24	AEG Sevilla
41462	Ni-Cd Aircraft Battery 40342	TEAM		24	AEG Sevilla
41777	Ni-Cd Aircraft Battery 2371-7	SAFT	A320	24	AEG Sevilla
41826	Ni-Cd Aircraft Battery 23678-1	SAFT	A320	24	AEG Sevilla
41978	Ni-Cd Aircraft Battery 40208-6	SAFT	A320	24	AEG Sevilla
42222	Ni-Cd Aircraft Battery 2708-2	TEAM	A320	24	AEG Sevilla
42437	Ni-Cd Aircraft Battery 4078-13	SAFT	A320	24	AEG Sevilla
42473	Ni-Cd Aircraft Battery 40300	SAFT		24	AEG Sevilla
42546	Ni-Cd Aircraft Battery 23678-2	SAFT	A320	24	AEG Sevilla
42586	Ni-Cd Aircraft Battery 40178-7	SAFT		24	AEG Sevilla
42670	Ni-Cd Aircraft Battery 2506-2	SAFT		24	AEG Sevilla
42700	Rudder Shut-Off Valve Assembly			27-21-05	AEG Sevilla
42755	Ni-Cd Aircraft Battery 27478	SAFT		24	AEG Sevilla
42786	Ni-Cd Aircraft Battery 4076-15	SAFT	A320	24	AEG Sevilla
4281	Ni-Cd Aircraft Battery 23478	SAFT		24	AEG Sevilla
42826	Ni-Cd Aircraft Battery 16108-1	SAFT		24	AEG Sevilla
42917	Ni-Cd Aircraft Battery 6206	SAFT		24	AEG Sevilla
42920	Ni-Cd Aircraft Battery 2522	SAFT		24	AEG Sevilla
42931	Ni-Cd Aircraft Battery 4072	SAFT		24	AEG Sevilla
42942	Ni-Cd Aircraft Battery 2376-7	SAFT	A320	24	AEG Sevilla
43014	Ni-Cd Aircraft Battery 4078-16	SAFT	A320	24	AEG Sevilla
43021	Ni-Cd Aircraft Battery 23678-3	SAFT	A320	24	AEG Sevilla
43034	Ni-Cd Aircraft Battery 4079-9	SAFT	A320	24	AEG Sevilla
43041	Ni-Cd Aircraft Battery 40778-11	SAFT	A320	24	AEG Sevilla
43042	Ni-Cd Aircraft Battery 4076-17	SAFT	Gulfstream,A320	24	AEG Sevilla
43095	Ni-Cd Aircraft Battery 40208-7	SAFT	A320	24	AEG Sevilla
43174	Ni-Cd Aircraft Battery A40209-1	SAFT		24	AEG Sevilla
43203	Ni-Cd Aircraft Battery 40508-1	SAFT	A320	24	AEG Sevilla
43210	Ni-Cd Aircraft Battery 4079-6	SAFT	A320	24	AEG Sevilla
43211	Ni-Cd Aircraft Battery 2778-10	SAFT	A320	24	AEG Sevilla
43228	Ni-Cd Aircraft Battery 4078-18	SAFT	A320	24	AEG Sevilla
43329	Ni-Cd Aircraft Battery 2778-15	SAFT	A320	24	AEG Sevilla
43335	Ni-Cd Aircraft Battery 26308-1	SAFT	A320	24	AEG Sevilla
43337	Ni-Cd Aircraft Battery 4078-16	SAFT	A320	24	AEG Sevilla
43384	Ni-Cd Aircraft Battery 26408-1	SAFT	A320	24	AEG Sevilla
43465	Ni-Cd Aircraft Battery 2376-8	SAFT	A320	24	AEG Sevilla
43555	Ni-Cd Aircraft Battery 23498-1	SAFT SA	A320	24	AEG Sevilla
434092	Ni-Cd Aircraft Battery 26108-3	SAFT	A320	24	AEG Sevilla
434140	Ni-Cd Aircraft Battery 1277-3	SAFT		24	AEG Sevilla
434162	Ni-Cd Aircraft Battery 4002	TEAM		24	AEG Sevilla
434184	Ni-Cd Aircraft Battery 26108-5	SAFT AMERICA AIR FORCE	A320	24	AEG Sevilla
434219	Ni-Cd Aircraft Battery 40178	SAFT		24	AEG Sevilla
434254	Ni-Cd Aircraft Battery 181CH	SAFT	A320	24	AEG Sevilla
434279	Ni-Cd Aircraft Battery 40100-2	SAFT		24	AEG Sevilla
434377	Ni-Cd Aircraft Battery 40178-21	SAFT		24	AEG Sevilla
434445	Ni-Cd Aircraft Battery 178	SAFT		24	AEG Sevilla
434469	ELECTRIC MOTOR ASSEMBLY	EATON / 62983	C-130,DC-10,A310,A300	29-21-08	AEG Sevilla
434512	Ni-Cd Aircraft Battery 26508	SAFT		24	AEG Sevilla
434547	Ni-Cd Aircraft Battery 19VO3KH B	SAFT		24	AEG Sevilla
434548	Ni-Cd Aircraft Battery 20VO3KH B	SAFT		24	AEG Sevilla
434690	Ni-Cd Aircraft Battery 40200-1	SAFT	A320	24	AEG Sevilla
434732	Ni-Cd Aircraft Battery 276CH	SAFT		24	AEG Sevilla
434742	Ni-Cd Aircraft Battery 26608	SAFT		24	AEG Sevilla

766385	Outboard Slat Actuator Assembly			27-81-18	AEG Sevilla
766461	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
766454	Auto Deploy Control Unit			24-23-35	AEG Sevilla
767173	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
767188	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
767226	Pump And Motor Assembly			24-14-22	AEG Sevilla
767910	STATOR ASSEMBLY, GENERATOR	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
767916	STATOR HOUSING	SUNDSTRAND	B737	24-17-50	AEG Bilbao
768342	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	ARJ21	24-26-16	AEG Bilbao
768342	Rotor Balance Assembly			24-26-16	AEG Sevilla
768616	Mid Slat Actuator Assembly			27-81-20	AEG Sevilla
769068	IDG	HAMILTON	B767-400,B777	24	AEG Bilbao
769883	EXCITER STATOR	SUNDSTRAND	B737	24	AEG Bilbao
770401	EXCITER ROTOR	HAMILTON SUNDSTRAND	A330	24	AEG Bilbao
770402	PMG STATOR	PRATT&WHITNEY	A330,A321	72-53-16	AEG Bilbao
770404	STATOR ASSEMBLY, EXCITER	PRATT	A320,B767,B777,B737,B747	75-21-01	AEG Bilbao
770404	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
771051	Generator Assembly			24-22-13	AEG Sevilla
771701	Input Housing Assembly			24-17-52	AEG Sevilla
772181	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	CFM56- E A 330, A 320, A 310, A 319, A 300, CFM56 A	24-00-00	AEG Bilbao
772183	STATOR HOUSING ASSEMBLY	SUNDSTRAND	737	24-17-50	AEG Bilbao
772292	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	V2500,A319,A321,A320,CFM56-5B	24-21-00	AEG Bilbao
772294	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A321	24-17-51	AEG Bilbao
772295	EXCITER STATOR HOUSING ASSEMBLY	SUNDSTRAND	UNK	24	AEG Bilbao
778496	Wing Isolation Check Valve			21-32-24	AEG Sevilla
778497	Trim Zone Temperature Valve			21-61-46	AEG Sevilla
782100	HP Bleed Pressure Switch			21-51-46	AEG Sevilla
785242	INTEGRATED DRIVE GENERATOR	HAMILTON SUNDSTRAND	A330, A340		AEG Bilbao
785242	RACE - ROLLER BEARING		UNK		AEG Bilbao
798884	Fuel Computer Tray			28-41-21	AEG Sevilla
802600	Windsheild			56-10-01-Obsolete	AEG Sevilla
802600	Windsheild			56-10-12	AEG Sevilla
820029	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820909	Fan Inlet Diffuser Housing			21-53-11	AEG Sevilla
820967	Check Valve			21-53-07	AEG Sevilla
820975	Oil Cooler Ejector			79-21-01	AEG Sevilla
841925	AC ROTOR ASSEMBLY	HONEYWELL	F-27		AEG Bilbao
848354	VARIABLE DISPLACEMENT	VICKERS	B727,A340,500,A330,500,MD- 10,B767,B747,A330,A300,A340,A320,A310	29-10-41	AEG Sevilla
849557	Hydraulic Motor/pump Assembly		MLP-11L,F,M56		AEG Sevilla
849589	VARIABLE DISPLACEMENT HYDRAULIC PUMP	EATON	A 330, B767, B737, F, B737	82-22-51	AEG Sevilla
861561	MULTI-PURPOSE FLOW STATOR ASSEMBLY	EATON/VICKERS	A300	29-10-47	AEG Sevilla
869843	FLUID PRESSURE REGULATING VALVE		UNK		AEG Sevilla
878229	ARMATURE ASSEMBLY	BENDIX	A330, A340	24	AEG Bilbao
878229	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS	A319,A320,V2500,B767,B737,B737- 1000,E03,B767,600,000,000,000	38-30-05	AEG Sevilla
887477	AC DRIVEN MOTORPUMP ASSEMBLY	VICKERS	B737-200,B737-100,B747,B727,B737	29-10-49	AEG Sevilla
887479	AC DRIVEN MOTORPUMP ASSEMBLY	EATON VICKERS FLUID POWER CONTROLS	B737-200,B737-100,B747,B727,B737	29-10-51	AEG Sevilla
887480	AC DRIVEN MOTORPUMP ASSEMBLY	EATON VICKERS FLUID POWER CONTROLS	F 27,B777,B727,B737	29-10-52	AEG Sevilla
887673	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS	320,V2500,DC-10-10,A321-200,A321- 100,A330,000,A340,000,100,B767	27-50-10	AEG Sevilla
896380	TORQUE LIMITER ASSEMBLY		UNK		AEG Bilbao
900094	25 Cubic Inch Accumulator			29-22-04	AEG Sevilla
900095	Hydraulic Accumulator			29-22-04	AEG Sevilla
933402	HYD MOTOR PUMP	EATON	CN-235, CN-295	29-10-41	AEG Sevilla
945169	Manifold Assembly, Filter, Hydraulic				AEG Sevilla
945170	Filter, Pressure, Hydraulic				AEG Sevilla
945190	Filter, Case Drain, Hydraulic				AEG Sevilla
960441	Hydraulic Reservoir Assembly				AEG Sevilla
960442	Hydraulic Reservoir Assembly				AEG Sevilla
960443	System 3 Hydraulic Reservoir Assembly				AEG Sevilla
971533	DC ELECTRIC MOTORPUMP ASSEMBLY	VICKERS	A330, A340	29-10-60	AEG Sevilla
971808	HIDRAULIC PUMP	VICKERS	EMB-135-145, DHC-8	29-11-15	AEG Sevilla
971808	Variable Displacement Hydraulic Pump				AEG Sevilla
971844	VARIABLE DISPLACEMENT	VICKERS	11ren1-700,DC-8,A340-600,A340- 600,A330-600,A330-600,CFM56,CFM56A	29-10-41	AEG Sevilla
972424	HYDRAULIC PUMP ASSEMBLIES	VICKERS	B747,B767,B777,CF6-80C2	29-11-00	AEG Sevilla
972630	VARIABLE DISPLACEMENT	VICKERS	A340-600,A340- 600,A330-600,A330-600,CFM56,CFM56A	29-10-41	AEG Sevilla
972952	HYDRAULIC PUMP ASSEMBLIES	VICKERS	B777-300,B767-400,B777- 400,B767-300,B767-300,CFM56,CFM56A	29-11-00	AEG Sevilla
974014	MOTOR PUMP ASSY	EATON	A321,A319,A320,A318	29	AEG Sevilla
974540	HYDRAULIC PUMP	EATON	A340-600,A340- 600,A330-600,A330-600,CFM56,CFM56A	29-10-72	AEG Sevilla
974641	Reservoir Level Switch Assembly				AEG Sevilla
974641	Reservoir Level Switch - NewPart Number -				AEG Sevilla
974800	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS	B757,B777,B727,11ren1-700,A340- 600,A340-600,A340-600,CFM56,CFM56A	41-29-02	AEG Sevilla
974947	VARIABLE DISPLACEMENT	VICKERS	A340-600,A340-600,CFM56,CFM56A	29-10-55	AEG Sevilla
974947	VARIABLE DISPLACEMENT	VICKERS	11,B767,B747,A330,A300,A340,A320,A310, A320,B727,11ren1-700,A300,A340	29-10-41	AEG Sevilla
974976	VARIABLE DISPLACEMENT	VICKERS	A320,A340,600,A340,CFM56,CFM56A	29-10-41	AEG Sevilla
975247	Valve Assembly, PTU Select, Hydraulic				AEG Sevilla
975250	Valve, Bypass, Heat Exchanger				AEG Sevilla
975253	Valve Assembly, Isolation, Hydraulic				AEG Sevilla
975256	Hydraulic Balanced Relief Valve				AEG Sevilla
975257	Valve Assembly, Accumulator Isolation, Hydraulic				AEG Sevilla
975278	Automatic Qty. Measuring Fuse				AEG Sevilla
1056350	PRESSURE CONTROL VALVE	PARKER	DC-8,B727-200,B727-100,B737,B707,MD- 80,81	29-20-15	AEG Sevilla
112358	ROTOR	BENDIX	UNK		AEG Bilbao
112359	ARMATURE ASSEMBLY	NATIONAL	F-27	27	AEG Sevilla
139558	CVR Audio Mixer			23-71-05	AEG Sevilla
118377	AUDIO PANEL CONTROL	AVTECH	B737-300,B737	23-50-17	AEG Sevilla
1185237	AUDIO PANEL CONTROL	SAFT	UNK	24	AEG Sevilla
122727	Audio Remote Electronic Unit			23-50-28	AEG Sevilla
1241078	INDICATOR HYDRAULIC PRESSURE	GRIMES		27-00-00	AEG Sevilla
1263742	Audio Electronic Control Unit (AECU)			23-50-34	AEG Sevilla
1263744	Audio Electronic Control Unit (AECU)			23-50-34	AEG Sevilla
1264126	Audio Control Panel (CMM With IPL)			23-50-57	AEG Sevilla
1264127	Audio Control Panel (CMM With IPL)			23-50-57	AEG Sevilla
1344825	Passenger Address/Cabin Interphone Controller			23-31-11	AEG Sevilla
1570421	Servovalve Spoiler			27-64-00	AEG Sevilla
1700089	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
1700586	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
1701317	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	ERUCRUPPO Regional Jet-900,CRJ1000 Regional Jet,1000,EMB,300,EMB	24	AEG Bilbao
1701317	Integrated Drive Generator			24-21-12	AEG Sevilla
1701320	GENERATOR ASSEMBLY	HAMILTON	ERUCRUPPO Regional Jet-900,CRJ1000 Regional Jet,1000,EMB,300,CFM56,CFM56A	24-22-13	AEG Bilbao
1701410	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
1701422	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
1701469	PMG AND SUPPORT ASSEMBLY	SUNSTRAD	CL-601	24	AEG Bilbao
1701482	STATOR	HAMILTON SUNDSTRAND	737	24	AEG Bilbao
1701483	STATOR ASSEMBLY	HAMILTON	B757,A310	24-22-03	AEG Bilbao
1701487	STATOR ASSEMBLY-PMG	SUNDSTRAND	B737	24	AEG Bilbao
1701736	Input Housing Assembly			24-17-52	AEG Sevilla
170766	VSCF GEN	SUNDSTRAND	B777	24-25-00	AEG Bilbao
170768	VSCF GEN	SUNDSTRAND	B777-300,B777-200,B777	24-25-00	AEG Bilbao
1701863	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
1701925	ADG Strut/Generator Assembly			24-23-04	AEG Sevilla
1701931	Pump And Motor Assembly			24-14-22	AEG Sevilla
1702369	EXCITER ROTOR ASSEMBLY	HAMILTON SUNDSTRAND	737	24	AEG Bilbao
1702370	EXCITER ROTOR ASSEMBLY	HAMILTON SUNDSTRAND	B777,A330	24	AEG Bilbao
1702377	ROTOR ASSEMBLY, EXCITER	HAMILTON SUNDSTRAND	A340,MD-11	24	AEG Bilbao
1702690	STATOR ASSEMBLY - AC GENERATOR	SUNSTRAD	737	24	AEG Bilbao
1702711	STATOR ASSEMBLY, ALTERNATING CURRENT	SUNDSTRAND	B757,B747,A320,B767	24-11-79	AEG Bilbao
1702713	STATOR ASSEMBLY, EXCITER	SUNSTRAD	B757,A310	24	AEG Bilbao
1702714	STATOR ASSEMBLY - MAIN GENERATOR	SUNDSTRAND	B737-600	24	AEG Bilbao
1702715	STATOR ASSEMBLY, GENERATOR	SUNDSTRAND	737	24	AEG Bilbao
1702719	STATOR	HAMILTON SUNDSTRAND	A330	29	AEG Sevilla
1702726	STATOR ASSEMBLY - EXCITER	SUNSTRAD	A340	24	AEG Bilbao

1702733	EXCITER ROTOR ASSEMBLY	SUNSTRAD	B767,B757,B747,A300		AEG Bilbao
1703938	DEAERATOR		737		AEG Bilbao
1704222	Drive Shaft Assembly			27-52-02	AEG Sevilla
1704223	Drive Shaft Assembly			27-52-02	AEG Sevilla
1705769	Carrier Shaft Assembly			24-13-04	AEG Sevilla
1706903	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	CFM56	24-00-00	AEG Bilbao
1706907	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	E-A330-A320-A310-A300-A300-COMEA-A320-B737	24-26-15	AEG Bilbao
1708897	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	CFM56	24-00-00	AEG Bilbao
1708899	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	E-A330-A320-A310-A300-A300-COMEA-A320-B737	24-26-15	AEG Bilbao
1709121	IDG	HAMILTON	A330-A320-A320-A319-A318-CFM56-EA-COMEA-EB-COMEA-EC	24-00-00	AEG Bilbao
1712025	Outboard Slat Actuator Assembly			27-81-18	AEG Sevilla
1712505	Inboard Flap Actuator Assembly			27-52-07	AEG Sevilla
1712507	Midboard Right Flap Actuator Assembly			27-52-19	AEG Sevilla
1712509	Midboard Left Flap Actuator Assembly			27-52-20	AEG Sevilla
1712513	Outboard Left Flap Actuator Assembly			27-52-22	AEG Sevilla
1713344	Flap Brake/Position Sensor Unit			27-52-43	AEG Sevilla
1713346	Slat Brake/Position Sensor Unit			27-81-21	AEG Sevilla
1713700	Mid Slat Actuator Assembly			27-81-20	AEG Sevilla
1713731	Drive Shaft Assembly			27-52-02	AEG Sevilla
1713733	Drive Shaft Assembly			27-52-02	AEG Sevilla
1713739	Drive Shaft Assembly			27-52-02	AEG Sevilla
1718201	IDG	HAMILTON	A319 NEO, A320 NEO, A321 NEO	7187	AEG Bilbao
1718205	IDG	HAMILTON	A319 NEO, A320 NEO, A321 NEO	71552	AEG Bilbao
1721000	EXCITER STATOR HOUSING ASSEMBLY	HAMILTON	UNK		AEG Bilbao
1721152	INTEGRATED DRIVE GENERATOR	HAMILTON	A320	71552	AEG Bilbao
1721393	STATOR AND HOUSING ASSEMBLY	HAMILTON	A320, A3240-200, A340-300, A340-600, A340-600, A340-600, A340-600	24-17-50	AEG Bilbao
1725616	IDG INTEGR DRIVE GENERATOR	HAMILTON	B737NG/Boeing 737 MAX	24-11-85	AEG Bilbao
2030781	MODULE ANTI-SKID SHUTLE DISCONNECT	HAMILTON	UNK		AEG Sevilla
217804	Controller			21-31-70	AEG Sevilla
2249956	STARTER GENERATOR		UNK	24-35-02	AEG Sevilla
2349038	SERVO FUEL INJECTOR MODEL RSA-10ED1		LYCOMING ENGINES		AEG Sevilla
2524038	SERVO FUEL INJECTOR		USED ON LYCOMING ENGINES		AEG Sevilla
2524273	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524273	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524298	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524298	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524366	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524366	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524420	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524420	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524422	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524422	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524477	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524477	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524491	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524491	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524492	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524492	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524500	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524500	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524556	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524556	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524601	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524601	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524693	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524693	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524709	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524709	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524733	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524733	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524811	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524811	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524846	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524846	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524889	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524889	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2524880	SERVO FUEL INJECTOR MODEL RSA-10ED1	PRECISION AIRMOTIVE	LYCOMING ENGINES		AEG Sevilla
2524880	SERVO FUEL INJECTOR	PRECISION AIRMOTIVE	USED ON LYCOMING ENGINES		AEG Sevilla
2607483	SLEEVE-AXLE/MLG	HONEYWELL	UNK	32	AEG Sevilla
2770080	Check Valve			28-20-21	AEG Sevilla
2770082	Refuelling Adapter			28-20-19	AEG Sevilla
2770086	Fuel Drain Valve			28-20-18	AEG Sevilla
2770087	Fuel Drain Valve			28-20-18	AEG Sevilla
2780481	Check Valve			28-20-16	AEG Sevilla
2800015	Pressure Relief and Dump Valve			28-30-05	AEG Sevilla
2810022	Refueling Shutoff Valve			28-20-11	AEG Sevilla
2810070	Refuel Adapter			28-20-46	AEG Sevilla
2810073	Main Engine Boost Pump-Ejector			28-20-32	AEG Sevilla
2810074	Tank Scavenge Ejector Pump				AEG Sevilla
2810108	Tank Scavenge Ejector Pump				AEG Sevilla
2950004	Electric Motor Operated Actuator Assembly			28-24-11	AEG Sevilla
2950016	Vent Valve				AEG Sevilla
2950022	Fuel Transfer Shutoff Valve Assembly			28-20-53	AEG Sevilla
2950006	Refuel/Defuel Adapter and Cap Assembly			28-24-03	AEG Sevilla
2960008	Engine Feed Ejector Pump			28-21-09	AEG Sevilla
2960027	1/2-Inch NPT Fuel Motor-Operated Shutoff Valve			28-22-08	AEG Sevilla
2960029	1/2-Inch NPT Fuel Motor-Operated Shutoff Valve			28-24-02	AEG Sevilla
2960042	1-Inch Spar Mounted Valve			28-21-46	AEG Sevilla
2960044	1.25-Inch Spar Mounted Shutoff Valve			28-23-04	AEG Sevilla
3024372	AUTOTRANSFORMER	TELEFLEX DUREL	UNK		AEG Sevilla
3057992	AUTOTRANSFORMER	ECE - TELEFLEX SYN	UNK	33-42-12	AEG Sevilla
3058969	STATOR	A/C BRAKE CO	UNK		AEG Bilbao
3076518	STATOR ASSY BRAKE	TELEFLEX	UNK		AEG Bilbao
3076548	STATOR	TELEFLEX	A310	33	AEG Bilbao
311137	AUTOTRANSFORMER ASSY	GTELEFLEX	UNK		AEG Sevilla
3810040	Reservoir Assembly				AEG Sevilla
3810041	Reservoir Assembly				AEG Sevilla
3882350	FUEL CONTROL UNIT		UNK		AEG Sevilla
3882730	Fuel Control Assy			49-30-91	AEG Sevilla
4037102	TAKE-OFF AND TAXI LIGHT	ECE TELEFLEX	MD80-A321-A320-B747-A310-A300-600-A300	33-43-31-33	AEG Sevilla
4037132	TAKE-OFF AND TAXI LIGHT	TELEFLEX	MD80-A321-A320-B747-A310-A300-600-A300	33-43-31-33-35-43-01	AEG Sevilla
4065713	WING ICING INSPECTION LIGHT	IN SERVICES	A321A318A300	33-42-21-33	AEG Sevilla
4065729	WING ICING INSPECTION LIGHT	IN SERVICES	A321A318A300	33-42-21-33	AEG Sevilla
4100762	Power Transfer Unit Hydraulic				AEG Sevilla
4101054	LAVATORY / GALLEY VENT FAN	HAMILTON	B737,B757	21-20-04	AEG Sevilla
4173763	LANDING LIGHT	TELEFLEX	B737-300 A321A318,B757A300	33-43-12,33-43-13	AEG Sevilla
4191695	RETRACTABLE LANDING LIGHT	ECE	C-150,A318,A300-600,A320-A319,A318,A300-A300	33-42-12	AEG Sevilla
4203503	HYD MOTOR	PARKER	A321A319,A318,A320-221A320	27-50-06	AEG Sevilla
4205400	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	B767,B757,B747,A321A320,A319,CF6-80,CFM56-4B,CFM56-4C,CFM56-4D	REF-88	AEG Sevilla
4205401	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	MD-11,B747-400,B757-200	REF-88	AEG Sevilla
4205601	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	B757,A310,A300,A320,A319,A318,A321A3	REF-103	AEG Sevilla
4205602	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	SAAB 340,A340,A330,A318,A340-600,A310,A300,A300	REF-103	AEG Sevilla
4205603	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	B747,A340,A330,A321A319,A320,A318	29-20-28	AEG Sevilla
4205604	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC PUMP	HSDE	A340,A330,A321A320,A319	29	AEG Sevilla
4233488	TAKE OFF LIGHT	ECE - TELEFLEX	C-150,B777,B757,A318,A320-200	33-46-01	AEG Sevilla
4235654	TAXI LIGHT	ECE - TELEFLEX	A300-600-150,DC-8,B747-200,A310,A300,B737,A318,A320	33-46-02	AEG Sevilla
4254944	AUTOTRANSFORMER, ASSY	TELEFLEX	UNK	33-49-14	AEG Sevilla
4273511	TAKE-OFF AND TAXI LIGHT	ECE TELEFLEX	A320 A321 A319 A318 A310 A300-600 A300	33-43-31-33	AEG Sevilla
4273527	TAKE-OFF AND TAXI LIGHT	ECE TELEFLEX	A320 A321 A319 A318 A310 A300-600 A300	33-43-31-33-35-43-01	AEG Sevilla

4289452	WING SCAN LIGHT	TELEFLEX	A321A318A330A310A300A340	33-49-26	AEG Sevilla
4289468	WING SCAN LIGHT	TELEFLEX	A321A318A330A310A300A340	33-49-26	AEG Sevilla
4292209	LANDING LIGHT	ZODIAC	A350,F100,A321,A318,A330,A320,A330- 340,330,330,330,330	33-42-14	AEG Sevilla
4292491	LOGO LIGHT	ECE-TELEFLEX SONERAVIA	A350,A320,A321,A318,A340,A330	33-47-11,33-43- 3-22	AEG Sevilla
4295078	ENGINE SCAN LIGHT	IN SERVICES	A321A318A340A330	33-49-28	AEG Sevilla
4295085	ENGINE SCAN LIGHT	TELEFLEX SYNERAVIA	A321A318A340A330	33-49-28	AEG Sevilla
4295092	ENGINE SCAN LIGHT	IN SERVICES	A321A318A340A330	33-49-28	AEG Sevilla
4295107	ENGINE SCAN LIGHT	IN SERVICES	A321A318A340A330	33-49-28	AEG Sevilla
4295114	ENGINE SCAN LIGHT	IN SERVICES	A321A318A340A330	33-49-28	AEG Sevilla
4295121	ENGINE SCAN LIGHT	IN SERVICES	A321A318A340A330	33-49-28	AEG Sevilla
4298117	TAKE-OFF AND TAXI LIGHT	ECE-TELEFLEX- SONERAVIA	A330-200C	33-46-12	AEG Sevilla
4299172	AUTOTRANSFORMER	ECE / GLAR BAN	TRW A321A330 A320 B757 A320-340 A340	33	AEG Sevilla
4315542	RETRACTABLE LANDING LIGHT	ECE	C-130A318A317 A321A318 A330 A320 A330- 340 A320 A330 A320 A330 A340	33-42-12	AEG Sevilla
4325173	AUTOTRANSFORMER	ECE - TELEFLEX SYN	A330, A340	33-43-03	AEG Sevilla
4328733	LOGO LIGHT	ECE-TELEFLEX SONERAVIA	A330, A340, A320	33-47-11,33-43- 3-22	AEG Sevilla
4331772	RETRACTABLE LANDING LIGHT	ECE	A350,DC-8A318,B757/B737/A300- 600,A321 A320 A310 A320 A340 A320	33-42-12	AEG Sevilla
4333302	LOGO LIGHT	ECE	B757	33	AEG Sevilla
4333318	LOGO LIGHT	ECE	B757	33	AEG Sevilla
4333325	LOGO LIGHT	ECE	B757	33	AEG Sevilla
4333332	LOGO LIGHT	ECE	B757	33	AEG Sevilla
4339107	Nose Gear Landing Light	EUE-TELEFLEX SONERAVIA	A340, A330, A320	33-41-08	AEG Sevilla
4358532	LOGO LIGHT	EUE-TELEFLEX SONERAVIA	A340, A330, A320	33-47-11, 33-43-11	AEG Sevilla
4359596	Wiper Blade Assembly			30-42-13	AEG Sevilla
4359826	Wiper/Steal Panel Switch			30-42-18	AEG Sevilla
4363682	Windshield Wiper System			30-42-00	AEG Sevilla
4364686	Electrical Harness			30-42-19	AEG Sevilla
4375825	Electronic Control Unit			30-42-12	AEG Sevilla
4503066	Auxiliary Power Unit			49-20-00	AEG Bilbao
4503066	Auxiliary Power Unit			49-20-00	AEG Bilbao
4503090	Engine Control Harness Assembly			49-10-08	AEG Bilbao
4503140	Fuel Pump Assembly			49-32-07	AEG Sevilla
4503215	Auxiliary Power Unit			49-20-00	AEG Bilbao
4503215	Auxiliary Power Unit			49-20-00	AEG Bilbao
4503236	Engine Control Harness Assembly			49-10-25	AEG Bilbao
4504616	FCU	TRIUMPH ACCESSORY RESERVE		49-10-25	AEG Bilbao
4524582	SERVO FUEL INJECTOR MODEL RSA-10ED1		LYCOMING ENGINES		AEG Sevilla
4581008	Lavatory Floor Assy			53-10-04	AEG Sevilla
4581013	Lavatory Door Assy			52-50-01	AEG Sevilla
4582006	FORWARD LAVATORY SECTION ASSEMBLY			53-10-02	AEG Sevilla
4582006	Lavatory Forward Section Assy			53-10-02	AEG Sevilla
4582007	Lavatory Side And Upper Structure Assy			53-10-03	AEG Sevilla
4582008	Lavatory Floor Assy			53-10-04	AEG Sevilla
4582046	Lavatory Fluorescent Light Lens Assy			33-20-01	AEG Sevilla
4583006	FORWARD LAVATORY SECTION ASSEMBLY			53-10-02	AEG Sevilla
4584008	Lavatory Floor Assy			53-10-04	AEG Sevilla
4635001	Cockpit Door Assy			52-51-10	AEG Sevilla
4950029	STARTER MOTOR	SUNDSTRAND	T-621-T-701, T621-T6C1, 46C2, 46C2A, 46C2, 46C3A, 46C7, 46C7A, 46C14	49	AEG Sevilla
4950029	Starter Motor			49-41-03	AEG Sevilla
4950136	MOTOR-STARTER	HAMILTON	A321A319,APS500,A320,CFM56- E,F,CSM6A,6B	49-41-07	AEG Sevilla
4950703	MOTOR-STARTER	OLYZO	A320	49	AEG Sevilla
4951799	STARTER MOTOR	SUNDSTRAND	T-621-T-701, T621-T6C1, 46C2, 46C2A, 46C2, 46C3A, 46C7, 46C7A, 46C14	49	AEG Sevilla
4951957	APU STARTER	AUXILIARY POWER INTL	B707, B777, B737, B737	49-41-05	AEG Sevilla
4952164	MOTOR-STARTER	SUNDSTRAND	A321A319,APS500,A320, CFM56,CSM6A,6B,CSM6A,6B	49-41-07	AEG Sevilla
5003588	MAIN WHEEL ASSEMBLY	ABS	F 27	32-40-57	AEG Sevilla
5004236	BRAKE ASSEMBLY	ABS	A330, A340	32-43-47	AEG Sevilla
5006473	BRAKE ASSY		UNK		AEG Sevilla
5006484	BRAKE ASSEMBLY	ABS	C-212	32-43-47	AEG Sevilla
5006586	MAIN WHEEL ASSEMBLY	MEGGITT	A330, A340	72-37-07	AEG Sevilla
501637	SLEEVE-AXLE/MLG	AIRCRAFT BRAKING SYSTEMS	A321	32	AEG Sevilla
501641	Main Wheel			32-42-14	AEG Sevilla
5060809	HOUSING ASSEMBLY	PLESSEY AEROSPACE		UNK	AEG Sevilla
5906732	AC GENERATOR	HAMILTON ELECTRICAL	A330,A321A319,A320	24-23-51	AEG Bilbao
5909006	AC GENERATOR	HONEYWEL	A321A319,A320	24-00-00	AEG Bilbao
5910047	AC GENERATOR	HONEYWEL	A319, A321, B777, A320	24-23-51	AEG Bilbao
5910139	APU GENERATOR	HAMILTON ELECTRICAL	A340,A330	24-23-53	AEG Bilbao
5911360	Drive Shaft Assembly			27-52-02	AEG Sevilla
5911560	Drive Shaft Assembly			27-52-02	AEG Sevilla
5911605	Inboard & Outboard Flap Skew Sensors			27-52-14	AEG Sevilla
5912505	Electrical Motor			27-52-15	AEG Sevilla
5912560	Inboard & Outboard Flap Skew Sensors			27-52-14	AEG Sevilla
5912576	Drive Shaft Assembly			27-52-02	AEG Sevilla
5912577	Drive Shaft Assembly			27-52-02	AEG Sevilla
5912578	Drive Shaft Assembly			27-52-02	AEG Sevilla
5912833	APU GENERATOR	HAMILTON ELECTRICAL	T621-T700,A320,A340,CFM56-58,CFM56- 60	24-00-00	AEG Bilbao
5913107	Inboard & Outboard Flap Skew Sensors			27-52-14	AEG Sevilla
9391701	Fwd FIA Panel			33-23-01	AEG Sevilla
9513011	Baggage Bulkhead Door Assembly			53-10-09	AEG Sevilla
9521001	Cockpit Door Assembly			52-50-03	AEG Sevilla
9521001	Cockpit Door Assembly			52-50-03	AEG Sevilla
9523001	Fortified Cockpit Door			52-51-14	AEG Sevilla
9524001	Fortified Cockpit Door			52-51-15	AEG Sevilla
9524101	Fortified Cockpit Door(WIRAS)			52-51-17	AEG Sevilla
9535416	PLATE BACKING BRAKE	MEGGITT AIRCRAFT BRAKING SYSTEMS		UNK	AEG Sevilla
9541105	FLT Compl Panel Assemblies				AEG Sevilla
9541107	FLT Compl Panel Assemblies				AEG Sevilla
9541109	FLT Compl Panel Assemblies				AEG Sevilla
9543476	NOSE WHEEL ASSEMBLY	ABS	A330, A340	32	AEG Sevilla
9550339	TRANSDUCER ASSEMBLY	AIRCRAFT BRAKING SYSTEMS	B757	32-48-04	AEG Sevilla
9811505	3/8 In NON RETURN VALVE	FLY REFUELLING LTD	C-295	28-22-02	AEG Sevilla
1001830	Emergency MLG Selector Valve			32-35-11	AEG Sevilla
20101420	AUTOBRAKE ASSEMBLY VALVE MODULE	TEXTRON	B737,B757,B767	32-40-04	AEG Sevilla
20900110	CONTROL UNIT-INTE		UNK		AEG Sevilla
21804100	Element				AEG Sevilla
23420600	Element				AEG Sevilla
26101782	Fire Detectors				AEG Sevilla
26212000	Element				AEG Sevilla
81204433	S SHAFT		UNK		AEG Bilbao
81204471	STATOR ASSEMBLY, MAIN EXCITER	LUCAS	A330, A340	24-23-51	AEG Bilbao
81204654	ROTOR ASSEMBLY MAIN EXCITER	TRW	A320	24-23-51	AEG Bilbao
81205185	PE HOUSING AND STATOR ASSEMBLY	LUCAS	A330, A340		AEG Bilbao
81205182	ROTOR AND SHAFT ASSEMBLY, MACHINED	LUCAS	A320	24-23-51	AEG Bilbao
81205691	STATOR ASSEMBLY, WOUND, ME	LUCAS	A330, A340	24	AEG Bilbao
81205820	HOUSING AND STATOR ASSEMBLY	LUCAS		5/8 BAR5601F-24- 4	AEG Bilbao
81205821	STATOR ASSEMBLY, WOUND MAIN	TECHNOFAN	A320	24-23-51	AEG Bilbao
81205961	ROTOR ASSEMBLY, FINISHED	LUCAS	A320	24-23-51	AEG Bilbao
81207093	STATOR AND HOUSING ASSEMBLY, PE	LUCAS	A330, A340	24	AEG Bilbao
81207174	MACHINED ROTOR & SHAFT ASSEMBLY	GOODRICH	A330, A340		AEG Bilbao
81207213	ROTOR ASSEMBLY, FINISHED ME	LUCAS	A330, A340	24-23-53	AEG Bilbao
81207321	ROTOR ASSY	LUCAS	A320	24-23-51	AEG Bilbao
81207327	EXCITER ROTOR	LUCAS	A320	24-23-51	AEG Bilbao
81207367	ROTOR ASSEMBLY, FINISHED	LUCAS	A320	24-23-51	AEG Bilbao
81207408	FINISHED ROTOR ASSEMBLY	LUCAS	A330	24-23-53	AEG Bilbao
81207412	HOUSING AND STATOR ASSEMBLY	LUCAS	A330, A340		AEG Bilbao
81207425	ROTOR ASSEMBLY, FINISHED	LUCAS	A320	24-23-51	AEG Bilbao
81207426	ROTOR AND SHAFT ASSEMBLY, MACHINED	LUCAS	A320	24-23-51	AEG Bilbao
81207444	HOUSING AND STATOR ASSEMBLY	LUCAS	A330, A340		AEG Bilbao
81207461	MACHINED ROTOR & SHAFT ASSEMBLY	GOODRICH	A330, A340		AEG Bilbao
81207474	ROTOR ASSEMBLY, FINISHED	LUCAS	A330	REWIND	AEG Bilbao
81207485	STATOR ASSEMBLY, MAIN WOUND	LUCAS	A330, A340		AEG Bilbao

81207491	MAIN FRAME, STATOR ASSEMBLY	GOODRICH	A330, A340		24-23-53	AEG Bilbao
81207504	NAMEPLATE		UNK			AEG Sevilla
81207540	STATOR ASSEMBLY, MAIN WOUND	GOODRICH	A330, A340		24-23-53	AEG Bilbao
81207562	ROTOR ASSEMBLY, FINISHED ME	GOODRICH	A330, A340		24-23-53	AEG Bilbao
81207563	ROTOR ASSEMBLY, FINISHED	GOODRICH	A330, A340		24-23-53	AEG Bilbao
81207563	ROTOR ASSEMBLY, FINISHED	LUCAS	A330, A340			AEG Bilbao
81207571	ROTOR ASSEMBLY, FINISHED	GOODRICH	A330, A340		24-23-53	AEG Bilbao
81207587	MAIN WOUND STATOR ASSEMBLY	LUCAS	A330, A340			AEG Bilbao
81207597	APU GEN ROTOR	LUCAS	A320, A319, A321		24-23-51	AEG Bilbao
81207613	ROTOR AND SHAFT ASSEMBLY, MACHINED	SAFRAN POWER	A330, A340		24-20-72	AEG Bilbao
81207659	EXCITER ROTOR	SAFRAN (GOODRICH)	A330, A340		24-23-51	AEG Bilbao
81207660	ROTOR ASSEMBLY, FINISHED	GOODRICH	A320		REWIND	AEG Bilbao
81207673	AMENDMENT PLATE	LUCAS UK	UNK			AEG Sevilla
81207690	STATOR ASSEMBLY, MAIN WOUND	GOODRICH	A330, A340			AEG Bilbao
81207704	ROTOR ASSEMBLY, FINISHED	LUCAS	A330, A340		24-23-53	AEG Bilbao
81207706	ROTOR ASSEMBLY, FINISHED	LUCAS	A330, A340		24-23-53	AEG Bilbao
81207707	ROTOR ASSEMBLY, FINISHED ME	LUCAS	A330, A340		24-23-53	AEG Bilbao
81207736	FINISHED ROTOR ASSEMBLY	GOODRICH	A330, A340		24-20-72	AEG Bilbao
81207741	STATOR, MAIN, WOUND ASSEMBLY		UNK			AEG Bilbao
81207743	MAIN FRAME AND STATOR ASSEMBLY		UNK			AEG Bilbao
81207799	NAMEPLATE		UNK			AEG Sevilla
90005273	Anti-Skid Control Unit				32-48-56	AEG Sevilla
90005542	Main Wheel				32-41-44	AEG Sevilla
90005543	Brake				32-44-94	AEG Sevilla
90005613	Drive Cap				32-48-99	AEG Sevilla
90005644	AS Control Unit				32-48-97	AEG Sevilla
114079001	ELECTRO-HYDRAULIC SELECTOR	SMITHS	A318, A321, A319, A320		32-31-34	AEG Sevilla
114079002	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A318, A321, A319, A320		32-31-34	AEG Sevilla
114079005	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A318, A321, A319, A320		32-31-34	AEG Sevilla
114079006	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A318, A321, A319, A320		32-31-34	AEG Sevilla
114079009	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A300, A318, A321, A319, A320		32-31-34	AEG Sevilla
114079010	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A318, A321, A319, A320		32-31-34	AEG Sevilla
114079012	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A300, A318, A321, A319, A320		32-31-34	AEG Sevilla
114079013	ELECTRO-HYDRAULIC SELECTORS	GEAVIATION	A300, A318, A321, A319, A320		32-31-34	AEG Sevilla
114079014	ELECTRO-HYDRAULIC SELECTORS	GEAVIATION	A318, A321, A319, A320		32-31-34	AEG Sevilla
114079015	ELECTRO-HYDRAULIC SELECTORS	MESSIER	A318, A321, A319, A320, A320-221		32-31-34	AEG Sevilla
114079016	SELECTOR-DOOR, ELECTRO-HYDRAULIC	MESSIER	A330, A318, A321, A319, A320, A320-221, A320-222, A320-223		32-31-34	AEG Sevilla
114079017	ELECTRO-HYDRAULIC SELECTORS	MESSIER	A330, A318, A321, A319, A320, A320-223		32-31-34	AEG Sevilla
114079018	ELECTRO-HYDRAULIC SELECTORS	MESSIER	A330, A318, A321, A319, A320		32-31-34	AEG Sevilla
114079019	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A330, A318, A321, A319, A320		32-31-25	AEG Sevilla
114087001	BYPASS VALVE	SMITHS	A330, A318, A321, A319, A320		32-31-25	AEG Sevilla
114087002	BYPASS VALVE	SMITHS	A330, A310, A300, A321, A319, A318, A320		32-31-25	AEG Sevilla
114087003	BYPASS VALVE	SMITHS	A330, A310, A300, A321, A319, A318, A320		32-31-25	AEG Sevilla
114087004	BYPASS VALVE	GENERAL ELECTRIC	A330, A310, A300, A321, A319, A318, A320		32-31-25	AEG Sevilla
114087005	BYPASS VALVE	GENERAL ELECTRIC	A330, A310, A300, A321, A319, A318, A320		32-31-25	AEG Sevilla
114087006	BYPASS VALVE	GENERAL ELECTRIC	DC-10, A330, A310, A300, A321, A319, A318, A320		32-31-25	AEG Sevilla
114087007	BYPASS VALVE	GENERAL ELECTRIC	A330, A321, A319, A318, A320		32-31-25	AEG Sevilla
114087008	VALVE, BYPASS	MESSIER	A321, A319, A318, A320		32-31-25	AEG Sevilla
114087009	BYPASS VALVE	TRIUMPH ACTUATION SYSTEM	A321, A320, A319, A318		32-31-25	AEG Sevilla
114087010	BYPASS VALVE	MESSIER SERVICES	A321, A320, A319, A318		32-11-21	AEG Sevilla
114095001	MLG LOCK STAY ACTUATOR	MESSIER SERVICES	F100, A318, A321, A319, A320		32-11-21	AEG Sevilla
114095002	LOCK STAY ACTUATOR	MESSIER SERVICES	A318, A321, A319, A320		32-11-21	AEG Sevilla
114095003	LOCK STAY ACTUATOR	MESSIER SERVICES	A318, A321, A319, A320		32-11-21	AEG Sevilla
114095004	LOCK STAY ACT.	MESSIER SERVICES	A330, A318, A321, A320-221, A320-222		32-11-21	AEG Sevilla
11422002	MLG DOOR ACTUATOR	GE AVIATION	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11422003	MLG DOOR ACTUATOR	GE AVIATION	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11422004	MLG DOOR ACTUATOR	GE AVIATION	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11422006	MLG DOOR ACTUATOR	GE AVIATION SYSTEMS	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11422007	MLG DOOR ACTUATOR	GE AVIATION	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11422008	MLG DOOR ACTUATOR	GE AVIATION SYSTEMS	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11422009	MLG DOOR ACTUATOR	GE AVIATION SYSTEMS	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11422010	MLG DOOR ACTUATOR	SMITHS	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11422011	MLG DOOR ACTUATOR	GE AVIATION	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11422012	MLG DOOR ACTUATOR	GE AVIATION	A340, A330, A310, A300, A321, A320, A319, A318		32-31-35	AEG Sevilla
11493010	RETRACTION ACTUATOR	MESSIER - DOWTY	A318, A321, A319, A320		32	AEG Sevilla
11493637	RETRACTION ACTUATOR-PIN	SAFRAN	A321, A320, A319, A318, A320-221		32-31-84	AEG Sevilla
114256320	CYLINDER	SAFT	A340		24	AEG Bilbao
201042176	HOSE ASSEMBLY	K0654	A330/340			AEG Sevilla
201042177	HOSE ASSEMBLY	K0654	A330/340			AEG Sevilla
201042178	HOSE ASSEMBLY	K0654	A330			AEG Sevilla
201042180	HOSE ASSEMBLY	UNKNOWOWN	A330			AEG Sevilla
201042193	HOSE ASSEMBLY	K0654	A330			AEG Sevilla
201042194	HOSE ASSEMBLY	K0654	A330/340		32	AEG Sevilla
201042195	HOSE ASSY	K0654	A330			AEG Sevilla
201042197	HOSE ASSEMBLY	FAP92	A330/340			AEG Sevilla
201042198	HOSE ASSY	FAP92	A330/340			AEG Sevilla
201042201	HOSE ASSEMBLY	K0654	A320			AEG Sevilla
201042203	HOSE ASSY	FAP92	A330/340			AEG Sevilla
201042298	HOSE ASSEMBLY	K0654	A330			AEG Sevilla
201042322	HOSE ASSY	FAP92	A330/340			AEG Sevilla
201042569	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042570	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042575	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-86	AEG Sevilla
201042576	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-86	AEG Sevilla
201042577	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-86	AEG Sevilla
201042581	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-86	AEG Sevilla
201042587	BOGIE HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-87	AEG Sevilla
201042588	BOGIE HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-87	AEG Sevilla
201042589	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042590	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042633	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-81	AEG Sevilla
201042635	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-81	AEG Sevilla
201042636	W&B BOGIE HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-82	AEG Sevilla
201042637	W&B BOGIE HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-82	AEG Sevilla
201042640	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042641	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042642	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042643	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042644	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042645	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042646	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042647	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042648	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042649	W&B BOGIE HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-82	AEG Sevilla
201042695	W&B BOGIE HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-82	AEG Sevilla
201042725	W&B BOGIE HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-82	AEG Sevilla
201042726	BOGIE HARNESS	ULTRA ELECTRONICS SYSTEM	A330-2000-900		32-11-84	AEG Sevilla
201042727	W&B BOGIE HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-82	AEG Sevilla
201042728	W&B BOGIE HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-82	AEG Sevilla
201042731	BOGIE HARNESS	ULTRA ELECTRONICS SYSTEM	A330-2000-900		32-11-84	AEG Sevilla
201042760	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla
201042761	STRUT HARNESS	SAFRAN LANDING SYSTEM	A330-2000-900		32-11-83	AEG Sevilla

201042778	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Sevilla
201042779	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Sevilla
201042780	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Sevilla
201042781	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Sevilla
201042786	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Sevilla
201042787	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Sevilla
201042788	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Sevilla
201042789	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Sevilla
201042794	BOGIE HARNESS	ULTRA ELECTRONICS	A330-200F-300	32-11-84	AEG Sevilla
201042795	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Sevilla
201042796	BOGIE HARNESS	ULTRA ELECTRONICS	A330-200F-300	32-11-84	AEG Sevilla
201042797	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Sevilla
201042798	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Sevilla
201056909	PIN LOCK STAY CARDAN	MESSIER DOWTY	A321.A320.A320-221	32-11-21	AEG Sevilla
201057506	TRIANGULATION LINK	MESSIER	A321.A319.A318.A320	32	AEG Sevilla
201057611	UPPER PIN (SPRINGS)	MESSIER	A321.A319.A318.A320	32	AEG Sevilla
201057623	CLIFF PIN	MESSIER	A321.A319.A318.A320	32	AEG Sevilla
201057625	LOWER PIN (SPRINGS)	MESSIER	A321.A319.A318.A320	32	AEG Sevilla
201057627	LOCK LINK LOWER PIN	MESSIER DOWTY	A321.A319.A318.A320.A320-221	32-11-39	AEG Sevilla
201057634	CLIFF	MESSIER	A321.A319.A318.A320	32	AEG Sevilla
201057644	PIN (LOCK LINK/BANANA LINK)	MESSIER	A321.A319.A318.A320	32	AEG Sevilla
201059001	LOCK SPRING	MESSIER DOWTY	B757.A321.A319.A318.A320-221.A320	32-11-19	AEG Sevilla
20134007	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20134008	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20134015	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32.32-11-45.32-11-	AEG Sevilla
20134016	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32.32-11-45.32-11-	AEG Sevilla
20158001	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20158002	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20158003	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20158004	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20158007	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20158008	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32.32-11-45.32-11-	AEG Sevilla
20159001	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20159002	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20159003	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20159004	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20159007	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20159008	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32.32-11-45.32-11-	AEG Sevilla
20160331	MAIN FITTING (LH)	SAFRAN	A320		AEG Sevilla
20160332	MAIN FITTING (RH)	SAFRAN	A320		AEG Sevilla
20161001	DRESSING-MLG	MESSIER DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161002	DRESSING-MLG	MESSIER DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161003	DRESSING-MLG	MESSIER DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161004	DRESSING-MLG	MESSIER DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161005	LH MLG DRESSINGS	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161006	RH MLG DRESSING	MESSIER-DOWTY	A320	32-11-32	AEG Sevilla
20161007	DRESSING-MLG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161008	DRESSING-MLG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161009	LH MLG DRESSING	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161010	RH MLG DRESSINGS	MESSIER-DOWTY	A320	32-11-32	AEG Sevilla
20161011	DRESSING-MLG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161012	DRESSING-MLG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161013	DRESSING-MLG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161014	DRESSING-MLG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161015	DRESSING-MLG	MESSIER DOWTY	A321.A319.A318.A320	32-11-24	AEG Sevilla
20161016	DRESSING-MLG	MESSIER DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20161616	BRACKET LH	MESSIER	A321.A320.A319.A318		AEG Sevilla
20163001	BASIC SIDE STAY	MESSIER DOWTY	A321.A319.A318.A320	32	AEG Sevilla
20163002	BASIC SIDE STAY	MESSIER DOWTY	A321.A319.A318.A320	32	AEG Sevilla
20163003	BASIC SIDE STAY	MESSIER DOWTY	A321.A319.A318.A320	32	AEG Sevilla
20163004	BASIC SIDE STAY	MESSIER DOWTY	A321.A319.A318.A320-221.A320	32	AEG Sevilla
20163309	CUFF	MESSIER	A321.A320.A319.A318		AEG Sevilla
20163605	UPPER CARDAN	MESSIER	A321.A320.A319.A318		AEG Sevilla
20163609	SIDE STAY PIVOT PIN	MESSIER DOWTY	A321.A319.A318.A320.A320-221	32-11-38	AEG Sevilla
20163948	UPPER CARDAN	K0654	A320		AEG Sevilla
20163949	UPPER CARDAN	K0654	A320		AEG Sevilla
20168007	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32.32-11-45.32-11-	AEG Sevilla
20168008	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20168014	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20168015	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20168018	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20168019	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20168020	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20168021	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20168022	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321.A319.A318.A320	32-11-43	AEG Sevilla
20172712	CABLE BONDING	MESSIER-DOWTY	A321.A319.A318.A320	32	AEG Sevilla
201269499	TORQUE LINK APEX PIN NUT	SAFRAN	A330	32-12-02	AEG Sevilla
201727001	BOFE ASSEMBLY	SAFRAN	A330	32-11-74	AEG Sevilla
201727003	BOGIE ASSEMBLY	#N/D	A330		AEG Sevilla
201727004	BOGIE ASSEMBLY	#N/D	A330		AEG Sevilla
201727248	BOGIE BEAM AND AXLE SUBASSEMBL	SAFRAN	A330	32-11-74	AEG Sevilla
201727595	LOCK BOLT, FWD PINTLE PIN	K0654	A330	32-12-02	AEG Sevilla
20137001	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20137002	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20137003	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20137004	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20137005	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20137006	RH MAIN LANDING GEAR	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
20137008	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
201574001	MAIN LANDING GEAR	MESSIER	A320	32	AEG Sevilla
201574002	MAIN LANDING GEAR	MESSIER	A320	32	AEG Sevilla
201575001	MAIN LANDING GEAR	MESSIER	A321.A319.A318.A320	32-11-32	AEG Sevilla
201575002	MAIN LANDING GEAR	MESSIER	A321.A319.A318.A320	32-11-32	AEG Sevilla
201575003	MAIN LANDING GEAR	MESSIER	A321.A320.A319.A318	32-11-32	AEG Sevilla
201575004	MAIN LANDING GEAR	MESSIER	A321.A319.A318.A320	32-11-32	AEG Sevilla
201575005	MAIN LANDING GEAR	MESSIER	A321.A319.A318.A320	32-11-32	AEG Sevilla
201575006	MAIN LANDING GEAR	MESSIER	A321.A319.A318.A320	32-11-32	AEG Sevilla
201575007	MAIN LANDING GEAR	MESSIER DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
201575008	R/H MAIN LDG	MESSIER DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
201575009	MAIN LANDING GEAR ASSY	MESSIER DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
201575010	MLG RH	MESSIER DOWTY	A321.A319.A318.A320	32-11-32	AEG Sevilla
201575052	R/H MLG LEG ASSY	K0654	A320		AEG Sevilla
201576001	MAIN LANDING GEAR	MESSIER DOWTY	A319.A318.A320	32	AEG Sevilla
201576002	MAIN LANDING GEAR	MESSIER-DOWTY	A319.A318.A320	32-11-32	AEG Sevilla
20183001	MAIN LANDING GEAR LEG	MESSIER	A321	32-11-83	AEG Sevilla
20183002	MAIN LANDING GEAR LEG	MESSIER	A321	32-11-83	AEG Sevilla
20183304	Cardan bracket (LH)	SAFRAN	A320		AEG Sevilla
20183305	Cardan Bracket (RH)	SAFRAN	A320		AEG Sevilla
20183604	Upper torque link pin	MESSIER	A321.A320.A319.A318	32	AEG Sevilla
20183605	LOWER TORQUE LINK PIN	MESSIER	A321.A320.A319.A318	32	AEG Sevilla
20183628	FORWARD PINTLE PIN LOCK BOLT	MESSIER	A321.A320.A319.A318		AEG Sevilla
20187001	MLG LEG AND DRESSINGS	AIRBUS	A321	32	AEG Sevilla
20187002	MLG LEG AND DRESSINGS	AIRBUS	A321	32	AEG Sevilla
20188001	MAIN LANDING GEAR INST L	UNKNKOOWN	A321	32-11-81	AEG Sevilla
20188002	R/H MAIN LANDING GEAR INTLL	UNKNKOOWN	A321	32-11-81	AEG Sevilla
20189001	SIDE STAY BASIC	UNKNKOOWN	A320	32-11-86	AEG Sevilla
20190001	SIDE STAY COMPLETE	MESSIER	A321	32	AEG Sevilla
20190002	SIDE STAY COMPLETE	MESSIER-DOWTY	A321	32-11-85	AEG Sevilla
20199001	LEG HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-88	AEG Sevilla

201399002	LEG HARNESS	MESSIER-BUGATTI II-DOWTY	A320,A321	32-11-88	AEG Sevilla
201399003	LEG HARNESS	MESSIER-BUGATTI II-DOWTY	A320	32-11-88	AEG Sevilla
201399004	LEG HARNESS	MESSIER-BUGATTI II-DOWTY	A320	32-11-82	AEG Sevilla
201399005	HARNESS 1M AND 2M	ULTRA ELECTRONICS	A319,A318,A320	32	AEG Sevilla
201399006	HARNESS 1M AND 2M	SAFRAN	A320	32-12-11	AEG Sevilla
201400001	LEG HARNESS	MESSIER-BUGATTI II-DOWTY	A320	32-11-82	AEG Sevilla
201400002	LEG HARNESS	MESSIER-BUGATTI II-DOWTY	A320	32-11-82	AEG Sevilla
201400003	HARNESS 1M AND 2M	ULTRA ELECTRONICS	A319,A318,A320	32-11-45	AEG Sevilla
201400004	HARNESS 1M AND 2M	ULTRA ELECTRONICS	A319,A318,A320	32-11-45	AEG Sevilla
201402001	AXLE HARNESS	MESSIER-BUGATTI II-DOWTY	A320	32-11-11	AEG Sevilla
201402002	AXLE HARNESS	MESSIER-BUGATTI II-DOWTY	A320	32-11-11	AEG Sevilla
201402201	2M AXLES ENHANCED HARNESS	MESSIER DOWTY	A321,A319,A318,A320	32	AEG Sevilla
201402202	AXLE HARNESS 1M AND 2M	SAFRAN	A320	32	AEG Sevilla
201402203	AXLE HARNESS	MESSIER-BUGATTI II-DOWTY	A320	32-11-89	AEG Sevilla
201402204	AXLE HARNESS	MESSIER-BUGATTI II-DOWTY	A320	32-11-89	AEG Sevilla
201402205	MAIN LDG & AXLE HARNESS	ULTRA ELECTRONICS	A320	32-11-44	AEG Sevilla
201402206	MAIN LDG & AXLE HARNESS	ULTRA ELECTRONICS	A320	32-11-44	AEG Sevilla
201402207	AXLE HARNESS 1M AND 2M	SAFRAN	A320	32	AEG Sevilla
201403300	LOWER LOCK LINK	MESSIER	A321,A320,A319,A318		AEG Sevilla
201419001	DAMPER	MESSIER SERVICES	B737,A318,A321,A319,A320,B747	32-11-93	AEG Sevilla
201441002	UPPER SPRING BRACKET	K0654	A330	32-11-91	AEG Sevilla
201441004	LOWER SPRING BRACKET	SAFRAN	A330	32-11-91	AEG Sevilla
201441010	WASHER	FAP92	A330		AEG Sevilla
201442606	CONNECTING LINK	SAFRAN	A330	32-11-92	AEG Sevilla
201442609	PIVOT LINK	SAFRAN	A330	32-11-92	AEG Sevilla
201442613	LOWER SPRING/PIVOT LINK PIN	SAFRAN	A330	32-11-92	AEG Sevilla
201442615	CONNECTING LINK/PIVOT LINK PIN	SAFRAN	A330	32-11-92	AEG Sevilla
201442633	CONNECTING LINK/LOCK LINK UPPER	SAFRAN	A330	32-11-92	AEG Sevilla
201442651	PIVOT LINK CENTER PIN	SAFRAN	A330	32-11-90	AEG Sevilla
201480002	BOGIE PITCH TRIMMER	#N/D	A330		AEG Sevilla
201481001	UNLOCK ACTUATOR	MESSIER-DOWTY LANDING GEAR	A340,A330	32	AEG Sevilla
201482001	LOCK LINK	MESSIER-DOWTY	A330	32-12-08	AEG Sevilla
201482305	LOWER LOCK LINK	SAFRAN	A330	32-12-08	AEG Sevilla
201482609	LOCK LINK/SIDE STAY PIN	MESSIER-DOWTY	A330	32-12-06	AEG Sevilla
201483001	SIDE STAY	MESSIER-DOWTY	A330	32-12-07	AEG Sevilla
201483214	BRACKET ASSEMBLY	SAFRAN	A330	32-12-07	AEG Sevilla
201484001	SIDE STAY LH	HONEYWELL	A330	32-12-06	AEG Sevilla
201484002	SIDE STAY RH	NONE SPECIFIED	A330	32-12-06	AEG Sevilla
201484606	BRACKET SINGLE TARGET	SAFRAN	A330	32-12-06	AEG Sevilla
201485001	BOGIE ASSEMBLY	#N/D	A330		AEG Sevilla
201487001	SHOCK STRUT	MESSIER-DOWTY	A330	32-12-03	AEG Sevilla
201487214	PISTON ASSY	SAFRAN	A330	32-12-03	AEG Sevilla
201487216	PISTON SLIDING	SAFRAN	A330	32-12-03	AEG Sevilla
201487219	PISTON SLIDING	SAFRAN	A330	32-12-03	AEG Sevilla
201487300	SLIDING PISTON	MESSIER	A330	32-11-96	AEG Sevilla
201487307	SLIDING PISTON	MESSIER	A330	32-11-96	AEG Sevilla
201487309	PISTON SLIDING	MESSIER	A330	32-11-96	AEG Sevilla
201488002	RH MAIN STRUT	SAFRAN	A330		AEG Sevilla
201488204	LINK SUBASSEMBLY, LOWER	MESSIER-DOWTY	A330	32-12-02	AEG Sevilla
201488337	MAIN FITTING (LH)	SAFRAN	A330	32-12-02	AEG Sevilla
201488650	PIN S/M	MESSIER-DOWTY	A330	32-12-02	AEG Sevilla
201488651	PIN S/M	MESSIER-DOWTY	A330	32-12-02	AEG Sevilla
201489242	SLEEVE SUBASSEMBLY LUBRICATION	K0654	A330	32-12-02	AEG Sevilla
201489304	LOWER TORQUE LINK	SAFRAN	A330	32-12-02	AEG Sevilla
201489780	ROLLER, UPLOCK	K0654	A330	32-11-71	AEG Sevilla
201520001	MAIN LDG & AZLE HARNESS	MESSIER SERVICES	A318,A320	32-11-44	AEG Sevilla
201520002	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A319,A318,A320	32,32-11-12,32-11-11	AEG Sevilla
201520003	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A318,A320	32,32-11-12,32-11-11	AEG Sevilla
201520004	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A319,A318,A320	32,32-11-12,32-11-11	AEG Sevilla
201520005	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A330,A319,A320	32,32-11-12,32-11-11	AEG Sevilla
201520006	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A330,A319,A320	32,32-11-12,32-11-11	AEG Sevilla
201520007	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A330,A319,A320	32,32-11-12,32-11-11	AEG Sevilla
201520008	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A330,A319,A320	32,32-11-12,32-11-11	AEG Sevilla
201521001	MAIN LANDING GEAR COMPLETE	UNKNOWOWN	A318	32	AEG Sevilla
201521002	MAIN LANDING GEAR COMPLETE	UNKNOWOWN	A318	32	AEG Sevilla
201521003	MAIN LANDING GEAR COMPLETE	SAFRAN	A321	32	AEG Sevilla
201521004	MAIN LANDING GEAR COMPLETE	SAFRAN	A321	32	AEG Sevilla
201522001	MAIN LANDING GEAR LEG	SAFRAN	A321,A320	32	AEG Sevilla
201522002	MAIN LANDING GEAR LEG	SAFRAN	A321,A320	32	AEG Sevilla
201522003	MAIN LANDING GEAR LEG	SAFRAN	A321,A320	32	AEG Sevilla
201522004	MAIN LANDING GEAR LEG	SAFRAN	A321,A320	32	AEG Sevilla
201522300	MAIN FITTING (LH)	K0654	A320		AEG Sevilla
201522301	MAIN FITTING (RH)	K0654	A320		AEG Sevilla
201522302	UPPER TORQUE LINK	K0654	A320		AEG Sevilla
201522303	LOWER TORQUE LINK	K0654	A320		AEG Sevilla
201522360	MAIN FITTING (RH)	K0654	A320		AEG Sevilla
201522600	FORWARD PINTLE PIN	MESSIER	A321,A320,A319,A318	32-12-22	AEG Sevilla
201523001	MLG LEG AND DRESSINGS	AIRBUS	A320,A321	29	AEG Sevilla
201523002	RH MLG	AIRBUS	A320,A321	32	AEG Sevilla
201523003	MAIN LANDING GEAR LEG AND DRES	AIRBUS	A320,A321	32	AEG Sevilla
201523004	MAIN LANDING GEAR LEG AND DRES	AIRBUS	A320,A321	32	AEG Sevilla
201524001	STAY ASSY-SIDE-MLG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Sevilla
201524002	STAY ASSY-SIDE-MLG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Sevilla
201525001	STAY-SIDE	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Sevilla
201525300	UPPER SIDE STAY	MESSIER	A321,A320,A319,A318		AEG Sevilla
201525301	LOWER SIDE STAY	MESSIER	A321,A320,A319,A318		AEG Sevilla
201525302	LOWER CARDAN	MESSIER	A321,A320,A319,A318	32-12-14	AEG Sevilla
201531001	STAY-LOCK	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Sevilla
201531600	UPPER LOCK LINK	MESSIER	A321,A320,A319,A318		AEG Sevilla
201582003	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A319,A318,A320	32	AEG Sevilla
201582004	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A319,A318,A320	32	AEG Sevilla
201582006	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A319,A318,A320	32	AEG Sevilla
201582007	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A320,A319,A318	32-12-24	AEG Sevilla
201582008	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A320,A319,A318	32-12-24	AEG Sevilla
201584001	LH MLG GEAR COMPLETE	MESSIER DOWTY	A321	32-12-20	AEG Sevilla
201584002	RH MLG GEAR COMPLETE	MESSIER DOWTY	A321	32-12-20	AEG Sevilla
201587001	MAIN LANDING GEAR LEG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Sevilla
201587002	MAIN LANDING GEAR LEG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Sevilla
201587003	MAIN LANDING GEAR LEG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Sevilla
201587004	MAIN LANDING GEAR LEG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Sevilla
201587303	UPPER TORQUE LINK	MESSIER	A321,A320,A319,A318		AEG Sevilla
201587304	LOWER TORQUE LINK	MESSIER	A321,A320,A319,A318		AEG Sevilla
201587602	FORWARD PINTLE PIN STUB BOLT	MESSIER	A321,A320,A319,A318	32-12-22	AEG Sevilla
201587608	FORWARD PINTLE PIN STUB BOLT	MESSIER	A321,A320,A319,A318	32	AEG Sevilla
201587610	FORWARD PINTLE PIN STUB BOLT	MESSIER	A321,A320,A319,A318	32	AEG Sevilla
201587611	FORWARD PINTLE PIN STUB BOLT	MESSIER	A321,A320,A319,A318	32	AEG Sevilla
201590001	RETRACTION ACTUATOR	MESSIER SERVICES	A330,A321,A320,A319,A318	32-31-86	AEG Sevilla
201590002	RETRACTION ACTUATOR	MESSIER SERVICES	L-1011,A321,A320,A319,A318	32-31-86	AEG Sevilla
201590003	RETRACTION ACTUATOR	MESSIER SERVICES	A330,B767,B757,A321,A320,A319,A318	32-31-86	AEG Sevilla
201590004	RETRACTION ACTUATOR	MESSIER DOWTY	A321,A319,A318,A320	32-31-86	AEG Sevilla
201590906	CYLINDER	MESSIER - DOWTY	A321,A320,A319,A318	32-31-86	AEG Sevilla
201590909	PISTON	MESSIER	A321,A319,A318,A320-221,A320	32-31-86	AEG Sevilla
201590910	NUT	MESSIER	A321,A319,A318,A320-221,A320	32-31-86	AEG Sevilla
201590913	GLAND	MESSIER	A321,A319,A318,A320-221,A320	32-31-86	AEG Sevilla
201655166	BOGIE HARNESS	ULTRA ELECTRONICS	A330-200F-300	32-11-84	AEG Sevilla
201655176	BOGIE HARNESS	ULTRA ELECTRONICS	A330-200F-300	32-11-84	AEG Sevilla
201659001	MAIN LANDING GEAR	MESSIER DOWTY	A321	32-12-20	AEG Sevilla
201659002	MAIN LANDING GEAR	MESSIER DOWTY	A321	32-12-20	AEG Sevilla
201659003	MAIN LANDING GEAR COMPLETE	SAFRAN	A321		AEG Sevilla

201659004	MAIN LANDING GEAR COMPLETE	SAFRAN	A321		AEG Sevilla
201660001	SIDE STAY COMPLETE	MESSIER DOWTY	A321A320,A319,A318	32	AEG Sevilla
201660001	STAY -SIDE	MESSIER DOWTY	A321A320,A319,A318	32	AEG Sevilla
201661300	UPPER SIDE STAY	MESSIER	A321A320,A319,A318		AEG Sevilla
201661301	LOWER SIDE STAY	MESSIER	A321A320,A319,A318	32	AEG Sevilla
201661302	CUFF	MESSIER	A321A320,A319,A318		AEG Sevilla
201661304	BANANA LINK	MESSIER	A321A320,A319,A318		AEG Sevilla
201661601	SIDE STAY PIVOT PIN	MESSIER	A321A320,A319,A318		AEG Sevilla
201661602	CUFF	MESSIER	A321A320,A319,A318		AEG Sevilla
201661603	SIDE STAY LOWER CARDAN PIN	MESSIER	A321A320,A319,A318		AEG Sevilla
201661610	UPPER CARDAN NUT	MESSIER	A321A320,A319,A318		AEG Sevilla
201661611	LOWER CARDAN NUT	MESSIER	A321A320,A319,A318		AEG Sevilla
201661613	CUFF	MESSIER	A321A320,A319,A318		AEG Sevilla
201676210	ROLLER SUBASSEMBLY UPLock	K0654	A330	32-11-71	AEG Sevilla
400070000	Manual Selector Landing Gear Valve			32-30-01	AEG Sevilla
400090000	Manual Bypass Valve			32-30-02	AEG Sevilla
699008003	Festhering Pump			61-21-24	AEG Sevilla
750004000	Manual Bypass & Runaround Valve			32-30-03	AEG Sevilla
750005000	MLG Selector Valve			32-30-05	AEG Sevilla
750006000	NLG Selector Valve			32-30-04	AEG Sevilla
860185002	Accumulator				AEG Sevilla
860188002	Accumulator, 75 Cubic Inch			32-41-04	AEG Sevilla
860188004	Accumulator, 75 Cubic Inch			32-41-04	AEG Sevilla
860190003	Accumulator				AEG Sevilla
860197001	Accumulator			32-40-10	AEG Sevilla
860199001	Accumulator				AEG Sevilla
860204001	Accumulator			32-40-09	AEG Sevilla
860206001	Accumulator				AEG Sevilla
860207001	Accumulator				AEG Sevilla
860218001	Accumulator				AEG Sevilla
860219001	Accumulator				AEG Sevilla
870100000	REP Y CALIBRACION EQ MEDIDA		UNK		AEG Sevilla
2,98035E+12	Lavatory Water Faucet			38-11-04	AEG Sevilla
2,98036E+12	Lavatory Water Faucet			38-11-04	AEG Sevilla
2,98038E+12	Lavatory Water Faucet			38-11-04	AEG Sevilla
3.6E+85	STARTER	ALLIED SIGNAL	C-130		AEG Sevilla
2.8E+100	Oil Cooler-Heat Exchanger Assembly			79-20-11	AEG Sevilla
0059-0008-3	Nipple Check Valve			80-00-04	AEG Sevilla
0071-0007-3	Fitting Nipple Assembly			38-11-01	AEG Sevilla
015839-02	Water Level And Monitoring System			38-18-03	AEG Sevilla
01584B-2	Fan Inlet Temperature Transmitter (T2)		CF34-8C,CF34-8E	74-32-00	AEG Sevilla
015700-000	Ni-Cd Aircraft Battery 1656	SAFT	ATR 72,ATR 42	24	AEG Sevilla
015838-01	Water Level And Monitoring System			38-18-03	AEG Sevilla
015839-01	Water Level And Monitoring System			38-18-03	AEG Sevilla
015840-01	Water Level And Monitoring System			38-18-03	AEG Sevilla
015840-02	Water Level And Monitoring System			38-18-03	AEG Sevilla
017444-000	Ni-Cd Aircraft Battery 16156	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
018090-000	Ni-Cd Aircraft Battery 16156-1	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
018718-000	Ni-Cd Aircraft Battery 4078	SAFT	ATR 72,ATR 42	24	AEG Sevilla
018804-000	Ni-Cd Aircraft Battery 2376-4	SAFT	A320	24	AEG Sevilla
018962-000	Ni-Cd Aircraft Battery 23576-1	SAFT	A300	24	AEG Sevilla
019500-000	Ni-Cd Aircraft Battery 4076-12	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
019513-000	Ni-Cd Aircraft Battery 4071-2	SAFT	A320	24	AEG Sevilla
019615-000	Ni-Cd Aircraft Battery 401076	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
019654-000	Ni-Cd Aircraft Battery 40253	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
020413-000	Ni-Cd Aircraft Battery 12277-2	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
020678-000	Ni-Cd Aircraft Battery 4078-6	SAFT	A320	24	AEG Sevilla
0218-0032-Ihrought-	4-Inch Waste System Drain Valve			38-37-10	AEG Sevilla
021937-000	Ni-Cd Aircraft Battery 4078-9	SAFT	A320	24	AEG Sevilla
022019-000	Ni-Cd Aircraft Battery 4078-10	SAFT	Embraer,A320	24	AEG Sevilla
023167-000	Ni-Cd Aircraft Battery 4078-14	SAFT	A320,B737	24	AEG Sevilla
023322-000	Ni-Cd Aircraft Battery 4076-13	SAFT	A320	24	AEG Sevilla
023470-000	Ni-Cd Aircraft Battery 1756	SAFT	Bell		AEG Sevilla
023476-000	Ni-Cd Aircraft Battery M8157/9- 2	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
023498-000	Ni-Cd Aircraft Battery 23676-2	SAFT	A320	24	AEG Sevilla
023525-000	Ni-Cd Aircraft Battery 23576-2	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
023663-000	Ni-Cd Aircraft Battery 40576-14	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
023694-000	Ni-Cd Aircraft Battery 4078-19	SAFT	B737	24	AEG Sevilla
023773-000	Ni-Cd Aircraft Battery 2386-1	SAFT	A320,MD-90	24	AEG Sevilla
023789-000	Ni-Cd Aircraft Battery 4017CH-1	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
023828-000	Ni-Cd Aircraft Battery 2376-10	SAFT	Sukorsky A320	24-31-07	AEG Sevilla
024227-000	Ni-Cd Aircraft Battery 4015CH11	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
024470-000	Ni-Cd Aircraft Battery 27578-2	SAFT	A320	24	AEG Sevilla
024555-000	Ni-Cd Aircraft Battery 4076-15	SAFT	Bell,A320		AEG Sevilla
024904-000	Ni-Cd Aircraft Battery 4417CH14	SAFT	B737	24	AEG Sevilla
024947-000	Ni-Cd Aircraft Battery 407CH9	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
025554-000	Ni-Cd Aircraft Battery 552CH1	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
025776-000	Ni-Cd Aircraft Battery 437CH14	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
025897-000	Ni-Cd Aircraft Battery 176CH	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
025899-000	Ni-Cd Aircraft Battery 438CH2	SAFT	VARIOUS AIRCRAFTS	24	AEG Sevilla
025930-000	Ni-Cd Aircraft Battery 437CH1		VARIOUS AIRCRAFTS		AEG Sevilla
026101-11	DRIVE SHAFT	NONE SPECIFIED			AEG Sevilla
02-6101-11	DRIVE SHAFT	FLIGHT INDUSTRIES		33	AEG Sevilla
03-6101-13	DRIVE SHAFT	FLIGHT INDUSTRIES		33-49-20	AEG Sevilla
04-1505-1429	STROBE LIGHT PS	BRUCE INDUSTRIES	ATR 42,ATR 72		AEG Sevilla
0514RJB1	Relay Junction Box			24-50-01	AEG Sevilla
0555-11	DC GEAR MOTOR				AEG Bilbao
0618910G	ADAPTER BELL OUTPUT BAL ASSY				AEG Bilbao
0623006D	ADAPTER BELL OUTPUT BAL ASSY				AEG Bilbao
064-01054-30	VHF COMMUNICATIONS TRANSCIVERS	WULFSBERG		23	AEG Sevilla
064-1015-01	KTR 953 Receiver / Exciter			23-20-08	AEG Sevilla
064-1016-X	KCU 951 Control Unit			23-20-04	AEG Sevilla
064-1017-X	KAC 952 POWER Amplifier / Antenna Coupler			23-20-07	AEG Sevilla
064-1047-61	RECEIVER, TRANSMITTER	TRONAIR			AEG Sevilla
06-8010-6500	ENGINE OIL SERVICE UNIT		CN-235		AEG Sevilla
066-01066 SERIES	KLM 706 A DISTANCES MEASURING EQUIPMENT.	KING		34	AEG Sevilla
066-01067-0000	RADAR RECEIVER				AEG Sevilla
066-03063	K1227 ADF INDICATOR				AEG Sevilla
066-03063-SERIES	K1227 ADF INDICATOR	KING RADIO		KMA24H	AEG Sevilla
066-1093 SERIES	KLM 706 A DISTANCES MEASURING EQUIPMENT.	KING		34,N/A	AEG Sevilla
066-3059-00	INDICATOR ADF	KING			AEG Sevilla
069-1024	VHF NAV/COMM TRANSCIVER				AEG Sevilla
069-1025	VHF NAV/COMM TRANSCIVER				AEG Sevilla
0711480-001	VALVE, SHUTOFF HYDRAULIC	ARKWIN INDUSTRIES	A340,A320	78	AEG Sevilla
0711480-003	VALVE, SHUTOFF HYDRAULIC	ARKWIN INDUSTRIES INC.	A340,A320	78	AEG Sevilla
0711480-004	VALVE, SHUTOFF HYDRAULIC		A340,A320		AEG Sevilla
080-2070-01	Windshield Heat Controller			30-40-03	AEG Sevilla
08-60162	Cubic Inch Accumulator			32-40-11	AEG Sevilla
0860163001002	Accumulator				AEG Sevilla
0860164001002	Accumulator- Hydraulic System #3				AEG Sevilla
0871H5	Ice Detector		CRJ-700,CRJ900 Regional Jet-900	30-80-01	AEG Sevilla
09-1146-53	TM-400 Trim Servo Assembly				AEG Sevilla
100-0211-01	Battery Charger 100-0211-01		600-2B/W,Challenger 601C,Challenger 601C,CRJ (Regional Jet, 300-310) (Regional), 600-2B/W,CRJ-700,CRJ-900 Regional Jet-900 (CRJ, CRJ900) (Regional Jet, 300-310)	24-35-02	AEG Sevilla
100-0211-02	Battery Charger			24-32-06	AEG Sevilla
10-0055	EMERGENCY EXIT LIGHT	GRIMES / HONEYWELL			AEG Sevilla
10-0055 SERIES	EMERGENCY EXIT LIGHT	GRIMES		33-50-28	AEG Sevilla
10-0055-1	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230,Dash 8	33-50-28	AEG Sevilla
10-0055-11	LIGHT, EMERGENCY	GRIMES	C-295,CN-235,Dash 8	33-50-28	AEG Sevilla
10-0055-13	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Sevilla

10-0055-15	EMERGENCY EXIT LIGHT	GRIMES	DHC8.CN-235.C-295.230	33-50-28	AEG Sevilla
10-0055-17	EMERGENCY EXIT LIGHT	GRIMES	DHC8.CN-235.C-295.230	33-50-28	AEG Sevilla
10-0055-19	EMERGENCY EXIT LIGHT	GRIMES	DHC8.CN-235.C-295.230	33-50-28	AEG Sevilla
10-0055-21	EMERGENCY EXIT LIGHT	GRIMES	DHC8.CN-235.C-295.230	33-50-28	AEG Sevilla
10-0055-23	EMERGENCY EXIT LIGHT	GRIMES	DHC8.CN-235.C-295.230	33-50-28	AEG Sevilla
10-0055-25	EMERGENCY EXIT LIGHT	GRIMES	DHC8.CN-235.C-295.230	33-50-28	AEG Sevilla
10-0055-3	LIGHT, EMERGENCY	GRIMES	DHC8.CN-235.C-295.230	33-50-28	AEG Sevilla
10-0055-5	EMERGENCY EXIT LIGHT	GRIMES	DHC8.CN-235.C-295.230	33-50-28	AEG Sevilla
10-0055-7	EMERGENCY EXIT LIGHT	GRIMES	DHC8.CN-235.C-295.230	33-50-28	AEG Sevilla
10-0055-9	EMERGENCY EXIT LIGHT	SAFT	DHC8.CN-235.C-295.230	24	AEG Sevilla
1-002-0102-1652	SERIES LIGHT DIMMER	SIMMONDS	B777/B747/B737	28	AEG Sevilla
10-0341	Closest Light			33-30-05	AEG Sevilla
10-0341-1	Closest Light		B757/B747/B777/B767	33-30-05	AEG Sevilla
10-0341-13	Closest Light		B747/B777/B767/B757	33-30-05	AEG Sevilla
10-0341-15	Closest Light		B757/B767/B747/B777	33-30-05	AEG Sevilla
10-0341-3	Closest Light		B747/B747/B777/B757	33-30-05	AEG Sevilla
10-0341-5	Closest Light		B747/B767/B757/B777	33-30-05	AEG Sevilla
10-0341-7	Closest Light		B767/B757/B747	33-30-05	AEG Sevilla
10-0561-11	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-12	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-13	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-14	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-15	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-16	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-17	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-18	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-19	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-TA38	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-20	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-21	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-3	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-4	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-5	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-6	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-7	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-8	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0561-9	Baggage Door Warning Sign			33-29-26	AEG Sevilla
10-0688	Floodlight			33-23-04	AEG Sevilla
10-0688-1	Floodlight			33-23-04	AEG Sevilla
10-0688-11	Floodlight			33-23-04	AEG Sevilla
10-0688-13	Floodlight			33-23-04	AEG Sevilla
10-0688-15	Floodlight			33-23-04	AEG Sevilla
10-0688-17	Floodlight			33-23-04	AEG Sevilla
10-0688-19	Floodlight			33-23-04	AEG Sevilla
10-0688-21	Floodlight			33-23-04	AEG Sevilla
10-0688-23	Floodlight			33-23-04	AEG Sevilla
10-0688-27	Floodlight			33-23-04	AEG Sevilla
10-0688-29	Floodlight			33-23-04	AEG Sevilla
10-0688-3	Floodlight			33-23-04	AEG Sevilla
10-0688-5	Floodlight			33-23-04	AEG Sevilla
10-0688-7	Floodlight			33-23-04	AEG Sevilla
10-0688-9	Floodlight			33-23-04	AEG Sevilla
10079-01	LOAD SELECT CONTROL UNIT		B767-300,B757-200,B767/B757/B747-400		AEG Sevilla
101-000-137	RECEIVER, RADIO	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-014	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-015	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-023	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-024	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-025	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-026	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-027	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-028	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-029	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-030	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-031	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-032	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-033	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-034	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-035	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-036	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-037	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-038	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-039	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-040	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-041	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100101-042	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100102	NOSE LANDING GEAR	SAFRAN			AEG Sevilla
10-100102-001	NOSE LANDING GEAR (W/O)	SAFRAN			AEG Sevilla
10-100102-002	NOSE LANDING GEAR (W/O)	SAFRAN			AEG Sevilla
10-100102-003	NOSE LANDING GEAR (W/O)	SAFRAN			AEG Sevilla
10-100102-004	NOSE LANDING GEAR (W/O)	SAFRAN			AEG Sevilla
10-100102-005	NOSE LANDING GEAR (W/O)	SAFRAN			AEG Sevilla
10-100102-006	NOSE LANDING GEAR (W/O)	SAFRAN			AEG Sevilla
10-100102-007	NOSE LANDING GEAR	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-000	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-001	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-002	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-003	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-004	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-005	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-006	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-007	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-008	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-009	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-010	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-011	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-012	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-013	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-014	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-015	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-016	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-017	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-018	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-019	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-020	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-021	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-022	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-023	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-024	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-025	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
10-100103-026	GEAR-NOSE LANDING	SAFRAN LANDING SYSTEM			AEG Sevilla
101003-04-01	MECHANISM ASSY	SAFRAN	UNK		AEG Sevilla
10-101001	2M UPPER HARNESS	SAFRAN	A340	32-09-91	AEG Sevilla
10-101001-003	HARNESS, 2M UPPER	SAFRAN	A340	32-09-91	AEG Sevilla
10-101001-004	HARNESS, 2M UPPER	SAFRAN	A340	32-09-91	AEG Sevilla
10-101001-005	HARNESS, 2M UPPER	MESSIER-BUGATTI-DOMINIEZ ELECTRICAL	A340	32-09-92	AEG Sevilla
10-10101	1M LOWER ELECTRICAL HARNESS	SAFRAN	A340	32-09-92	AEG Sevilla
10-10101-000	HARNESS, 1M LOWER ELECTRICAL	GRIMES	A340	335036	AEG Sevilla
10-1014-1	INTERIOR ILLUMINATED EMERGENCY EXIT	GRIMES	UNK	335036	AEG Sevilla

10-1014-3	INTERIOR ILLUMINATED EMERGENCY EXIT	GRIMES	UNK	335036	AEG Sevilla
10-1014-5	INTERIOR ILLUMINATED EMERGENCY EXIT	GRIMES	UNK	335036	AEG Sevilla
10-1014-7	INTERIOR ILLUMINATED EMERGENCY EXIT chairs	SAFRAN	UNK		AEG Sevilla
10-101702-000	UPPER DRAG STAY	SAFRAN	A340		AEG Sevilla
10-101902	LOCK LINK	SAFRAN	A340		AEG Sevilla
10-101902-000	LOCK LINK	MESSIER-DOWTY SA	A340	32-33-41	AEG Sevilla
10-102001-001	UNLOCKING ACTUATOR	SAFRAN	A340		AEG Sevilla
10-102101-000	DOWNLOCK SPRING	SAFRAN	A340		AEG Sevilla
10-102701-002	RETRACTION ACTUATOR ASSEMBLY	SAFRAN	A340		AEG Sevilla
10-102701-003	RETRACTION ACTUATOR ASSEMBLY	SAFRAN	A340		AEG Sevilla
10-102701-004	RETRACTION ACTUATOR ASSEMBLY	MESSIER-DOWTY SA	A340	32	AEG Sevilla
10-102701-005	RETRACTION ACTUATOR ASSEMBLY	SAFRAN	A340		AEG Sevilla
10-103002	TOWING FITTING	SAFRAN	A340		AEG Sevilla
10-103002-000	TOW FITTING	SAFRAN	A340		AEG Sevilla
10-103002-001	TOW FITTING	SAFRAN	A340		AEG Sevilla
10-103301-003	HARNES, N.L.G LEFT GS ANTENNA	SAFRAN	A340		AEG Sevilla
10-103301-004	HARNES, N.L.G LEFT GS ANTENNA	SAFRAN	A340		AEG Sevilla
10-103501-003	HARNES, N.L.G RIGHT GS ANTENNA	SAFRAN	A340		AEG Sevilla
10-103501-004	HARNES, N.L.G RIGHT GS ANTENNA	SAFRAN	A340		AEG Sevilla
101-0400	Pilot's Guide (Optional)			TP101	AEG Sevilla
101-0401	Pilot's Guide (Optional)			TP101	AEG Sevilla
101-0402	Pilot's Guide (Optional)			TP101	AEG Sevilla
1010530 SERIES	CYLINDRAL HYD PRESS ACCUM	SAFRAN	UNK		AEG Sevilla
101-0600	Pilot's Guide (Optional)			TP101	AEG Sevilla
101-0601	Pilot's Guide (Optional)			TP101	AEG Sevilla
101-0603	Pilot's Guide (Optional)			TP101	AEG Sevilla
10-1081-1	Passenger Service Unit			33-20-34	AEG Sevilla
10-1081-11	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-12	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-1M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-2	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-2M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-3	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-3M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-4	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-4M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-5	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-5M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-6	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-6M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-7	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-7M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-8	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1081-8M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Sevilla
10-1096-01	Pneumatic Detector		A320		AEG Sevilla
10-1096-02	Pneumatic Detector		A320		AEG Sevilla
10-1097-01	Pneumatic Detector				AEG Sevilla
10-1097-02	Pneumatic Detector		A320		AEG Sevilla
10-1098	Pneumatic Detector				AEG Sevilla
10-1099	Pneumatic Detector		A320		AEG Sevilla
10-110105	CENTER LANDING GEAR	SAFRAN	A340		AEG Sevilla
10-110105-002	CENTER LANDING GEAR	SAFRAN	A340		AEG Sevilla
10-110105-003	CENTER LANDING GEAR	SAFRAN	A340		AEG Sevilla
10-110105-004	CENTER LANDING GEAR	SAFRAN	A340		AEG Sevilla
10-110105-005	CENTER LANDING GEAR	SAFRAN	A340		AEG Sevilla
10-110105-006	CENTER LANDING GEAR	SAFRAN	A340		AEG Sevilla
10-110105-007	CENTER LANDING GEAR	SAFRAN	A340		AEG Sevilla
10-110105-008	CENTER LANDING GEAR	SAFRAN	A340		AEG Sevilla
10-110105-009	CENTER LANDING GEAR	SAFRAN	A340		AEG Sevilla
10-110207	MAIN FITTING SHOCK ABSORBER, S	SAFRAN	A340		AEG Sevilla
10-110207-002	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Sevilla
10-110207-003	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Sevilla
10-110207-004	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Sevilla
10-110207-005	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Sevilla
10-110207-006	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Sevilla
10-110302	DRAG STAY COMPLETE	SAFRAN	A340		AEG Sevilla
10-110302-000	DRAG STAY COMPLETE	SAFRAN	A340		AEG Sevilla
10-110501-006	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-007	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-014	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-015	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-016	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-017	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-018	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-019	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-020	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-021	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110501-022	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110502-000	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110502-001	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110502-002	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110502-003	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110502-004	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110502-005	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110503	MAIN FITTING SHOCK ABSORBER ST	SAFRAN	A340		AEG Sevilla
10-110504	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110504-001	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110504-002	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Sevilla
10-110504-003	MAIN FITTING SHOCK ABS STRUCTU	SAFRAN	A340		AEG Sevilla
10-110504-004	MAIN FITTING SHOCK ABS STRUCTU	SAFRAN	A340		AEG Sevilla
10-110504-103	MAIN FITTING SHOCK ABS STRUCTU	SAFRAN	A340		AEG Sevilla
10-110504-104	MAIN FITTING SHOCK ABS STRUCTU	SAFRAN	A340		AEG Sevilla
10-110507	MAIN FITTING SHOCK ABSORBER ST	SAFRAN	A340		AEG Sevilla
10-110605	MAIN FITTING SHOCK ABSORBER DR	SAFRAN	A340		AEG Sevilla
10-110605-001	MAIN FITTING SHOCK ABS DRESSIN	SAFRAN	A340		AEG Sevilla
10-110605-002	MAIN FITTING SHOCK ABS DRESSIN	SAFRAN	A340		AEG Sevilla
10-110803	BOGIE BEAM DRESSING	SAFRAN	A340		AEG Sevilla
10-110803-000	BOGIE BEAM DRESSING	SAFRAN	A340		AEG Sevilla
10-110803-001	BOGIE BEAM DRESSING	SAFRAN	A340		AEG Sevilla
10-111102	LOCK LINK	SAFRAN	A340		AEG Sevilla
10-111102-000	LOCK LINK	SAFRAN	A340		AEG Sevilla
10-111201-000	LOCK SPRING	SAFRAN	A340		AEG Sevilla
10-111301-002	ACTUATOR-UNLOCK.CLG	MESSIER-DOWTY SA	A340	32	AEG Sevilla
10-111301-003	UNLOCK ACTUATOR	GRIMES AEROSPACE	A340	32-00	AEG Sevilla
10-111301-004	UNLOCK ACTUATOR	SAFRAN	A340		AEG Sevilla
10-111402	DRAG STAY DRESSING	SAFRAN	A340		AEG Sevilla
10-111402-000	DRAG STAY DRESSING	SAFRAN	A340		AEG Sevilla
10-111702	1M STRUT HARNESS	MESSIER-DOWTY SA	A340	32-09-93	AEG Sevilla
10-111702-000	1M STRUT HARNESS	MESSIER-DOWTY SA	A340	32-09-93	AEG Sevilla
10-111702-001	1M STRUT HARNESS	SAFRAN	A340		AEG Sevilla
10-111703	1M STRUT HARNESS	MESSIER-DOWTY SA	A340	32-09-93	AEG Sevilla
10-111703-000	1M STRUT HARNESS	SAFRAN	A340		AEG Sevilla
10-111704	1M STRUT HARNESS	MESSIER-DOWTY SA	A340	32-09-93	AEG Sevilla
10-111704-000	1M STRUT HARNESS	MESSIER-BEGAT (I DOWTY EX AMP S.A.)	A340	32-09-94	AEG Sevilla
10-111801	2M STRUT HARNESS	MESSIER-DOWTY SA	A340	32-09-94	AEG Sevilla
10-111801-002	2M STRUT HARNESS	MESSIER-DOWTY SA	A340	32-09-94	AEG Sevilla
10-111801-003	2M STRUT HARNESS	SAFRAN	A340		AEG Sevilla
10-111802	2M STRUT HARNESS	MESSIER-DOWTY SA	A340	32-09-94	AEG Sevilla
10-111802-000	2M STRUT HARNESS	SAFRAN	A340		AEG Sevilla

10-124204-002	1M STRUT HARNESS (RH)	SAFRAN	A340		AEG Sevilla
10-124204-003	1M STRUT HARNESS (RH)	SAFRAN	A340		AEG Sevilla
10-124302	2M LEFT HAND ELECTRICAL HARNESS	SAFRAN	A340		AEG Sevilla
10-124302-001	2M STRUT HARNESS (LH)	SAFRAN	A340		AEG Sevilla
10-124302-002	2M STRUT HARNESS (LH)	SAFRAN	A340		AEG Sevilla
10-124303	2M LEFT HAND ELECTRICAL HARNESS	SAFRAN	A340		AEG Sevilla
10-124303-000	2M STRUT HARNESS (LH)	SAFRAN	A340		AEG Sevilla
10-124303-001	2M STRUT HARNESS (LH)	SAFRAN	A340		AEG Sevilla
10-124403	2M RIGHT HAND ELECTRICAL HARNESS	SAFRAN	A340		AEG Sevilla
10-124403-001	2M STRUT HARNESS (RH)	SAFRAN	A340		AEG Sevilla
10-124403-002	2M STRUT HARNESS (RH)	SAFRAN	A340		AEG Sevilla
10-124404	2M RIGHT HAND ELECTRICAL HARNESS	SAFRAN	A340		AEG Sevilla
10-124404-000	2M STRUT HARNESS (RH)	SAFRAN	A340		AEG Sevilla
10-124404-001	2M STRUT HARNESS (RH)	SAFRAN	A340		AEG Sevilla
10-124405	2M RIGHT HAND ELECTRICAL HARNESS	SAFRAN	A340		AEG Sevilla
10-124405-000	2M STRUT HARNESS (RH)	MESSIER SERVICES	A340	32-12-41	AEG Sevilla
10-124501-000	1M BOGIE HARNESS	MESSIER SERVICES	A340	32-12-41	AEG Sevilla
10-124501-001	1M BOGIE HARNESS	MESSIER SERVICES	A340	32-12-41	AEG Sevilla
10-124501-002	1M BOGIE HARNESS	MESSIER SERVICES	A340	32-12-41	AEG Sevilla
10-124502-000	1M BOGIE HARNESS	SAFRAN	A340		AEG Sevilla
10-124701	2M ELECTRICAL HARNESS	SAFRAN	A340		AEG Sevilla
10-124701-001	2M BOGIE HARNESS	SAFRAN	A340		AEG Sevilla
10-124701-002	2M BOGIE HARNESS	SAFRAN	A340		AEG Sevilla
10-124701-003	2M BOGIE HARNESS	SAFRAN	A340		AEG Sevilla
10-124702	2M ELECTRICAL HARNESS	SAFRAN	A340		AEG Sevilla
10-124702-000	2M BOGIE HARNESS	HONEYWELL	A340	33-20-51	AEG Sevilla
10-1327-9	FLUORESCENT WINDOW LIGHT	GOODRICH	B737-300,B737-400,B737-500,B737-800,B737-900,B737-900,B737-900	32-46-27	AEG Sevilla
10-133X	Interior Illuminated Window And Exit Sign	GOODRICH	B737-300,B737-400,B737-500,B737-800,B737-900,B737-900	33-20-52	AEG Sevilla
101-380096-1	MAIN LANDING GEAR BRAKE ASSEMBLY	HONEYWELL	KN-235	33-21-39,33,32,21-39	AEG Sevilla
10-1418-1	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-69	AEG Sevilla
10-1418-11	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-69	AEG Sevilla
10-1418-12	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-69	AEG Sevilla
10-1418-2	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-69	AEG Sevilla
10167N01000	Torque Indicator		DHC8,Dash 8,(DHC)Dash 8-100	77-10-36	AEG Bilbao
10167N02000	Torque Indicator		DHC8,Dash 8,(DHC)Dash 8-100	77-10-36	AEG Bilbao
10169N01000	Prop RPM Indicator		DHC8,Dash 8,(DHC)Dash 8-100	77-12-06	AEG Bilbao
10170N01000	NH3 RPM Indicator		DHC8,Dash 8,(DHC)Dash 8-100	77-12-07	AEG Bilbao
10-1733-1	FLUORESCENT WINDOW LIGHT	HONEYWELL	B737-300,B737-400,B737-500,B737-800,B737-900	33-21-39	AEG Sevilla
10-1733-2	FLUORESCENT WINDOW LIGHT	HONEYWELL	B737-300,B737-400,B737-500,B737-800,B737-900	33-21-39	AEG Sevilla
10-1733-3	FLUORESCENT WINDOW LIGHT	MESSIER-DOWTY	B737-300,B737-400,B737-500,B737-800,B737-900	33-21-39	AEG Sevilla
10-1733-4	FLUORESCENT WINDOW LIGHT	MESSIER-DOWTY	B737-300,B737-400,B737-500,B737-800,B737-900	32-12-62	AEG Sevilla
10175N01000	Interlurbine Temperature Indicator		Dash 8,DC-8	77-20-28	AEG Bilbao
10176N01000	NL% RPM Indicator		Dash 8,DC-8	77-12-08	AEG Bilbao
10177N01000	NH3% RPM Indicator		DHC8,Dash 8,(DHC)Dash 8-100	77-12-07	AEG Bilbao
10178N01001	Stato/flex Air temperature Indicator		Dash 8	77-20-27	AEG Bilbao
10178N02010	Stato/flex Air temperature Indicator		Dash 8	77-20-27	AEG Bilbao
10-204-6-T-2	VHF Glideslope Blade Antennas				AEG Sevilla
10-208-15-B-2	VHF Navigation (Marker) Blade Antennas				AEG Sevilla
102-1090	Standby Control Panel		Jetstream 31,Jetstream 41		AEG Sevilla
10-210901-001	SHOCK STRUT ASSEMBLY	MESSIER-DOWTY	A340	32-12-62	AEG Sevilla
10-210901-002	SHOCK STRUT ASSEMBLY	MESSIER-DOWTY	A330	32-12-62	AEG Sevilla
10-210901-003	SHOCK STRUT ASSEMBLY	SAFRAN	A330		AEG Sevilla
10-210901-004	SHOCK STRUT ASSEMBLY	MESSIER	A330	32-31-90	AEG Sevilla
10-211001-001	ACTUATOR, MLG RETRACTION	MESSIER-DOWTY	A330	32-12-63	AEG Sevilla
10-211501-001	BOGIE AND DRESSINGS, MLG	SAFRAN LANDING	A330	32-12-63	AEG Sevilla
10-211501-002	BOGIE AND DRESSINGS, MLG	SAFRAN	A330		AEG Sevilla
10-211501-004	BOGIE AND DRESSINGS, MLG	SAFRAN LANDING	A330	32-12-64	AEG Sevilla
10-211701-000	BOGIE ASSEMBLY	SAFRAN LANDING	A330-300	32-12-64	AEG Sevilla
10-211701-001	BOGIE ASSEMBLY	SAFRAN LANDING	A330	32-12-64	AEG Sevilla
10-211701-002	BOGIE ASSEMBLY	SAFRAN LANDING	A330	32-12-64	AEG Sevilla
10-211701-003	BOGIE ASSEMBLY	SAFRAN	A330	32-12-64	AEG Sevilla
10-211701-004	BOGIE ASSEMBLY	MESSIER-DOWTY	A330	32-12-66	AEG Sevilla
10-212101-000	SIDE STAY BASIC	MESSIER-DOWTY	A330	32-12-66	AEG Sevilla
10-212101-001	SIDE STAY BASIC	MESSIER-DOWTY	A330	32-31-88	AEG Sevilla
10-212102-000	TRIMMER, MLG BOGIE PITCH	SAFRAN	A330		AEG Sevilla
10-212901	1M STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-12-68	AEG Sevilla
10-212901-000	1M STRUT HARNESS	SAFT	A330	24	AEG Sevilla
10-213001 SERIES	1M STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-12-68	AEG Sevilla
10-213501	1M & 2M BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-70	AEG Sevilla
10-213701 SERIES	1M & 2M BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-70	AEG Sevilla
10-250-9-B-2	VHF Navigation Blade Antennas				AEG Sevilla
103068-14	Cabin Air Pressure Outflow/Safety Valve		DHC8	21-31-74	AEG Sevilla
103-1090	Standby Control Panel		Jetstream 31,Jetstream 41		AEG Sevilla
103-1290	Standby Control Panel		Jetstream 31,Jetstream 41		AEG Sevilla
103472-1	Valve, Outflow/Safety			21-31-72	AEG Sevilla
103472-2	Valve, Outflow/Safety			21-31-72	AEG Sevilla
10-375401-000	2M UPPER ELECTRICAL HARNESS (EV)	SAFRAN LANDING	A318/A319/A320F	32-27-75 (EV)	AEG Sevilla
10-375501-000	1M UPPER ELECTRICAL HARNESS (EV)	SAFRAN LANDING	A318/A319/A320F	32-27-83 (EV)	AEG Sevilla
10-376301-000	1M UPPER ELECTRICAL HARNESS (non. 1700.1700.1700)	SAFRAN LANDING	A318/A319/A320F	32-27-82 (EV)	AEG Sevilla
10-377001-000	LOWER ELECTRICAL HARNESS (EV)	SAFRAN LANDING	A318/A319/A320F	32-27-84 (EV)	AEG Sevilla
10500-100series	Main Landing Gear Retraction Actuator			32-30-01	AEG Sevilla
10500-500series	Main Landing Gear Retraction Actuator			32-30-10	AEG Sevilla
10500-550series	Main Landing Gear Retraction Actuator			32-30-11	AEG Sevilla
1065-82-02Z-A	V/UHF ANTENNA	TEXTRON	UNK	32-40-0	AEG Sevilla
10-60556-10	PUMP MOTOR PACKAGE	PARKER	B727,B747,B737	29-20-15	AEG Sevilla
10-60556-12	PUMP MOTOR PACKAGE	PARKER	B747-400,B727,B747,B737	29-20-15	AEG Sevilla
10-60556-15	PUMP MOTOR PACKAGE	PARKER	B747-400,B727,B747,B737	29-20-15	AEG Sevilla
10-60556-16	PUMP MOTOR PACKAGE	PARKER	B747-400,B727,B747,B737	29-20-15	AEG Sevilla
10-60556-17	PUMP MOTOR PACKAGE	PARKER	B747-400,B727,B747,B737	29-20-15	AEG Sevilla
10-60556-18	PUMP MOTOR PACKAGE	PARKER HANNIFIN	B747-400,B727,B747,B737	29-20-15	AEG Sevilla
10-60556-19	PUMP MOTOR PACKAGE	THE BOEING	UNK	29-20-15	AEG Sevilla
10-60556-20	PUMP MOTOR PACKAGE	THE BOEING	B747-400,B727,B747,B737	29-20-15	AEG Sevilla
10-60556-30	PUMP MOTOR PACKAGE	PARKER	B727,B747,B737	29-20-15	AEG Sevilla
10-60556-6	PUMP MOTOR PACKAGE	PNEUDRAULICS	B737-100,B727,B747,B737	32-30-02	AEG Sevilla
10-60599-1	HYDRAULIC PRIORITY RELIEF CART	SARGENT	B737,B737-600,B737-500,B737-400,B707	32-30-01	AEG Sevilla
10-6123-1	LANDING GEAR SELECTOR VALVE ASSEMBLY	BOEING	B737	30-40-14	AEG Sevilla
10-61292-4	HYDRAULIC MOTORPUMP ASSEMBLY	EATON	B737	29-11-26	AEG Sevilla
10-61292-5	HYDRAULIC MOTORPUMP ASSEMBLY	EATON	B737	29-11-26	AEG Sevilla
10-61329-31	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH 1000 PSI MOTOR	BOEING	B747,B737	30-40-14	AEG Sevilla
10-61329-32	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH 1000 PSI MOTOR	BOEING	B747,B737	30-40-14	AEG Sevilla
10-61329-37	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH 1000 PSI MOTOR	BOEING	B747,B737	30-40-14	AEG Sevilla
10-61329-38	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH 1000 PSI MOTOR	BOEING	B747,B737	30-40-14	AEG Sevilla
10-61329-39	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH 1000 PSI MOTOR	BOEING	B747,B737	30-40-14	AEG Sevilla
10-61329-40	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH 1000 PSI MOTOR	GOODRICH	B747,B737	30-40-14	AEG Sevilla
10-61329-41	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH 1000 PSI MOTOR	BOEING	B747,B737	30-40-14	AEG Sevilla
10-61329-42	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH 1000 PSI MOTOR	BOEING	B747,B737	30-40-14	AEG Sevilla
10-61833-7	WINDOW HEAT CONTROL UNIT	THE BOEING	B737	32-40-18	AEG Sevilla
10-62204-17	ANTISKID VOLUMETRIC FUSE ASSEMBLY	SAWYER INDUSTRIES	BOEING 777-200	27	AEG Sevilla
106785B100	Motor Assembly		B707,B727,B737,B747,B767,B777,DC-9,MD-80,4800	28-20-10	AEG Sevilla
106788A182	Actuator			28-20-09	AEG Sevilla
106788A210	Actuator		B747,Dash 8,C-130,DHC8	28-20-07	AEG Sevilla
107-120	ARMATURE	COLLINS / HUGHES	UNK	23-33-46	AEG Sevilla
1-09731-00-01	Enclosure			49-11-00	AEG Sevilla
1-09731-01-00	Enclosure Assy			49-11-01	AEG Sevilla
1-09731-01-01	Enclosure Assy			49-11-02	AEG Sevilla
1-09731-02-00	Door Assy		CRJ Regional Jet-200	49-11-03	AEG Sevilla
1-09731-02-01	Panel		CRJ Regional Jet-200	49-11-04	AEG Sevilla
103480-121	SEAT ELECTRONICS BOX	ROCKWELL COLLINS	B767	23-33-48	AEG Sevilla

1103860-120-02	SEAT ELECTRONIC BOX	BENDIX	UNK		AEG Sevilla
1108-11	Pilot / Co-Pilot Seat				AEG Sevilla
1108-17	Pilot / Co-Pilot Seat				AEG Sevilla
1108-19	Pilot / Co-Pilot Seat				AEG Sevilla
1108-21	Pilot / Co-Pilot Seat				AEG Sevilla
1108-23	Pilot / Co-Pilot Seat				AEG Sevilla
1108-25	Pilot / Co-Pilot Seat				AEG Sevilla
1108-27	Pilot / Co-Pilot Seat				AEG Sevilla
1108-5	Pilot / Co-Pilot Seat				AEG Sevilla
1108-7	Pilot / Co-Pilot Seat				AEG Sevilla
1108-9	Pilot / Co-Pilot Seat				AEG Sevilla
1110-5AD	Pilot And Co-Pilot Seat				AEG Sevilla
1110-5AG	Pilot And Co-Pilot Seat				AEG Sevilla
1110-7AD	Pilot And Co-Pilot Seat				AEG Sevilla
1110-7AG	Pilot And Co-Pilot Seat				AEG Sevilla
11139-2	50 Cubic Inch Hydraulic Accumulator Assembly				AEG Sevilla
11140-2	100 Cubic Inch Hydraulic Accumulator Assembly				AEG Sevilla
1121S1	Hydraulic Flow Regulator Valve				AEG Sevilla
1140-0110-SERIES	ROCKWELL-COLLINS	SMITHS	767	32-31-34	AEG Sevilla
1140-0122	Fuel Stick			28-40-07	AEG Sevilla
114095004-010	ACTUATOR-LOCK STAY	SAFT AMERICA PATTERSON	A330.A321.A319.A318.A320.A320-200		AEG Sevilla
1151336-1	Wing Anti-Ice Temperature Controller				AEG Sevilla
1152090-6Series1	Left AC Contactor Box Galley Opt 2			24-23-03	AEG Sevilla
1152092-3Series1	AC generator Control Unit (Auxilec)			24-23-02	AEG Sevilla
1152092-4Series1	AC generator Control Unit (Auxilec)			24-23-02	AEG Sevilla
1152110-2Series1	40 Amp Hour Battery			24-34-01	AEG Sevilla
1152124-6	Right AC Contactor Box Galley Opt 2 Series 1			24-24-04	AEG Sevilla
1152130-4Series1	Left AC Contactor Box (No Galley Option)			24-24-06	AEG Sevilla
1152148-4Series1	Right AC Contactor Box (No Galley Option)			24-24-07	AEG Sevilla
1152230-3Series1Series2	DC Contactor Box			24-24-10	AEG Sevilla
1152230-4Series1Series2	DC Contactor Box			24-24-10	AEG Sevilla
1152346-1Series1	400 AMP DC Current Shunt			24-24-17	AEG Sevilla
1152424-1Series1	200 AMP DC Current Shunt			24-24-18	AEG Sevilla
1153-1	ELECTRIC MOTOR	SAFT	FALCON 20	24	AEG Bilbao
11-5833-1	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-11	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-13	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-15	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-17	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-19	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-21	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-23	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-25	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-3	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-5	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-7	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11-5833-9	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Sevilla
11545260-1	FUSE PIN - TRUNNION SUPP - FWD	SAFT	B737-800,B737-700,B737-600,B737	24	AEG Sevilla
11-6537-1	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	GRIMES	B737-300,B737-200,B737-400,B737-600,B737-700,B737-800,B737-900,B737-1000	33-21-42	AEG Sevilla
11-6537-3	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	HONEYWELL	B737-300,B737-200,B737-400,B737-600,B737-700,B737-800,B737-900,B737-1000	33-21-42	AEG Sevilla
11-6537-5	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	HONEYWELL	B737-300,B737-200,B737-400,B737-600,B737-700,B737-800,B737-900,B737-1000	33-21-42	AEG Sevilla
11-6537-7	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	HONEYWELL	B737-300,B737-200,B737-400,B737-600,B737-700,B737-800,B737-900,B737-1000	33-21-42	AEG Sevilla
11-6537-9	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	SAFT	B737-300,B737-200,B737-400,B737-600,B737-700,B737-800,B737-900,B737-1000	24	AEG Sevilla
117PE1Y00	RETRACTABLE LANDING LIGHT	AVTECH	A318, A319, A320, A321	23	AEG Sevilla
1200008-000MODA	5 Channel Selcal Decoder			23-20-24	AEG Sevilla
1200008-000thruD03	CSD-714 Selcal			23-21-01	AEG Sevilla
1200008-00X	CSD-714 Selcal			23-20-04	AEG Sevilla
121210-3	SCREW	SUNDSTRAND	DC-10,CF6-50,B727,A300	28	AEG Sevilla
122-4508	FIELD ASSEMBLY	SUNDSTRAND	UNK	28	AEG Sevilla
122-6607	ARMATURE		UNK		AEG Bilbao
122723-SERIES	FUEL BOOST PUMP	HONEYWELL	UNK	49	AEG Sevilla
123690-2-1	One And One-Half Inch Diameter Check Valve			21-20-27	AEG Sevilla
124536-SERIES	FUEL CONTROL UNIT	MROG01	UNK	31-09-02,24,31	AEG Sevilla
125076-13	HEADSET ELECTRICAL	AVTECH	UNK	29-20-25,29	AEG Sevilla
1251-1	MOTOR	PARKER	A300,SAAB 340	29-20-25,29	AEG Sevilla
1251-2	MOTOR	SIERRA NETWORKS	A300		AEG Sevilla
126842-2-1	Diffuser Vane Actuator		CRJ Regional Jet-200,CRJ Regional Jet-190,B737	49-60-59	AEG Sevilla
1272-2700	INDICATOR, HEIGHT		UNK		AEG Sevilla
12D1006	Valve, Drain,Water System Lavatory			38-21-01	AEG Sevilla
12D1006	Valve, Drain,Water System Galley		A320	38-11-19	AEG Sevilla
130009AG	Electric Motor Operated Actuator		EMB-190		AEG Sevilla
130009G	Electric Motor Operated Actuator Assembly		B777,CRJ-700		AEG Sevilla
130522-1	Control		(DHC)Dash 8-100,(DHC)Dash 8-100,(DHC)Dash 8-100,(DHC)Dash 8-100	21-31-68	AEG Sevilla
130522-2	Control		(DHC)Dash 8-100,(DHC)Dash 8-100,(DHC)Dash 8-100,(DHC)Dash 8-100	21-31-68	AEG Sevilla
131410-1	Pump		(DHC)Dash 8-100,(DHC)Dash 8-100,(DHC)Dash 8-100,(DHC)Dash 8-100	21-31-76	AEG Sevilla
1316200-3	BRAKE METERING VALVE	GE	B737,B767	77-12-23	AEG Sevilla
131858B	Extension A/B Com Boards			27-61-27	AEG Sevilla
1321-536250	Level Control Valve				AEG Sevilla
1338-1450	PRESSURE TRANSDUCER	UNK	A320 NEO	21-50-10	AEG Sevilla
1386112-4	STATOR	LEAR SIEGLER	UNK		AEG Bilbao
140-057	Wheel Speed Anti Skid System			32-42-77	AEG Sevilla
140-057-1	Wheel Speed Anti Skid System			32-42-77	AEG Sevilla
140-057-2	Wheel Speed Anti Skid System			32-42-77	AEG Sevilla
1440200-1	SPRING-STRTUT ASSY/MG UP/LOCK	MONOGRAM SYSTEMS	A330	38-31-13	AEG Sevilla
14300-010	MOTOR PUMP FILTER ASSEMBLY	MONOGRAM SYSTEMS	A320		AEG Sevilla
14300-041	FUSING AND STATUT ASSY WITH CONNECTOR LEADS	MONOGRAM SYSTEMS	UNK	38-31-13	AEG Sevilla
14300-084	MOTOR PUMP FILTER ASSEMBLY	MONOGRAM SYSTEMS	A320	38-31-13	AEG Sevilla
14300-092	MOTOR PUMP FILTER ASSEMBLY	MONOGRAM SYSTEMS	A320	38-31-13	AEG Sevilla
14300-136	MOTOR PUMP FILTER ASSEMBLY	MONOGRAM SYSTEMS	UNK	38-31-13	AEG Sevilla
14300-137	MOTOR PUMP FILTER ASSEMBLY	MONOGRAM SYSTEMS	A320,A300,MD-80-83	38-34-17	AEG Sevilla
14330-350	VACUUM GENERATOR ASSEMBLY	MONOGRAM SYSTEMS	B727,B747,401,ERJ-175,ERJ-170,A320,A320,A319,A318,A320,300	38-34-29	AEG Sevilla
14350-007	Toilet Assembly		CRJ Regional Jet-200	38-35-04	AEG Sevilla
14350-008	Toilet Assembly		CRJ Regional Jet-200	38-35-04	AEG Sevilla
14350-011	Toilet Assembly		CRJ Regional Jet-200	38-35-04	AEG Sevilla
14403-003A	LIQUID LEVEL TRANSMITTER	MONOGRAM SYSTEMS	B767,A321,A320,A319,A318	38-34-11	AEG Sevilla
14403-003B	LIQUID LEVEL TRANSMITTER	MONOGRAM SYSTEMS	B767,A321,A320,A319,A318	38-34-11	AEG Sevilla
14403-003C	LIQUID LEVEL TRANSMITTER	MONOGRAM SYSTEMS	B767,A320-232,A321,A320,A319,A318	38-34-11	AEG Sevilla
14403-085	LIQUID LEVEL SENSOR	MONOGRAM SYSTEMS	B767,A320-232,A321,A320,A319,A318	38-34-29	AEG Sevilla
14403-125	Liquid level sensor		A321A320,A319,A318,B767		AEG Sevilla
14-40605-09	PISTON LANDING GEAR STRUT	BOEING	UNK	33-21-07	AEG Sevilla
14783A2	OIL TEMP	GRIMES	UNK	33-12-33	AEG Sevilla
15-0003-10	Instrument Floodlight			33-10-77	AEG Sevilla
15-0003-11	Instrument Floodlight			33-10-77	AEG Sevilla
15-0003-2	Instrument Floodlight			33-10-77	AEG Sevilla
15-0003-3	Instrument Floodlight			33-10-77	AEG Sevilla
15-0003-5	Instrument Floodlight			33-10-77	AEG Sevilla
15-0003-6	Instrument Floodlight			33-10-77	AEG Sevilla
15-0003-7	Instrument Floodlight			33-10-77	AEG Sevilla
15-0003-8	Instrument Floodlight			33-10-77	AEG Sevilla
15-0007-1	COCKPIT UTILITY LIGHT	GRIMES	A300, B777, DC-9, MD-90	33-12-33	AEG Sevilla
15-0007-101	COCKPIT UTILITY LIGHT	GRIMES	B777, DC-9, MD-90	33-12-33	AEG Sevilla
15-0007-103	COCKPIT UTILITY LIGHT	GRIMES	A300, B777, DC-9, MD-90	33-12-33	AEG Sevilla
15-0007-105	COCKPIT UTILITY LIGHT	GRIMES	A300, B777, DC-9, MD-90	33-12-33	AEG Sevilla
15-0007-107	COCKPIT UTILITY LIGHT	GRIMES	A300, B777, DC-9, MD-90	33-12-33	AEG Sevilla
15-0007-109	COCKPIT UTILITY LIGHT	GRIMES	A300, B777, DC-9, MD-90	33-12-33	AEG Sevilla
15-0007-111	COCKPIT UTILITY LIGHT	GRIMES	A300, B777, DC-9, MD-90	33-12-33	AEG Sevilla
15-0007-113	COCKPIT UTILITY LIGHT	GRIMES	A300, B777, DC-9, MD-90	33-12-33	AEG Sevilla
15-0007-115	COCKPIT UTILITY LIGHT	GRIMES	A300, B777, DC-9, MD-90	33-12-33	AEG Sevilla

1566000-1	Spoiler Actuator Assembly			Dash 8	27-61-03	AEG Sevilla
1570421-02	Servovalve Spoiler				27-64-00	AEG Sevilla
15809889-1	STATOR		HONEYWELL	UNK		AEG Bilbao
1581594-1	STATOR		HONEYWELL	UNK		AEG Bilbao
1582363-1	STATOR		HONEYWELL	UNK		AEG Bilbao
1583816-2	ROTOR		BENDIX	UNK	24	AEG Bilbao
15840-1	AIR/OIL COOLER			C-212		AEG Sevilla
15840-3	AIR/OIL COOLER			C-212		AEG Sevilla
15A005-201	APU Exhaust System Ducts & Insulation				49-81-00	AEG Bilbao
15A024-3	APU Exhaust System Ducts & Insulation				49-81-00	AEG Bilbao
15A101-101	APU Exhaust System Ducts & Insulation				49-81-00	AEG Bilbao
15A102-103	Upper Inlet Duct Assembly (5A102-103)			CRJ Regional Jet-100,CRJ Regional Jet-300	49-11-02	AEG Sevilla
15A104	APU Enclosure Assembly (5A104 repair the APU)				49-11-01	AEG Bilbao
15A105-101	APU Exhaust System Ducts & Insulation				49-81-00	AEG Bilbao
15A106-101	APU Exhaust System Ducts & Insulation				49-81-00	AEG Bilbao
15A107-101	APU Exhaust System Ducts & Insulation				49-81-00	AEG Bilbao
160148-1	Oil Temp Cont. Valve			F100,A310 A300,B747,B767,MD-11	49-94-10	AEG Sevilla
160148-2	Oil Temp Cont. Valve			CRJ Regional Jet-100,CRJ Regional Jet-300,CRJ Regional Jet-440,CRJ Regional Jet-560	49-94-10	AEG Sevilla
160151-5	Fuel Booster Pump Assy				28-20-32	AEG Sevilla
16040-117	Shock Strut NLG/Shock Strut Subassy and Subassy			CRJ Regional Jet-100	32-20-04	AEG Sevilla
16040-119	Shock Strut NLG/Shock Strut Subassy and Subassy			CRJ Regional Jet-100	32-20-04	AEG Sevilla
16076A10001	Plenum Shock Strut NLG/Shock Strut Subassy and Subassy				21-51-95	AEG Sevilla
16100-103thru-115	Plenum Shock Strut NLG/Shock Strut Subassy and Subassy				32-20-04	AEG Sevilla
1611130-1	AXLE MLG	BOEING		B737-900,B737-800,B737-700,B737-600,B737	32-11-12	AEG Sevilla
1611130-2	AXLE MLG	BOEING		B737-900,B737-800,B737-700,B737-600,B737	32-11-12	AEG Sevilla
1611130-3	AXLE MLG	BOEING		B737-900,B737-800,B737-700,B737-600,B737	32-11-12	AEG Sevilla
1611130-4	AXLE MLG	BOEING		B737-900,B737-800,B737-700,B737-600,B737	32-11-12	AEG Sevilla
1611130-7	AXLE MLG	BOEING		B737-900,B737-800,B737-700,B737-600,B737	32-11-12	AEG Sevilla
1611130-8	AXLE MLG	BOEING		B737-900,B737-800,B737-700,B737-600,B737	32-11-12	AEG Sevilla
1611131	AXLE SLEEVE	THE BOEING COMPANY		B737, B737-700, B737	32-11-12	AEG Sevilla
1611131-1	AXLE SLEEVE	THE BOEING COMPANY		B737, B737-700, B737	32-11-12	AEG Sevilla
1611131-SERIES	AXLE SLEEVE	THE BOEING COMPANY		B737, B737-700, B737	32-11-12	AEG Sevilla
1619228-2	MAIN LANDING GEAR INSTALLATION	BOEING		B737	32	AEG Sevilla
1619228-2	MAIN LANDING GEAR INSTALLATION	#N/D		B737		AEG Sevilla
161N0001-115	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING		B777,C-130,B757	32-32-05	AEG Sevilla
161N0001-116	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING		B777,B757	32-32-05	AEG Sevilla
161N0001-136	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING		B777,C-130,B757	32-32-05	AEG Sevilla
161N0001-147	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING		B777,C-130,B757	32-32-05	AEG Sevilla
161N0001-148	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING		B777,B757	32-32-05	AEG Sevilla
161N0001-54	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING		B777,C-130,B757	32-32-05	AEG Sevilla
161N0001-55	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING		B777,C-130,B757	32-32-05	AEG Sevilla
161T6005-4	SPINDLE	BOEING		B767	32-11-20	AEG Sevilla
161W160-1	AXLE MLG	AXLE		B777	32-11-18	AEG Sevilla
161W160-12	AXLE MLG			B777		AEG Sevilla
161W160-5	AXLE MLG	AXLE		B777	32-11-18	AEG Sevilla
161W160-6	AXLE MLG	AXLE		B777	32-11-18	AEG Sevilla
161W162-11	AXLE MLG			B777		AEG Sevilla
161W162-13	AXLE MLG			B777		AEG Sevilla
161W162-14	AXLE MLG			B777		AEG Sevilla
161W162-5	AXLE MLG	BOEING		B777	32-11-18	AEG Sevilla
161W162-7	AXLE MLG			B777		AEG Sevilla
1627608-1	TOGGLE			UNK		AEG Sevilla
162A0301-1	LH TRUNNION PIN ASSEMBLY	BOEING		B737	32	AEG Sevilla
162A0301-3	LH TRUNNION PIN ASSEMBLY	BOEING		B737	32	AEG Sevilla
162A0301-301	LH TRUNNION PIN ASSEMBLY	BOEING		B737	32-30-61	AEG Sevilla
162A0302-1	RH TRUNNION PIN ASSEMBLY	BOEING		B737	32	AEG Sevilla
162A0302-3	RH TRUNNION PIN ASSEMBLY	BOEING		B737	32	AEG Sevilla
162A0302-301	RH TRUNNION PIN ASSEMBLY	BOEING		B737	32-30-61	AEG Sevilla
162A0303-1	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-2	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-3	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-301	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-302	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-303	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-304	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-307	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-308	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-309	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-310	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-311	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-4	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-5	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-6	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-7	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-8	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A0303-9	SPACER-TRUNNION	BOEING		B737	32-30-61	AEG Sevilla
162A1404-3	COLLAR	BOEING		B737-900,B737-800,B737-700,B737-600,B737	32-21-12	AEG Sevilla
162A1404-4	COLLAR	BOEING		B737-900,B737-800,B737-700,B737-600,B737	32	AEG Sevilla
162A218-1	LOCK LINK SHAFT	BOEING		B737	32	AEG Sevilla
162A218-2	LOCK LINK SHAFT	BOEING		B737	32	AEG Sevilla
162A218-301	LOCK LINK SHAFT	BOEING		B737	32-21-07	AEG Sevilla
162A2201-1	NOSE LANDING	BOEING		B737	32-21-07	AEG Sevilla
162A2201-3	NOSE LANDING	BOEING		B737	32	AEG Sevilla
162A2201-301	NOSE LANDING	BOEING		B737	32-21-07	AEG Sevilla
162A2201-302	NOSE LANDING	BOEING		B737	32	AEG Sevilla
162A2304-1	WASHER	BOEING		B737	32-21-07	AEG Sevilla
162A2304-301	WASHER	BOEING		B737	32-21-07	AEG Sevilla
162A2305-1	NUT	BOEING		B737	32	AEG Sevilla
162A2305-301	NUT	BOEING		B737	32	AEG Sevilla
162B243	INDICATOR OIL TEMPERATURE	ULTRA ELECTRONICS		C-212	79	AEG Sevilla
162B3F	INDICATOR OIL ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS		DC-9,DC-8	05-40BC-13	AEG Sevilla
162BL SERIES	Steering Actuator/Swivel	LEWIS ENG		B737	31-20-07	AEG Sevilla
16300-103	Steering Actuator/Swivel			CRJ Regional Jet-100,CRJ Regional Jet-300,CRJ Regional Jet-440,CRJ Regional Jet-560	32-50-12	AEG Sevilla
16300-104	Steering Actuator/Swivel			CRJ Regional Jet-100,CRJ Regional Jet-300	32-50-12	AEG Sevilla
16300-107	Steering Actuator/Swivel				32-50-12	AEG Sevilla
16300-109	Steering Actuator/Swivel				32-50-12	AEG Sevilla
16330-107	Shock Strut NLG/Shock Strut Subassy and Subassy			B757	32-20-04	AEG Sevilla
16330-109	Shock Strut NLG/Shock Strut Subassy and Subassy			C-130	32-20-04	AEG Sevilla
1646-1-6	DIMMABLE FLUORESCENT LAMP CONTROL	AVTECH		B737-300,B737-200,B737	33-10-04	AEG Sevilla
1646-1-6 MOD A	DIMMABLE FLUORESCENT LAMP CONTROL	AVTECH		DC-9,DC-8,B737-200,B727,B737	33	AEG Sevilla
1646-1-6 MOD B	DIMMABLE FLUORESCENT LAMP CONTROL	AVTECH		DC-9,DC-8,B737-200,B727,B737	33	AEG Sevilla
1646-1-6A	FLUORESCENT LAMP CPNTROLLER	AVTECH		B737	33	AEG Sevilla
1646-1-6B	FLUORESCENT LAMP CPNTROLLER	AVTECH		B737	33	AEG Sevilla
1646-1-6MOD A	DIMMABLE FLUORESCENT LAMP CONTROL	AVTECH		B737	33	AEG Sevilla
1646-1-7	FLUORESCENT LAMP CONTROL	AVTECH		A320,B737-300,B737-200,B737	33-10-04	AEG Sevilla
1646-1-7 MOD A	DIMMABLE FLUORESCENT LAMP CONTROL	AVTECH		B737-300,B737	33	AEG Sevilla
1646-1-7 MOD B	DIMMABLE FLUORESCENT LAMP CONTROL	AVTECH		B737-300,B737	33	AEG Sevilla
1646-1-7A	FLUORESCENT LAMP CPNTROLLER	AVTECH		B737	33	AEG Sevilla
1646-1-7B	FLUORESCENT LAMP CPNTROLLER	AVTECH		B737	33	AEG Sevilla
1646-1-7MOD A	DIMMABLE FLUORESCENT LAMP CONTROL	AVTECH		B737	33	AEG Sevilla
16480-101	NLG Steering Manifold			CL-60,CRJ Regional Jet-100,CRJ Regional Jet-300	32-50-16	AEG Sevilla
165E0948-00	Voice Recorder/Microphone/Unit/Voice Recorder				23-70-02	AEG Sevilla
165E1233-00	Model 2200S SolidState Cockpit VoiceRecorder				23-70-03	AEG Sevilla
16650-101	Steering Control Module Assembly			B757,C-130	32-50-13	AEG Sevilla
16789-101	Hydraulic Compensator Assembly			CRJ-700,CL-601	32-50-14	AEG Sevilla
16900-101	Electronic Control Unit				32-50-15	AEG Sevilla
16902-03	Electronic Control Unit				32-50-15	AEG Sevilla
16902-04	Electronic Control Unit				32-50-15	AEG Sevilla
1700089 SERIES	ROTOR BALANCE ASSEMBLY			B777,B767-400		AEG Bilbao

1700089A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
1700089B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
170121B	Lube And Scavenge Pump			79-21-01	AEG Sevilla
170137A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	ERJ175 Regional Jet-900,CRJ1000	24	AEG Bilbao
170137A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	A320X319,ERJ-170,CRJ900 Regional Jet-900,CRJ1000	24-21-12	AEG Sevilla
1701320B	GENERATOR ASSEMBLY	UTC AEROSPACE	CRJ900 Regional Jet-900,CRJ-700	24	AEG Bilbao
1701320C	GENERATOR ASSEMBLY	HAMILTON	CRJ900 Regional Jet-900,CRJ-700	24-22-13	AEG Bilbao
1701410 SERIES	ROTOR BALANCE ASSEMBLY	HAMILTON	B777	24	AEG Bilbao
1701410A	ROTOR BALANCE ASSEMBLY	UTC	B777	24-26-10	AEG Bilbao
170279A	STATOR	SUNDSTRAND	A330		AEG Bilbao
1703381-01	DIODE PACK	SUNDSTRAND	B737	24-26-12	AEG Sevilla
1704600-1	VALVE PRESSURE REDUCING 8	NABTESCO AEROSPACE	L-1011,B737-500,B737-400,B737-300,MD-80,B737	27-22-01	AEG Sevilla
17051-101	MLG Unlock And Actuator Assembly		Challenger 600,CRJ Regional Jet-100,CRJ	32-30-15	AEG Sevilla
1708054A	DIODE PACKAGE ASSEMBLY	HAMILTON			AEG Sevilla
1708899A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A320,B737	24-26-15	AEG Bilbao
1708899B	ROTOR		A320	24-11-88	AEG Bilbao
171001-30	PLACA, CIRCUITOS C		UNK		AEG Sevilla
171025A	Outboard Slat Actuator Assembly		CRJ-700	27-81-18	AEG Sevilla
1712505A	Inboard Flap Actuator Assembly			27-52-07	AEG Sevilla
1712507A	Midboard Right Flap Actuator Assembly			27-52-19	AEG Sevilla
1712507B	Midboard Right Flap Actuator Assembly			27-52-19	AEG Sevilla
1712509A	Midboard Left Flap Actuator Assembly		CRJ-700	27-52-20	AEG Sevilla
1712509B	Midboard Left Flap Actuator Assembly		CRJ-700	27-52-20	AEG Sevilla
1712513A	Outboard Left Flap Actuator Assembly			27-52-22	AEG Sevilla
1712513B	Outboard Left Flap Actuator Assembly			27-52-22	AEG Sevilla
171346A	Slat Brake/Position Sensor Unit			27-81-21	AEG Sevilla
1713700A	Mid Slat Actuator Assembly			27-81-20	AEG Sevilla
1714309A	Type A Right-Hand Inboard & Left-Hand			27-81-28	AEG Sevilla
1714311A	Type B Right-Hand Outboard and Left-Hand			27-81-29	AEG Sevilla
1714311A	Inboard Slat Disconnect Control				AEG Sevilla
171851-01	PCU	BE AVONICS	UNK	23-32-82	AEG Sevilla
1721000A	EXCITER STATOR HOUSING ASSEMBLY	HAMILTON	UNK		AEG Bilbao
1721395A	STATOR AND HOUSING ASSEMBLY	HAMILTON	A320, A3240-200, A340-300, A340-600, A340-600, A318, A319, A320, A321	24-17-50	AEG Bilbao
172800-1	Cabin Windows			56-20-00	AEG Sevilla
172800-11	Cabin Windows			56-20-00	AEG Sevilla
172800-13	Cabin Windows			56-20-00	AEG Sevilla
172800-3	Cabin Windows			56-20-00	AEG Sevilla
172800-5	Cabin Windows			56-20-00	AEG Sevilla
172800-7	Cabin Windows			56-20-00	AEG Sevilla
172900-1	Cabin Windows			56-20-00	AEG Sevilla
17319-105	MLG Auxiliary Assembly		CRJ Regional Jet-200,B737	32-30-13	AEG Sevilla
173227-502	VIDEO DISTRIBUTION BOX		UNK		AEG Sevilla
173595-02	DISPLAY		UNK		AEG Sevilla
1756-1	Main Battery		A320	24-32-06	AEG Sevilla
1756-3	Main Battery			24-32-06	AEG Sevilla
176200-204	Self Contained Hand Flushing Toilet Assembly			38-31-12	AEG Sevilla
1784389-653	COMPASS, GYROSYN	SPERRY	DC-9,DC-8,B737-200,B727	34-33-00	AEG Sevilla
1785A010003	Duct Ground Connection HP			36-12-19	AEG Sevilla
179120-2	STARTER MOTOR	SUNDSTRAND	T-821,T-810, T-821-T-850, A320, A321, A320X, A321X, A320X, A321X	49	AEG Sevilla
179120-2	Starter Motor			49-41-03	AEG Sevilla
179120-3	STARTER MOTOR	HAM SUNDSTRAND	B777,A320,B737	49-41-05	AEG Sevilla
18-1299-6	FLAP POSITION INDICATOR	HONEYWELL	B737-500,B737-400,B737-300,B737-200,B737	27-50-07	AEG Sevilla
182828-02	HEADSET ELECTRICAL	DAVID CLARK	C-295,CN-235	31	AEG Sevilla
183990-0001	CONTROL UNIT, COCKPI		UNK		AEG Sevilla
1905A0000-01	VALVE SAFETY	LIEBHERR-AEROSPACE	A321,A319,A318,A320-232,A320	32-31-17	AEG Sevilla
1942100-1	SENSOR CABINA		UNK		AEG Sevilla
1A081-0155-1	TOILET FLUSH	YOKOHAMA RUBBER	B767,B737-500,B737-400,B737-	25-41-18	AEG Sevilla
1A081-0155-11	FLUSH TIMER SWITCH	YOKOHAMA RUBBER	B737-500,B737-400,B737-	25-41-18	AEG Sevilla
1B6010-3R	Pilot And Co-Pilot Seat				AEG Sevilla
1B6010-4R	Pilot And Co-Pilot Seat				AEG Sevilla
1FA01134-1	VALVE SELECTOR RETRACTION/EXTENSION CONTROL, LANDING GEAR	FRISBY AEROSPACE	B737-600,B737,B737	32-31-03	AEG Sevilla
1FA01134-2	SELECTOR VALVE	FRISBY AEROSPACE	B737-600,B737,B737-86N,B737-683,B737	32-31-03	AEG Sevilla
1FA14012-6	ACTUATOR, THRUST REVERSER COWL	TRUMPF ACTUATION	B737,B737-500,B737-500,B737-400,B737-	78-31-01	AEG Sevilla
1FA14012-7	ACTUATOR, THRUST REVERSER COWL	TRUMPF ACTUATION	B737,B737-500,B737-500,B737-400,B737-	78-31-01	AEG Sevilla
1FA14012-8	ACTUATOR, THRUST REVERSER COWL	TRUMPF ACTUATION	B737,B737-500,B737-500,B737-400,B737-	78-31-01	AEG Sevilla
1U169	TAIL SKID ACTUATOR	SMITHS	CRJ-700,CRJ Regional Jet-	32-70-1	AEG Sevilla
1U1243-1	GRAVEL DEFLECTOR ACTUATOR	SMITHS	B737-500,B737-400,B737-300,B737	32-50-02	AEG Sevilla
1U1243-2	GRAVEL DEFLECTOR ACTUATOR	SMITHS	B737-500,B737-400,B737-300,B737	32-50-02	AEG Sevilla
1X0004427-10	Taxi Light			33-40-19	AEG Sevilla
1X0455068-01	Nose Gear Landing Light		CRJ-700	33-41-08	AEG Sevilla
1X0455068-03	Nose Gear Landing Light			33-41-08	AEG Sevilla
1X2005097-00	LOGO LIGHT	HELLA	A318,A320,A321,A320X,A321X,A320X,CRJ-700,CRJ900 Regional Jet-	33-43-01	AEG Sevilla
1X2005097-71	Logo Light		A320,CRJ-700,CRJ900 Regional Jet-	33-43-70	AEG Sevilla
1X2005097-72	Logo Light		A320,CRJ-700,CRJ900 Regional Jet-	33-43-70	AEG Sevilla
1X2005097-73	Logo Light		CRJ-700,CRJ900 Regional Jet-900,CRJ	33-43-70	AEG Sevilla
1X2005097-74	Logo Light		CRJ-700,CRJ900 Regional Jet-900,CRJ	33-43-70	AEG Sevilla
1X2455049-00	Hid Landing And Hid Taxi Light		CRJ-700,B747,C-130	33-40-71	AEG Sevilla
1X2455050-00	Hid Landing And Hid Taxi Light		CRJ-700,C-130	33-40-71	AEG Sevilla
2000A165K02	Serve Valve			27-25-07	AEG Sevilla
2010420-001	AUTOBRAKE ASSEMBLY VALVE MODULE	TEXTRON	B737	32-40-04	AEG Sevilla
2010420-003	AUTOBRAKE ASSEMBLY VALVE MODULE	HR TEXTRON	B737	32-40-04	AEG Sevilla
2010420-005	AUTOBRAKE ASSEMBLY VALVE MODULE	HR TEXTRON	B737,B767-200,B767,B757	32-40-04	AEG Sevilla
2010420-006	AUTOBRAKE ASSEMBLY VALVE MODULE	HR TEXTRON	B737,B767-200,B767,B757	32-40-04	AEG Sevilla
2010420-007	MODULE ASSY, VALVE	HR TEXTRON	B737,B767-200,B767,B757	32-40-04	AEG Sevilla
20102060-101	AUTOBRAKE ASSEMBLY VALVE MODULE	HR TEXTRON	B737-300,CRJ Regional Jet-200,B747-	32-40-03	AEG Sevilla
20102060-102	AUTOBRAKE ASSEMBLY VALVE MODULE	HR TEXTRON	A320,B737-500,B737-400,B737-	32-40-03	AEG Sevilla
20102060-103	MODULE	HR TEXTRON	CRJ Regional Jet-200,CRJ Regional Jet-	32-40-03	AEG Sevilla
201134 SERIES	MLG LEG AND AXLE HARNESS	ULTRA ELECTRONICS	A318/A319/A320	32-11-43	AEG Sevilla
201158 SERIES	MLG LEG AND AXLE HARNESS	ULTRA ELECTRONICS	A318/A319/A320	32-11-43	AEG Sevilla
201159 SERIES	MLG LEG AND AXLE HARNESS	ULTRA ELECTRONICS	A318/A319/A320	32-11-43	AEG Sevilla
201600-1	ARMATURE	AIRSEARCH	A319	49	AEG Bilbao
201600-2	ARMATURE	AIRSEARCH	A318,A319	49-41-16	AEG Bilbao
20161 SERIES	MAIN LANDING GEAR DRESSINGS	SAFRAN LANDING	A318/A319/A320	32-11-24	AEG Sevilla
20168 SERIES	MLG LEG AND AXLE HARNESS	ULTRA ELECTRONICS	A318/A319/A320	32-11-43	AEG Sevilla
201573007-020	LH LEG ASSY MLG	SAFRAN	A320		AEG Sevilla
201573008-040	RH LEG ASSY MLG	SAFRAN	A320		AEG Sevilla
201575007-010	MAIN LANDING GEAR	MESSIER DOWTY	A320	32	AEG Sevilla
201575007-020	LH MAIN LANDING GEAR	MESSIER DOWTY	A320	32	AEG Sevilla
201575007-030	LH LEG ASSY MLG	MESSIER DOWTY	A320	32-11-32	AEG Sevilla
201575007-035	MAIN LANDING GEAR	MESSIER DOWTY	A320	32	AEG Sevilla
201575007-040	LH MLG	MESSIER DOWTY	A320,A320-221	32-11-11	AEG Sevilla
201575008-010	RH LEG ASSEMBLY MLG	MESSIER DOWTY	A320	32-11-32	AEG Sevilla
201575008-020	RH LEG ASSEMBLY MLG	MESSIER-DOWTY	A320	32-11-32	AEG Sevilla
201575008-030	RH LEG ASSY MAIN LG	MESSIER DOWTY	A320,A320-221	32-11-11	AEG Sevilla
201575008-035	RH LEG ASSEMBLY MLG	MESSIER DOWTY	A320	32	AEG Sevilla
201575008-040	RH MAIN LANDING GEAR	MESSIER DOWTY	A320	32-11-32	AEG Sevilla
20187001-010	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-020	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-030	LH MLG	MESSIER-DOWTY	A320	32-11-82	AEG Sevilla
20187001-040	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-050	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-060	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-070	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-080	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-090	LH MLG	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-100	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-110	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187001-120	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187002-010	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
20187002-020	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla

201387002-030	RH MLDG	MESSIER-DOWTY	A320	32-11-82	AEG Sevilla
201387002-040	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
201387002-050	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
201387002-060	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
201387002-070	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
201387002-080	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
201387002-090	RH LNG	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
201387002-100	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
201387002-110	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
201387002-120	MLG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Sevilla
201399 SERIES	MAIN LANDING GEAR HARNESS	SAFRAN LANDING SYSTEMS	A321, A330-200, A320XLR	32-11-88	AEG Sevilla
201400 SERIES	MAIN LANDING GEAR HARNESS	SAFRAN LANDING SYSTEMS	A321, A330-200, A320XLR	32-12-28	AEG Sevilla
201401 SERIES	MLG LEG AND AXLE HARNESS	ULTRA PCS LIMITED	A318/A319/A320	32-11-44	AEG Sevilla
201402 SERIES	AXLE HARNESS	SAFRAN LANDING SYSTEMS	A321	32-12-29	AEG Sevilla
201419001-020	DAMPER	MOORE WILCOX AEROSPACE	A318, A321, A320, A319, B747	32	AEG Sevilla
201480002-010	BOGE PITCH TRIMMER	#N/A	A330		AEG Sevilla
201480002-015	BOGR PITCH TRIMMER	MESSIER-DOWTY	A340, A330	32-12-09	AEG Sevilla
201480002-020	BOGE PITCH TRIMMER	MESSIER-DOWTY	A340, A330	32-12-09	AEG Sevilla
201481001-005	UNLOCK ACTUATOR	MESSIER-DOWTY LANDING GEAR SYSTEMS	A340, A330	32	AEG Sevilla
201484001-005	STAY-COMPLETE SIDE LH	MESSIER-DOWTY	A330	32-12-06	AEG Sevilla
201484001-010	STAY-COMPLETE SIDE LH	MESSIER-DOWTY	A330	32-12-06	AEG Sevilla
201484001-015	STAY-COMPLETE SIDE LH	MESSIER-DOWTY	A330	32-12-06	AEG Sevilla
201484002-005	MLG SIDE STAY COMPLETE	MESSIER-DOWTY	A330	32-12-06	AEG Sevilla
201487001-010	STRUT-SHOCK	HONEYWELL	A330		AEG Sevilla
201520 SERIES	MLG LEG AND AXLE HARNESS	SAFRAN LANDING SYSTEMS	A318/A319/A320	32-11-44	AEG Sevilla
201524001-030	SIDE STAY COMPLETE	SAFRAN	A320	32	AEG Sevilla
201590002-020	RETRACTION ACTUATOR	MESSIER SERVICES	CRJ Regional Jet-200, A318, A320- 200, A321, A320XLR, A321XLR	32-32-31-86	AEG Sevilla
201640001-010	STAY ASSY-SIDE,MLG	MESSIER-DOWTY	A320	32-12-13	AEG Sevilla
20219-0101	HYDRAULIC OIL QUANTITY TRANSMITTER	SIMMONDS PRECISION	B737-700, CRJ Regional Jet-200, B737- 400, B737	29-30-24	AEG Sevilla
20220-01	COMPENSATOR		UNK		AEG Sevilla
20220-0101	QTY TRANSMITTER	SIMMONDS PRECISION	CRJ Regional Jet-200, B737-800, B737- 400, B737	29-30-24	AEG Sevilla
20241207-2	STATOR	ALLIED SIGNAL AEROSP			AEG Bilbao
2045M3P01	ALTERNATOR		UNK		AEG Bilbao
2045M3P02	ALTERNATOR		UNK		AEG Sevilla
204790-1-1	TURBINE DRIVEN CENTRIFUGAL COMPRESSOR	HONEYWELL	P-3	3-30AK-94	AEG Sevilla
204790-2-1	COMPRESSOR CENTRIFUGA	HONEYWELL	P-3	3-30AK-94	AEG Sevilla
2067593-2657	VHF NAV RECEIVER	BENDIX	B737-300, B737-400, B737-500, B737- 600, B737, 700, B737, 700, A320, B737	34	AEG Sevilla
209A10	CONTROL UNIT-INTE		UNK		AEG Sevilla
2100140-003	Throttle Gearbox Assembly			76-10-04	AEG Sevilla
2100140-005	Throttle Gearbox Assembly			76-10-04	AEG Sevilla
2100140-007	Throttle Gearbox Assembly			76-10-04	AEG Sevilla
2107-1AA	Attendant Seats				AEG Sevilla
2107-1AB	Attendant Seats				AEG Sevilla
2107-1AC	Attendant Seats				AEG Sevilla
2107-1AD	Attendant Seats				AEG Sevilla
2107-1AE	Attendant Seats				AEG Sevilla
2107-1AF	Attendant Seats				AEG Sevilla
2107-1AG	Attendant Seats				AEG Sevilla
2107S07Y01	CONTROL LEVER	ZODIAC	A321/A319/A320-200/A340-315/A320- 200, B737-400, B737, A320, A321	32	AEG Sevilla
2102MN-372M	Fault Indicator			2102MN-372M	AEG Sevilla
219764-2	Selector, Cabin Pressure		CRJ Regional Jet-100	21-32-30	AEG Sevilla
219764-4	Selector, Cabin Pressure		CRJ Regional Jet-100	21-32-30	AEG Sevilla
219764-5	Selector, Cabin Pressure		CRJ Regional Jet-100, CRJ Regional Jet- 200	21-32-30	AEG Sevilla
219764-6	Selector, Cabin Pressure		CRJ Regional Jet-100, CRJ Regional Jet- 200	21-32-30	AEG Sevilla
21C223-175	HYDRAULIC PRESSURE SWITCH	CONDEC / CONRAD ELECT CORP	B747-200, B777, B757, B747, B737, B767	29-09-01,29	AEG Sevilla
21C223-177	HYDRAULIC PRESSURE SWITCH	CONRAD ELECTED	700, B737, B747, B757, B767, B737	32,29-09-01,29	AEG Sevilla
21C223-178	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B777, B747, B757, B737, B767	29-09-01	AEG Sevilla
21C223-199	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, CRJ Regional Jet-200, B737- 700, B737, B747, B757, B767, B737	29-09-02	AEG Sevilla
21C223-200	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B737-200, B737, B747, B757, B767	29-09-02	AEG Sevilla
21C223-201	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, CRJ Regional Jet-200, B737- 700, B737, B747, B757, B767	29-09-02	AEG Sevilla
21C223-208	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B747-200, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-209	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	DC-10, DC-9, CRJ-200, B737-700, B737- 800, B737, B747, B757, B767	29-09-02	AEG Sevilla
21C223-211	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-212	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-214	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-216	HYDRAULIC PRESSURE SWITCH	EATON/CONDEC	B747, B737-900, B737-800, B737-700, B737- 600, B737	29-09-02	AEG Sevilla
21C223-252	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-253	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B777, CRJ Regional Jet-200, B737- 700, B737	29-09-02	AEG Sevilla
21C223-275	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-297	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-301	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-312	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, CRJ Regional Jet-	29-09-02	AEG Sevilla
21C223-319	HYDRAULIC PRESSURE SWITCH	CONDEC / CONRAD ELECTED	700, B737, B747, B757, B767, B737	29-09-01	AEG Sevilla
21C223-320	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-321	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-322	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-323	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B737, A320, B737-300, B737-400, B737- 500, B737, B747, B757, B767	29-09-02	AEG Sevilla
21C223-324	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707, B777, B747, B737-900, B737-800, B737- 700, B737	29-09-02	AEG Sevilla
21C223-326	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	CRJ Regional Jet-	29-09-03	AEG Sevilla
21C223-327	HYD PRESSURE SWITCH	EATON AEROSPACE LLC	B737-300, A320, B737-800, B737- 700, B737	29-09-03	AEG Sevilla
21C223-341	HYDRAULIC SWITCH PRESSURE	EATON	B737, B777, B737	29	AEG Sevilla
21C223-461A	SWITCH-PRESSURE	EATON	B737-300, CRJ Regional Jet-200, CRJ Regional Jet-200, CRJ Regional Jet-	29-34-01,29	AEG Sevilla
21C223-461A	Pressure Switch	EATON	B737-300, CRJ Regional Jet-200, CRJ Regional Jet-200, CRJ Regional Jet-	29-34-01	AEG Sevilla
21C223-518	HYD PRESSURE SWITCH	EATON ELECTRICAL SENSING CONTROLS	B737-300, B737-400, B737-500, B737- 600, B737, B747, B757, B767	29-09-04	AEG Sevilla
21C223-519	HYDRAULIC PRESSURE SWITCH	EATON	700, B737, A320, B737-300, B737-400, B737- 500, B737, B747, B757, B767	29-09-05	AEG Sevilla
21C223-520	HYDRAULIC PRESSURE SWITCH	CUSTOM CONTROLS	B777, B767, B737, B737	29-09-05	AEG Sevilla
21C223-521	HYDRAULIC PRESSURE SWITCH	EATON	B777, B757, B737, B767	29-09-05	AEG Sevilla
21C223-522	HYDRAULIC PRESSURE SWITCH	EATON/CONDEC	B767, B777, B737, B737	29-09-05	AEG Sevilla
21C223-522	HYDRAULIC PRESSURE SWITCH	EATON	B767, B777, B737, B737	29-09-05	AEG Sevilla
21C223-523	HYDRAULIC PRESSURE SWITCH	EATON	B767, B777, B737, B737	29-09-05	AEG Sevilla
21C223-524	HYDRAULIC PRESSURE SWITCH	EATON	B777, B767, B737, B737	29-09-05	AEG Sevilla
21C223-525	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B737, B767, B737	29-09-06,29	AEG Sevilla
21C223-526	HYDRAULIC PRESSURE SWITCH	EATON		38624	AEG Sevilla
21C223-527	HYDRAULIC PRESSURE SWITCH	BOEING	B737-300, B737-900, B737-800, B737- 700, B737, A320, B737-300, B737-400, B737- 500, B737, B747, B757, B767	29-09-05	AEG Sevilla
21C223-528	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B737, B777, B767, B737	29-09-06,29	AEG Sevilla
21C223-534	HYDRAULIC PRESSURE SWITCH	EATON ELECTRICAL SENSING CONTROLS	CRJ Regional Jet-	29-09-04	AEG Sevilla
21C223-535	HYDRAULIC PRESSURE SWITCH	EATON	B737, B757, B747, B767	29-09-07,29	AEG Sevilla
21C223-659	HYDRAULIC PRESSURE SWITCH	EATON		39899	AEG Sevilla
21C223-XXX	HYDRAULIC PRESSURE SWITCH	EATON	B737-500, B737-400, B737-300, B767, B737	29	AEG Sevilla
214001-10	PANEL CONTROL ELECTRIC		UNK		AEG Sevilla
2-1466-3	Main Brake Assembly			32-42-17	AEG Sevilla
2-1466-4	Main Brake Assembly			32-42-17	AEG Sevilla
2-1466-5	Main Brake Assembly			32-42-17	AEG Sevilla
214C40-1-1I5	ALTITUDE SWITCH	EATON	A320, B737-300, B737- 400, B737, B747, B757, B767	34-11-01	AEG Sevilla
214C40-1-7I	SWITCH	EATON	700, B737, B747, B757, B767, B737	34-11-01	AEG Sevilla
214C40-1-75	PRUSSURE SPARE PARTS	EATON	A320, B737-300, B737- 400, B737, B747, B757, B767	34-11-01	AEG Sevilla
214C40-1-77	ALTITUDE SWITCH	EATON	700, B737, B747, B757, B767, B737	34-11-01	AEG Sevilla
2-1617	Main Brake Assembly			32-46-70	AEG Sevilla
2-1665	Main Landing Gear Brake Assembly			32-46-88	AEG Sevilla
2-1676	MAIN LANDING GEAR BRAKE ASSEMBLY	BFG	King CN-235, King Air 200	32-46-27	AEG Sevilla
215TS07Y00	LEVER	ZODIAC	A340, A330, A321, A319, A320	32-31-13	AEG Sevilla
2-1605	MLG Brake Assembly			32-48-33	AEG Sevilla
2-1605-1	MLG Brake Assembly			32-48-33	AEG Sevilla
2-1605-2	MLG Brake Assembly			32-48-33	AEG Sevilla
218066-1	APU FUEL PUMP	ZODIAC	B737-200, B737-300, B737-400, B737- 500, B737, B747, B757, B767	28-28-25-04	AEG Sevilla
218066-2	APU FUEL PUMP	ZODIAC	B737-200, B737-300, B737-400, B737- 500, B737, B747, B757, B767	28-28-25-04	AEG Sevilla
218066-3	APU FUEL PUMP	ZODIAC	B737-200, B737-300, B737-400, B737- 500, B737, B747, B757, B767	28-28-25-04	AEG Sevilla
21C1-1-168	PRESSURE SWITCH	EATON	B777, A300	79-34-11	AEG Sevilla
21C1-3-21	FUEL PRESS SWITCH	AEROSPACE ENGINEERING	B747-400, B767, B737, B747, B737	28-42-01	AEG Sevilla

21C1-3-22	FUEL PRESS SWITCH	AEROSPACE ENGINEERING DIVISION	B737-86N,B767,B757,B747,B737	28-42-01	AEG Sevilla
21SND4-104A	PRESSURE SWITCH	EATON AEROSPACE LLC	B747-200,B777,B767,B757,B737,B747	31-09-01	AEG Sevilla
21SND4-104B	PRESSURE SWITCH	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-104D	SCAVENGE OIL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-104E	PRESSURE SWITCH	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-104F	PRESSURE SWITCH	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-158A	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747-200,B777,B767,B757,B747,B757	31-09-01,31,73	AEG Sevilla
21SND4-158B	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747-200,B767,B757,B777,B747,B757	31-09-01	AEG Sevilla
21SND4-158C	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747-200,B777,B767,B757,B747,B757	31-09-01,31,73,0	AEG Sevilla
21SND4-158D	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747-200,B777,B767,B757,B747,B757	0,31-09-01,31	AEG Sevilla
21SND4-159	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747-200,B777,B767,B757,B737,B747	31-09-01,79,31	AEG Sevilla
21SND4-159A	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747-200,MD-11,DC	79-21-25	AEG Sevilla
21SND4-159B	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747-200,MD-11,DC	31-09-01	AEG Sevilla
21SND4-159C	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747-200,MD-11,DC	79-21-25	AEG Sevilla
21SND4-159D	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747-200,MD-11,DC	79-21-25	AEG Sevilla
21SND4-209A	ASSEMBLY	CONSOLIDATED CONTROLS	CF6-80C2,B737-300,B747,B757,CFM56-3	79-09-03	AEG Sevilla
21SND4-211	PRESSURE SWITCH	CONDEC	B737-300,B737-300,B747,B757,CFM56-3	79-21-25	AEG Sevilla
21SND4-211A	PRESSURE SWITCH	CONDEC	B737-300,B737-300,B747,B757,CFM56-3	79-21-25	AEG Sevilla
21SND4-224	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	A320,A321,A320XLR,A321XLR,A320XLR-11	79-34-02	AEG Sevilla
21SND4-225	SWITCH-OIL PRESSURE	EATON AEROSPACE LLC	B747	79-34-02	AEG Sevilla
21SND4-226	PRESSURE SWITCH	CONDEC	B737-300,B737-300,B747,B757,CFM56-3	79-21-25	AEG Sevilla
21SND4-226A	PRESSURE SWITCH	CONDEC	B737-300,B737-300,B747,B757,CFM56-3	79-21-25	AEG Sevilla
21SND4-23F	PRESSURE SWITCH	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-23G	PRESSURE SWITCH	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-23H	PRESSURE SWITCH	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-23J	LOW OIL PRESS WIRING SWITCH	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-23K	PRESSURE SWITCH	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-24F	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01	AEG Sevilla
21SND4-24G	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	B747	79-21-25	AEG Sevilla
21SND4-24H	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	B747	79-21-25	AEG Sevilla
21SND4-24J	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01,31,73	AEG Sevilla
21SND4-24K	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01	AEG Sevilla
21SND4-25F	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01	AEG Sevilla
21SND4-25G	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON	B747	79-21-25	AEG Sevilla
21SND4-25H	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01	AEG Sevilla
21SND4-25J	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON	B747	79-21-25	AEG Sevilla
21SND4-25K	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01	AEG Sevilla
21SND4-26E	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01	AEG Sevilla
21SND4-26F	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01	AEG Sevilla
21SND4-26G	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01	AEG Sevilla
21SND4-26H	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	B747	79-21-25	AEG Sevilla
21SND4-26J	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	B747	31-09-01	AEG Sevilla
21SND4-26K	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	A-320	AEG Sevilla	
21SND4-275A	LOW OIL PRESSURE SWITCH	EATON	B757,A318,A320,V2500	79-34-15	AEG Sevilla
21SND4-298A	SCAVENGE FILTER PRESSURE SWITCH	EATON	CF6-80C2,A318,A320,V2500	79-35-16	AEG Sevilla
21SND4-300B	HYDRAULIC PRESSURE SWITCH	EATON	CF6-80C2,B737-300,V2500,A320XLR,A321XLR	73-34-15	AEG Sevilla
21SND4-306	LP OIL WARNING PRESSURE SWITCH	EATON AEROSPACE LLC	B747	31-09-01,31,73	AEG Sevilla
21SND4-306A	LP OIL WARNING PRESSURE SWITCH	EATON AEROSPACE LLC	B747	31-09-01,79,31	AEG Sevilla
21SND4-306B	LP OIL WARNING PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	B747	79-21-25	AEG Sevilla
21SND4-324	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	B747	79-34-02	AEG Sevilla
21SND4-325	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	B747	79-34-02	AEG Sevilla
21SND4-334	DIFFERENTIAL PRESSURE SWITCH	AIRBUS INDUSTRIES	A320,A321,A320XLR,A321XLR	79-34-02	AEG Sevilla
21SND4-335	DIFFERENTIAL PRESSURE SWITCH	EATON	B747	79-34-02	AEG Sevilla
21SND4-337A	ENGINE FUEL LOW PRESSURE SWITCH	EATON	B747,A330	73-33-11	AEG Sevilla
21SND4-338	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	A330,B737	73-33-11	AEG Sevilla
21SND4-339C	ENGINE OIL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	A330, A340	73-33-11	AEG Sevilla
21SND4-340	SCAVENGE OIL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	A330	73-33-11, 79-09-03	AEG Sevilla
21SND4-341A	ENGINE OIL FEED/SCAVENGE LINE DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	A340,A320	73-33-11	AEG Sevilla
21SND4-389A	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SND4-389B	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SND4-402	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SND4-403	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SND4-414	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SND4-415	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SND4-460	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SND4-461	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SND4-467	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	CF6-80C2	79-34-02	AEG Sevilla
21SND4-468	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	CF6-80C2	79-34-02	AEG Sevilla
21SND4-XXX	SCAVENGE OIL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	EATON	DC-10,B747	72	AEG Sevilla
21SND4-42	PRESSURE SWITCH	CONSOLIDATED CONTROLS	B747,B737,B767	80-21-03	AEG Sevilla
21SND4-52	SWITCH-THERMAL ANTI ICE	CONSOLIDATED CONTROLS	B737-300,B737-300,B747,B757,CFM56-3	80-21-03	AEG Sevilla
21SND4-84	PRESSURE SWITCH	CONSOLIDATED CONTROLS	B747,B757,B747-400,B767	80-21-03	AEG Sevilla
226114-1	Fuel Booster Pump		Challenger CRJ-700	28-20-77	AEG Sevilla
226114-3	Fuel Booster Pump		Challenger CRJ-700	28-20-77	AEG Sevilla
226115-1	Canister			28-20-78	AEG Sevilla
226115-2	Canister			28-20-78	AEG Sevilla
228077-3	APU Booster Pump			28-20-80	AEG Sevilla
228-50020	Nose Inlet Cowl			71-61-01	AEG Sevilla
228-50080	Upper/Lower Access Cowl			71-14-01	AEG Sevilla
228-50080	Upper/Lower Access Cowl			71-14-01	AEG Sevilla
228-50082	Nose Cowl Side Panel, Fixed Core Cowl/Service Door			71-13-01	AEG Sevilla
228-50121	Nose Cowl Side Panel, Fixed Core Cowl/Service Door			71-13-01	AEG Sevilla
228-50142	Upper/Lower Core Cowl Door			71-12-01	AEG Sevilla
228-50142	Upper/Lower Core Cowl Door			71-12-01	AEG Sevilla
228-50181	Exhaust Nozzle Faring, Exhaust Nozzle		CRJ Regional Jet-100	78-11-00	AEG Sevilla
228-50300	Nose Lower Side Panel, Fixed Core Lower/Service Door			71-13-01	AEG Sevilla
228-55030	Exhaust Nozzle Faring, Exhaust Nozzle		CRJ Regional Jet-100	78-11-00	AEG Sevilla
228-550000	Engine Nacelle			20-00-00	AEG Sevilla
228-56480	Anti-Ice Press Relief Valve			30-22-04	AEG Sevilla
23048-021	DC STARTER GENERATOR	SAFRAN	AT-802 & AT-802A, PZL Mielec M-18A, D77, mitsubishi M-180, CESSNA, CRJ30	24-30-74	AEG Sevilla
23048-028	DC STARTER GENERATOR	SAFRAN	AT-802 & AT-802A, PZL mielec M-18A	24-30-74	AEG Sevilla
23065 SERIES	DC STARTER GENERATOR	GOODRICH	Heli/Corporate		AEG Sevilla
23065-1520	DRIVE SHAFT	NONE SPECIFIED	UNK		AEG Sevilla
23069 SERIES	DC STARTER GENERATOR	LEAR SIEGLER	C-212		AEG Sevilla
23078-003	DC STARTER GENERATOR	LUCAS AEROSPACE/LSI	Hawker	24	AEG Sevilla
23078-003-1	DC STARTER GENERATOR	LUCAS AEROSPACE/LSI	Hawker	24	AEG Sevilla
23078-005	DC STARTER GENERATOR	LUCAS AEROSPACE/LSI	Hawker/Merlin	24	AEG Sevilla
23078-005-1	DC STARTER GENERATOR	LUCAS AEROSPACE/LSI	Hawker	24	AEG Sevilla
23078-006	DC STARTER GENERATOR	LUCAS AEROSPACE/LSI	Hawker,Cessna	24	AEG Sevilla
23078-007	DC STARTER GENERATOR	GOODRICH MONROE	Hawker	24-30-06,24	AEG Sevilla
23078-008	DC STARTER GENERATOR	LUCAS AEROSPACE/LSI	Hawker	24	AEG Sevilla
23078-009	DC STARTER GENERATOR	LUCAS AEROSPACE/LSI	Hawker/Ember	24	AEG Sevilla
23078-010	DC STARTER GENERATOR	GOODRICH MONROE	Hawker,1900,Cessna,Caravan	72, 80	AEG Sevilla
23078-011	DC STARTER GENERATOR	LUCAS	Hawker,1900,Cessna,Caravan	72, 80	AEG Sevilla
23078-012	DC STARTER GENERATOR	GOODRICH MONROE	Hawker,1900,Cessna,Caravan	72, 80	AEG Sevilla
23078-020	STARTER GENERATOR	GOODRICH MONROE	Hawker,1900,Cessna,Caravan	72, 80	AEG Sevilla
23088-XXX	DC Starter-Generator			24-30-20	AEG Sevilla
2311M-113	Windshield Wiper Motor			30-42-06	AEG Sevilla
2311M-95	Windshield Wiper Motor			30-42-10	AEG Sevilla
2311M-96	Windshield Wiper Motor			30-42-10	AEG Sevilla
2311M-97	Windshield Wiper Motor			30-42-10	AEG Sevilla
2312M-41	Windshield Wiper Converter Assembly			30-43-03	AEG Sevilla
2313M-227-1	Windshield Wiper Motor-Converter			30-40-12	AEG Sevilla
2313M-227-2	Windshield Wiper Motor-Converter			30-40-12	AEG Sevilla
2313M-248-1	Windshield Wiper Motor-Converter Assembly		B747	30-40-01	AEG Sevilla
2313M-340-2	Windshield Wiper Motor-Converter		CRJ Regional Jet-200	30-40-10	AEG Sevilla
2313M-341-2	Windshield Wiper Motor-Converter		CRJ Regional Jet-200,CRJ-700	30-40-10	AEG Sevilla
2315M08-2	Blade Assy			30-44-06	AEG Sevilla
2315M-84-2	Windshield Wiper Blade Assembly			30-44-08	AEG Sevilla

233T3235-1007	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1010	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1011	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1012	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1013	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1015	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-11	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-12	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-13	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-1300	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1301	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1302	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1303	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1304	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1305	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1306	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-1307	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8757,8767	28-22-52	AEG Sevilla
233T3235-15	FUEL MANAGEMENT PANEL ASSY M10055	THE BOEING	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-17	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-20	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-21	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-23	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-300	FUEL MANAGEMENT PANEL ASSY M10055	THE BOEING	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-301	FUEL MANAGEMENT PANEL ASSY M10055	THE BOEING	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-5	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8737,8757,8767	28-22-52	AEG Sevilla
233T3235-7	FUEL MANAGEMENT PANEL ASSY M10055	BAE SYSTEMS	8737,8757,8767	28-22-52	AEG Sevilla
234100-100	Pitch Feel Trim Assembly		(DHC)Dash 8-Q400	27-32-01	AEG Sevilla
234200-106	Pitch Feel, Electromechanical Linear actuator		(DHC)Dash 8-Q400	27-32-02	AEG Sevilla
234200-107	Pitch Feel, Electromechanical Linear actuator		(DHC)Dash 8-Q400	27-32-02	AEG Sevilla
234200-108	Pitch Feel, Electromechanical Linear actuator		(DHC)Dash 8-Q400	27-32-02	AEG Sevilla
234200-109	Pitch Feel, Electromechanical Linear actuator		(DHC)Dash 8-Q400	27-32-02	AEG Sevilla
234300-103	Rudder Feel Trim Unit Assembly		(DHC)Dash 8-Q400	27-22-01	AEG Sevilla
234400-101	Aileron Feel Trim and Centering Assembly				AEG Sevilla
234500-103	Aileron Trim, Electromechanical Linear Actuator		(DHC)Dash 8-Q400		AEG Sevilla
234600-103	Pitch Trim Electromech. Lin. Act.		(DHC)Dash 8-Q400	27-32-03	AEG Sevilla
234600-104	Pitch Trim Electromech. Lin. Act.		(DHC)Dash 8-Q400	27-32-03	AEG Sevilla
234600-105	Pitch Trim Electromech. Lin. Act.		(DHC)Dash 8-Q400	27-32-03	AEG Sevilla
234700-103	Rudder Trim, Electromechanical Linear Actuator		(DHC)Dash 8-Q400	27-22-02	AEG Sevilla
23801025-511	STRUT ASSEMBLY	ROHR		71,71-10-62	AEG Sevilla
244-642-3	CARRIER LINING	GOULD/FAIRCHILD MAGNET GRAVE	UNK		AEG Sevilla
2-459-06	Incandescent Lamp Dimmer		B747,B747-200,B757,B767,CRJ-700	33-09-01	AEG Sevilla
250591 SERIES	STARTER GENERATOR		BEECH		AEG Sevilla
251A1240-3	ACTUATOR FLIGHT SPOILER	BOEING	B737	27-60-42	AEG Sevilla
251A1240-5	SPERRY FLIGHT POWER CONTROL UNIT	BOEING	B737	27-60-42	AEG Sevilla
251A1240-6	SPERRY FLIGHT POWER CONTROL UNIT	BOEING	B737	27-60-42	AEG Sevilla
251A1270-4	SPERRY FLIGHT POWER CONTROL UNIT	BOEING	737	27-60-42	AEG Sevilla
251A1270-5	SPERRY FLIGHT POWER CONTROL UNIT	BOEING	737	27-60-42	AEG Sevilla
251A1270-6	SPERRY FLIGHT POWER CONTROL UNIT	BOEING	737	27-60-42	AEG Sevilla
251A1510-3	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	BOEING	737	27-62-71	AEG Sevilla
2524057-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524088-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524115-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524120-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524148-3	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524158-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524164-2	FLOW DIVIDERS	PRECISION AIRMOTIVE	E-26 TAMIZ		AEG Sevilla
2524166-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524172-2	FLOW DIVIDERS	PRECISION AIRMOTIVE	E-26 TAMIZ		AEG Sevilla
2524177-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524188-1	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524218-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524219-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524220-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524221-2	FLOW DIVIDERS	PRECISION AIRMOTIVE	E-26 TAMIZ		AEG Sevilla
2524222-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524223-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524224-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524225-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524226-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524227-2	FLOW DIVIDERS	PRECISION AIRMOTIVE	E-26 TAMIZ		AEG Sevilla
2524240-2	FLOW DIVIDERS	PRECISION AIRMOTIVE	E-26 TAMIZ		AEG Sevilla
2524248-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524265-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524302-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524327-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524342-2	FLOW DIVIDERS		E-26 TAMIZ		AEG Sevilla
2524397-2	FLOW DIVIDERS	PRECISION AIRMOTIVE	E-26 TAMIZ		AEG Sevilla
2524416-2	FLOW DIVIDERS	PRECISION AIRMOTIVE	E-26 TAMIZ		AEG Sevilla
2524421-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524571-2	FLOW DIVIDERS	PRECISION AIRMOTIVE	E-26 TAMIZ		AEG Sevilla
2524586-2	FLOW DIVIDERS	BENDIX	E-26 TAMIZ		AEG Sevilla
2524610-2	FLOW DIVIDERS	PRECISION AIRMOTIVE	E-26 TAMIZ		AEG Sevilla
2527110-3	ROD		B737		AEG Sevilla
2530-1	Temperature Switch and Associated valves	BOEING	CRJ Regional Jet-200,CRJ Regional Jet-100,Challenger,40E,Challenger,800	27-31-64	AEG Sevilla
25615C27A26A1	INDICATOR PRESSURE		UNK		AEG Sevilla
256A3351-1	FLAP ACTUATION GEARBOX ASSEMBLY	BOEING	8737-600,8737-683,8737	27-55-87	AEG Sevilla
256A3351-2	FLAP ACTUATION GEARBOX ASSEMBLY	BOEING	8737-600,8737-86N,8737	27-55-87	AEG Sevilla
256A3351-3	FLAP ACTUATION GEARBOX ASSEMBLY	BOEING	8737-600,8737	27-55-87	AEG Sevilla
256A3351-4	FLAP ACTUATION GEARBOX ASSEMBLY	BOEING	8737-600,8737	27-55-87	AEG Sevilla
2588420-906	FLIGHT DIRECTOR CTRL	SPERRY/HONEYWELL	B737	34-22-06	AEG Sevilla
2593604-222	CONTROL-FLIGHT DIRECTOR	HONEYWELL	C-212	34-28-01	AEG Sevilla
2594618-901	INDICATOR TRUE	SPERRY FLIGHT SYSTEMS (HONEYWELL)	MD80,MD-11DC,CRJ-900,B737-200,B737-300,B737-400,CRJ-100,CRJ-900	34-14-08	AEG Sevilla
26-1000-250G	TRANSMITTER,PRESSUR		UNK		AEG Sevilla
26101389	EMERGENCY LOCATOR TRANSMITTER SYSTEM,M.M.E.T.E.I.	SPERRY/HONEYWELL	C-235	34	AEG Sevilla
26-3338	Electrohydraulic Servo Valve Assembly			27-60-07	AEG Sevilla
2634-1	Hydraulic Bleed / Relief Valve			29-13-33	AEG Sevilla
2670288-4	MANUALLY OPERATED GEAR SEQUENCE VALVE	PARKER	B747-400,B747-100,B737,8757,8747	32-30-20	AEG Sevilla
2670288-5	MANUALLY OPERATED GEAR SEQUENCE VALVE	PARKER	B747-400,B747-100,B737,8757,8747	32-30-20	AEG Sevilla
2670288-6	MANUALLY OPERATED GEAR SEQUENCE VALVE	PARKER	B747-100,B737,8757,8747,B747-400,B737-200	32-30-20	AEG Sevilla
2670288-7	MANUALLY OPERATED GEAR SEQUENCE VALVE	PARKER HANNIFIN	F100,B747-100,B737,8757,8747,B747-400	32-30-20	AEG Sevilla
2670288-8	MANUALLY OPERATED GEAR SEQUENCE VALVE	PARKER	F100,B737,8757,8747	32-30-20	AEG Sevilla
2670288-9	MANUALLY OPERATED GEAR SEQUENCE VALVE ASSEMBLY	PARKER HANNIFIN	8737,8757,8747	32-30-20	AEG Sevilla
268263-138	AC GENERATOR		UNK		AEG Bilbao
27000-3-5-7	Spoiler Power Control Unit Assembly			27-62-01	AEG Sevilla
27001-3	Electro hydraulic Servo valve Assembly			27-60-07	AEG Sevilla
2704202-1	ALTERNATING CURRENT GEARED MOTOR	HONEYWEL	CRJ-700,B747-400,B747	27-80-08,27	AEG Sevilla
2704202-2	ALTERNATING CURRENT GEARED MOTOR	HONEYWEL	8747-400,B747	27-80-08,27	AEG Sevilla
2704202-3	ALTERNATING CURRENT GEARED MOTOR	HONEYWEL	CRJ-700,B747-400,B747	27-80-08,27	AEG Sevilla
2704202-4	ALTERNATING CURRENT GEARED MOTOR	HONEYWEL	CRJ-700,B747-400,B747-100,B747	27-80-08,27	AEG Sevilla
2704202-5	ALTERNATING CURRENT GEARED MOTOR	HONEYWEL	8737,8747-400,B747-100,B747	27-80-08,27,27-60,3	AEG Sevilla
2704442-3	DIRECT CURRENT MOTOR	ALLIEDSIGNAL	GTCP331-500B,B747,B777	49-42-02	AEG Bilbao
2704442-4	DIRECT CURRENT MOTOR	ALLIEDSIGNAL	GTCP331-500B,B747,B777	49-42-02	AEG Bilbao
2704442-5	DIRECT CURRENT MOTOR	ALLIEDSIGNAL	GTCP331-500B,B747,B777-200,B777	49-42-02	AEG Bilbao
2704458-1-1	Engine Starter Motor		CRJ Regional Jet-100	49-41-14	AEG Sevilla
2704506-1	MOTOR-STARTER	HONEYWELL	CRJ Regional Jet-100	49-41-20	AEG Sevilla
2704506-2	MOTOR-STARTER	HONEYWELL	AS38,GTCP151-9A,AS320-300,AS320-300,CRJ-900,CRJ-100	49-42-51	AEG Sevilla
2704506-3	MOTOR-STARTER	HON	AS38,AS21A319,AS320	49-41-20	AEG Sevilla
2704506-4	MOTOR-STARTER	HONEYWELL	AS38,AS21A319,AS320	49	AEG Sevilla
2704506-5	MOTOR-STARTER	HONEYWELL ENGINES SYSTEME	AS320		AEG Sevilla

2707905-3	HOUSING ASSY STATOR	AIRESEARCH	UNK		AEG Bilbao
2709955-1	ARMATURE ASSY	ALLIED SIGNAL	GTCPS33-500B.B777	49	AEG Bilbao
2709969-1	FRONT END BELL ASSEMBLY	UNKNCOOWN	UNK	49	AEG Bilbao
27-1000-4000SG	TRANSMITER	KULITE	C-295.CN-235	29	AEG Sevilla
2710772-1	FIELD	HONEYWELL	A300	49-41-22	AEG Bilbao
27256-1-3-5	Connecting Arm Assembly Aileron P.C.U			27-14-02	AEG Sevilla
2730489M1	Light-Weight Accumulator		Dash 8.B737		AEG Sevilla
273A120-1	WASHER	BOEING	B737	32	AEG Sevilla
273A120-2	NUT	BOEING	B737	32	AEG Sevilla
273A120-3	NUT	BOEING	B737	32	AEG Sevilla
273A120-4	NUT	BOEING	B737	32	AEG Sevilla
273A120-5	NUT	UNKNCOOWN	B737	32	AEG Sevilla
273A121-1	PIN	BOEING	B737	32	AEG Sevilla
273A121-2	PIN	BOEING	B737	32	AEG Sevilla
273A121-3	PIN	BOEING	B737	32	AEG Sevilla
273A121-4	PIN	BOEING	B737	32	AEG Sevilla
273A122-1	NUT	BOEING	B737	32	AEG Sevilla
273A125-1	RETAINER	BOEING	B737	32	AEG Sevilla
273A210-10	MLG RETRACT ACTUATOR ASSEMBLY	BOEING	B737	32-32-37	AEG Sevilla
273A210-101	MLG RETRACT ACTUATOR ASSEMBLY	THE BOEING	B737	32-32-37	AEG Sevilla
273A210-1	MLG RETRACT ACTUATOR ASSEMBLY	BOEING	B737	32-32-37	AEG Sevilla
273A210-3	MLG RETRACT ACTUATOR ASSY	BOEING	B737	32-32-37	AEG Sevilla
273A210-4	MLG RETRACT ACTUATOR ASSEMBLY	BOEING	B737	32-32-37	AEG Sevilla
273A210-5	MLG RETRACT ACTUATOR ASSEMBLY	BOEING	B737	32-32-37	AEG Sevilla
273A210-6	MLG RETRACT ACTUATOR ASSEMBLY	BOEING	B737	32-32-37	AEG Sevilla
273A210-7	MLG RETRACT ACTUATOR ASSEMBLY	BOEING	B737	32-32-37	AEG Sevilla
273A210-8	MLG RETRACT ACTUATOR ASSEMBLY	BOEING	B737	32-32-37	AEG Sevilla
273A210-9	MLG RETRACT ACTUATOR ASSEMBLY	BOEING	B737	32-32-37	AEG Sevilla
273A2310-1	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
273A2501-1	ACTUATOR	BOEING	B737-900.B737-800.B737-700.B737-600.B737.6737.6737.6737	32-32-42	AEG Sevilla
273A3610-1	MAIN GEAR SHIMMY DAMPER ASSEMB	BOEING	B737	32-30-62	AEG Sevilla
273A3610-2	MAIN GEAR SHIMMY DAMPER ASSEMB	BOEING	B737	32-30-62	AEG Sevilla
273A3610-3	MAIN GEAR SHIMMY DAMPER ASSEMB	BOEING	B737	32-30-62	AEG Sevilla
273A3610-4	MAIN GEAR SHIMMY DAMPER ASSEMB	BOEING	B737	32-30-62	AEG Sevilla
273A3610-5	MAIN GEAR SHIMMY DAMPER ASSEMB	BOEING	B737	32-30-62	AEG Sevilla
273A3610-6	MAIN GEAR SHIMMY DAMPER ASSEMB	BOEING	B737	32	AEG Sevilla
273A3610-7	MAIN GEAR SHIMMY DAMPER ASSEMB	BOEING	B737	32-30-62	AEG Sevilla
273N2000-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING	B777.B757-200.B757	32-32-05	AEG Sevilla
273N2000-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING	B777.B757-200.B757	32-32-05	AEG Sevilla
273N2000-7	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING	B777.B757-200.B757	32-32-05	AEG Sevilla
273N2000-8	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING	B777.B757-200.B757	32-32-05	AEG Sevilla
273N2006-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING	B777.B757-200.B757	32-32-05	AEG Sevilla
273N2006-2	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING	B777.B757-200.B757	32-32-05	AEG Sevilla
273N2006-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING	B777.B757-200.B757	32-32-05	AEG Sevilla
273N2006-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	BOEING	B777.B757-200.B757	32-32-05	AEG Sevilla
273N2006-5	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	THE BOEING	B777.B757-200.B772.B757	32-32-05	AEG Sevilla
273T102-8	ACTUATOR	BOEING	B767-200.B767	32-32-00	AEG Sevilla
273T412-4	ACTUATOR NLG RETRACT	BOEING	B767-200.B767.B767	32-34-00	AEG Sevilla
27400-1-5	Rudder Power Control Unit Assembly			27-23-01	AEG Sevilla
2-7460-5	ANTI SKID	SMITHS AEROSPACE	B747, B747-400, B757, B767, B737		AEG Sevilla
2-7460-SERIES	MODULE, ANTI-SKID SHUTTLE DISCONNECT	#N/D	B767		AEG Sevilla
274N1003-10	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12	AEG Sevilla
274N1003-13	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12	AEG Sevilla
274N1003-15	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12	AEG Sevilla
274N1003-4	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12	AEG Sevilla
274N1003-5	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12	AEG Sevilla
274N1003-6	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12	AEG Sevilla
274N1003-7	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12	AEG Sevilla
274N1003-8	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12	AEG Sevilla
274N1028-4	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12	AEG Sevilla
274N1028-5	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12, 32-41-14	AEG Sevilla
274N1028-6	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-12, 32-41-14	AEG Sevilla
274U0003-4	BRAKE ACCUMULATOR ISOLATION VA	BOEING	B737	32-41-10	AEG Sevilla
274U0003-8	BRAKE ACCUMULATOR ISOLATION VA	VALVE	B737	32-41-10	AEG Sevilla
275N1211-2	NLG STEERING ACTUATOR	BOEING	B757-200,B777,B757	32-51-15	AEG Sevilla
275T6221-1	NOSE GEAR STEERING ACTUATOR ASSEMBLY	BOEING	B767-200,B737,B767	32-51-10	AEG Sevilla
275T6221-2	NOSE GEAR STEERING ACTUATOR ASSEMBLY	BOEING	B767-200,B767	32-51-10	AEG Sevilla
275T6221-3	STEERING ACTUATOR	THE BOEING	B767-200,B737,B767	32-51-10	AEG Sevilla
27600-3	Elevator Power Control Unit Control Unit		CRJ Regional Jet-200,CRJ Regional Jet-300,ERJ-145,CRJ-900	27-33-01	AEG Sevilla
2760131-101	Floater Valve			28-20-17	AEG Sevilla
2760131-102	Floater Valve			28-20-17	AEG Sevilla
2760131-103	Floater Valve			28-20-17	AEG Sevilla
2-7679-1	FUSE ASSEMBLY, FLOW RATE	TRIUMPH ACTUATION SYSTEMS, WILMINGTON, WYOMING, TRIUMPH ACTUATION SYSTEMS, WYOMING	B-747, B-767, B-777		AEG Sevilla
2-7679-2	FUSE ASSEMBLY, FLOW RATE	TRIUMPH ACTUATION SYSTEMS, WYOMING	B-747, B-767, B-777		AEG Sevilla
2-7680-1	FLOW RATE FUSE ASSEMBLY	#N/D	B737-200, B737-300, B737-400, B737-500		AEG Sevilla
2-7680-2	FLOW RATE FUSE ASSEMBLY	SMITHS AEROSPACE	B737-200, B737-300, B737-400, B737-500		AEG Sevilla
2-7681-1	FLOW RATE FUSE ASSEMBLY	SMITHS	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	27-32-03	AEG Sevilla
2-7681-2	FLOW RATE FUSE ASSEMBLY	SMITHS AEROSPACE	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	27-32-03	AEG Sevilla
2770082-101	Refueling Adapter			28-20-19	AEG Sevilla
2770537-103	Rudder Power Control Unit			27-20-01	AEG Sevilla
2770537-104	Rudder Power Control Unit			27-20-01	AEG Sevilla
2770537-105	Rudder Power Control Unit			27-20-01	AEG Sevilla
2770537-106	Rudder Power Control Unit			27-20-01	AEG Sevilla
2770537-107	Rudder Power Control Unit			27-20-01	AEG Sevilla
2770537-108	Rudder Power Control Unit			27-20-01	AEG Sevilla
2770537-109	Rudder Power Control Unit			27-20-01	AEG Sevilla
2770537-110	Rudder Power Control Unit			27-20-01	AEG Sevilla
2-7735-1	HYDRAULIC FUSE	SMITHS	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-40-13	AEG Sevilla
2-7736-1	HYDRAULIC FUSE, NOSE GEAR	GE	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-40-14	AEG Sevilla
2-7737-1	BRAKES HYDRAULIC FUSE ASSY	SMITHS	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-40-15	AEG Sevilla
2-7756-1	HYDRAULIC FUSE	SMITHS AEROSPACE	B767	32-31-03	AEG Sevilla
27800-3	Ground Spoiler Actuator Assembly		CRJ Regional Jet-100,AS00,MD-11,ATR, B737, B767, CRJ, E175, Embraer, etc.	27-63-01	AEG Sevilla
2780491-105	Vent Valve			28-20-20	AEG Sevilla
2780491-107	Vent Valve			28-20-20	AEG Sevilla
2780491-109	Vent Valve			28-20-20	AEG Sevilla
2780491-111	Vent Valve			28-20-20	AEG Sevilla
2780491-113	Vent Valve			28-20-20	AEG Sevilla
2780491-115	Vent Valve			28-20-20	AEG Sevilla
2780491-117	Vent Valve			28-20-20	AEG Sevilla
2780491-119	Vent Valve			28-20-20	AEG Sevilla
2780491-121	Vent Valve			28-20-20	AEG Sevilla
2-7807-1	FUSE AY	SMITHS	B767,B737	29	AEG Sevilla
27A10614-101-11	ACCUMULATORS	TELEDYNE	B777	29	AEG Sevilla
2-8011-1	FUSE ASSEMBLY, FLOW RATE	GE	B777-200,B777	32-34-02	AEG Sevilla
2-8020-1	FUSE: VOLUMETRIC	SMITHS	B767,B737-900,B737-800,B737-700,B737-600,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-11	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-12	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-13	HYDRAULIC FUSE	SMITHS INDUSTRIES	B767,B737-900,B737-800,B737-700,B737-600,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-14	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-15	HYDRAULIC FUSE	SMITHS INDUSTRIES	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-16	HYDRAULIC FUSE, NOSE GEAR	SMITHS	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-18	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-2	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B767,B737-900,B737-800,B737-700,B737-600,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-24	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-500,B737-400,B737-300,B737-200,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-25	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-900,B737-800,B737-700,B737-600,B737.6737.6737.6737	32-31-01	AEG Sevilla
2-8020-26	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-800,B737-600,B737-500,B737-400,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-27	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-900,B737-800,B737-700,B737-600,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-28	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-900,B737-800,B737-700,B737-600,B737.6737.6737.6737	32-31-04	AEG Sevilla
2-8020-29	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B737-900,B737-800,B737-700,B737-600,B737.6737.6737.6737	32-31-04	AEG Sevilla

2-8020-3	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B767/B757-900/B757-800/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	32-31-04	AEG Sevilla
2-8020-5	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B767/B757-900/B757-800/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	32-31-04	AEG Sevilla
2-8020-6	FUSE ASSEMBLY QUANTITY MEASURING	SMITHS	B767/B757-900/B757-800/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	32-31-04	AEG Sevilla
2-8041-1	ANTISKID VOLUMETRIC FUSE ASSEMBLY	SMITHS	B767/B757-900/B757-800/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	32-40-18	AEG Sevilla
2810044-101	Check Valve		CRJ Regional Jet-2810 CRJ Regional Jet-300A	28-27-04	AEG Sevilla
28107-1	SERVO INTERFACE		UNK		AEG Sevilla
2-8117-3	Fuse Assembly, Quantity Measuring		B777,CRJ-700		AEG Sevilla
2-8181-2	FUSE ASSEMBLY, FLOW RATE	GE AVIATION SYSTEMS	B777,A340,A330	29-11-01	AEG Sevilla
28SN0412	HANDESET ASSY	BAE SYSTEMS	B737	23-31-01	AEG Sevilla
28SN0412-1	ATTENDANT HANDESET ASSY	BAE SYSTEMS	B727,B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-10	ATTENDANT HANDESET	THE BOEING	B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-2	ATTENDANT HANDESET	THE BOEING	B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-28	ATTENDANT HANDESET	THE BOEING	B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-29	ATTENDANT HANDESET	THE BOEING	B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-3	ATTENDANT HANDESET ASSY	THE BOEING	B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-30	ATTENDANT HANDESET	THE BOEING	B777,B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-4	ATTENDANT HANDESET	THE BOEING	B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-8	ATTENDANT HANDESET ASSY	THE BOEING	B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-9	ATTENDANT HANDESET ASSY	THE BOEING	B757,B737,B767	23-42-64	AEG Sevilla
28SN0412-XX	ATTENDANT HANDESET	BAE SYSTEMS	757	23-42-64	AEG Sevilla
28ST0001-207	AUDIO ACCESSORY UNIT	THE BOEING	B767,B757	23-42-68	AEG Sevilla
28ST0001-209	AUDIO ACCESSORY UNIT	THE BOEING	B767,B757	23-42-68	AEG Sevilla
28ST0001-77	AUDIO ACCESSORY UNIT	THE BOEING	B767,B757	23-42-61	AEG Sevilla
28ST0001-102	CSEU POWER SUPPLY	THE BOEING	B747-200,B757,B767,B747	27-09-56	AEG Sevilla
28ST0001-103	CSUPHRSUPPLYMOD	THE BOEING	B747-200,B767,B747,B757	27-09-56	AEG Sevilla
28ST0001-104	CSEU POWER SUPPLY	THE BOEING	B747-200,B767,B747,B757,B747-400,B767-200,B767	27-09-57	AEG Sevilla
28ST0001-104 MOD A	CSEU POWER SUPPLY	BAE SYSTEMS	B767,B757,B747,B737	27-09-57	AEG Sevilla
28ST0001-104 MOD AE	CSEU POWER SUPPLY	BAE SYSTEMS	B767,B757	27-09-57	AEG Sevilla
28ST0001-104 MOD B	CSEU POWER SUPPLY	BAE SYSTEMS	B767,B757,B747,B737	27-09-57	AEG Sevilla
28ST0001-201	CSEU POWER SUPPLY ASSEMBLY	THE BOEING	B767,B747,B757-200,B757	27-09-58	AEG Sevilla
28ST0001-201 MOD A	CSEU POWER SUPPLY ASSEMBLY	BAE SYSTEMS	B767,B757,B747		AEG Sevilla
28ST0022-51	AUDIO PANEL CONTROL	THE BOEING	A320,B767,B757	23	AEG Sevilla
28ST0022-51 MOD A	AUDIO PANEL CONTROL	BAE SYSTEMS	B767,B757	23	AEG Sevilla
28ST0022-51 MOD AB	AUDIO PANEL CONTROL	BAE SYSTEMS	A320,B767,B757	23	AEG Sevilla
28ST0024-18	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-19	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-20	MODULE ASSY PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-21	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-22	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-23	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-24	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-25	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-26	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-27	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-28	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-29	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-30	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-41	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-8	PILOT CALL PANEL	BAE SYSTEMS	B767,B757	23-42-59	AEG Sevilla
28ST0024-9	PILOT CALL PANEL	BOEING	B737-900/B757-900/B757-700/B757-400/B757-300/B757-200/B757-100/B757-00	23-42-59	AEG Sevilla
28ST0024-SERIES	PILOT CALL PANEL MODULE ASSEMBLY	BOEING	B767,B757	23-42-59	AEG Sevilla
28ST0033-23	Warning Electronics Unit Stall Warning Printed Circuit Assembly	BAE SYSTEMS	B767,B757	27-32-51	AEG Sevilla
28ST0033-29	Warning Electronics Unit Stall Warning Printed Circuit Assembly	BAE SYSTEMS	B767,B757	27-32-51	AEG Sevilla
28ST0033-SERIES	Warning Electronics Unit Stall Warning Printed Circuit Assembly	BOEING	B767,B757		AEG Sevilla
28ST0035-10	MODULE WEU POWER SUPPLY	BAE SYS	DC-9,DC-8,B727,B767,B757,B747	31-51-20	AEG Sevilla
28ST0035-10 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYSTEMS	B747,B767	31-51-20	AEG Sevilla
28ST0035-10 MOD AB	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYSTEMS	B747,B767	31	AEG Sevilla
28ST0035-10A	WARNING ELECTRONIC UNIT POWER SUPPLY	BAE SYSTEMS	767		AEG Sevilla
28ST0035-10AB	WARNING ELECTRONIC UNIT POWER SUPPLY	BAE SYSTEMS	767		AEG Sevilla
28ST0035-11	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYS	B767,B757,B747	31-51-20	AEG Sevilla
28ST0035-11 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYSTEMS	B747,B767	31-51-20	AEG Sevilla
28ST0035-11 MOD AB	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYSTEMS	B747,B767	31	AEG Sevilla
28ST0035-11AB	WARNING ELECTRONIC UNIT POWER SUPPLY	BAE SYSTEMS	767		AEG Sevilla
28ST0035-3	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYS	B747,B767,B757	31-51-20	AEG Sevilla
28ST0035-3 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYSTEMS	767	31-51-20	AEG Sevilla
28ST0035-3A	WARNING ELECTRONIC UNIT POWER SUPPLY	BAE SYSTEMS	767		AEG Sevilla
28ST0035-9	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYS	MD-80-83,B767,B757,B747	31-51-20	AEG Sevilla
28ST0035-9 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYSTEMS	B747,B767	31-51-20	AEG Sevilla
28ST0035-9 MOD AB	WARNING ELECTRONIC UNIT POWERSUPPLY	BAE SYSTEMS	B747,B767	31	AEG Sevilla
28ST0035-9A	WARNING ELECTRONIC UNIT POWER SUPPLY	BAE SYSTEMS	767		AEG Sevilla
28ST0035-9AB	WARNING ELECTRONIC UNIT POWER SUPPLY	BAE SYSTEMS	767		AEG Sevilla
28ST0093-11	PACK FLOW CONTROL PCB	BAE SYSTEMS	B757,B767	21-51-52	AEG Sevilla
28ST0093-11 MOD A	PACK FLOW CONTROL PCB	BAE SYSTEMS	B767	21-51-52	AEG Sevilla
28ST0093-11A	PACK FLOW CONTROL PCB	BAE SYSTEMS	767	21-51-52	AEG Sevilla
28ST0093-8	PACK FLOW CONTROL PCB	BOEING	B757,B767	21-51-52	AEG Sevilla
28ST0096-13	ELECTRONIC ENGINE CONTROL DISCRETE	BOEING	B747-200,B767	75-21-51	AEG Sevilla
28ST0096-17	ELECTRONIC ENGINE CONTROL DISCRETE	BOEING	B747,B767,B757	75-25-51	AEG Sevilla
28ST0096-5	ELECTRONIC ENGINE CONTROL DISCRETE	BOEING	B767,B757	75-21-51	AEG Sevilla
28ST0096-7	PC ASSY-ECC	BAE	B767,B747,B757	75-21-51	AEG Sevilla
28ST0471-17	PC AY	BAE SYSTEMS	B767		AEG Sevilla
28ST0496-1	ECAS DPL SWITCH MODUL	THE BOEING	B757,B767	31-41-52	AEG Sevilla
28ST0553-1	ILS CONTROL PANEL	BOEING	B767,B757	34-31-61	AEG Sevilla
28ST0553-2	ILS CONTROL PANEL	BOEING	B767,B757	34-31-61	AEG Sevilla
28ST0553-3	ILS CONTROL PANEL	BAE SYSTEMS	B767,B757	34-31-61	AEG Sevilla
28ST0553-4	ILS CONTROL PANEL	BOEING	B767,B757	34-31-61	AEG Sevilla
28ST0554-SERIES	VOR CONTROL PANEL		757, 767		AEG Sevilla
28ST0554-3	VOR CONTROL PANEL	THE BOEING	B767,B757	34-51-61	AEG Sevilla
28ST0554-3 MOD. A	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-3 MOD. B	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-3 MOD. C	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-3 MOD. D	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-3 MOD. E	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-3A	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-3B	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-3C	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-3D	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-3E	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-4	VOR CONTROL PANEL	THE BOEING	B767,B757	34-51-61	AEG Sevilla
28ST0554-4A	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-5	VOR/DME CONTROL PANEL	THE BOEING	B767,B757	34-51-61	AEG Sevilla
28ST0554-5 MOD. A	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-5 MOD. B	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-5 MOD. C	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-5 MOD. D	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-5 MOD. E	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-5A	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-5B	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-5C	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-5D	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-5E	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-6	VOR CONTROL PANEL	THE BOEING	B757-200,B767,B757	34-51-61	AEG Sevilla
28ST0554-6 MOD. A	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-6 MOD. AB	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0554-6A	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-6AB	VOR CONTROL PANEL	BOEING	757, 767		AEG Sevilla
28ST0554-6B	VOR CONTROL PANEL	BAE SYSTEMS	757, 767		AEG Sevilla
28ST0557-1	ADF CONTROL PANEL	BOEING	B767,B757	34-57-62	AEG Sevilla
28ST0557-2	ADF CONTROL PANEL	BOEING	A320,B727,B767,B757	34-57-92	AEG Sevilla
28ST0852	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	UNK		AEG Sevilla

285T0852-1	KEYPAD COCKPIT DOOR ACCESS	THE BOEING	B737-300,B747-300,B737-500,B737-800,B737-900,B737-900ER	52-51-03	AEG Sevilla
285T0852-1 MOD A	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	B737-300,B747-300	52-51-03	AEG Sevilla
285T0852-1 MOD AB	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	B737-300,B747-300	52-51-03	AEG Sevilla
285T0852-1A	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	UNK	52-51-03	AEG Sevilla
285T0852-1B	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	UNK	52-51-03	AEG Sevilla
285T0855-1	CONTROLLER DOOR ACCESS	BOEING	B747-200,B737-900,B737-800,B737-700,B737-500,B737-300,B737-200	52-51-04	AEG Sevilla
285T0855-5	CONTROLLER FDAS	BOEING	B737-300,B747-300	52-51-04	AEG Sevilla
285T0855-6	FLIGHT DECK ACCESS SYSTEM CONTROLLER	BAE SYSTEMS	B777	52-51-04	AEG Sevilla
285T104-1	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-10	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-11	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-13	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-15	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-17	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-17 MOD B	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-17 MOD BC	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-17 MOD C	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-17B	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-17C	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-18	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-18 MOD A	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-18 MOD AB	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-18 MOD B	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-18A	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-18AB	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-18B	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-19	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-21	WARNING ELECTRONIC UNIT STALL WARN/WIND	BOEING	B757,B767	27-32-52	AEG Sevilla
285T104-22	PC ASSY - STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-23	WARNING ELECTRONIC UNIT STALL WARN/WIND	BOEING	B757,B767	27-32-52	AEG Sevilla
285T104-24	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B757,B767	27-32-52	AEG Sevilla
285T104-9	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
285T104-SERIES	WARNING ELECTRONIC UNIT STALL WARN/WIND	BAE SYSTEMS	B-767,B-757	27-32-52	AEG Sevilla
2890022-101	Vent Relief Valve		C-130		AEG Sevilla
2890022-102	Vent Relief Valve		C-130		AEG Sevilla
289545-7	GENERATOR	HONEYWELL	B737-600,B737-500,B737-400,B737-300	49-41-21	AEG Bilbao
289545-7A	STARTER GENERATOR	S-GEN	B737,CFM56-7B,LEAP-1B	49-41-21	AEG Sevilla
289545-7B	STARTER GENERATOR	HONEYWELL	B737,CFM56-7B,LEAP-1B	49-41-21	AEG Sevilla
289545-9	STARTER/GENERATOR	HONEYWELL	B737-600,B737,CFM56-7B,LEAP-1B	49-41-21	AEG Sevilla
289556-1	AC GENERATOR	HONEYWELL	UNK		AEG Bilbao
289556-1-A	AC GENERATOR		UNK		AEG Bilbao
289556-1-B	AC GENERATOR		UNK		AEG Bilbao
289556-1-C	AC GENERATOR		UNK		AEG Bilbao
289556-1-D	AC GENERATOR		UNK		AEG Bilbao
289556-1-E	AC GENERATOR		UNK		AEG Bilbao
29-1205246-00	DELAY VALVE	MESSIER-DOWTY	A340	32-30-98	AEG Sevilla
2940025-102	Engine Feed Shutoff Valve			28-21-29	AEG Sevilla
2940049-102	Aft Tank Refuel Shutoff Valve			28-23-33	AEG Sevilla
2944T100-SERIES	POWER DRIVE UNIT	TELAIR	A319, A320, A321	25-51-18	AEG Sevilla
2955T100-SERIES	POWER DRIVE UNIT	TELAIR	A330, A340	25-51-19	AEG Sevilla
2CM353C3H	AC GEN		UNK		AEG Bilbao
2LA002607-22	Service Light		CRJ-700	33-31-12	AEG Sevilla
2LA002760-39	Strobe Light (Red)		A320,CRJ Regional Jet-200,A300,A310,A320XLR	33-42-15	AEG Sevilla
2LA005109-00	Cargo Compartment Light		A300,CRJ-700,B737	33-20-06	AEG Sevilla
2LA005111	Dome Light			33-20-08	AEG Sevilla
2LA005112	Dome Light			33-20-08	AEG Sevilla
2LA005115	Dome Emergency Light And Ceiling Light			33-52-09	AEG Sevilla
2LA005163-20	Fight Crew Reading Light		A320,CRJ Regional Jet-200,CRJ-700	33-11-22	AEG Sevilla
2LA005171-65	Passenger Service Unit		CRJ Regional Jet-200,ATR 72	33-22-11	AEG Sevilla
2LA005303-01	TAIL STROBE LIGHT	HELLA	A318,B747,A321,A330,A330-300,A340,B737-300	33-42-21	AEG Sevilla
2LA005303-05	TAIL STROBE LIGHT	HELLA	A318,A319,A320,A321,A330,A330-300,A340,B737-300	33-42-21	AEG Sevilla
2LA005308-01	WING STROBE LIGHT	HELLA	A318,A319,A320,A321,A330,A330-300,A340,B737-300	33-42-31	AEG Sevilla
2LA005308-05	WING STROBE LIGHT	HELLA	A318,A319,A320,A321,A330,A330-300,A340,B737-300	33-42-31	AEG Sevilla
2LA005414-01	Overwing Emergency Light, tow. & rearw. LH & RH		A320,CRJ Regional Jet-200,A300,A310,A320XLR	33-52-31	AEG Sevilla
2LA005467-00	Warning Light, red & Warning Light		A320-200,B737,A320,A318,A319	33-25-01	AEG Sevilla
2LA005469-00	Warning Light, white "SLIDE ARMED"		A321,A319,A320,A318	33-25-02	AEG Sevilla
2LA005938	Fight Attendant Call Light			33-25-12	AEG Sevilla
2LA006178-02	Wing Strobe Light		CRJ Regional Jet-200,C-130,CRJ-700	33-42-26	AEG Sevilla
2LA006181-01	Rear Pos. Strobe Light		A300,CRJ900 Regional Jet,CRJ Regional Jet-200	33-42-27	AEG Sevilla
2LA006181-22	Rear Pos. Strobe Light		A300,CRJ Regional Jet-200,C-130,CRJ-700	33-42-27	AEG Sevilla
2LA006419-70	Tail Light		CRJ-700,CRJ Regional Jet-200,CRJ900	33-42-28	AEG Sevilla
2LA006419-71	Tail Light		CRJ Regional Jet-200,CRJ-700,CRJ900	33-42-28	AEG Sevilla
2LA006615-22	Navigation Light		CRJ-700,B727	33-42-29	AEG Sevilla
2LA006616-22	Navigation Light		CRJ-700,B767	33-42-29	AEG Sevilla
2LA006634-11	Passenger Service Unit		CRJ Regional Jet-200,CRJ-700	33-22-11	AEG Sevilla
2LA006634-12	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Sevilla
2LA006634-21	Passenger Service Unit		B737,CRJ Regional Jet-200	33-22-11	AEG Sevilla
2LA006634-22	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Sevilla
2LA006634-31	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Sevilla
2LA006634-32	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Sevilla
2LA006634-41	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Sevilla
2LA006634-42	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Sevilla
2LA006923-70	Cargo Compartment Light		CRJ-700,F100	33-31-13	AEG Sevilla
2LA007353-45	Passenger Service Unit		CRJ-700,F100	33-32-11	AEG Sevilla
2LA08353-00	Chart Holder Light Assy, Housing Assy		B737	33-11-23	AEG Sevilla
2LA455010-00	STROBE LIGHT	GOODRICH AEROSPACE	A320,A318,A321,A319,A330,A330-300,A340,CRJ Regional Jet-200,CRJ-700,B737-300	33-42-24	AEG Sevilla
2LA455010-06	STROBE LIGHT	GOODRICH LIGHTING	A300,CRJ Regional Jet-200,A320,A310	33-42-24	AEG Sevilla
2LA455010-21	STROBE LIGHT	GOODRICH LIGHTING	A319,A300,A340,A330,A320,A310	33-42-24	AEG Sevilla
2LA455030-73	Wing Inspection Light		CRJ-700,L-1011	33-40-72	AEG Sevilla
2LA455030-74	Wing Inspection Light		CRJ-700,SAAB 340	33-40-72	AEG Sevilla
2LA455032-70	Cargo Loading Light		CRJ Regional Jet-200,CRJ-700	33-32-70	AEG Sevilla
2LA455063-70	Tail Strobe Light		CRJ-700,CRJ900 Regional Jet-900	33-42-70	AEG Sevilla
30-0191	Wing-Position Navigational Light			33-42-34	AEG Sevilla
30-0191-1	Wing-Position Navigational Light		Dash 8,DH8C,B727	33-42-34	AEG Sevilla
30-0191-10	Wing-Position Navigational Light		B727,DH8C,B737-300,B737-400,DH8C,B737-500,DH8C,B737-600,DH8C	33-42-34	AEG Sevilla
30-0191-11	Wing-Position Navigational Light		Dash 8,B727,DH8C	33-42-34	AEG Sevilla
30-0191-2	Wing-Position Navigational Light		Dash 8,B727,DH8C	33-42-34	AEG Sevilla
30-0191-5	Wing-Position Navigational Light		Dash 8,DH8C,B727	33-42-34	AEG Sevilla
30-0191-6	Wing-Position Navigational Light		Dash 8,B727,DH8C	33-42-34	AEG Sevilla
30-0191-7	Wing-Position Navigational Light		Dash 8,B727,DH8C	33-42-34	AEG Sevilla
30-0191-8	Wing-Position Navigational Light		MD-80-83,Dash 8,B727,DH8C	33-42-34	AEG Sevilla
30-0191-9	Wing-Position Navigational Light		B727,Dash 8,DH8C,Dash 8-100,CRJ,Dash 8-300,DH8C,B737-300	33-42-34	AEG Sevilla
30-0234	Wing Position Navigation Light			33-41-76	AEG Sevilla
30059-1471	BACKPLATE DAMPENER	NONE SPECIFIED	UNK		AEG Sevilla
30059-1480	PLATE DAMPENER	NONE SPECIFIED	UNK		AEG Sevilla
30076-2460	BACKPLATE DAMPENER	NONE SPECIFIED	UNK	24	AEG Sevilla
30079-2460	BACKPLATE DAMPENER		UNK		AEG Bilbao
30081-001	DC GENERATOR	SMITHS	BRASILIA	24-30-90	AEG Bilbao
30081-010	DC GENERATOR	SMITHS	BRASILIA	24-30-90	AEG Bilbao
30-0881-1	STROBE LIGHT	GRIMES AEROSPACE CO.	B737-200,B727,A300	33-48-11	AEG Sevilla
300-90496-0501	CIRCUIT CARD ASSEMBLY	BENDIX	UNK		AEG Sevilla
30-0906	STROBE LIGHT	GRIMES AEROSPACE	B737	33-40-69	AEG Sevilla
30-0906-1	STROBE LIGHT	HONEYWELL/GRIMES	B737-200,B737-500,B737-400,B737-300	33-40-69	AEG Sevilla
30-0906-10	STROBE LIGHT	HONEYWELL/GRIMES	B737-200,B737-500,B737-400,B737-300	33-40-69	AEG Sevilla
30-0906-101	STROBE LIGHT	HONEYWELL/GRIMES	B737-200,B737-500,B737-400,B737-300	33-40-69	AEG Sevilla
30-0906-103	STROBE LIGHT	HONEYWELL/GRIMES	B737-200,B737-500,B737-400,B737-300	33-40-69	AEG Sevilla
30-0906-104	STROBE LIGHT	HONEYWELL/GRIMES	B737-200,B737-500,B737-400,B737-300	33-40-69	AEG Sevilla
30-0906-105	WING POS LIGHT	HONEYWELL/GRIMES	B737-200,B737-500,B737-400,B737-300	33-40-69	AEG Sevilla

3022191-000	VARIABLE DISPLACEMENT HYDR ASSEMBLY	EATON		20757	AEG Sevilla
30-2481-3	NAVIGATION LIGHT	#N/D	737, 777		AEG Sevilla
30-2481-5	NAVIGATION LIGHT	HONEYWELL/GRIMES	B767/B737/B737-300/B737-600/B777/B737		AEG Sevilla
30-2505-3	UPPER FUSELAGE ANTI-COLLISION LIGHT	GRIMES AERO	BOEING 737-800/900	33-42-03	AEG Sevilla
30-2506-3	LOWER AIRCRAFT ANTI-COLLISION FUSELAGE STROBE LIGHT	GRIMES AERO - HONEYWELL	BOEING 737-800/900	33-42-04	AEG Sevilla
30-2554	Wing Position Light			33-42-14	AEG Sevilla
30-2554-1	Wing Position Light		(DHC)Dash 8-400, Dash 8, B737	33-42-14	AEG Sevilla
30-2554-2	Wing Position Light		(DHC)Dash 8-400, Dash 8	33-42-14	AEG Sevilla
30-2555	Tail Position Navigational Light			33-42-13	AEG Sevilla
30-2555-1	Tail Position Navigational Light		B737	33-42-13	AEG Sevilla
30-2555-3	Tail Position Navigational Light			33-42-13	AEG Sevilla
30-2557	Floodlight			33-42-12	AEG Sevilla
30-2557-1	Floodlight			33-42-12	AEG Sevilla
30-2557-2	Floodlight			33-42-12	AEG Sevilla
30-2557-3	Floodlight			33-42-12	AEG Sevilla
30-2557-4	Floodlight			33-42-12	AEG Sevilla
30-2558	Wing Inspection Light			33-42-11	AEG Sevilla
30-2558-1	Wing Inspection Light			33-42-11	AEG Sevilla
30-2558-2	Wing Inspection Light			33-42-11	AEG Sevilla
30-2558-3	Wing Inspection Light			33-42-11	AEG Sevilla
30-2558-4	Wing Inspection Light			33-42-11	AEG Sevilla
30-2581-3	ELECTRICAL TAIL LOGO FLOODLIGHT	HONEYWELL	A340	33-42-30	AEG Sevilla
30-2610	Integral Anticollision Strobe Light		DHC8, Dash 8	33-44-30	AEG Sevilla
30-2610-1	STROBE LIGHT	GRIMES/HONEYWELL	Dash 8, CRJ	33-44-30	AEG Sevilla
30-2683-1	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747/B777/B737-300/B737-200/B737	33-42-36	AEG Sevilla
30-2683-10	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747 ATR 72 ATR 42 B737	33-42-36	AEG Sevilla
30-2683-11	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL	B747/B777/ATR 72 ATR 42 B737	33-42-36	AEG Sevilla
30-2683-12	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL	B747/B777/B737-300/B737-200/B737	33-42-36	AEG Sevilla
30-2683-13	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL	B747/B777/B737-300/B737-200/B737	33-42-36	AEG Sevilla
30-2683-14	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL	B747/B737-300/B737-200/B737	33-42-36	AEG Sevilla
30-2683-2	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747/B737-300/B737-200/B777/B737	33-42-36	AEG Sevilla
30-2683-5	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747/B777/ATR 72 ATR 42 B737	33-42-36	AEG Sevilla
30-2683-6	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747/B777/B737-200/B737	33-42-36	AEG Sevilla
30-2683-9	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747/B777/B737	33-42-36	AEG Sevilla
30-2722-01	STROBE LIGHT ASSY		UNK		AEG Sevilla
3029683-001	HYDRAULIC MOTORPUMP ASSEMBLY	EATON	A321A319, A340, A330, A320	29-21-20	AEG Sevilla
3029981-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASS	EATON AEROS	CRJ Regional JET 100, ERJ175, DC, CRJ, CRJ, CRJ, CRJ	29-10-03,29	AEG Sevilla
3031174-001	Reservoir Level Switch Assembly				AEG Sevilla
3031863-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS	A320 NEO	29-11-34	AEG Sevilla
3031863-002	HYDRAULIC PUMP	EATON AEROS/GRIMES/ELIUD	A320 NEO	29-11-34	AEG Sevilla
3033116-100	UPLOCK ASSEMBLY	EATON	A320, A320X320, 747, A318, A319, A320, A319, A320, A340, A340, A350, A350, A350, A350		AEG Sevilla
304543-4	APU Ignition Unit, Ignition Exciter		GTCP36-150R1	49-41-25	AEG Bilbao
3056566-01	Ignition Cable Assembly CH53536			74-20-29	AEG Sevilla
3059-1471	BACKPLATE DAMPENER		UNK		AEG Bilbao
31073-052	AILERON SERVOCONTROL	LUCAS/GOODRICH	B757, A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-053	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-054	AILERON SERVOCONTROL	LUCAS/GOODRICH	B757, A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-055	AILERON SERVOCONTROL	LUCAS/GOODRICH	B757, A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-057	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-058	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-060	AILERON SERVOCONTROL	LUCAS/GOODRICH	B757, A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-063	AILERON SERVOCONTROL	LUCAS/GOODRICH	A321, A318, A320, A319, A300	27-14-51	AEG Sevilla
31073-064	AILERON SERVOCONTROL	LUCAS/GOODRICH	B737, A318, A321, B747, A320, A319, A300	27-14-51	AEG Sevilla
31073-065	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318, A321, A319, B747, A320, A300, A320-200	27-14-51	AEG Sevilla
31073-067	AILERON SERVOCONTROL	LUCAS/GOODRICH	B737, A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-068	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318, A321, B747, A320, A319, A300, A320-200, A320, A300	27-14-51	AEG Sevilla
31073-080	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-090	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-100	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318, A321, A320, A319, A300	27-14-51	AEG Sevilla
31073-110	AILERON SERVOCONTROL	LUCAS/GOODRICH	B737/A318, A321, A319, A300, A320-222, A320-200, A321, A320	27-14-51	AEG Sevilla
31075-840	ELEVATOR SERVOCONTROL	GOODRICH ACTUATION	A318, A319, A320, A321	27-34-52	AEG Sevilla
31077-100	INBOARD SPOILER ACTUATOR	GOODRICH ACTUATION	A321, A319, A320, A320-222, A320-200, A321, A320	27-64-21	AEG Sevilla
31077-111	INBOARD SPOILER ACTUATOR	GOODRICH ACTUATION	F-16, A321, A318, A320-232, A320, A319	27-64-21	AEG Sevilla
31077-200	INBOARD SPOILER ACTUATOR	GOODRICH ACTUATION	A321, A320, A319	27-64-21	AEG Sevilla
31077-211	INBOARD SPOILER ACTUATOR	GOODRICH ACTUATION	A318, A321, A319, A320, A320-232	27-64-21	AEG Sevilla
3164 SERIES	AC GENERATOR	LEAR SIEGLER	UNK		AEG Bilbao
3164-1350	ROTOR EXCITER	LEAR SIEGLER	UNK	24	AEG Bilbao
3164-1420	STATOR PM	LEAR SIEGLER	UNK	24	AEG Bilbao
3164-5532	ROTOR	LEAR SIEGLER	UNK	24	AEG Bilbao
31220-1020	STATOR	LEAR SIEGLER	UNK	24	AEG Bilbao
3122424-04	Ignition Cable Assembly CH53456-2			74-20-09	AEG Sevilla
3128501-1	ISFD DEDICATED BATTERY CHARGER (DBC)	ACME ELECTRIC	B737, B757, B767	24-31-05	AEG Sevilla
31340-1032	STATOR MAIN	LUCAS	UNK	24	AEG Bilbao
31342-001	ALTERNATOR	GOODRICH MONROE	CRJ-700, CN-235	24-21-05	AEG Bilbao
31342-003	GENERATOR-AC26KVA	GOODRICH MONROE	CN-235	24-21-05	AEG Bilbao
31342-004	GENERATOR-AC	GOODRICH MONROE	C-295, CN-235	24-20-57	AEG Bilbao
31342-006	AC GENERATOR	LUCAS	CN-235, C-295	24	AEG Bilbao
31342-007	AC GENERATOR	TRW AERONAUTICAL ELECTRIC	C-295	24-20-57	AEG Bilbao
31342-352	ROTOR ASSEMBLY	DYNAMIC AIR	CN-235, C-295	24	AEG Bilbao
3142-003	AC GENERATOR (26KVA)		UNK		AEG Bilbao
3-1442	Nose wheel		Dash 8, DHC8	32-40-17	AEG Sevilla
3-1490-1Opt10Opt2Opt3	Main Wheel Assembly			32-45-68	AEG Sevilla
3-1490-2Opt10Opt2Opt3	Main Wheel Assembly			32-45-68	AEG Sevilla
3-1573	Main Wheel Assembly			32-48-32	AEG Sevilla
315A1801-14	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	CRJ Regional JET-200, CFM56-3, B737-300, B737-400, B737-500, DC, CRJ Regional JET-200, CRJ Regional JET-200, CRJ Regional JET-200	78-31-02	AEG Sevilla
315A1801-15	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	CFM56-3, B737-300, B737-400, B737-500, DC, CRJ Regional JET-200, CRJ Regional JET-200, CRJ Regional JET-200	78-31-02	AEG Sevilla
315A1801-18	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	CFM56-3, B737-300, B737-400, B737-500, DC, CRJ Regional JET-200, CRJ Regional JET-200, CRJ Regional JET-200	78-31-02	AEG Sevilla
315A1801-19	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	CFM56-3, B737-300, B737-400, B737-500, DC, CRJ Regional JET-200, CRJ Regional JET-200, CRJ Regional JET-200	78-31-02	AEG Sevilla
315A1801-22	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	CFM56-3, B737-300, B737-400, B737-500, DC, CRJ Regional JET-200, CRJ Regional JET-200, CRJ Regional JET-200	78-31-02	AEG Sevilla
315A1801-23	THRUST REVERSE HYDRAULIC ACTUATOR ASSEMBLY	THE BOEING	CFM56-3, B737-300, B737-400, B737-500, DC, CRJ Regional JET-200, CRJ Regional JET-200, CRJ Regional JET-200	78-31-02	AEG Sevilla
315A1801-26	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	CFM56-3, B737-300, B737-400, B737-500, DC, CRJ Regional JET-200, CRJ Regional JET-200, CRJ Regional JET-200	78-31-02	AEG Sevilla
315A1801-27	THRUST REVERSE HYDRAULIC ACTUATOR ASSEMBLY	THE BOEING	CFM56-3, B737-300, B737-400, B737-500, DC, CRJ Regional JET-200, CRJ Regional JET-200, CRJ Regional JET-200	78-31-02	AEG Sevilla
315A2800-1	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	B-737	78-31-18	AEG Sevilla
315A2800-2	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	B-737	78-31-18	AEG Sevilla
315A2801-1	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	B-737	78-31-19	AEG Sevilla
315A2801-4	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	B-737	78-31-19	AEG Sevilla
315A2801-5	THRUST REVERSE LOCKING ACTUATOR ASSEMBLY	THE BOEING	B-737	78-31-19	AEG Sevilla
31-7611-1	NAVIGATIONAL LIGHT SUBASSEMBLY	INTERNATIONAL INTERNATIONAL	B767/B747-100/B777-200/B777	33-41-77	AEG Sevilla
31-7611-2	NAVIGATIONAL LIGHT SUBASSEMBLY	INTERNATIONAL INTERNATIONAL	B767/B747-100/B777-200/B777	33-41-77	AEG Sevilla
3181-196-901	VACUUM AND PRESURE	FOKKER AIRCRAFT BV	UNK	28	AEG Sevilla
3181-233-901	VACUUM AND PRESURE	FOKKER SERVICES BV	UNK	28	AEG Sevilla
3202232-1	2 In Dia Check Valve, Pressure Regulating Valve		UNK	21-50-73	AEG Sevilla
3202896-1	2&Frac12: Diameter Check Valve		A300, MD-11, A320, B737, CRJ Regional JET, CRJ Regional JET, CRJ Regional JET	36-14-79	AEG Sevilla
32032-1900	HUB DAMPENER		UNK		AEG Bilbao
321-400-703-0	DOOR OPENING HYDRAULIC ACTUATOR	ROHR	C-150, B777, CFM56-3B, CFM56-3C, A320, A321, A320, A321	78-36-51	AEG Sevilla
321-400-704-0	DOOR OPENING HYDRAULIC ACTUATOR	ROHR	C-150, B777, CFM56-3B, CFM56-3C, A320, A321, A320, A321	78-36-51	AEG Sevilla
321-400-705-0	DOOR OPENING HYDRAULIC ACTUATOR	ROHR	C-150, B777, CFM56-3B, CFM56-3C, A320, A321, A320, A321	78-36-51	AEG Sevilla
3238470-1	Actuator Ball Screw		B747-400	78-32-73	AEG Sevilla
3238470-2	Actuator Ball Screw		B747-400	78-32-73	AEG Sevilla
325-0083-01	Toilet Control Cable Assembly		UNK	38-31-07	AEG Sevilla
3282970-2	STOP MECHANISM	HONEYWELL	CFM56-5MU-1, B737, B747, A320, A321, A320, A321, A320, A321	75-31-22	AEG Sevilla
3282970-3	STOP MECHANISM	HONEYWELL	CFM56-5MU-1, B737, B747, A320, A321, A320, A321, A320, A321	75-31-22	AEG Sevilla
3282970-4	STOP MECHANISM	HONEYWELL INTL	CFM56-5MU-1, B737, B747, A320, A321, A320, A321, A320, A321	75-31-22	AEG Sevilla
3282970-5	STOP MECHANISM	HONEYWELL	CFM56-5A	75	AEG Sevilla
3291024-5	Shutoff Valve		B777, A330	80-12-19	AEG Sevilla
3291024-6	Shutoff Valve		A330, B777	80-12-19	AEG Sevilla
3291210-4	Load Control Valve		UNK	49-54-03	AEG Sevilla
3291210-6	Load Control Valve		UNK	49-54-03	AEG Sevilla
329196-13	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	Hercules-1, 100-C-130	32	AEG Sevilla

330296-15	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130	451-37-3	AEG Sevilla
330296-19	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	Hercules-L-100.C-130	32	AEG Sevilla
330359-1	STRUT ASSEMBLY NOSE LANDING GEAR	LOCKHEED	Hercules-L-100.C-130	32	AEG Sevilla
33-065-1	NORMAL ANTISKID VALVE MODULE (AVM)	CRANE AEROSPACE	B777.B757-200.B747-400.B767.B757.B747	32-42-51	AEG Sevilla
33-065-2	NORMAL ANTISKID VALVE MODULE (AVM)	CRANE AEROSPACE	B777.B747-400.B767.B757.B747	32-42-51	AEG Sevilla
33-067-1	ALTERNATE ANTISKID VALVE MODULE (AVM)	HYDRO AIRE	B777.B767.B757.B747	32-42-51	AEG Sevilla
33-067-2	ALTERNATE ANTISKID VALVE MODULE (AVM)	HYDRO AIRE	B777.B757-200.B747-400.B767.B757.B747	32-42-51	AEG Sevilla
3314203-3	STRUT ASSY NOSE LANDING GEAR	LOCKHEED	C-130	32	AEG Sevilla
3316498-1	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	MD-90.Hercules-L-100.C-130	32	AEG Sevilla
3316498-7	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	Hercules-L-100.C-130	32	AEG Sevilla
3316500-15	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130	32	AEG Sevilla
332-0002-01	Waste Drain Valve		B737.B727.B747.DH8.B757	38-31-05	AEG Sevilla
332-000X	Waste Drain Valve			38-30-06	AEG Sevilla
332-001X	Waste Drain Valve			38-30-06	AEG Sevilla
332-002X	Waste Drain Valve			38-30-06	AEG Sevilla
332-003X	Waste Drain Valve			38-30-06	AEG Sevilla
3367-10	Ballast Unit		A321A318	33-24-97	AEG Sevilla
3367-11	Ballast Unit			33-24-97	AEG Sevilla
33793-3	RECEIVER, TRANSMITTER	NONE SPECIFIED	UNK		AEG Sevilla
3382-10	Lampholder			33-22-01(TDS)	AEG Sevilla
33823-2	CONTROL RADAR SET		UNK		AEG Sevilla
33824-1	INDICATOR, AZMUTH		UNK		AEG Sevilla
3385-20	Fluorescent Lamp Fixture			33-22-02(TDS)	AEG Sevilla
3385-30	Fluorescent Lamp Fixture			33-22-02(TDS)	AEG Sevilla
33A64-1612-010	CONTROL BOX		UNK		AEG Sevilla
34265-1	COCKPIT LIGHT	GRIMES	A350.B757-300.B747-200.B757-	33-10-23	AEG Sevilla
34265-10	COCKPIT LIGHT	HONEYWELL	A350.A320.A321.B757-300.B747-	33	AEG Sevilla
34265-11	COCKPIT LIGHT	HONEYWELL	A350.A320.A321.B757-	33	AEG Sevilla
34265-12	COCKPIT LIGHT	HONEYWELL	A350.A320.A321.B757-300.B747-	33	AEG Sevilla
34265-13	COCKPIT LIGHT	HONEYWELL	A350.B757-300.B747-200.B757-	33	AEG Sevilla
34265-14	COCKPIT LIGHT	GRIMES	A350.B757-300.B747-200.B757-	33-10-23	AEG Sevilla
34265-15	COCKPIT LIGHT	GRIMES	A350.A320.A321.B757-300.B747-	33-10-23	AEG Sevilla
34265-16	COCKPIT LIGHT	GRIMES	A350.A320.A321.B757-300.B747-	33-10-23	AEG Sevilla
34265-17	COCKPIT LIGHT	GRIMES	A350.A320.A321.B757-300.B747-	33-10-23	AEG Sevilla
34265-18	COCKPIT LIGHT	GRIMES	A350.A320.A321.B757-300.B747-	33-10-23	AEG Sevilla
34265-19	COCKPIT LIGHT	GRIMES	A350.A320.A321.B757-300.B747-	33-10-23	AEG Sevilla
34265-20	COCKPIT LIGHT	GRIMES	A350.A320.A321.B757-300.B747-	33-10-23	AEG Sevilla
34265-21	COCKPIT LIGHT	HONEYWELL	A350.B757-300.B747-200.B757-	33	AEG Sevilla
34265-22	COCKPIT LIGHT	GRIMES	B707.A320.A321.B757-300.B747-	33-10-23	AEG Sevilla
34265-23	COCKPIT LIGHT	HONEYWELL	A350.A320.A321.B757-300.B747-	33	AEG Sevilla
34265-24	COCKPIT LIGHT	HONEYWELL	A350.A320.A321.B757-300.B747-	33	AEG Sevilla
34265-25	COCKPIT LIGHT	HONEYWELL	A350.A320.A321.B757-300.B747-	33-10-23	AEG Sevilla
34265-26	COCKPIT LIGHT	HONEYWELL	A350.A320.A321.B757-300.B747-	33	AEG Sevilla
34-61-11	-	#N/D	UNK		AEG Sevilla
34765-5	CONTROL RADAR SET		UNK		AEG Sevilla
3478A01001			CRJ1000	21-51-94	AEG Sevilla
3478A01001	Air Cycle Machine			21-51-94	AEG Sevilla
350448-5	STARTER		UNK		AEG Sevilla
350571-6	STARTER		UNK		AEG Sevilla
350880-6	VARIABLE DISPLACEMENT HYDRAULIC PUMP	EATON / 62983	B707.DC-10-40.A310-300.B757-600.L-101.B767-300.B747-400.B757-	29-11-03	AEG Sevilla
350880-7	VARIABLE DISPLACEMENT HYDRAULIC PUMP	EATON / 62983	A310.B747-400.B757-	29-11-04	AEG Sevilla
35-82596-698	GEAR ASSY NOSE	BEECHCRAFT	UNK		AEG Sevilla
358800-1	NOSE LANDING GEAR UNLOCK ASSEMBLY	HONEYWELL	Hercules-L-100.C-130	16L1-3-10-3	AEG Sevilla
358800-5	NOSE LANDING GEAR UNLOCK ASSEMBLY	HONEYWELL	Hercules-L-100.C-130	16L1-3-10-3	AEG Sevilla
358800-9	NOSE LANDING GEAR UNLOCK ASSEMBLY	LOCKHEED	Hercules-L-100.C-130	16L1-3-10-3	AEG Sevilla
35H	EXTINTOR	KIDDE GRAVINER	UNK	26-24-01	AEG Sevilla
3603100-1	FUEL CONTROL ASSEMBLY	GARRET	C-130.B727	49	AEG Sevilla
3603100-2	FUEL CONTROL ASSEMBLY	GARRET	C-130	49	AEG Sevilla
3603100-9	FUEL CONTROL ASSEMBLY	HONEYWELL	F-15.C-130.B727	49	AEG Sevilla
36051812-7	ELECTRICAL ENGINE STARTER	HONEYWELL	B-737-100/-200/-300/-400/-500		AEG Sevilla
3609088-1	Valve Assembly	INTERNATIONAL		49-90-45	AEG Sevilla
3609150-8	FUEL CONTROL ASSEMBLY	ALLIED SIGNAL	F-15.MD-11.B767.B747.A310.A300.B757	49	AEG Sevilla
361257-1	Valve Assembly			49-90-45	AEG Sevilla
3614400-1	TRANSDUCER ASSEMBLY	HONEYWELL	A300-	49-51-93	AEG Sevilla
3614400-2	TRANSDUCER ASSEMBLY	HONEYWELL	A300-600.B767.B757.A310.A300.B707	49-51-93	AEG Sevilla
3614400-4	TRANSDUCER ASSEMBLY	HONEYWELL	A300-600.B767.B757.A310.A300.B707	49-51-93	AEG Sevilla
3614400-6	TRANSDUCER ASSEMBLY	HONEYWELL	A300-600.B767.B757.A310.A300	49-51-93	AEG Sevilla
3614400-7	TRANSDUCER ASSEMBLY	HONEYWELL	A300-	49-51-93	AEG Sevilla
3615853-1	Valve Assy	INTERNATIONAL	A300-600.B767.B757.A310.A300	49-90-47	AEG Sevilla
3616293-1	Valve Assembly			49-90-45	AEG Sevilla
3617750-1	FCU APU	HONEYWELL	B757-300.B757-400.B757-	49	AEG Sevilla
3617750-2	TURBINE TYPE FUEL CONTROL UNIT	HONEYWELL	B757-300.B757-400.B757-	49	AEG Sevilla
3617750-3	TURBINE TYPE FUEL CONTROL UNIT	HONEYWELL	DC-8.B727.B757.MD-80.DC-9	49	AEG Sevilla
3617750-4	TURBINE TYPE FUEL CONTROL UNIT	HONEYWELL	DC-8.B727.B757.MD-80.DC-9	49	AEG Sevilla
366-028	Refuel/Defuel Panel			28-24-05	AEG Sevilla
366-029	Refuel/Defuel Indicator			28-24-06	AEG Sevilla
366-209	Integrated Refuel Panel			28-41-72	AEG Sevilla
367-040	Standard Electronic Module Assembly			28-40-88	AEG Sevilla
367-118	Fuel Quantity Computer			28-41-47	AEG Sevilla
367-119	High Level Control Unit			28-24-07	AEG Sevilla
368-105	INTERRUPTOR, PULSADO		UNK		AEG Sevilla
36E135-2C	STARTER		UNK		AEG Sevilla
370439-1	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Sevilla
371688 SERIES	FUEL CONTROL UNIT	HONEYWELL	UNK		AEG Sevilla
371688-10	FUEL CONTROL UNIT	INTERNATIONAL	UNK		AEG Sevilla
37-391	Servovalve Assembly		B757	32-43-70	AEG Sevilla
37-409	3-Way Servovalve Assembly		B757	32-48-33	AEG Sevilla
380258-1	PNEUMATIC AIR SYSTEM POWER GAS TUBING ENGINE	HONEYWELL	UNK		AEG Sevilla
380-971	380-971-1	BF GOODRICH	A330	32-48-36	AEG Sevilla
3810056-101	MODULE CONTROL VALVE THRUST	PARKER	B757-300.B757-400.B757-	29-10-26	AEG Sevilla
3810056-103	MODULE CONTROL VALVE THRUST	PARKER	B757-300.B757-400.B757-	29-10-26	AEG Sevilla
3810056-104	MODULE CONTROL VALVE THRUST	PARKER	B757-300.B757-400.B757-	29-10-26	AEG Sevilla
3810056-105	MODULE CONTROL VALVE THRUST	PARKER	CFM56-3B.B757-300.B757-	29-10-26	AEG Sevilla
3810056-106	MODULE CONTROL VALVE THRUST	PARKER	CFM56-3B.B757-300.B757-	29-10-26	AEG Sevilla
3810056-107	MODULE CONTROL VALVE THRUST	PARKER	CFM56-3B.B757-300.B757-	29-10-26	AEG Sevilla
3810056-108	MODULE CONTROL VALVE THRUST	PARKER	CFM56-3B.B757-300.B757-	29-10-26	AEG Sevilla
3810056-109	MODULE CONTROL VALVE THRUST	PARKER	CFM56-3B.B757-300.B757-	29-10-26	AEG Sevilla
38116-1-7	ENGINE, GAS, TURBINE	HONEYWELL	C-130	49	AEG Sevilla
38116-1-8	AUXILIARY POWER UNIT	HONEYWELL	C-130	49	AEG Sevilla
381800-1001	LEADING EDGE SLAT ACTUATOR ASSEMBLY	PARKER	B737-300.B737-600.B737-683.B737	27-80-06	AEG Sevilla
381800-1003	LEADING EDGE SLAT ACTUATOR ASSEMBLY	PARKER	B737-300.B737-600.B737	27-80-06	AEG Sevilla
381800-1005	LEADING EDGE SLAT ACTUATOR ASSEMBLY	PARKER	B737-600.B737-683.B737-683.B737	27-80-06	AEG Sevilla
38210-394	VARIOMETRE	THALES	UNK	34	AEG Sevilla
3830155-2	Valve Assembly			49-90-45	AEG Sevilla
3830156-2	Valve Assembly			49-90-45	AEG Sevilla
3830159-1	Valve Assembly			49-90-45	AEG Sevilla
3842160-9	APU COOLING FAN	AIRESEARCH/HONEYWELL	GTCP331-250R.GTCP331-200ER.B767-300.B747-400.A310.A300.B747.B757-	49-51-69	AEG Sevilla
384303X	Exit Sign Assy			33-20-04	AEG Sevilla
38-791500	Hydraulic Fuse, Volumetric, With Bypass Valve, Solenoid, 3-Way, 2-Position, Normally Closed		C-130	32-41-05	AEG Sevilla
38-793500	Hydraulic Fuse, Volumetric, With Bypass Valve, Solenoid, 3-Way, 2-Position, Normally Closed		C-130	32-41-15	AEG Sevilla
3880410-14	Valve Assy		A300.MD-11A310.B747.B767	49-90-43	AEG Sevilla
388058-1	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Sevilla
388058-19	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Sevilla
388058-9	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Sevilla
3880620-2	Valve Assembly			49-90-45	AEG Sevilla
3880620-3	Valve Assembly			49-90-45	AEG Sevilla
388134-5	NC Solenoid Valve			49-30-93	AEG Sevilla
3882350 SERIES	FUEL CONTROL UNIT		UNK		AEG Sevilla
3882500-12	FUEL CONTROL UNIT	AIRESEARCH	GTCP331-250R.GTCP331-200ER.B767-300.B747-400.A310.A300.B747.B757-	49	AEG Sevilla
3882500-14	FUEL CONTROL UNIT	AIRESEARCH	GTCP331-250R.GTCP331-200ER.B767-300.B747-400.A310.A300.B747.B757-	49	AEG Sevilla

3882500-16	FUEL CONTROL UNIT	HONEYWELL	GTCP331-250R1GTCP331-200ER/B767-	49	AEG Sevilla
3882500-17	FUEL CONTROL UNIT	AIRESEARCH	GTCP331-250R1GTCP331-200ER/B767-	49	AEG Sevilla
3882500-X	FUEL CONTROL UNIT	HONEYWELL	GTCP331/B767/B747/A310/A300	49	AEG Sevilla
3882550-1	FLOW DIVIDER AND DRAIN VALVE ASSEMBLY	ALLIEDSIGNAL	B747/GT1CP331-250R1GTCP331-	49-31-63	AEG Sevilla
3882550-2	FLOW DIVIDER AND DRAIN VALVE ASSEMBLY	ALLIEDSIGNAL	B747/GT1CP331-250R1GTCP331-	49-31-63	AEG Sevilla
3882550-3	FLOW DIVIDER AND DRAIN VALVE ASSEMBLY	ALLIEDSIGNAL	B747/GT1CP331-250R1GTCP331-	49-31-63	AEG Sevilla
3882730-10	Fuel Control Assy			49-30-91	AEG Sevilla
3882825-1	FUEL CONTROL ASSEMBLY	HONEYWELL	A319JMD-80/B757/A320	49-30-97	AEG Sevilla
3882825-2	FUEL CONTROL ASSEMBLY	HONEYWELL	A319JMD-80/B757/A320	49-30-97	AEG Sevilla
3882825-3	FUEL CONTROL ASSEMBLY	HONEYWELL	A319JMD-80/B757/A320	49-30-97	AEG Sevilla
3882825-4	FUEL CONTROL ASSEMBLY	HONEYWELL	A319JMD-80/B757/A320	49-30-97	AEG Sevilla
3882825-5	FUEL CONTROL ASSEMBLY	HONEYWELL	A319JMD-80/B757/A320	49-30-97	AEG Sevilla
3882825-6	FUEL CONTROL ASSEMBLY	HONEYWELL	A319JMD-80/B757/A320	49-30-97	AEG Sevilla
3882825-8	FUEL CONTROL ASSEMBLY	HONEYWELL	A319JMD-80/B757/A320/A320-200	49-30-97	AEG Sevilla
3882825-9	FUEL CONTROL ASSEMBLY	HONEYWELL	A319JMD-80/B757/A320/A320-200	49-30-97	AEG Sevilla
3883220-3	ACTUATOR IGV	HONEYWELL	B737 A320 MD-80-83/A320-200	49-50-02	AEG Sevilla
3883240-3	FUEL CONTROL ASSEMBLY	HONEYWELL	MD-11/B767/B747/A310/A300/GT1CP331-	49-31-65	AEG Sevilla
3883240-5	FUEL CONTROL ASSEMBLY	HONEYWELL	MD-11/B767/B747/A310/A300/GT1CP331-	49-31-65	AEG Sevilla
3883240-6	FUEL CONTROL ASSEMBLY	HONEYWELL	GTCP331-350C/A340/A350	49-31-65	AEG Sevilla
3883240-7	FUEL CONTROL ASSEMBLY	HONEYWELL	GTCP331-350C/A340/A350	49	AEG Sevilla
3883255-2	TORQUE MOTOR	HONEYWELL	A330/A340	49-31-65	AEG Sevilla
3883255-3	TORQUE MOTOR	HONEYWELL	A330/A340	49-31-65	AEG Sevilla
3883255-4	TORQUE MOTOR	HONEYWELL	A330/A340	49-31-65	AEG Sevilla
3883255-x	TORQUE MOTOR	HONEYWELL	A330/A340	49-31-65	AEG Sevilla
3883297-1	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Sevilla
3883297-2	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Sevilla
3883297-3	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Sevilla
3883297-4	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Sevilla
3883297-5	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Sevilla
3883297-6	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Sevilla
3883297-7	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Sevilla
3883297-8	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Sevilla
3883297-9	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Sevilla
3883730-X	FUEL CONTROL UNIT				AEG Sevilla
3883900-1	FUEL CONTROL UNIT	HONEYWELL			AEG Sevilla
3883900-X	FUEL CONTROL UNIT				AEG Sevilla
3883964-3	FUEL CONTROL UNIT	HONEYWELL			AEG Sevilla
3883964-4	FUEL CONTROL UNIT	HONEYWELL			AEG Sevilla
3883964-X	FUEL CONTROL UNIT				AEG Sevilla
38-841-01	Sensor Test System			32-60-04	AEG Sevilla
3884629-3	Oil Cooler Fan			49-51-79	AEG Sevilla
3884629-4	Oil Cooler Fan			49-51-79	AEG Sevilla
3884629-5	Oil Cooler Fan			49-51-79	AEG Sevilla
388827-2	STARTER	HONEYWELL	A310,GTCP331-350C,B767/A340,A330	49-41-10	AEG Bilbao
388827-3	APU STARTER	HONEYWELL	MD-11/B767/A310/A300/GT1CP331-	49-41-10	AEG Bilbao
388827-4	STARTER	ALLIEDSIGNAL	GTCP331-350C/A310,B767/A340,A330	49-41-10	AEG Bilbao
388827-X	STARTER	ALLIEDSIGNAL	GTCP331-350C	49-41-10	AEG Bilbao
3890010-102	PRESSURE RELIEF VALVE	PARKER	B77/B77/B767/300/B757/400/B737/	32-40-04	AEG Sevilla
3890010-103	PRESSURE RELIEF VALVE	PARKER HANNIFIN	400/B737/400/B737/400/B737/	32-40-04	AEG Sevilla
38E93-4			VALVULA BITSH	19328	AEG Sevilla
38H	EXTINTOR	KIDDE GRAVINER	UNK	26-24-01	AEG Sevilla
39-249	DUAL PRESSURE CONTROL VALVE	CRANE/HYDRO-AIRE	MD-80,MD80,DC-9	32-32-42-30,32-	AEG Sevilla
39-249-1	DUAL PRESSURE CONTROL VALVE	CRANE/HYDRO-AIRE	MD-80,MD-90,ATR 72,ATR 42,MD80,DC-	32,32-42-30	AEG Sevilla
39-249-2	DUAL PRESSURE CONTROL VALVE	CRANE/HYDRO-AIRE	MD-80,MD-90,MD80,DC-9,DC-9-30,MD-	32,32-42-30	AEG Sevilla
39-30-0100-0000	HOUSING ASSY	AOA	UNK	21	AEG Sevilla
39-353	HYD. VALVE	CRANE HYDRO-AIRE	B-727, B-737	32-40-52	AEG Sevilla
394324 SERIES	FLOW DIVIDER AND DRAIN		UNK		AEG Sevilla
394390 SERIES	FLOW DIVIDER AND DRAIN		UNK		AEG Sevilla
394408 SERIES	FLOW DIVIDER AND DRAIN		A300 A310 B747 B767 MD11		AEG Sevilla
39-483	DUAL PRESSURE CTRL VALVE	CRANE/HYDRO-AIRE	B737	32-40-69	AEG Sevilla
39-671	Valve		Dash 8,C-130	32-42-76	AEG Sevilla
396800-10	MOTOR GEAR HYDRAULIC	ARGO-TECH	CFM56-5A321A319A320A318,CFM56-	75-31-11	AEG Sevilla
396800-11	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5A321A319A320A318,CFM56-	75-31-11	AEG Sevilla
396800-12	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5A321A319A320A318,CFM56-	75-31-11	AEG Sevilla
396800-5	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5A321A319A318A320	75	AEG Sevilla
396800-6	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5A321A319A318A320	75	AEG Sevilla
396800-7	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5A321A319A320A318,CFM56-	75-31-11	AEG Sevilla
396800-8	MOTOR GEAR HYDRAULIC	ARGO-TECH	CFM56-5A321A319A320A318,CFM56-	75-31-11	AEG Sevilla
396800-9	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5A321A319A320A318,CFM56-	75-31-11	AEG Sevilla
396800-SERIES	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	707, E3, E8, E6	75	AEG Sevilla
39-771	Control Valve		CL-601	32-43-29	AEG Sevilla
398724-1-1	Three Inch Diameter Electric Bulb/ty Shutoff		CRJ Regional Jet-100,CRJ Regional Jet-	21-20-19	AEG Sevilla
399200-27-223	Inspection of Thin Wall Condition for the PFTU		300,B737,604	27-223	AEG Sevilla
399200-6054	Fight Controls Pitch Feel Trim Unit				AEG Sevilla
399300-2	FUEL BOOSTER PUMP, SINGLE FUEL VOLUME	ARGO-TECH	MD80,MD-80-83,MD-90,MD-80,DC-	28-20-6	AEG Sevilla
399500-1	FUEL BOOSTER PUMP, SINGLE FUEL VOLUME	ARGO-TECH	MD80,MD-90,MD-80,DC-9,B777	28-20-6	AEG Sevilla
3A18-0003	Crew Seat Assembly				AEG Sevilla
3A18-0004	Crew Seat Assembly				AEG Sevilla
3C2200A	Roll Control Input Module			27-61-10	AEG Sevilla
3E2042	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2044	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2046	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2048	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2071	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2090	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2334	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2342	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2346	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2414	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2456	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E2457	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
3E3203-1	Fill Adapter And Cap Assembly			38-11-31	AEG Sevilla
3E3209-1	Fill/Drain Valve Assembly		Challenger 600,CRJ-700	38-11-25	AEG Sevilla
3E3291-1	Air Filter			38-40-11	AEG Sevilla
3E3292-1	Regulator, Pressure		B757	38-40-04	AEG Sevilla
40205-2-4559	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Sevilla
40205-3	LANDING LIGHT	GRIMES AEROSPACE	N/A	33-41-51	AEG Sevilla
40205-3-4559	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Sevilla
40205-3-Q4559	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Sevilla
40205-3-Q4559X	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Sevilla
40205-4	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Sevilla
40205-4-4559	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Sevilla
40205-5	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Sevilla
40205-5-4559	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Sevilla
40205-6	LANDING LIGHT	GRIMES AEROSPACE	N/A	33-41-51	AEG Sevilla
40205-6-Q4559	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Sevilla
40205-7-4559	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Sevilla
40205-7-Q4559	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Sevilla
4020735004	Pressure Regulating Valve Assembly		CRJ Regional Jet-100	75-22-00	AEG Sevilla
4042T50P02	Alternator Stator/Alternator Rotor Vc.			74-12-00	AEG Sevilla
4048-10	Fluorescent Lamp Fixture			33-22-03	AEG Sevilla
4048-11	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Sevilla
4048-20	Fluorescent Lamp Fixture			33-22-03	AEG Sevilla
4048-20	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Sevilla
4048-21	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Sevilla
4048-30	Fluorescent Lamp Fixture			33-22-03	AEG Sevilla
4048-30	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Sevilla
4048-31	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Sevilla
4048-40	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Sevilla
4048-41	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Sevilla
4048-SERIES	Restraint System Assembly			33-22-03(TDS)	AEG Sevilla

4049-10	Fluorescent Lamp Fixture			33-22-04	AEG Sevilla
4049-10	Lamp Carrier			33-22-04(FDS)	AEG Sevilla
4049-204049-21	Lamp Carrier			33-22-04(FDS)	AEG Sevilla
4049-30	Fluorescent Lamp Fixture			33-22-04	AEG Sevilla
4049-30	Lamp Carrier			33-22-04(FDS)	AEG Sevilla
4049-314049-40	Lamp Carrier			33-22-04(FDS)	AEG Sevilla
4049-40	Fluorescent Lamp Fixture			33-22-04	AEG Sevilla
4049-41	Lamp Carrier			33-22-04(FDS)	AEG Sevilla
4060T81G03	B-Bump Vent Regulator Valve		CRJ Regional Jet-100	75-21-00	AEG Sevilla
4060T81G04	B-Bump Vent Regulator Valve		CRJ Regional Jet-100	75-21-00	AEG Sevilla
407009-1	INDICATOR AZMUTH		UNK		AEG Sevilla
407010001	Air Jet Pump			21-30-38	AEG Sevilla
4096T33P07	High Voltage Igniter			74-21-39	AEG Sevilla
41000740-103	THRUST REVERSER VALVE ASSEMBLY	HRTEXTRO	DC9MD80	78-30-01	AEG Sevilla
41000740-104	THRUST REVERSER VALVE ASSEMBLY	HR TEXTIRON - HONEYWELL SARGENT	A300, A320, A330	78-30-01	AEG Sevilla
4101099F	FAN		A310, A320	49-52-04	AEG Sevilla
4105DA	LANDING GEAR VALVE		C-130,B737-500,B737-400,B737-300,B737-300	32-30-01	AEG Sevilla
4106T93G01	B-Bump Vent Regulator		Challenger 600	75-21-01	AEG Sevilla
4120T0SP02	Starter Control Valve		CRJ-700,CRJ900 Regional Jet-900	80-12-29	AEG Sevilla
4120T4P02	Vibration Accelerometer		CF34-8C,MD-11	77-31-01	AEG Sevilla
4120T6P01	Oil Pressure Transmitter		CF34-10E,CF34-8C,CF34-8E,CRJ-700	77-41-02	AEG Sevilla
4120T9P02	Oil Level / Temperature Sensor		B747,CF34-8C,CF34-8C1	79-32-42	AEG Sevilla
4121T6P02	Operability Bleed Valve			80-12-39	AEG Sevilla
4123T6P01	Sump Seal Valve		CRJ Regional Jet-100,CF34-8E,CRJ-700	75-22-01	AEG Sevilla
4123T7P02	Obsolete		CF34-8C,CF34-8E	80-12-41	AEG Sevilla
4123T7P02	Operability Bleed Fuel Actuated Valve		CF34-8C,CF34-8E	80-12-41	AEG Sevilla
4123T7P03	Obsolete		CF34-8C,CF34-8E	80-12-41	AEG Sevilla
4123T7P03	Operability Bleed Fuel Actuated Valve		CF34-8C,CF34-8E	80-12-41	AEG Sevilla
4123T7P04	Operability Bleed Fuel Actuated Valve		CF34-8C,CF34-8E	80-12-41	AEG Sevilla
4124T6P05	Fuel Injector			73-11-07	AEG Sevilla
412700-27-324	Rudder Shutoff Valve			27-324	AEG Sevilla
4147T69P01	Main Fuel Control			73-21-03	AEG Sevilla
4147T69P02	Main Fuel Control			73-21-03	AEG Sevilla
4147T69P03	Main Fuel Control			73-21-03	AEG Sevilla
4147T69P04	Main Fuel Control			73-21-03	AEG Sevilla
4157T43P01	Sump Seal Shutoff Valve		CRJ Regional Jet-100,CF34-8C5	75-22-02	AEG Sevilla
421CC02	Single Pole Contactor		Challenger 300	24-64-01	AEG Sevilla
42-265	CONTROL BOX ASSEMBLY	HYDRO-AIRE	B737	32-32-40-51	AEG Sevilla
4259-3I	Lavatory Drain Plug Assembly			38-33-03	AEG Sevilla
42-791-1A	Unit Assembly, Anti, Skid Control			32-42-83	AEG Sevilla
42-867	Unit Assembly, Anti, Skid Control			32-42-83	AEG Sevilla
42-925-1	Anti Skid Control Unit			32-43-53	AEG Sevilla
42R164-1	Temperature Transducer			28-42-15	AEG Sevilla
42R165-1	Temperature Transducer			28-42-15	AEG Sevilla
430084-1	CAJA		UNK		AEG Sevilla
430201-1	UNISON STATOR	UNISON IND	A320		AEG Bilbao
4323-3	Lock Assembly			52-50-12	AEG Sevilla
4323-7	Lock Assembly			52-50-12	AEG Sevilla
438023-2	INDICATOR TORQUEMET	TEXAS INSTRUMENTS	UNK		AEG Sevilla
44090-3941-03	ANEMOMETRE	THALES	UNK	34	AEG Sevilla
442120-1	Fuel Control Unit, APJ			49-31-77	AEG Sevilla
4428-150-80-10	Flap Position Indicator		DHC8,Dash 8,B727/B737-200,DLC-8,DLC-30	27-50-10	AEG Sevilla
4428-150-80-11	Flap Position Indicator		DHC8,Dash 8,B727/B737-200,DLC-8,DLC-30	27-50-10	AEG Sevilla
44347-2	INDICATOR TORQUEMET	TEXAS INSTRUMENTS	UNK		AEG Sevilla
449-2	Power Supply Unit		CRJ Regional Jet-100,CRJ Regional Jet-900	24-30-03	AEG Sevilla
44E15-1A	Water Separator			44U-23-851A	AEG Sevilla
44E15-1B	Water Separator			44U-23-851A	AEG Sevilla
44E15-2A	Water Separator		Dash 8	44U-23-851A	AEG Sevilla
44E15-2B	Water Separator		Dash 8	44U-23-851A	AEG Sevilla
44E16-1A	Water Separator		Dash 8	44U-23-851A	AEG Sevilla
45-0057-1	RETRACTABLE LANDING LIGHT ASSEMBLY	HONEYWELL	DC-9, MD-80, MD-90,DC10	33-40-08	AEG Sevilla
45-0057-3	RETRACTABLE LANDING LIGHT ASSEMBLY	GRIMES AERO - HONEYWELL	MD-80, MD-90, DC-9	33	AEG Sevilla
45-0083-1	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL/GRIMES	B707/B737-300,B727/B737-200,B757/B737	33-40-15	AEG Sevilla
45-0083-3	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL/GRIMES	B707/MD-11/DC-10/B747/B737-300	33-40-15	AEG Sevilla
45-0083-5	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL	B707/MD-11/DC-10/B747/B737-300	33-40-15	AEG Sevilla
45-0083-7	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL/GRIMES	F100F30/B737-300/B707/B737-300	33-40-15	AEG Sevilla
45-0212-1	AIRCRAFT RETRACTABLE LANDING LIGHT	HONEYWELL	C-212, CN-235	33	AEG Sevilla
45-0350-4	RETRACTABLE LANDING LIGHT	HONEYWELL	A330, A340	33	AEG Sevilla
450446A	FCU	TRIUMPH ACCESSORY			AEG Sevilla
450446B	FCU	TRIUMPH ACCESSORY			AEG Sevilla
45212101-16	STOPLOCK	TRW AERONAUTICAL SYSTEMS	B757, B767	25-53-08	AEG Sevilla
453665 / MPEV3-011-8	PUMP-HYDR MOTOR DRIVEN		CN-235, CN-295		AEG Sevilla
453665 / MPEV3-011-8	PUMP-HYDR MOTOR DRIVEN		CN-235, CN-295		AEG Sevilla
453665 / MPEV3-011-8	PUMP-HYDR MOTOR DRIVEN		CN-235, CN-295		AEG Sevilla
45-52122-605242CW	ACTUATOR FLAP 2VALVE 6		UNK		AEG Sevilla
4564-5A6-1	TRANSMITTER POSITION	HONEYWELL	P-3		AEG Sevilla
456M378	Crewmember PBE			PRM-02	AEG Sevilla
458X008	Lavatory Floor Assy			53-10-04	AEG Sevilla
458X01X	Lavatory Door Assy			52-50-01	AEG Sevilla
46165-1	Electrical Harness Assembly- MLG			32-61-03	AEG Sevilla
46165-3	Electrical Harness Assembly- MLG			32-61-03	AEG Sevilla
463X001	Cockpit Door Assy			52-50-02	AEG Sevilla
46450-3	Stabilizer brace Electrical harness Assembly	MLG		32-40-02	AEG Sevilla
46450-5	Stabilizer Brace Electrical Harness Assembly	MLG		32-40-02	AEG Sevilla
46450-7	Stabilizer Brace Electrical Harness Assembly	MLG	C-130	32-40-02	AEG Sevilla
46460-3	Stabilizer brace electrical harness assembly	MLG		32-40-02	AEG Sevilla
46460-5	Stabilizer brace electrical harness assembly	MLG		32-40-02	AEG Sevilla
46460-7	Stabilizer Brace Electrical Harness Assembly	MLG	C-130	32-40-02	AEG Sevilla
466X00X	Bulkhead Panel Assy			53-10-01	AEG Sevilla
46847-3	Lever Assembly Alternate Extension System	MLG	(DHC)Dash 8-Q400	32-34-02	AEG Sevilla
46847-5	Lever Assembly Alternate Extension System	MLG	(DHC)Dash 8-Q400	32-34-02	AEG Sevilla
47150-5	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
47150-7	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
47150-9	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
47151-5	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
47152-5	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
47201-1	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
47201-3	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
47202-1	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
47202-3	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
472597-01	Controller, Fire Detector				AEG Sevilla
47300-1	Drag Strut Assembly NLG			32-21-03	AEG Sevilla
47300-3	Drag Strut Assembly NLG			32-21-03	AEG Sevilla
47300-5	Drag Strut Assembly NLG		(DHC)Dash 8-Q400	32-21-03	AEG Sevilla
47300-7	Drag Strut Assembly NLG		(DHC)Dash 8-Q400	32-21-03	AEG Sevilla
47300-9	Drag Strut Assembly NLG		(DHC)Dash 8-Q400	32-21-03	AEG Sevilla
473872-01	Fire Detection and Extinguishing System Control Assembly				AEG Sevilla
473872-02	Fire Detection and Extinguishing System Control Assembly				AEG Sevilla
473872-03	Fire Detection and Extinguishing System Control Assembly				AEG Sevilla
47390-1	Electrical Harness Assembly NLG			32-40-03	AEG Sevilla
47391-1	Electrical Harness Assembly NLG		CF-34-8C,CF-6-50,CF-6-80C2,CFM56-3,CFM56-7B,CFM56-7C,CFM56-7D,CFM56-7E,CFM56-7F,CFM56-7G,CFM56-7H,CFM56-7J,CFM56-7K,CFM56-7L,CFM56-7M,CFM56-7N,CFM56-7P,CFM56-7Q,CFM56-7R,CFM56-7S,CFM56-7T,CFM56-7U,CFM56-7V,CFM56-7W,CFM56-7X,CFM56-7Y,CFM56-7Z	32-40-03	AEG Sevilla
47391-1	Fire Detectors				AEG Sevilla
474560-2,474560-20;	M3000 Discrete Cabin Smoke Detector				AEG Sevilla
474560-X	Model 3000 Discrete Cabin Smoke Detectors				AEG Sevilla
4760A000K02	Rudder Control Unit (RCU)			27-25-03	AEG Sevilla
4760A000K03	Rudder Control Unit (RCU)			27-25-03	AEG Sevilla
476W2220-1H	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-14B	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-1E	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla

476W2220-IG	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-IH	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-U	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-IL	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-IM	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-22B	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-22C	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-2E	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-2G	ATTENDANT HANDESET CRADLE ASSEMBLY	BAE SYSTEMS	A330, A340	23-42-02	AEG Sevilla
476W2220-2H	ATTENDANT HANDESET CRADLE ASSEMBLY	BAE SYSTEMS	A330, A340	23-42-02	AEG Sevilla
476W2220-2J	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-2K	ATTENDANT HANDESET CRADLE ASSEMBLY	BAE SYSTEMS	A330, A340	23-42-02	AEG Sevilla
476W2220-2L	ATTENDANT HANDESET CRADLE ASSEMBLY	BAE SYSTEMS	A330, A340	23-42-02	AEG Sevilla
476W2220-7G	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-7H	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-7J	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-7L	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-7M	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-7N	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-9G	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-9H	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-9J	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-9L	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-9M	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
476W2220-9N	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Sevilla
47830-1	Door Actuator Assembly		(DHC)Dash 8-Q400,C-130	32-31-11	AEG Sevilla
47840-7	Noise Landing Gear FWD Doors Linkage Assembly		(DHC)Dash 8-Q400	32-22-01	AEG Sevilla
47840-9	Noise Landing Gear FWD Doors Linkage Assembly		(DHC)Dash 8-Q400	32-22-01	AEG Sevilla
47860-3	Noise Landing Gear FWD Doors Linkage Assembly		(DHC)Dash 8-Q400	32-22-01	AEG Sevilla
47860-4	Noise Landing Gear FWD Doors Linkage Assembly		(DHC)Dash 8-Q400	32-22-01	AEG Sevilla
4812 SERIES	MOTOR PUMP FILTER UNIT ASSY		A330, A340		AEG Sevilla
48150-5	Steering Control Manifold Assembly NLG		(DHC)Dash 8-Q400	32-51-02	AEG Sevilla
48150-7	Steering Control Manifold Assembly NLG		(DHC)Dash 8-Q400	32-51-02	AEG Sevilla
48150-9	Steering Control Manifold Assembly NLG		(DHC)Dash 8-Q400	32-51-02	AEG Sevilla
48285-SERIES	AIRCRAFT DIRECT CURRENT MOTORS		A330, A340		AEG Bilbao
48315-3	MOTOR FIELD	HONEYWELL	A330, A340		AEG Bilbao
48364-I-SERIES	ENGINE STARTER MOTOR	ALLIEDSIGNAL	A330, A340		AEG Sevilla
48378-SERIES	ENGINE STARTER MOTOR	AIRESEARCH	A330, A340	49	AEG Sevilla
48510-1	CRAM Mechanism Assembly Alternate Extension Components, I.M.G.		(DHC)Dash 8-Q400	32-34-03	AEG Sevilla
49000-I10-38	Dressed Shock Strut Assembly MLG			32-11-05	AEG Sevilla
49050-3TO-20	Dressed Shock Strut Assembly MLG			32-11-06	AEG Sevilla
49103-1-3-5-7-9-11-13-	Wiring Harness Assembly-MLG			32-61-01	AEG Sevilla
49300-3TO-10	Side Stay Assembly, Main Landing Gear			32-11-12	AEG Sevilla
49313-1-3-5-7-9-11-13-	Wiring Harness Assembly-MLG			32-61-01	AEG Sevilla
49400-3TO-7	Lock Actuator Assembly			32-11-13	AEG Sevilla
49500-9TO-18	Uplock Assembly MLG			32-11-14	AEG Sevilla
49600-5-7-11-13	Retraction Actuator Assembly- MLG			32-11-28	AEG Sevilla
49650-1-3	Pressure Switch/Restrictor Assembly- MLG			32-32-06	AEG Sevilla
49700-3	Auxiliary Actuator Assembly- MLG		B/37,CRJ-700,CRJ900 Regional Jet-900,C-130,	32-11-18	AEG Sevilla
49800-3	MLG Damper Assembly		B/37,CRJ-700,CRJ900 Regional Jet-900	32-10-02	AEG Sevilla
49901-1	Tail Bumper Skid Assembly		B/37,CRJ-700,CRJ900 Regional Jet-900	32-71-10	AEG Sevilla
49906-3-5-7	Shock Absorber Assembly Tail Bumper			32-71-01	AEG Sevilla
49913-5	Tail Bumper Strike Indicator Assembly		B/37,CRJ-700,CRJ900 Regional Jet-900	32-71-15	AEG Sevilla
49951-1	Tail Bumper Skid Assembly		CRJ-700,CRJ900 Regional Jet-900	32-71-11	AEG Sevilla
49952-1	Tail Bumper Strike Indicator Assembly		CRJ900 Regional Jet	32-71-16	AEG Sevilla
4E1213	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1283	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1294	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1311	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1327	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1350	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1387	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1560-2	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1639	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1749-2	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E1908-1	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
4E2360-2	Brush Assemblies Electrothermal Propeller De-icing System			30-60-01	AEG Sevilla
50-0024-17	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340		AEG Sevilla
50-0024-23	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340		AEG Sevilla
50-0024-25	LIGHT TAXI	HONEYWELL	C-295		AEG Sevilla
50-0024-3	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340	33-41-38	AEG Sevilla
50-0024-5	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340	33-41-38	AEG Sevilla
50-0024-7	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340	334138	AEG Sevilla
50-0024-9	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340	334138	AEG Sevilla
500040-03	BATTERY	SAFT	A320 F 28.F 27 C-295	34-47-27	AEG Sevilla
50-0176-1	LIGHT, TAKE-OFF	GRIMES AERO - ELECTRONICS	A330,A318,A321,A320,A319,A320-200	33-46-12	AEG Sevilla
50-0253	Taxing Light			33-42-10	AEG Sevilla
50-0253-1	Taxing Light		C-130	33-42-10	AEG Sevilla
5004236-2	BRAKE ASSEMBLY	AIRCRAFT BRAKING SYSTEM	A330, A340	32-43-47	AEG Sevilla
5004236-3	BRAKE ASSEMBLY	AIRCRAFT BRAKING SYSTEM	A330, A340	32-43-47	AEG Sevilla
5006484-1	BRAKE ASSEMBLY	AIRCRAFT BRAKING SYSTEM	C-212	32-43-47	AEG Sevilla
5006484-2	BRAKE ASSEMBLY	AIRCRAFT BRAKING SYSTEM	C-212	32-43-47	AEG Sevilla
5006484-3	BRAKE ASSY	MAISS	C-212		AEG Sevilla
5006586-1	HUB ASSY	MEGGITT	C-212	32-40-90	AEG Sevilla
500702-5211	AXIVANE FAN	HAMILTON1	DC-9, MD-80	21-50-10	AEG Sevilla
5009904-5	BREAK UNIT	ABS	F100		AEG Sevilla
50-1026016-01	NLG RETRACTION ACTUATOR ASSY		A340-600		AEG Sevilla
50-1026017-01	NLG RETRACT ACTUATOR ASSY		A340-600		AEG Sevilla
50-1026034-00	NLG RETRACTION ACTUATOR ASSY		A340-600		AEG Sevilla
501-1078-07	EMERGENCY POWER SUP	JET ELECTRONICS AND TECHNOLOGY	A330, A340	24-20-03	AEG Sevilla
501-1-13775-004	STARTER MOTOR	PLESSEY DYNAMICS	A330, A340	80	AEG Sevilla
501-1-13775-006	STARTER MOTOR	PLESSEY DYNAMICS	A330, A340	80	AEG Sevilla
501-1-13775-06A	STARTER MOTOR	PLESSEY DYNAMICS	A330, A340	80	AEG Sevilla
501-1-14561	STARTER MOTOR		A330, A340		AEG Sevilla
501-1-14561-004	MOTOR-STARTER	EATON	A320,CFM56-5A,CFM56-5B	49-41-07	AEG Sevilla
501-1-14972-001	END BELL		A330, A340		AEG Bilbao
501-1247-03	Stick Pusher System		CRJ Regional Jet-200,C-130	27-30-10	AEG Sevilla
501637-1	SLEEVE-AXLE/MLG	A320	A320		AEG Sevilla
501637-1R	SLEEVE-AXLE/MLG	A320	A321		AEG Sevilla
50-1206222-00	AFT PINTLE PIN LH	AIRBUS	A340-500		AEG Sevilla
50-1206222-00	AFT PINTLE PIN RH	AIRBUS	A340/500		AEG Sevilla
5020-1	CVR Audio Mixer			23-71-05	AEG Sevilla
50-2106020-00	LOWER TORQUE LINK	SAFRAN	A330	32-12-61	AEG Sevilla
50-2106021-00	UPPER TORQUE LINK	SAFRAN	A330	32-12-61	AEG Sevilla
50-2106025-00	BRAKE ROD	SAFRAN	A330	32-12-61	AEG Sevilla
50-2106026-00	RETRACTION LINK (LH)	SAFRAN	A330	32-12-61	AEG Sevilla
50-2106027-00	RETRACTION BRACKET (LH)	SAFRAN	A330	32-12-61	AEG Sevilla
50-2106026-00	RETRACTION LINK (RH)	SAFRAN	A330	32-12-61	AEG Sevilla
50-2106027-00	RETRACTION BRACKET (RH)	SAFRAN	A330	32-12-61	AEG Sevilla
50-2107001-00	MAIN FITTING LH	SAFRAN	A330	32-12-61	AEG Sevilla
50-2107002-00	SHORTENING LINK (LOWER)	SAFRAN	A330	32-12-61	AEG Sevilla
50-2107003-00	SHORTENING LINK (UPPER)	SAFRAN	A330	32-12-61	AEG Sevilla
50-2108001-00	MAIN FITTING (RH)	SAFRAN	A330	32-12-61	AEG Sevilla
50-2109008-00	RECOIL NUT	SAFRAN	A330		AEG Sevilla
50-2113001-00	RETRACTION ACTUATOR CYLINDER	SAFRAN	A330	32-31-90	AEG Sevilla
50-2113002-00	RETRACTION ACTUATOR PISTON ROD	SAFRAN	A330	32-31-90	AEG Sevilla
50-2113003-00	RETRACTION ACTUATOR PISTON HEA	SAFRAN	A330	32-31-90	AEG Sevilla
50-2113004-00	RETRACTION ACTUATOR GLAND	SAFRAN	A330	32-31-90	AEG Sevilla
50-2117002-00	BOGIE BEAM	#N/D	A330		AEG Sevilla

519892-4-1	ENGINE STARTER MOTOR	AIRESEARCH	Challenger,Hawker,Gulfstream,146,CRJ Boeing,144,300	49-41-04,49	AEG Sevilla	
519892-5	ENGINE STARTER MOTOR	HONEYWELL	Challenger,Hawker,Gulfstream	49	AEG Sevilla	
519892-5	Engine Starter Motor		Hawker,Gulfstream,Challenger	49-41-04	AEG Sevilla	
519892-5-1	ENGINE STARTER MOTOR	AIRESEARCH	Challenger,Hawker,Gulfstream,146,CRJ	49-41-04,49	AEG Sevilla	
519892-6	ENGINE STARTER MOTOR	HONEYWELL	Challenger,Hawker,Gulfstream,CRJ Boeing,144,300	49	AEG Sevilla	
51SP6231-1	Engine Air Intake Pneumatic De-Icers			17470	AEG Sevilla	
51U056	SWITCH PRESSURE	EATON		PW4000 79-21-26	AEG Sevilla	
51U056-001	SWITCH PRESSURE	EATON		PW4000 79-21-26	AEG Sevilla	
51U012	SWITCH PRESSURE	EATON		PW4000 79-21-26	AEG Sevilla	
52000-9-13-15-17-19-2	Dressed Shock Strut Assembly NLG				32-21-06 AEG Sevilla	
52000-13-15-17	Drag Brace Assembly- NLG				32-21-05 AEG Sevilla	
522-0688-003	ANTENNA	COLLINS	M180,M0-11DC-10,DC-9,DC-8,A310,B747-300,CRJ900,CRJ700,CRJ900 Regional Jet, DC-8,CRJ700,CRJ900 Regional Jet	CAM-5366	AEG Sevilla	
522-1660-031	TRANSCIVER_HF	ROCKWELL COLLINS			23 AEG Sevilla	
522-24447-251	CONTROL BOX				AEG Sevilla	
522-2996-00	MARKER BEACON	ROCKWELL COLLINS	C-130,M180,DC-10,DC-9,DC-8,A310,B747-300,CRJ900,CRJ700,CRJ900 Regional Jet, DC-8,CRJ700,CRJ900 Regional Jet	34	AEG Sevilla	
522-4088-203	VHF TRAN	ROCKWELL COLLINS		23-24-00	AEG Sevilla	
52250-5	Lockdown Actuator Assembly NLG			32-21-30	AEG Sevilla	
52300-9	Retract Actuator Assembly-NLG			DC-8,CRJ700,CRJ900 Regional Jet-900,1,300	32-21-32 AEG Sevilla	
52350-5-6	Steering Actuator Assembly-NLG				32-51-03 AEG Sevilla	
52501-V-3V-5	Wiring Harness Assembly-NLG				32-61-02 AEG Sevilla	
52505-1	Wiring Harness Assembly-NLG				32-61-02 AEG Sevilla	
52506-1	Wiring Harness Assembly-NLG				32-61-02 AEG Sevilla	
52512-1	Wiring Harness Assembly-NLG				32-61-02 AEG Sevilla	
52513-V-3V-5	Wiring Harness Assembly-NLG				32-61-02 AEG Sevilla	
52514-V-3V-5	Wiring Harness Assembly-NLG				32-61-02 AEG Sevilla	
52600-3	NLG Forward Door Mechanism Assembly				32-22-02 AEG Sevilla	
5283D100-1	STARTER APJ				UNK AEG Sevilla	
5283D100-11	STARTER APJ				UNK AEG Sevilla	
5283D100-13	STARTER APJ	EEMCO	T-621-47CL, T621-46CL, 46C2, 46C2A, 46C2, 46C2A, 46C2, 46C2A	49	AEG Sevilla	
5283D100-15	STARTER APJ				UNK AEG Sevilla	
5283D100-17	STARTER APJ				UNK AEG Sevilla	
5283D100-19	STARTER APJ				UNK AEG Sevilla	
5283D100-21	STARTER MOTOR	EATON	B777,B737	49	AEG Sevilla	
5283D100-23	STARTER MOTOR	EATON	B777,B737	49	AEG Sevilla	
5283D100-25	STARTER MOTOR	EEMCO	UNK	49-41-03	AEG Sevilla	
5283D100-27	STARTER MOTOR	EATON	A330, A340	49-41-05	AEG Sevilla	
5283D100-3	STARTER APJ				UNK AEG Sevilla	
5283D100-5	STARTER APJ	EEMCO	T-621-47CL, T621-46CL, 46C2, 46C2A, 46C2, 46C2A, 46C2, 46C2A	49	AEG Sevilla	
5283D100-9	STARTER ELECTRIC	EATON	B737	49	AEG Sevilla	
5283D100-SERIES	MOTOR STARTER				UNK 49-41-05 AEG Sevilla	
52CS2610	Ground Spoiler Assy		B737	52CS2610	AEG Sevilla	
53000-1-3	Steering Manifold Assembly Nose Landing Gear				32-51-04 AEG Sevilla	
53050-1-3-5-7-9-10	Hydraulic Swivel Assembly Nose Landing Gear				32-51-06 AEG Sevilla	
53080-02	PUMP	Boeing	B787	29-10-82	AEG Sevilla	
53080-06	MOTOR DRIVEN HYDRAULIC PUMP	PARKER	B787	29-10-82	AEG Sevilla	
53150-2	PRESSURE VALVE	STERER	A330, A340		AEG Sevilla	
53340-3-5-7	Selector Valve				32-30-04 AEG Sevilla	
5348-200-80-10	Fuel Tank Temp Indicator		DHC8,Dash 8	28-60-01	AEG Sevilla	
53520-1	Landing Gear Control Assembly		Dash 8,DHC8,Dash 8-100,DHC8,Dash 8-300,DFC,Dash 8-300,DFC	32-30-41	AEG Sevilla	
53721-3	STRUT ASSY-NLG DOOR	AVIBANK	B767	32-22-1	AEG Sevilla	
540-1148-4	Nose Cow Anti-Ice Shutoff Valve				CRJ-700,CRJ900 Regional Jet-900,CRJ700,CRJ900 Regional Jet, DC-8,DHC8,Dash 8-100,DHC8,Dash 8-300,DFC,Dash 8-300,DFC	32-22-01 AEG Sevilla
5427-115-80-10	Dual Hyd Pressure Indicator				DHC8,Dash 8,DHC8,Dash 8-100,DHC8,Dash 8-300,DFC,Dash 8-300,DFC	29-60-01 AEG Sevilla
5427-116-80-10	Dual De-Ice Pressure Indicator				DHC8,Dash 8	30-60-01 AEG Sevilla
5427-361-80-10	Dual Oil Press Temp Indicator				DHC8,Dash 8,DHC8,Dash 8-100,DHC8,Dash 8-300,DFC,Dash 8-300,DFC	79-60-01 AEG Sevilla
5428-150-80-10	Park Brake Pressure Indicator				DHC8,Dash 8,C-130	32-60-01 AEG Sevilla
54-456	SLEEVE-AXLEMLG	BF GOODRICH	A320	32	AEG Sevilla	
54-456-1	SLEEVE-AXLEMLG	BF GOODRICH	A320	32	AEG Sevilla	
54-456-2	SLEEVE-AXLEMLG	BF GOODRICH	A320	32	AEG Sevilla	
54-472	SLEEVE, MLG AXLE	BF GOODRICH	A330, A330F, A340	32-41-58	AEG Sevilla	
54-480	NLG AXLES SLEEVES	BF GOODRICH	A330, A330F, A340	32-41-59	AEG Sevilla	
54-592	AXLE SLEEVE	BF GOODRICH-MESSIER	A340-500	32-41-95	AEG Sevilla	
54-593-1	AXLE SLEEVE	SAFKAN LANDING GEAR	A340-600		AEG Sevilla	
54C5467E01	Ground Spoiler Assy				27-60-01 AEG Sevilla	
55000-1-2	Dressed Shock Strut Assembly Main Landing Gear				32-11-34 AEG Sevilla	
55-1000-200D9	TRANSMITTER,PRESSUR		CN-235		AEG Sevilla	
551050 SERIES	CYLINDRAL HYD PRESS ACCUM		A330, A340		AEG Sevilla	
551200 SERIES	CYLINDRAL HYD PRESS ACCUM		A330, A340		AEG Sevilla	
55-1205231-01	AFT PINTLE PIN NUT	AIRBUS	A340-500		AEG Sevilla	
552430 SERIES	CYLINDRAL HYD PRESS ACCUM		A330, A340		AEG Sevilla	
55300-1-2	Side Stay Assembly Main Landing Gear				32-11-35 AEG Sevilla	
5543001-8	SHIMMY DAMPER	CESSNA	UNK		AEG Bilbao	
55-4505021-00	UPPER DIAPHRAGM TUBE	SAFRAN	A320		AEG Sevilla	
55-4533005-00	UPPER DIAPHRAGM TUBE	SAFRAN	A320		AEG Sevilla	
55540-2	Solenoid Operated Valve				32-30-04 AEG Sevilla	
5562-1	Passenger Address/Cabin Interphone Controller				23-31-10 AEG Sevilla	
5563-1	Interphone Handset/Cradle				CRJ1000 Regional Jet-1000,CRJ-700,CRJ900,Boeing,144,300,CRJ-1	23-31-01 AEG Sevilla
5617-352-91-11	INDICATOR ASSEMBLY	BRION LEROLUX	A330, A340	77	AEG Sevilla	
5617-352-91-12	DUAL ENGINE OIL PRESSURE TEMP IND	THALES	A330, A340	77	AEG Sevilla	
5617-353-99-10	DUAL ENGINE OIL PRESSURE TEMP IND	THALES	A330, A340	77	AEG Sevilla	
5617-355-91-11	DUAL ENGINE OIL PRESSURE TEMP IND	THALES	A330, A340	77	AEG Sevilla	
5617-358-91-10	DUAL ENGINE OIL PRESSURE TEMP IND	THALES	A330, A340	77	AEG Sevilla	
5617-359-80-10	DUAL ENGINE OIL PRESSURE TEMP IND	THALES	A330, A340	77	AEG Sevilla	
5618-1	MANO-CONTACT		A330, A340		77 AEG Sevilla	
565CA01	Contact				24-21-28 AEG Sevilla	
57000-1-3	Aileron Power Control Unit Assembly				27-14-03 AEG Sevilla	
5786-01	PUMP MOTOR PACKAGE	PARKER HANNIFIN	B747-400,B747-300,DLC-8,B737,B737-800,CRJ700,CRJ900	29-20-15	AEG Sevilla	
5786-02	PUMP MOTOR PACKAGE	ABEX AEROSPACE	B747-400,B747-300,DLC-8,B737,B737-800,CRJ700,CRJ900	29-20-15	AEG Sevilla	
5786-03	PUMP MOTOR PACKAGE	PARKER HANNIFIN	B747-400,B747-300,DLC-8,B737,B737-800,CRJ700,CRJ900	29-20-15	AEG Sevilla	
5786-04	PUMP MOTOR PACKAGE	PARKER HANNIFIN	B747-400,B747-300,DLC-8,B737,B737-800,CRJ700,CRJ900	29-20-15	AEG Sevilla	
5786-05	PUMP MOTOR PACKAGE	PARKER HANNIFIN	B747-400,B747-300,DLC-8,B737,B737-800,CRJ700,CRJ900	29-20-15	AEG Sevilla	
5786-06	PUMP MOTOR PACKAGE	PARKER HANNIFIN	B747-400,B747-300,DLC-8,B737,B737-800,CRJ700,CRJ900	29-20-15	AEG Sevilla	
5786-07	PUMP MOTOR PACKAGE	PARKER HANNIFIN	B747-400,B747-300,DLC-8,B737,B737-800,CRJ700,CRJ900	29-20-15	AEG Sevilla	
5786-10	PUMP MOTOR PACKAGE	PARKER HANNIFIN	B747-400,B747-300,DLC-8,B737,B737-800,CRJ700,CRJ900	29-20-15	AEG Sevilla	
5786-11	MOTOR PUMP	PARKER	700,800,800,800,800,800,800,800	29	AEG Sevilla	
57420-1	Solenoid Operated Landing Gear Valve				Dash 8,DHC8,Dash 8-100,C-130 32-30-10 AEG Sevilla	
57420-3	Solenoid Operated Landing Gear Valve				Dash 8,DHC8,Dash 8-100,C-130 32-30-10 AEG Sevilla	
57420-5	Solenoid Operated Landing Gear Valve				Dash 8,DHC8,Dash 8-100,DHC8,Dash 8-300,DFC,Dash 8-300,DFC 32-30-10 AEG Sevilla	
58057-82	GYRO COMPAS	SFIM	UNK	34-71-01	AEG Sevilla	
5821-01-3924589	RECEIVER TRANSMITTER				UNK AEG Sevilla	
5830202-101	Low Pressure Turbine Case Cooling Valve		MD-11,B747,A300	75-24-15	AEG Sevilla	
5830202-102	Low Pressure Turbine Case Cooling Valve		B747,MD-11,A300	75-24-15	AEG Sevilla	
5830202-103	Low Pressure Turbine Case Cooling Valve		B747,MD-11,A300	75-24-15	AEG Sevilla	
5830202-104	Low Pressure Turbine Case Cooling Valve		MD-11,B747,A300	75-24-15	AEG Sevilla	
5830202-105	Low Pressure Turbine Case Cooling Valve		B747,MD-11,B777,A300	75-24-15	AEG Sevilla	
5830202-106	Low Pressure Turbine Case Cooling Valve		B747,MD-11,A300	75-24-15	AEG Sevilla	
5-87448-3001	FLAP DRIVE POWER UNIT ASSEMBLY	BOEING	C-130,DC-8,B707	27-06-11	AEG Sevilla	
5-87448-3002	FLAP DRIVE POWER UNIT ASSEMBLY	BOEING	A330, A340	27	AEG Sevilla	
5-87448-3006	FLAP DRIVE POWER UNIT ASSEMBLY	BOEING	A330, A340	27	AEG Sevilla	
5-87448-3007	FLAP DRIVE POWER UNIT ASSEMBLY	BOEING	DC-8,B707	27-06-01	AEG Sevilla	
5910447-5059	NLG	BOEING	B737	32	AEG Sevilla	
5910447-5161/3920201	NLG ASSY/DRAG BRACE				UNK AEG Sevilla	
5910447-5561/3920202	NLG ASSY/DRAG BRACE				UNK AEG Sevilla	
5913667-1	GENERATOR-APJ	LUCAS UK	A321,A320,A319,A318,CFM56-5A,CFM56-5B,CFM56-5C,CFM56-5D,CFM56-5E,CFM56-5F,CFM56-5G,CFM56-5H,CFM56-5J,CFM56-5K,CFM56-5L,CFM56-5M,CFM56-5N,CFM56-5P,CFM56-5Q,CFM56-5R,CFM56-5S,CFM56-5T,CFM56-5U,CFM56-5V,CFM56-5W,CFM56-5X,CFM56-5Y,CFM56-5Z,CFM56-5AA,CFM56-5AB,CFM56-5AC,CFM56-5AD,CFM56-5AE,CFM56-5AF,CFM56-5AG,CFM56-5AH,CFM56-5AI,CFM56-5AJ,CFM56-5AK,CFM56-5AL,CFM56-5AM,CFM56-5AN,CFM56-5AO,CFM56-5AP,CFM56-5AQ,CFM56-5AR,CFM56-5AS,CFM56-5AT,CFM56-5AU,CFM56-5AV,CFM56-5AW,CFM56-5AX,CFM56-5AY,CFM56-5AZ,CFM56-5BA,CFM56-5BB,CFM56-5BC,CFM56-5BD,CFM56-5BE,CFM56-5BF,CFM56-5BG,CFM56-5BH,CFM56-5BI,CFM56-5BJ,CFM56-5BK,CFM56-5BL,CFM56-5BM,CFM56-5BN,CFM56-5BO,CFM56-5BP,CFM56-5BQ,CFM56-5BR,CFM56-5BS,CFM56-5BT,CFM56-5BU,CFM56-5BV,CFM56-5BW,CFM56-5BX,CFM56-5BY,CFM56-5BZ,CFM56-5CA,CFM56-5CB,CFM56-5CC,CFM56-5CD,CFM56-5CE,CFM56-5CF,CFM56-5CG,CFM56-5CH,CFM56-5CI,CFM56-5CJ,CFM56-5CK,CFM56-5CL,CFM56-5CM,CFM56-5CN,CFM56-5CO,CFM56-5CP,CFM56-5CQ,CFM56-5CR,CFM56-5CS,CFM56-5CT,CFM56-5CU,CFM56-5CV,CFM56-5CW,CFM56-5CX,CFM56-5CY,CFM56-5CZ,CFM56-5DA,CFM56-5DB,CFM56-5DC,CFM56-5DD,CFM56-5DE,CFM56-5DF,CFM56-5DG,CFM56-5DH,CFM56-5DI,CFM56-5DJ,CFM56-5DK,CFM56-5DL,CFM56-5DM,CFM56-5DN,CFM56-5DO,CFM56-5DP,CFM56-5DQ,CFM56-5DR,CFM56-5DS,CFM56-5DT,CFM56-5DU,CFM56-5DV,CFM56-5DW,CFM56-5DX,CFM56-5DY,CFM56-5DZ,CFM56-5EA,CFM56-5EB,CFM56-5EC,CFM56-5ED,CFM56-5EE,CFM56-5EF,CFM56-5EG,CFM56-5EH,CFM56-5EI,CFM56-5EJ,CFM56-5EK,CFM56-5EL,CFM56-5EM,CFM56-5EN,CFM56-5EO,CFM56-5EP,CFM56-5EQ,CFM56-5ER,CFM56-5ES,CFM56-5ET,CFM56-5EU,CFM56-5EV,CFM56-5EW,CFM56-5EX,CFM56-5EY,CFM56-5EZ,CFM56-5FA,CFM56-5FB,CFM56-5FC,CFM56-5FD,CFM56-5FE,CFM56-5FF,CFM56-5FG,CFM56-5FH,CFM56-5FI,CFM56-5FJ,CFM56-5FK,CFM56-5FL,CFM56-5FM,CFM56-5FN,CFM56-5FO,CFM56-5FP,CFM56-5FQ,CFM56-5FR,CFM56-5FS,CFM56-5FT,CFM56-5FU,CFM56-5FV,CFM56-5FW,CFM56-5FX,CFM56-5FY,CFM56-5FZ,CFM56-5GA,CFM56-5GB,CFM56-5GC,CFM56-5GD,CFM56-5GE,CFM56-5GF,CFM56-5GG,CFM56-5GH,CFM56-5GI,CFM56-5GJ,CFM56-5GK,CFM56-5GL,CFM56-5GM,CFM56-5GN,CFM56-5GO,CFM56-5GP,CFM56-5GQ,CFM56-5GR,CFM56-5GS,CFM56-5GT,CFM56-5GU,CFM56-5GV,CFM56-5GW,CFM56-5GX,CFM56-5GY,CFM56-5GZ,CFM56-5HA,CFM56-5HB,CFM56-5HC,CFM56-5HD,CFM56-5HE,CFM56-5HF,CFM56-5HG,CFM56-5HH,CFM56-5HI,CFM56-5HJ,CFM56-5HK,CFM56-5HL,CFM56-5HM,CFM56-5HN,CFM56-5HO,CFM56-5HP,CFM56-5HQ,CFM56-5HR,CFM56-5HS,CFM56-5HT,CFM56-5HU,CFM56-5HV,CFM56-5HW,CFM56-5HX,CFM56-5HY,CFM56-5HZ,CFM56-5IA,CFM56-5IB,CFM56-5IC,CFM56-5ID,CFM56-5IE,CFM56-5IF,CFM56-5IG,CFM56-5IH,CFM56-5II,CFM56-5IJ,CFM56-5IK,CFM56-5IL,CFM56-5IM,CFM56-5IN,CFM56-5IO,CFM56-5IP,CFM56-5IQ,CFM56-5IR,CFM56-5IS,CFM56-5IT,CFM56-5IU,CFM56-5IV,CFM56-5IW,CFM56-5IX,CFM56-5IY,CFM56-5IZ,CFM56-5JA,CFM56-5JB,CFM56-5JC,CFM56-5JD,CFM56-5JE,CFM56-5JF,CFM56-5JG,CFM56-5JH,CFM56-5JI,CFM56-5JJ,CFM56-5JK,CFM56-5JL,CFM56-5JM,CFM56-5JN,CFM56-5JO,CFM56-5JP,CFM56-5JQ,CFM56-5JR,CFM56-5JS,CFM56-5JT,CFM56-5JU,CFM56-5JV,CFM56-5JW,CFM56-5JX,CFM56-5JY,CFM56-5JZ,CFM56-5KA,CFM56-5KB,CFM56-5KC,CFM56-5KD,CFM56-5KE,CFM56-5KF,CFM56-5KG,CFM56-5KH,CFM56-5KI,CFM56-5KJ,CFM56-5KL,CFM56-5KM,CFM56-5KN,CFM56-5KO,CFM56-5KP,CFM56-5KQ,CFM56-5KR,CFM56-5KS,CFM56-5KT,CFM56-5KU,CFM56-5KV,CFM56-5KW,CFM56-5KX,CFM56-5KY,CFM56-5KZ,CFM56-5LA,CFM56-5LB,CFM56-5LC,CFM56-5LD,CFM56-5LE,CFM56-5LF,CFM56-5LG,CFM56-5LH,CFM56-5LI,CFM56-5LJ,CFM56-5LK,CFM56-5LL,CFM56-5LM,CFM56-5LN,CFM56-5LO,CFM56-5LP,CFM56-5LQ,CFM56-5LR,CFM56-5LS,CFM56-5LT,CFM56-5LU,CFM56-5LV,CFM56-5LW,CFM56-5LX,CFM56-5LY,CFM56-5LZ,CFM56-5MA,CFM56-5MB,CFM56-5MC,CFM56-5MD,CFM56-5ME,CFM56-5MF,CFM56-5MG,CFM56-5MH,CFM56-5MI,CFM56-5MJ,CFM56-5MK,CFM56-5ML,CFM56-5MM,CFM56-5MN,CFM56-5MO,CFM56-5MP,CFM56-5MQ,CFM56-5MR,CFM56-5MS,CFM56-5MT,CFM56-5MU,CFM56-5MV,CFM56-5MW,CFM56-5MX,CFM56-5MY,CFM56-5MZ,CFM56-5NA,CFM56-5NB,CFM56-5NC,CFM56-5ND,CFM56-5NE,CFM56-5NF,CFM56-5NG,CFM56-5NH,CFM56-5NI,CFM56-5NJ,CFM56-5NK,CFM56-5NL,CFM56-5NM,CFM56-5NN,CFM56-5NO,CFM56-5NP,CFM56-5NQ,CFM56-5NR,CFM56-5NS,CFM56-5NT,CFM56-5NU,CFM56-5NV,CFM56-5NW,CFM56-5NX,CFM56-5NY,CFM56-5NZ,CFM56-5OA,CFM56-5OB,CFM56-5OC,CFM56-5OD,CFM56-5OE,CFM56-5OF,CFM56-5OG,CFM56-5OH,CFM56-5OI,CFM56-5OJ,CFM56-5OK,CFM56-5OL,CFM56-5OM,CFM56-5ON,CFM56-5OO,CFM56-5OP,CFM56-5OQ,CFM56-5OR,CFM56-5OS,CFM56-5OT,CFM56-5OU,CFM56-5OV,CFM56-5OW,CFM56-5OX,CFM56-5OY,CFM56-5OZ,CFM56-5PA,CFM56-5PB,CFM56-5PC,CFM56-5PD,CF			

5936970-413008	FLAP CTRL VLV	NONE SPECIFIED	UNK		AEG Sevilla
597695	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
600500-3	Soap Dispenser			38-11-25	AEG Sevilla
600500-7	Soap Dispenser			38-11-25	AEG Sevilla
6007049-3	Brake Control Valve			32-48-09	AEG Sevilla
6007050-3	Park Brake Valve			32-48-10	AEG Sevilla
601010-4	Fill Cap Assembly			38-10-15	AEG Sevilla
60-1321-1	POWER-SUPPLY-BTRY-EMER-LT	GRIMES AERO	MD80,DC-W,Dash 8,ATP,B737-500,B737-	33-50-42	AEG Sevilla
60-1321-1LB	EMERGENCY EXIT LIGHT POWER SUPPLY	GRIMES AERO	A320,MD80,DC-W,Dash 8,ATP,B737-500,B737-	33-50-42	AEG Sevilla
60-1321-5	EMERGENCY EXIT LIGHT POWER SUPPLY	GRIMES AERO	MD80,DC-W,Dash 8,ATP,B737-500,B737-	33-50-42	AEG Sevilla
60-1321-5LB	EMERGENCY EXIT LIGHT POWER SUPPLY	GRIMES AERO	A320,MD80,DC-W,Dash 8,ATP,B737-500,B737-	33-50-42	AEG Sevilla
60-1321-7	EMERGENCY EXIT LIGHT POWER SUPPLY	GRIMES AERO	B747-200,DC-W,Dash 8,ATP,B737-500,B737-	33-50-42	AEG Sevilla
60-1321-7LB	EMERGENCY EXIT LIGHT POWER SUPPLY	GRIMES AERO	A320,MD80,DC-W,Dash 8,ATP,B737-500,B737-	33-50-42	AEG Sevilla
60IR43135-3	Pump, Water, Warm Water Wash System			38-11-00	AEG Sevilla
60-2799-1	Power Supply			33-50-32	AEG Sevilla
60-2799-13	Power Supply			33-50-32	AEG Sevilla
60-2799-3	Power Supply			33-50-32	AEG Sevilla
60-2799-5	Power Supply			33-50-32	AEG Sevilla
60-2799-7	Power Supply			33-50-32	AEG Sevilla
60-2799-9	Power Supply			33-50-32	AEG Sevilla
60-3274-5	POWER-SUPPLY	GRIMES	S76 Sikorsky	33-50-41	AEG Sevilla
60-3757-5	STROBE LIGHT	HONEYWELL	Q400	33-50-68	AEG Sevilla
60-3895-1	POWER-SUPPLY-BTRY-EMER-LT	GRIMES / HONEYWELL	C-212, CN-235, C-295	33-41-34-33	AEG Sevilla
6047755P01	Alternator Stator/Alternator Rotor Vc.			74-12-00	AEG Sevilla
60-4983-3	POWER SUPPLY ANTI-COLLISION SYSTEM	HONEYWELL	B737, B767,B777,B747	33-44-27	AEG Sevilla
60-4983-6	STROBE POWER SUPPLY	GRIMES AEROSPACE	B737	33-44-27	AEG Sevilla
605146-4	STATOR	AIRESEARCH	UNK	TP16	AEG Bilbao
605290 SERIES	MOTOR DRIVEN VANEXIAL FAN	HONEYWELL	A330, A340	21-20-32	AEG Sevilla
605457-2	MOTOR DRIVEN CENTRIFUGAL FAN	HONEYWELL	DC-10, B747, B767, MD-11	21-20-10	AEG Sevilla
605457-3	MOTOR DRIVEN CENTRIFUGAL FAN	HONEYWELL	B767, DC-10, MD-11, MD-80, B747	21-20-10	AEG Sevilla
605457-7	FAN	HONEYWELL	B767, MD-80, B747,B737, B767, B777	21-24-02	AEG Sevilla
605457-8	MOTOR DRIVEN CENTRIFUGAL FAN	HONEYWELL	B767, DC-10, MD-11, B747,B757	21-20-10	AEG Sevilla
605675-1	MOTOR DRIVEN VANEXIAL FAN	AIRESEARCH	B727, B747, DC-8, B737,B757	21-20-20	AEG Sevilla
605675-2	MOTOR DRIVEN VANEXIAL FAN	AIRESEARCH	B727, B747, DC-8	21-20-20	AEG Sevilla
6058003-X	STARTER GENERATOR		Lejeune		AEG Sevilla
606622-1	CABIN AIR RECIRCULATION FAN	HONEYWELL	B747/330U, B767/330U, B767/330U,	21-25-06	AEG Sevilla
606622-2	CABIN AIR RECIRCULATION FAN	AIRESEARCH	B747/330U, B767/330U, B767/330U,	21-25-06	AEG Sevilla
606622-3	CABIN AIR RECIRCULATION FAN	AIRESEARCH	B747/330U, B767/330U, B767/330U,	21-25-06	AEG Sevilla
606622-4	CABIN AIR RECIRCULATION FAN	AIRESEARCH	B747/330U, B767/330U, B767/330U,	21-25-06	AEG Sevilla
606635-2	STATOR ASSY - MOTOR	AIRESEARCH	A330, A340	TP16	AEG Bilbao
606707-1	FWD CARGO COMP VENT FAN	ALLIEDSIGNAL	B7-77-300U, B777-200U, B777-300U, B777-300U,	21-25-02	AEG Sevilla
606772-1	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11B757	21-25-04	AEG Sevilla
606772-2	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11B757	21-25-04	AEG Sevilla
606772-3	CABIN AIR RECIRCULATION FAN	HONEYWELL	MD-11B757-200,B767,B757	21-25-04	AEG Sevilla
606772-4	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11B757	21-25-04	AEG Sevilla
606772-5	CABIN AIR RECIRCULATION FAN	HONEYWELL	B757	21-25-04	AEG Sevilla
606772-6	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11B757	21-25-04	AEG Sevilla
606772-7	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11B757	21-25-04	AEG Sevilla
606802-2	WASTE SYSTEM VACUUM BLOWER	ALLIEDSIGNAL	B757,A330,B737-300,B737-300,B737-300,	38-32-02	AEG Sevilla
607518-2	CONTROL TEMPERATURE	GARRETT CANADA	B737,B777,B757	21-60-09	AEG Sevilla
607518-2 SERIES 2	TEMPERATURE CONTROL	GARRETT ALLIED	B737	21-60-09	AEG Sevilla
607518-2 SERIES 3	TEMPERATURE CONTROL	GARRETT ALLIED	B737	21-60-09	AEG Sevilla
607518-2 SERIES 4	TEMPERATURE CONTROL	GARRETT ALLIED	B737	21-60-09	AEG Sevilla
607618-1	BOMBA HIDRAULICA	NAVAIR	P3 ORION, P3 CONVERSION	30-300CH-1210	AEG Sevilla
60800263-1	AUTOBRAKE CONTROL MODULE	PARKER	B737,B757,B747,B727	32-40-01	AEG Sevilla
60800263-2	AUTOBRAKE CONTROL MODULE	THE BOEING	B737,B747-100,B737-300,B757,B747	32-40-01	AEG Sevilla
60800263-3	AUTOBRAKE CONTROL MODULE	PARKER	B747-400,B737,B737-300,B727,B757,B747	32-40-01	AEG Sevilla
60800263-4	AUTOBRAKE CONTROL MODULE	THE BOEING	B737/B747-400,B737-300,B757-300,B737-300,	32-40-01	AEG Sevilla
610120-103	CONTROL ASSY LIGHT		P3		AEG Sevilla
61-2276-1	HOUSING ASSEMBLY	HONEYWELL	A330, A340	33-50-38	AEG Sevilla
6-1404-0000-4	HAND PUMP	ASG	A319 A320 A321	29-21-01	AEG Sevilla
6146-1-6MOD B	DIMMABLE FLUORESCENT LAMP CONTROL		UNK		AEG Sevilla
6146-1-7MOD B	DIMMABLE FLUORESCENT LAMP CONTROL		UNK		AEG Sevilla
61474-108-1	TACHOMETER IND	THALES	A330, A340	77	AEG Sevilla
61474-108-2	TACHOMETER IND	THALES	A330, A340	77	AEG Sevilla
61533-102-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Sevilla
61533-103-1	INDICATOR TEMPERATURE	THALES	A330, A340	77	AEG Sevilla
61533-104-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Sevilla
61533-106-1	INDICATOR TEMPERATURE	THALES	A330, A340	77	AEG Sevilla
61533-107-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Sevilla
61533-109-1	TEMPERATURE IND		A330, A340		AEG Sevilla
61533-111-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Sevilla
61533-121-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Sevilla
6174-1	VALVE, HYDRAULIC FLOW REGULATOR	PNEUDRAU	B747,B737,B727	29-20-07	AEG Sevilla
6174-2	VALVE, HYDRAULIC FLOW REGULATOR	PNEUDRAU	B747,B737,B727	29-20-07	AEG Sevilla
61750-1	Solenoid Operated (MLG) Hydraulic Valve			32-30-02	AEG Sevilla
6190-1	Brake Volumetric Fuse - Overhaul manual			32-40-03	AEG Sevilla
6217100	ACTUATOR ELECTRO-ME		UNK		AEG Sevilla
622-0565-003	INDICATOR SUBASSY	ROCKWELL COLLINS	BEECH	34	AEG Sevilla
622-2551-002	CONTROL EQUIP RADAR	ROCKWELL COLLINS	CN-235	23	AEG Sevilla
622-2938-001	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS	A330, A340	34	AEG Sevilla
622-4404-001	Primary Servo And Servo Mounts				AEG Sevilla
622-5222-100	ADF RECEIVER	ROCKWELL COLLINS	B737	34-53-77	AEG Sevilla
622-6623-005	CONTROL NAVIGATION	ROCKWELL COLLINS	DHC-8, DHC-8-100, DHC-8-200, DHC-8-300,	23-80-10	AEG Sevilla
62461 SERIES	LIQUID COOLED MOTOR	UNKNOWN	A330, A340	29-20-16	AEG Sevilla
62490-7B	Valve, Bleed Air Check			36-10-21	AEG Sevilla
625638-1SERIES1	Mode Selector			21-60-61	AEG Sevilla
625868-1	SELECTOR CABIN ZONE TEMP	HONEYWELL	B767,B757	21-61-02	AEG Sevilla
625868-1 SERIES	CABIN ZONE TEMPERATURE SELECTOR		A330, A340		AEG Sevilla
6271-1	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	B737-300U,B737-300U,B737-300U,B737-	32-40-04	AEG Sevilla
6272-1	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAULICS	DC-8,B737-300,B737-300,B737-300,B737-	32-40-05	AEG Sevilla
6273-1	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	DC-8,B737-300,B737-300,B737-300,B737-	32-40-05	AEG Sevilla
6273-5	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	DC-8,B737-300,B737-300,B737-300,B737-	32-40-05	AEG Sevilla
6274-1	HYDRAULIC FUSE, VOLUMETRIC	BOEING	B737-300,B737-300,B737-300,B737-	32-40-04	AEG Sevilla
627962-2	Duct Temperature Sensor			21-60-60	AEG Sevilla
627964-1	Temperature Selector			21-60-62	AEG Sevilla
630AL01000	Accumulator Unit			33-13-97	AEG Sevilla
6373-1	VALVE, FLOW REGULATOR, HYDRAULIC	PNEUDRAU	B737-300U,B737-300U,B737-300U,B737-	32-51-01	AEG Sevilla
6373-2	VALVE FLOW REGULATOR HYDRAULIC	PNEUDRAU	B737-300U,B737-300U,B737-300U,B737-	32-51-01	AEG Sevilla
64110-D10-1	ALTIMETRO BAROMETRICO	THALES	BELL HELIC EUROCOPTER	34,34-10-03/02	AEG Sevilla
6430497-1	EXCITER ROTOR	HONEYWELL	B737-700		AEG Bilbao
6430580-1	STATOR RESOLVER	HONEYWELL	A330, A340		AEG Bilbao
6430580-2	ROTOR RESOLVER	HONEYWELL	UNK		AEG Bilbao
6430580-3	STATOR RESOLVER	HONEYWELL	A330, A340	24	AEG Bilbao
6430595-1	MAGNET-PERMANENT, GENERATOR	HONEYWELL	A330, A340		AEG Bilbao
6430603-1	END BELL	HONEYWELL	S330, S340		AEG Bilbao
6430612-1	EXCITER STATOR	HONEYWELL	A330, A340		AEG Bilbao
6430621-1	MAIN ROTOR ASSY	HONEYWELL	UNK		AEG Bilbao
6430621-2	MAIN ROTOR ASSY	HONEYWELL	UNK		AEG Bilbao
6430621-3	MAIN ROTOR ASSY	HONEYWELL	UNK		AEG Bilbao
6430624-1	ROTOR	HONEYWELL	B737		AEG Bilbao
6430624-2	ROTOR	HONEYWELL	B737	REWIND	AEG Bilbao
6430624-3	ROTOR AC GENERATOR	HONEYWELL	A330, A340		AEG Bilbao
6430624-4	AC GENERATOR ROTOR	HONEYWELL	A330, A340		AEG Bilbao
6430667-1	RESISTOR BOBBIN	HONEYWELL	A330, A340		AEG Bilbao
6431001-2	STATOR AND HOUSING ASSY	HONEYWELL	A330, A340		AEG Bilbao
6431006-1	EXCITER ROTOR	HONEYWELL	A330, A340		AEG Bilbao
6431006-2	EXCITER ROTOR	HONEYWELL	A330, A340		AEG Bilbao
645172-1	VACUUM BLOWER	HONEYWELL	A320,B737-900,B737-800,B737-700,B737-	38-32-06	AEG Sevilla

64572-2	VACUUM BLOWER	HONEYWELL	B737-400B737-900B737-800B737-1883B737-400B737-900B737-800B737-1883	38-32-06	AEG Sevilla
645405-1	CABIN AIR RECIRCULATION FAN	ALIEDSIGNAL	B737-400B737-900B737-800B737-1883	21-20-18	AEG Sevilla
645405-2	CABIN AIR RECIRCULATION FAN	ALIEDSIGNAL	B737-300B737-400B737-800B737-1883	21-20-18	AEG Sevilla
645405-X	CABIN AIR RECIRCULATION FAN	AIRESEARCH	B737, B747	21	AEG Sevilla
645423-2	ROTOR & SHAFT ASSY	HONEYWELL	A330, A340		AEG Bilbao
645423-3	ROTOR & SHAFT ASSY	HONEYWELL	A330, A340		AEG Bilbao
645458-2	IMPELLER-FAN	UNKNOWOWN	UNK		AEG Sevilla
645705-1	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11B757	21-25-12	AEG Sevilla
645705-2	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11B757	21-25-12	AEG Sevilla
645705-3	CABIN AIR RECIRCULATION FAN LH	AIRESEARCH	B747MD-90MD-11B757B757-200	21-25-12	AEG Sevilla
645705-4	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11B757	21-25-12	AEG Sevilla
64809-416-1	PRESSURE INDICATOR	THALES	A330, A340	29	AEG Sevilla
64809-418-1	PRESSURE INDICATOR	JAEGER	A330, A340	29	AEG Sevilla
64809-428-1	INDICPRESSION CARB	THALES	UNK	28-49-06	AEG Sevilla
64809-606-1	INDIC PRESSION HUI	THALES	A330, A340	63	AEG Sevilla
65-0294	INDICATOR LIGHT	GRIMES	UNK	33-10-03	AEG Sevilla
65-0294-1	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-200B737-600B737-300B737-100	33-10-03	AEG Sevilla
65-0294-11	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-200B737-600B737-300B737-100	33-10-03	AEG Sevilla
65-0294-13	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-200B737-600B737-300B737-100	33-10-03	AEG Sevilla
65-0294-15	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-600B737-300B737-100DC-10-8727	33-10-03	AEG Sevilla
65-0294-17	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-600B737-300B737-100B727B737-100	33-10-03	AEG Sevilla
65-0294-19	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-600B737-300B737-100B727B737-100	33-10-03	AEG Sevilla
65-0294-21	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-200B737-600B737-300B737-100	33-10-03	AEG Sevilla
65-0294-23	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-200B737-600B737-300B737-100	33-10-03	AEG Sevilla
65-0294-25	INDICATOR LIGHT ASSEMBLY	HONEYWELL GRIMES	B737-300B737-200B737-100	33-10-03	AEG Sevilla
65-0294-3	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-200B737-600B737-300B737-100	33-10-03	AEG Sevilla
65-0294-5	INDICATOR LIGHT ASSEMBLY	HONEYWELL	A320A320A319A319A330A300B737-400B737-300B737-100B737-1883	33-10-03	AEG Sevilla
65-0294-7	INDICATOR LIGHT ASSEMBLY	HONEYWELL	A320A320A319A319A330A300B737-400B737-300B737-100B737-1883	33-10-03	AEG Sevilla
65-0294-9	INDICATOR LIGHT ASSEMBLY	HONEYWELL	A320A320A319A319A330A300B737-400B737-300B737-100B737-1883	33-10-03	AEG Sevilla
65-0861-1	Indicator Light Assembly			33-10-83	AEG Sevilla
65-0861-3	Indicator Light Assembly			33-10-83	AEG Sevilla
65-0861-5	Indicator Light Assembly			33-10-83	AEG Sevilla
65-0861-7	Indicator Light Assembly			33-10-83	AEG Sevilla
65-17832-2	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
65-17832-3	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
65-17882-12	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-13	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-14	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-17	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-18	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-21	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-22	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-24	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-3	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-5	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-17882-7	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
6519009-71-1	STEP ASSY		UNK		AEG Sevilla
65-20846-1	INBOARD AND FILLET FLAP DRIVE POWER	BOEING	C-130B707	27-06-51	AEG Sevilla
65-20846-2	INBOARD AND FILLET FLAP DRIVE POWER	BOEING	B707	27-06-51	AEG Sevilla
65-20846-3	INBOARD AND FILLET FLAP DRIVE POWER	BOEING	B707	27-06-51	AEG Sevilla
65-20846-4	INBOARD AND FILLET FLAP DRIVE POWER	BOEING	B707	27-06-51	AEG Sevilla
65-20846-8	INBOARD AND FILLET FLAP DRIVE POWER	BOEING	B707	27-06-51	AEG Sevilla
65-20848-1	INBOARD FLAP DRIVE ELL GEARBOX	BOEING	C-130	27-06-62	AEG Sevilla
65-20848-2	INBOARD FLAP DRIVE ELL GEARBOX	BOEING	A330, A340	27-06-62	AEG Sevilla
65-20848-3	INBOARD FLAP DRIVE ELL GEARBOX	BOEING	A330, A340	27-06-62	AEG Sevilla
65-20848-4	INBOARD FLAP DRIVE ELL GEARBOX	BOEING	B707	27-06-62	AEG Sevilla
65-20848-5	INBOARD FLAP DRIVE ELL GEARBOX	BOEING	720B707	27-06-62	AEG Sevilla
65-20848-6	INBOARD FLAP DRIVE ELL GEARBOX	BOEING	B727B707	27-06-62	AEG Sevilla
65-20848-7	INBOARD FLAP DRIVE ELL GEARBOX	BOEING	A330, A340	27-06-62	AEG Sevilla
65-20848-8	INBOARD FLAP DRIVE ELL GEARBOX	BOEING	B707	27-06-62/27-06-64	AEG Sevilla
65-20852-1	INBOARD FLAP DRIVE TEE GEARBOX	BOEING	A330, A340	27-06-54	AEG Sevilla
65-20852-2	INBOARD FLAP DRIVE TEE GEARBOX	BOEING	B707	27-06-54	AEG Sevilla
65-20852-3	INBOARD FLAP DRIVE TEE GEARBOX	BOEING	B707	27-06-54,27	AEG Sevilla
65-44504-1	MAIN GEAR DAMPER ASSEMBLY	BOEING	B737	32-30-61	AEG Sevilla
65-44504-2	MAIN GEAR DAMPER ASSEMBLY	BOEING	B737	32-30-61	AEG Sevilla
65-44504-3	MAIN GEAR DAMPER ASSEMBLY	BOEING	B737	32-30-61	AEG Sevilla
65-44504-5	MAIN GEAR DAMPER ASSEMBLY	BOEING	B737	32-30-61	AEG Sevilla
65-44561-10	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8B737-900B737-400B737-1883B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-11	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	B737-300B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-12	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8B737-900B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-13	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8B737-900B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-14	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8B737-900B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-15	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8B737-900B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-5	ACTUATOR AY	BOEING	DC-8B737-900B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-6	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8B737-900B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-7	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8B737-900B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-8	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8B737-900B737-400B737-1883	27-60-41	AEG Sevilla
65-44561-9	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8B737-900B737-400B737-1883	27-60-41	AEG Sevilla
65-44610-3	NOSE GEAR HYDRAULIC ACTUATOR	BOEING	B737	32-32-30, 41	AEG Sevilla
65-44610-4	ACTUATOR ASSY	BOEING	B737	32-32-30, 41	AEG Sevilla
65-44625-10	LG LOCK ACTUATOR ASSY	BOEING	B737	US-05-05,32-30-31	AEG Sevilla
65-44625-11	NOSE GEAR HYDRAULIC ACTUATOR	BOEING	B737	32-30-41	AEG Sevilla
65-44625-14	LG LOCK ACTUATOR ASSY	BOEING	B737	US-05-05,32-30-31	AEG Sevilla
65-44625-18	NOSE GEAR LOCK ACTUATOR ASSEMBLY	BOEING	DC-8B737-900B737-400B737-200B737-100B737-300B737-400B737-1883	32-30-33	AEG Sevilla
65-44625-4	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-31	AEG Sevilla
65-44625-5	NOSE GEAR HYDRAULIC ACTUATOR	BOEING	B737	32-30-41	AEG Sevilla
65-44625-6	LG LOCK ACTUATOR ASSY	BOEING	B737	32-30-41	AEG Sevilla
65-44625-8	NOSE GEAR HYDRAULIC ACTUATOR	BOEING	B737	32-30-41	AEG Sevilla
65-44625-9	NOSE GEAR HYDRAULIC ACTUATOR	BOEING	B737	32-30-41	AEG Sevilla
65-44660-4	GRAVEL DEFLECTOR ACTUATOR	BOEING	B737	32-26-18	AEG Sevilla
65-44660-5	GRAVEL DEFLECTOR ACTUATOR	BOEING	B737	32-26-18	AEG Sevilla
65-44690-10	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
65-44690-11	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
65-44690-15	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
65-44690-16	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
65-44690-4	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
65-44690-8	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
65-44691-3	ASSEMBLY GEAR MODULAR PACKAGE	BOEING	737, 747, 757	32-09-11	AEG Sevilla
65-44691-4	ASSEMBLY GEAR MODULAR PACKAGE	BOEING	737, 747, 757	32-09-11	AEG Sevilla
65-44691-5	ASSEMBLY GEAR MODULAR PACKAGE	BOEING	737, 747, 757	32-09-11	AEG Sevilla
65-44691-6	ASSEMBLY GEAR MODULAR PACKAGE	BOEING	737, 747, 757	32-09-11	AEG Sevilla
65-44725-101	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B727B737-900B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-102	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-103	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-104	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-105	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-45	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B727B737-900B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-47	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-48	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-50	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B727B737-900B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-52	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-54	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-55	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-57	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-58	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-59	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-60	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B727B737-900B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-61	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla
65-44725-62	LEADING EDGE SLAT HYDRAULIC ACTUATOR	BOEING	B737-300B737-400B737-1883	27-81-47	AEG Sevilla

65-46481-88	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-36	AEG Sevilla
65-46481-89	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-36	AEG Sevilla
65-46481-90	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-36	AEG Sevilla
65-46481-91	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-36	AEG Sevilla
65-46481-92	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-36	AEG Sevilla
65-46481-93	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-36	AEG Sevilla
65-46481-94	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-36	AEG Sevilla
65-46481-95	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-46481-96	SPINDLE	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-46481-97	FLAP CARRIAGE ASSY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-36	AEG Sevilla
65-46481-98	FLAP CARRIAGE ASSY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-36	AEG Sevilla
65-4829	NOSE GEAR DRAG BRACE ASSEMBLY	BOEING	A330, A340	52-36-12	AEG Sevilla
65-4829-1	NOSE GEAR DRAG BRACE ASSEMBLY	BOEING	A330, A340	32	AEG Sevilla
65-4829-3	NOSE GEAR DRAG BRACE ASSEMBLY	BOEING	A330, A340	32	AEG Sevilla
65-4829-4	NOSE GEAR DRAG BRACE ASSEMBLY	BOEING	A330, A340	48330	AEG Sevilla
65-4829-5	NOSE GEAR DRAG BRACE ASSEMBLY	BOEING	A330, A340	48330	AEG Sevilla
65-4829-9	NOSE GEAR DRAG BRACE ASSEMBLY	BOEING	A330, A340	48330	AEG Sevilla
65-49580-11	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-12	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-13	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-14	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-15	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-16	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-17	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-18	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-19	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-20	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-49580-21	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-9/B737-500/B737-400/B737-	27-60-41	AEG Sevilla
65-61740-12	MLG OUTER CYLINDER ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	32-11-11	AEG Sevilla
65-61740-5	OUTER CYLINDER	BOEING	B/37-200	32-11-11	AEG Sevilla
65-63397-1	STRUT ASSY, LOWER SIDE	BOEING	B-737	32-17-11	AEG Sevilla
65-63397-10	MLG SIDE STRUT ASSEMBLY LOWER	BOEING	B-737	32-17-11	AEG Sevilla
65-63397-3	STRUT ASSY, LOWER SIDE	BOEING	B-737	32-17-11	AEG Sevilla
65-63397-5	STRUT ASSY, LOWER SIDE	BOEING	B-737	32-17-11	AEG Sevilla
65-63397-7	STRUT ASSY, LOWER SIDE	BOEING	B-737	32-17-11	AEG Sevilla
65-63397-9	MLG SIDE STRUT ASSEMBLY LOWER	BOEING	B-737	32-17-11	AEG Sevilla
65-67158-4	OUTBOARD FLAP TRACK ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57	AEG Sevilla
6577 SERIES	VANEAXIAL FAN ASSEMBLY	HAMILTON CLIMBERLAND	A330, A340	21	AEG Sevilla
65-79949-1	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-79949-10	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-79949-2	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-79949-3	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-79949-4	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-79949-5	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-79949-6	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-79949-7	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-79949-8	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-79949-9	OUTBOARD FLAP CARRIAGE ASSEMBLY	BOEING	B/37-500/B737-400/B737-300/B737-	57-53-35	AEG Sevilla
65-80051-1	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-10	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-11	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-13	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-14	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-18	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-20	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-3	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-5	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-6	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-7	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-80051-8	UPPER DRAG BRACE	BOEING	B/373	32-01-03	AEG Sevilla
65-84163-1	NOSE GEAR MINOR COMPONENTS	BOEING	B/373	32-01-03	AEG Sevilla
65950-1	Ground Spoiler Selector Solenoid Valve			27-60-21	AEG Sevilla
65950-3	Ground Spoiler Selector Solenoid Valve			27-60-21	AEG Sevilla
65960-1	Solenoid Valve, Unloading, Flight Spoiler Servo			27-58-31	AEG Sevilla
65960-3	Solenoid Valve, Unloading, Flight Spoiler Servo			27-58-31	AEG Sevilla
65C25676-2	NLG OUTER CYLINDER	BOEING	B/373-300	32	AEG Sevilla
65C25707-1	NLG STEM ORIFICE SUPPORT TUBE	BOEING	B/373-300	32	AEG Sevilla
65C25707-2	NLG STEM ORIFICE SUPPORT TUBE	BOEING	B/373-300	32-21-58	AEG Sevilla
65C26864-3	OUTBOARD GROUND SPOILER ACTUATOR	BOEING	B/373-900/B737-800/B737-700/B737-	27-62-71	AEG Sevilla
65C27360-1	NOSE GEAR MINOR COMPONENTS	BOEING	A330, A340	32-01-03	AEG Sevilla
65C27360-11	NOSE GEAR MINOR COMPONENTS	BOEING	B/373	32-01-03	AEG Sevilla
65C27360-12	NOSE GEAR MINOR COMPONENTS	BOEING	B/373	32-01-03	AEG Sevilla
65C27360-5	NOSE GEAR MINOR COMPONENTS	BOEING	B/373	32-01-03	AEG Sevilla
65C27360-7	NOSE GEAR MINOR COMPONENTS	BOEING	B/373	32-01-03	AEG Sevilla
65C27360-9	NOSE GEAR MINOR COMPONENTS	BOEING	B/373	32-01-03	AEG Sevilla
65C27601-1	LE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Sevilla
65C27601-2	LE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Sevilla
65C27601-3	LE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Sevilla
65C27601-4	LE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Sevilla
65C27601-5	LE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Sevilla
65C27601-6	LE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Sevilla
65C27601-7	LE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Sevilla
65C27601-8	LE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Sevilla
65C27601-9	LE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Sevilla
65C27631-1	DOOR BRACKET	BOEING	B/373	32	AEG Sevilla
65C27631-3	DOOR BRACKET	BOEING	B/373	32-01-03	AEG Sevilla
65C3099-1	NLG LOCK ACTUATOR	BOEING	B/373-500/B737-400/B737-300/B737-	32-32-30-33	AEG Sevilla
65C3099-2	NOSE GEAR LOCK ACTUATOR ASSEMBLY	THE BOEING	B/373-500/B737-400/B737-300/B737-	32-32-30-33	AEG Sevilla
65C31786-1	DOOR BRACKET	BOEING	B/373	32-01-03	AEG Sevilla
65C31786-4	DOOR BRACKET	BOEING	B/373	32-01-03	AEG Sevilla
65C32950-1	MLG METERING PIN	BOEING	B/373-500/B737-400/B737-300/B737-	32-11-11	AEG Sevilla
65C32950-2	MLG METERING PIN	BOEING	B/373-400	32	AEG Sevilla
65C32956-1	MAIN GEAR ACTUATOR ASSY	BOEING	B/373	32-30-13	AEG Sevilla
65C32956-3	ACTUATOR, MLG RETRACT	BOEING	B/373	32-30-13	AEG Sevilla
65C32956-4	ACTUATOR, MLG RETRACT	BOEING	B/373	32-30-13	AEG Sevilla
65C32956-6	MAIN GEAR ACTUATOR ASSY	BOEING	B/373	32-30-13	AEG Sevilla
65C33706-1	MLG BOLT ASSY REACTION LINK	BOEING	B/373-400	32-17-11	AEG Sevilla
65C33706-3	MLG BOLT ASSY REACTION LINK	BOEING	B/373-400	32	AEG Sevilla
65C37053-9	RUDDER PCU	BOEING	MD-80-83/B737	27-20-01	AEG Sevilla
65C38058-10	L/E ACTUATOR	BOEING	B/373-500/B737-400/B737-300/B737-	27-81-47	AEG Sevilla
65C38059-13	ACTUATOR ASSY	BOEING	B/747, B737	27-81-47	AEG Sevilla
65C38059-14	LEADING EDGE SLAT HYD ACT ASSEM	BOEING	B/373-500/B737-400/B737-300/B747/B737	27-81-47	AEG Sevilla
65C38059-15	ACTUATOR ASSY	BOEING	B/747, B737	27-81-47	AEG Sevilla
66005-01	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	A330, A340	29-10-30	AEG Sevilla
66007-01	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER AEROSPACE	A330, A340	29-10-31	AEG Sevilla
66068-05	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	C-100/B747-	29-11-30	AEG Sevilla
66068-06	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	B/727/B747-400/B767/B747/B777/B777-	29-11-30	AEG Sevilla
66068-07	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	B/727/B747-400/B767/B747/B777/B777-	29-11-30	AEG Sevilla
66068-08	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	B/727/B747-400/B767/B747/B777/B777-	29-11-30	AEG Sevilla
66071-73	SWITCH, PRESSURE	EATON AEROSPACE LLC	F27 F28	28	AEG Sevilla
6608201-X	STARTER GENERATOR		Learjet		AEG Sevilla
6608268-X	STARTER GENERATOR		Learjet		AEG Sevilla
6608458-XXX	STARTER GENERATOR		Learjet		AEG Sevilla
6608502-XXX	STARTER GENERATOR		Learjet		AEG Sevilla
66132-03	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	Trent-800/B767/B747/B737/B777/B767	29-11-36	AEG Sevilla
66132-04	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	Trent-800/B767/B747/B737/B777/B767	29-11-36	AEG Sevilla
66133-02	PUMP MOTOR PACKAGE	PARKER	B/727/B747/B747/B777/B777-222	29-11-37	AEG Sevilla
66133-03	PUMP MOTOR PACKAGE	PARKER	B/727/B747-400/B767/B747/B777/B777-	29-11-37	AEG Sevilla
66133-04	PUMP MOTOR PACKAGE	PARKER	B/727/B747-400/B767/B747/B777/B777-	29-11-37-29	AEG Sevilla
66173-03	HYDRAULIC PUMP	PARKER	Learjet/Learjet 45/Dash 8/DPCH/Dash 8-	29	AEG Sevilla
66190-02	Variable Delivery Hydraulic Pump				AEG Sevilla

66190-03	Variable Delivery Hydraulic Pump				AEG Sevilla
66190-04	Variable Delivery Hydraulic Pump				AEG Sevilla
66190-05	Variable Delivery Hydraulic Pump				AEG Sevilla
66195-01	Pump Motor Package			29-20-41	AEG Sevilla
66198-01	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	B727,A330,A340,CFM56-5C		AEG Sevilla
66198-02	AP19V-21-02 ENGINE DRIVEN	PARKER	B727,A330,A340,CFM56-5C		AEG Sevilla
66198-03	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	A330,A340,CFM56-5C		AEG Sevilla
66760-1	FDP AND SLAT HYDRAULIC	EATON AEROSPACE	B737,B727,B767,B757	27-51-05	AEG Sevilla
66760-2	FDP AND SLAT HYDRAULIC	EATON AEROSPACE	B737,B727,B767,B757	27-51-05	AEG Sevilla
66760-3	FDP AND SLAT HYDRAULIC	EATON AEROSPACE	B737,B727,B757-200,B767,B757	27-51-05	AEG Sevilla
66760-4	FDP AND SLAT HYDRAULIC	EATON	B737,B727,B757-200,B767,B757	27-51-05	AEG Sevilla
66760-5	FDP AND SLAT HYDRAULIC	EATON AEROSPACE	B757-200,B767,B757	27-51-05	AEG Sevilla
6700-300-80-10	AC Power Monitor			24-60-01	AEG Sevilla
6700-300-80-10	AC Power Monitor			24-60-01-4	AEG Sevilla
6700-400-80-10	DC Power Monitor			24-60-02	AEG Sevilla
6700-400-80-11	DC Power Monitor			24-60-02	AEG Sevilla
670750-107	ACTUATOR ELECTRO -ME	LOCKHEED	UNK		AEG Sevilla
670764-103	GENERATOR TACHOMETE	LOCKHEED MARTIN	UNK		AEG Bilbao
6800-1	Battery Temp Monitor			24-60-03-4	AEG Sevilla
6800-100-80-10	Battery Temp Monitor			24-60-03	AEG Sevilla
68-04-714	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Sevilla
6805307L	VIBRATOR, IGNITION CO		UNK		AEG Sevilla
69-14106-1	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
69-14106-2	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
69-14106-3	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
69-14106-4	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
69-14106-6	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
69-14106-7	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
692545-7	Solenoid Valve			49-30-67	AEG Sevilla
69-35385-1	AFT LOCK MECHANISM SHAFT	BOEING	B737	32-01-03	AEG Sevilla
69-35385-2	AFT LOCK MECHANISM SHAFT	BOEING	B737	32-01-03	AEG Sevilla
69-35391-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-35391-2	DRAG BRACE,PIN	BOEING	B737	32-01-03	AEG Sevilla
69-35394-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-35394-2	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-35394-3	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-35394-4	NLG PIN DRAG BRACE UPPER	BOEING	B737-3000,B737-4000,B737-5000,B737-6000,B737-7000,B737-8000	32-01-03	AEG Sevilla
69-35396-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-35396-2	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-35396-3	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-35396-4	LWR DRAG BRACE BOLT	BOEING	B737	32-01-03	AEG Sevilla
69-35396-5	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-35500-3	MAIN GEAR LOCK ACTUATOR ASSEMB	BOEING	B737	32-30-21	AEG Sevilla
69-35500-4	MAIN GEAR LOCK ACTUATOR ASSEMB	BOEING	B737	32-30-21	AEG Sevilla
69-35500-5	MAIN GEAR LOCK ACTUATOR ASSEMB	BOEING	B737	32-30-21	AEG Sevilla
69-35500-6	MAIN GEAR LOCK ACTUATOR ASSEMB	BOEING	B737	32-30-21	AEG Sevilla
69-36622-3	NLG ORIFICE PLATE UPPER	BOEING	B737-100	32-21-58	AEG Sevilla
69-37307-112	ENGINE APU FIRE MODULE	BOEING	B737	26-10-45	AEG Sevilla
69-38709-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-38709-3	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-38709-5	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-38710-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-39473-5	MLG BOLT ASSY LOWER DRAG STRUT	BOEING	B737-100	32	AEG Sevilla
69-39473-6	MLG BOLT ASSY LOWER DRAG STRUT	BOEING	B737-100	32	AEG Sevilla
69-41629-1	MLG BOLT DOWNLOCK LINK PIVOT	BOEING	B737-100	32	AEG Sevilla
69-42196-4	FORWARD TRUNION BEARING BOLT	BOEING	B737	32	AEG Sevilla
69-42196-5	FORWARD TRUNION BEARING BOLT	BOEING	B737	32	AEG Sevilla
696001-9A	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Sevilla
69-53800-1	BUNGIE SPRING ASSEMBLY	BOEING	B737	32-01-03	AEG Sevilla
69-53800-4	BUNGIE SPRING ASSEMBLY	BOEING	B737	32-01-03	AEG Sevilla
695457-3	NLG STEERING CYLINDER ASSY		A330, A340		AEG Sevilla
69-54600-1	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
69-54600-2	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Sevilla
69-62779-1	MLG BOLT ASSY UPPER DOWNLOCK	BOEING	B737-100	32-17-11	AEG Sevilla
69-62779-3	MLG BOLT ASSY UPPER DOWNLOCK	BOEING	B737-100	32-17-11	AEG Sevilla
69-68115-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-68148-1	MLG BOLT ASSY REACTION LINK	BOEING	B737-100	32	AEG Sevilla
69-68149-1	MLG BOLT ASSY UPPER SIDE STRUT	BOEING	B737-100	32-17-11	AEG Sevilla
69-68150-1	MLG BOLT ASSY SIDE STRUT	BOEING	B737-100	32	AEG Sevilla
69-73677-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-73677-3	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-73677-5	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-73677-9	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Sevilla
69-7745-5	MLG FLSE BOLT ASSY UPPER DRAG	BOEING	B737-3000,B737-4000,B737-5000,B737-6000,B737-7000,B737-8000	32	AEG Sevilla
69-77456-12	MAIN GEAR ACTUATOR ASSEMBLY	BOEING	B737	27-60-01	AEG Sevilla
69-77456-9	MAIN GEAR ACTUATOR ASSEMBLY	BOEING	B737	23-30-01	AEG Sevilla
69-77522-1	MLG BOLT ASSY UPPER SIDE STRUT	BOEING	B737-400	32-17-11	AEG Sevilla
69-77523-1	MLG BOLT ASSY SIDE STRUT	BOEING	B737-400	32-17-11	AEG Sevilla
4F2392-5	FILTERED RESTRICTOR VALVE	CRISSAIR	B737	32-30-02	AEG Sevilla
4F2392-6	FILTERED RESTRICTOR VALVE	CRISSAIR	B737	32-30-02	AEG Sevilla
70A46-511	FAN ASSEMBLY	AIRSCREW HOWDEN	A330, A340	21	AEG Sevilla
70A46-521	FAN ASSEMBLY	AIRSCREW HOWDEN	A330, A340	21	AEG Sevilla
7002493-906	INDICATOR, ATTITUDE	HONEYWELL	C-212	34-22-41	AEG Sevilla
70-0253-1	Advisory Lights Control Unit			33-10-52	AEG Sevilla
70-0253-5	Advisory Lights Control Unit			33-10-52	AEG Sevilla
70-0253-7	Advisory Lights Control Unit			33-10-52	AEG Sevilla
70-0366-11	BALLAST	HONEYWELL	B737,B737-3000,B747,B737-800,B737-600,B737-7000	33-21-43	AEG Sevilla
70-0366-3	FLUORESCENT LAMP BALLAST ASSY	GRIMES	B747,B737-300,B767,B737,B757,B737-500	33-21-43	AEG Sevilla
70-0366-5	FLUORESCENT LAMP BALLAST ASSY	HONEYWELL	B727,B737-600,B737,B757,B737-500	33-21-43	AEG Sevilla
70-0366-7	BALLAST UNIT	HONEYWELL	B747,B737,B757,B737-500	33-21-43	AEG Sevilla
70-0366-9	FLUORESCENT LAMP BALLAST ASSY	GRIMES	B727,B747,B737-500,B757,B737	33-21-43	AEG Sevilla
7008FS-472-P3	GT RING		UNK		AEG Sevilla
702200-1	FIRE BOOSTER PUMP, SINGLE FUEL VOLUME	ARGO-TECH	MD80,MD-80,MD-80,MD-80,B747,MD-80,DC-9,ERJ145	28-20-6	AEG Sevilla
702300-1	FIRE BOOSTER PUMP, SINGLE FUEL VOLUME	ARGO-TECH	MD80,MD-90,B747,MD-80,DC-9,B777	28-20-6	AEG Sevilla
70277-10	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-16	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-17	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-18	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-20	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-21	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-24	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-25	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-26	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-27	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-30	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-34	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-35	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-36	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-37	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-38	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-39	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-50	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-51	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-52	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-53	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-8	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70277-9	ROTARY HYDRAULIC SNUBBER		B747		AEG Sevilla
70290-70544	FAUCET ASSEMBLY	ADAMS RITE	A320	38-10-37	AEG Sevilla
70577-10	ROTARY HYDRAULIC SNUBBER	EATON AEROSPACE - HYDRAULIC SYSTEMS	B757,B747	52	AEG Sevilla

70577-16	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-17	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-18	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-20	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-21	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-24	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-25	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-26	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-27	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-30	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-34	ROTARY HYDRAULIC SNUBBER	EATON	8737,8757,8747	52	AEG Sevilla
70577-35	ROTARY HYDRAULIC SNUBBER	EATON	8737,8757,8747	52	AEG Sevilla
70577-36	ROTARY HYDRAULIC SNUBBER	EATON	8757,8747	52	AEG Sevilla
70577-37	ROTARY HYDRAULIC SNUBBER	EATON	8737,DC-10,8757,8747	52	AEG Sevilla
70577-38	ROTARY HYDRAULIC SNUBBER	EATON	DC-10,8757,8747	52	AEG Sevilla
70577-39	ROTARY HYDRAULIC SNUBBER	EATON	DC-10,8757,8747	52	AEG Sevilla
70577-40	ROTARY HYDRAULIC SNUBBER	EATON	DC-10,8757,8747	52	AEG Sevilla
70577-41	ROTARY HYDRAULIC SNUBBER	EATON	MD-11,8757,8747	52	AEG Sevilla
70577-42	ROTARY SNUBBER	STERER	MD-11,8757,8747	52	AEG Sevilla
70577-43	ROTARY SNUBBER	STERER	MD-11,8757,8747	52	AEG Sevilla
70577-44	ROTARY HYDRAULIC SNUBBER	STERER	8757-200,8757,8747	52	AEG Sevilla
70577-45	ROTARY SNUBBER LH DOOR	STERER	8787,8767-200,8757,8747	52	AEG Sevilla
70577-50	ROTARY HYDRAULIC SNUBBER	EATON	8787,8747-400,8757,8747	52	AEG Sevilla
70577-51	ROTARY HYDRAULIC SNUBBER	EATON	8757,8737,8737,8747-400,8747	52	AEG Sevilla
70577-52	ROTARY HYDRAULIC SNUBBER	EATON-STERER	8757,8747-400,8747	52	AEG Sevilla
70577-53	ROTARY HYDRAULIC SNUBBER	EATON	8757,8737,8737,8747-400,8747	52	AEG Sevilla
70577-8	ROTARY HYDRAULIC SNUBBER	EATON	8757,8737,8747	52	AEG Sevilla
70577-9	ROTARY HYDRAULIC SNUBBER	EATON	8747	52	AEG Sevilla
706400-2	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	8737,A320,CFM56-3	75-31-12	AEG Sevilla
706400-3	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	8737,A320,CFM56-3	75-31-12	AEG Sevilla
706400-4	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	8737,A320,CFM56-3	75-31-12	AEG Sevilla
706786-2	DUAL CHANNEL FUEL GAGE AMPLIFIER	ZODIAC	A340	28	AEG Sevilla
706786-3	DUAL CHANNEL FUEL GAGE AMPLIFIER	ZODIAC	8757	28	AEG Sevilla
7083107-1	Component Maintenance Manual			49-81-01	AEG Sevilla
7083113-1	Component Maintenance Manual			49-81-01	AEG Sevilla
7088110-1	Harness Assembly			49-15-07	AEG Sevilla
70895-1	BOX ASSY	ADAMS RITE	A320 NEO	38-20-20	AEG Sevilla
70900-3	ELECTRONIC CONTROL BOX	ADAMS RITE	A320	38-20-20	AEG Sevilla
705448	Carrier Shaft Assembly			24-13-04	AEG Sevilla
7178-1	HYDRAULIC FUSE UNIT AND MANIFOLD	EATON AEROSPACE	A340,A330	32,32-11-41	AEG Sevilla
7178-2	HYDRAULIC FUSE UNIT AND MANIFOLD ASSEMBLY	EATON AEROSPACE	A340-212,A340-211,A340,A330-342,A340-313,A340	32,32-11-41	AEG Sevilla
7179-1	PITCH TRIMMER	EATON AEROSPACE	A340-212,A340-211,A340,A330	32,32-11-41	AEG Sevilla
7179-2	HYDRAULIC FUSE UNIT AND MANIFOLD	EATON AEROSPACE	A340-212,A340-211,A340,A330-313,A330	32,32-11-41	AEG Sevilla
7182-2	HYDRAULIC FUSE UNIT AND MANIFOLD	EATON	A330		AEG Sevilla
71404-1	DUAL BRAKE METERING VALVE	EATON	8777-300,8757-300,8747-200,8757-400,8777-300,8757-300,8747-200,8757-400	32-41-04	AEG Sevilla
71404-2	DUAL BRAKE METERING VALVE	EATON	8777-300,8757-300,8747-200,8757-400,8777-300,8757-300,8747-200,8757-400	32-41-04	AEG Sevilla
751133E	DRIVE CONSTANT SPEED		UNK		AEG Bilbao
761506Y	CONTROL NOSE WHEEL STEERING	ZODIAC	A320,A330,A340	32-51-11	AEG Sevilla
717506Y	NOSE WHEEL STEERING CONTROLLER	IN SERVICES	A320,A330,A340	32-51-11	AEG Sevilla
71982-1	Temperature Switch and Associated valves				AEG Sevilla
720845 SERIES	GENERATOR ASSEMBLY	SUNDSTRAND	CRJ Regional Jet-200,CRJ Regional Jet-	24-22-01	AEG Bilbao
720845E	GENERATOR ASSEMBLY	HAMILTON	CRJ Regional Jet-200,CRJ Regional Jet-	24-21-08	AEG Bilbao
720845-SERIES	GENERATOR ASSEMBLY		CRJ Regional Jet-200,CRJ Regional Jet-	24-21-04	AEG Bilbao
720847A	Current Transformer Assembly			24-25-01	AEG Sevilla
72091-1DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-1SDXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-17DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-19DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-1DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-21DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-23DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-25DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-27DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-29DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-2DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-31DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-33DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-35DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-37DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-3DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72091-7DXXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Sevilla
72095-1	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320	38	AEG Sevilla
72095-3	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320, A330, A340	38-12-73	AEG Sevilla
72095-5	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320,A330	38	AEG Sevilla
72095-7	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320	38	AEG Sevilla
72095-9	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320	38	AEG Sevilla
721429A	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721429B	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721429C	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721429D	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721429E	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721432A	ROTOR ASSEMBLY	SUNDSTRAND	A330, A340	24-26-03	AEG Bilbao
721432B	ROTOR ASSEMBLY	SUNDSTRAND	A330, A340	24-26-03	AEG Bilbao
721432C	ROTOR ASSEMBLY	SUNDSTRAND	A330, A340	24-26-03	AEG Bilbao
721432D	ROTOR ASSEMBLY	SUNDSTRAND	A330, A340	24-26-03	AEG Bilbao
721432E	ROTOR ASSEMBLY	HAMILTON	UNK	24-26-03	AEG Bilbao
721863B	Uplock			24-15-53	AEG Sevilla
721863C	Uplock			24-15-53	AEG Sevilla
722-536-1	Oil Level Detector			79-34-01	AEG Sevilla
722-536-3	Oil Level Detector			79-34-01	AEG Sevilla
72266-3	FUEL BOOSTER CANISTER PUMP	LEAR ROMEC	A330, A340	28-20-24	AEG Sevilla
72305039-1	WING TIP ANTICEDROOP LIGHT ASSEMBLY	HONEYWELL	8757-600,8757	33-43-86	AEG Sevilla
72305039-2	WING TIP ANTICEDROOP LIGHT ASSEMBLY	HONEYWELL	8757-600,8757	33-43-86	AEG Sevilla
72305039-3	WING TIP ANTICEDROOP LIGHT ASSEMBLY	HONEYWELL	8757-600,8757	33	AEG Sevilla
72305039-4	WING TIP ANTICEDROOP LIGHT ASSEMBLY	HONEYWELL	8757-600,8757	33	AEG Sevilla
72390-2	FUEL BOOSTER CANISTER PUMP	LEAR ROMEC	A330, A340	28-20-24	AEG Sevilla
7-26-4	INDICATOR, HOMIG				AEG Sevilla
726506Y1	EXCITER ROTOR		UNK		AEG Bilbao
72792C	IDG	SUNDSTRAND	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792D	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792E	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792F	IDG	SUNDSTRAND	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792G	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792H	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792I	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792J	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792K	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792L	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792M	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
72792N	IDG	HAMILTON	8767,8757,CF6-80C2,CF6-80C2,HB211-	24-00-00	AEG Bilbao
727810A	AUXILIARY GENERATOR	HAMILTON	8747,8757,8767,8757,CF6-80C2,HB211-	24-21-00	AEG Bilbao
727810B	AUXILIARY GENERATOR	HAMILTON	8747,8757,8767,8757,CF6-80C2,HB211-	24-21-00	AEG Bilbao
727810C	AUXILIARY GENERATOR	SUNDSTRAND	8747,8757,8767,8757,CF6-80C2,HB211-	24-21-00	AEG Bilbao
728431B	Ejector Jack ADG Charge Pump			24-15-52	AEG Sevilla
728431C	Ejector Jack ADG Charge Pump			24-15-52	AEG Sevilla
728843 SERIES	ROTOR BALANCE ASSEMBLY	HAMILTON	A330, A340	24	AEG Bilbao
728843D	ROTOR	SUNDSTRAND	8757, 8767, 8747, A300	24-26-01	AEG Bilbao
728843E	ROTOR	SUNDSTRAND	8757, 8767, 8747, A300	24-26-01	AEG Bilbao
728843F	ROTOR	SUNDSTRAND	8757, 8767, 8747, A300	24-26-01	AEG Bilbao
728843G	ROTOR	SUNDSTRAND	8757, 8767, 8747, A300	24-26-01	AEG Bilbao

7-45416-23	Manual Release Control Assy				AEG Sevilla
7-45416-29	Manual Release Control Assy				AEG Sevilla
7-45500-1	Flap Control Lever Assembly			27-50-00	AEG Sevilla
7-45500-2	Flap Control Lever Assembly			27-50-00	AEG Sevilla
7-45500-3	Flap Control Lever Assembly			27-50-00	AEG Sevilla
7-45501-1	Fight Spoiler Lever Control Assembly			27-61-01	AEG Sevilla
7-45502-1	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
7-45502-1A	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
7-45502-1B	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
7-45502-3	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
7-45502-5	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
746277 SERIES	STATOR HOUSING	HAMILTON	A330, A340	24-17-09	AEG Bilbao
74794A	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
74794B	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
74794C	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
74794D	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
74794E	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
74794F	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
747-5750-1-0	AC MOTOR WITH BRAKE ASSEMBLY	BOEING	A330, A340	25-55-49	AEG Sevilla
747740 SERIES	STATOR HOUSING	HAMILTON	A330, A340	24-17-31	AEG Bilbao
747740A	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
747740B	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
747740C	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
747740D	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
747740E	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
747740F	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
747740G	STATOR HOUSING	SUNDSTRAND	A320	24-17-31	AEG Bilbao
747768 SERIES	ROTOR BALANCE ASSEMBLY	HAMILTON	A330, A340	24	AEG Bilbao
747768C	ROTOR	SUNDSTRAND	B737,A310,A300,B747,B767,B757	24-26-01	AEG Bilbao
747768D	ROTOR	SUNDSTRAND	A300*	24-26-01	AEG Bilbao
747768-SERIES	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A300,B737,A310,A300,B747,B767,B757	24-26-01	AEG Bilbao
7500-00111-03	Power Supply		757, 767, 747, A300		AEG Sevilla
7500-00111-04	Power Supply				AEG Sevilla
7500-00111-05	Power Supply				AEG Sevilla
7500-00111-06	Power Supply				AEG Sevilla
7500-00111-07	Power Supply				AEG Sevilla
7500-00184-01	Power Supply				AEG Sevilla
750659-1	Overtemperature Switch			21-61-29	AEG Sevilla
750659-16	Overtemperature Switch			21-61-29	AEG Sevilla
750659-17	Overtemperature Switch			21-61-29	AEG Sevilla
750659-3	Overtemperature Switch			21-61-29	AEG Sevilla
750659-4	Overtemperature Switch			21-61-29	AEG Sevilla
750659-8	Overtemperature Switch			21-61-29	AEG Sevilla
750662-2	Separator Assy, Water			21-61-29	AEG Sevilla
750662-8	Separator Assy, Water			21-61-29	AEG Sevilla
750665-1	Overtemperature Switch			21-61-29	AEG Sevilla
750665-10	Overtemperature Switch			21-61-29	AEG Sevilla
750665-9	Overtemperature Switch			21-61-29	AEG Sevilla
751202A	ELECTRICAL HARNESS	HAMILTON	A-320, A321	24-18-12	AEG Sevilla
751202B	ELECTRICAL HARNESS	HAMILTON	A-320, A321	24-18-12	AEG Sevilla
751202C	ELECTRICAL HARNESS	HAMILTON	A-320, A321	24-18-12	AEG Sevilla
751202D	ELECTRICAL HARNESS	HAMILTON	A-320, A321	24-18-12	AEG Sevilla
751202E	ELECTRICAL HARNESS	HAMILTON	A-320, A321	24-18-12	AEG Sevilla
751344A	ROTOR ASSEMBLY, EXCITER	SUNDSTRAND	A330, A340	24	AEG Bilbao
752063A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11	24-26-08	AEG Bilbao
752157 SERIES	INTEGRATED DRIVE GENERATOR	HAMILTON	A340	24-11-81	AEG Bilbao
752157B	INTEGRATED DRIVE GENERATOR	HAMILTON	A340,CFM56-5C	24-21-00	AEG Bilbao
752157C	INTEGRATED DRIVE GENERATOR	HAMILTON	A340,CFM56-5C	24-21-00	AEG Bilbao
752157D	IDG	HAMILTON	A330,A340,CFM56-5C	24-21-00	AEG Bilbao
752168A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	Trent-700,A330	24-11-82	AEG Bilbao
752168B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B777,Trent-700,A330,CFM56-5C	24-21-00	AEG Bilbao
752168C	INTEGRATED DRIVE GENERATOR	HAMILTON	A330-200, A330-300, A330 NEO	30279	AEG Bilbao
752168D	INTEGRATED DRIVE GENERATOR	HAMILTON	A330-200, A330-300, A330 NEO	30279	AEG Bilbao
752685 SERIES	STATOR HOUSING ASSEMBLY	HAMILTON	A330, A340	24-17-33	AEG Bilbao
753129A	EXCITER ROTOR	SUNDSTRAND	B757	24	AEG Bilbao
753129AY1	EXCITER ROTOR		B757,B767		AEG Bilbao
753129B	EXCITER ROTOR	SUNDSTRAND	B757	24	AEG Bilbao
753129-SERIES	ROTOR ASSEMBLY EXCITER		B757,B767		AEG Bilbao
753367A	ROTOR BALANCE ASSEMBLY	HAMILTON	A340	24-26-09	AEG Bilbao
753490A	STATOR AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A340	24-17-35	AEG Bilbao
753490B	STATOR AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A340	24-17-35	AEG Bilbao
753490C	STATOR AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A340	24-17-35	AEG Bilbao
754481-1	Cabin/Duct Temperature Sensor			21-61-24	AEG Sevilla
754491-1	Cabin/Duct Temperature Sensor			21-61-24	AEG Sevilla
755017A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	A330,CFM56-5C	24-21-00	AEG Bilbao
755017B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	A330	24-11-82	AEG Bilbao
755057A	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
755057B	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
755057C	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
755057D	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
755057E	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
755359A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757,B737-900,B757-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100,B737	24-00-00	AEG Bilbao
755359B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757,B737-900,B757-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100,B737	24-00-00	AEG Bilbao
755359C	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757,B737-900,B757-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100,B737	24-00-00	AEG Bilbao
755359D	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757,B737-900,B757-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100,B737	24-11-76	AEG Bilbao
755446B	IDG	HAMILTON	A300,B737,B747,400,B747,700,B747,B767	24-00-00	AEG Bilbao
755446B	Integrated Drive Generator	SUNDSTRAND	900,Challenger,ADA,Challenger	24-21-08	AEG Sevilla
755446C	IDG	HAMILTON	CRJ Regional,Je-100,CRJ Regional,Je-200,Challenger,ADA,Challenger	24-00-00	AEG Bilbao
755446C	Integrated Drive Generator	SUNDSTRAND	CRJ Regional,Je-100,CRJ Regional,Je-200,Challenger,ADA,Challenger	24-21-08	AEG Sevilla
755446D	IDG	HAMILTON	CRJ Regional,Je-100,CRJ Regional,Je-200,Challenger,ADA,Challenger	24-00-00	AEG Bilbao
755446D	Integrated Drive Generator	SUNDSTRAND	CRJ Regional,Je-100,CRJ Regional,Je-200,Challenger,ADA,Challenger	24-21-08	AEG Sevilla
755446E	IDG	HAMILTON	CRJ Regional,Je-100,CRJ Regional,Je-200,Challenger,ADA,Challenger	24-00-00	AEG Bilbao
755446E	Integrated Drive Generator	SUNDSTRAND	CRJ Regional,Je-100,CRJ Regional,Je-200,Challenger,ADA,Challenger	24-21-08	AEG Sevilla
755704A	Pump And Motor			24-14-14	AEG Sevilla
755961 SERIES	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
755961D	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11	24-26-10	AEG Bilbao
755961E	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
755961F	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
755961G	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11,B777	24-26-10	AEG Bilbao
755961H	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
755961I	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11,B777	24-26-10	AEG Bilbao
755961K	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11,B777	24-26-10	AEG Bilbao
755961L	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
756066B	EXCITER ROTOR	SUNDSTRAND	A330	24	AEG Bilbao
756899A	APU GENERATOR	HAMILTON	B767,B767-400,B777-222,B777,CF6-80C2	24-21-00	AEG Bilbao
756829 SERIES	STATOR HOUSING	HAMILTON	A330, A340	24-17-09	AEG Bilbao
756910 SERIES	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340		AEG Bilbao
756911A	EXCITER AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A330	24-17-37	AEG Bilbao
756911B	EXCITER AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A330	24-17-37	AEG Bilbao
756911C	EXCITER AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A330	24-17-37	AEG Bilbao
756911D	EXCITER AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A330	24-17-37	AEG Bilbao
757030F SERIES	ROTOR BALANCE ASSEMBLY	HAMILTON	A330, A340	24	AEG Bilbao
757030F	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	UNK	24-26-10	AEG Bilbao
757030G	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	UNK	24-26-10	AEG Bilbao
757030H	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	UNK	24-26-10	AEG Bilbao
757066A	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
757066B	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
757066C	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
757066D	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao

757066E	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
757066F	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
757066G	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
757066H	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
757068 SERIES	STATOR HOUSING ASSEMBLY	HAMILTON	A330, A340		AEG Bilbao
757068G	STATOR HOUSING ASSEMBLY	HAMILTON	A330, A340	24	AEG Bilbao
757652B	EXCITER ROTOR	SUNDSTRAND	A330, A340	24	AEG Bilbao
758861B	EXCITER ROTOR ASSEMBLY	HAMILTON	UNK	24	AEG Bilbao
758922A	INTEGRATED DRIVE GENERATOR	HAMILTON	A330, A340	24	AEG Bilbao
759467 SERIES	STATOR HOUSING	HAMILTON	A330, A340	24-17-09	AEG Bilbao
7611574	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE	B737NG/Boeing 737 MAX	24-11-85.	AEG Bilbao
7611574A	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE	B737NG/Boeing 737 MAX	24-11-85.	AEG Bilbao
7611574B	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE	B737NG/Boeing 737 MAX	24-11-85.	AEG Bilbao
761341A	ADG GCU			24-23-10	AEG Sevilla
7613-551-91-13	TERMOMETER	THALES	A330, A340	77	AEG Sevilla
7613-551-91-14	T4 INDICATOR		A330, A340		AEG Sevilla
761574A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B737-900B737-800B737-700B737-600	24	AEG Bilbao
761574B	INTEGRATED DRIVE GENERATOR	HAMILTON	B737-900B737-800B737-700B737-600	24-00-00	AEG Bilbao
762067A	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
762067B	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
762067C	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
762067D	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
762067E	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
762067F	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
762067G	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
762109A	STATOR ASSEMBLY - MAIN GENERATOR	SUNDSTRAND	A330, A340	24	AEG Bilbao
762359 SERIES	ROTOR	HAMILTON	737	24-26-12	AEG Bilbao
762359A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737	24-26-12	AEG Bilbao
762359A13	ROTOR	SUNDSTRAND	737		AEG Bilbao
762359B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
762359C	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
762359D	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
762359E	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
762359F	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
762359F3	ROTOR	HAMILTON	737		AEG Bilbao
762367A	GENERATOR MAIN FIELD WOUND ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
762367B	GENERATOR MAIN FIELD WOUND ASSEMBLY	HAMILTON	B737-600		AEG Bilbao
762517A	STATOR	SUNDSTRAND	A330, A340	24	AEG Bilbao
762620A	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
762620B	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
762620C	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
762620D	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
762620E	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
762620F	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
762888B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B7700-710,B771	24	AEG Bilbao
763226-01	DIODE PACK	HAMILTON	B737		AEG Bilbao
763226-12	SEMICONDUCTOR	SUNDSTRAND	B737		AEG Bilbao
763226-13	DIODE PACK	HAMILTON	B737		AEG Sevilla
763226-14	DIODE PACK	SUNDSTRAND	B737		AEG Bilbao
763775A	ELECTRICAL HARNESS	SUNDSTRAND	B767	24-18-02,24	AEG Sevilla
764294A	PMG STATOR	HAMILTON	B737	24	AEG Bilbao
764685-2	SWITCH AIRSPEED	HAMILTON	UNK	38282	AEG Sevilla
764861-2	PRECOOLER		UNK		AEG Sevilla
764930 SERIES	STATOR HOUSING ASSEMBLY		A330, A340		AEG Bilbao
764939A	IDG	SUNDSTRAND	Trent-800,B777-300,B777-200,B777	24-11-83	AEG Bilbao
764939B	IDG	SUNDSTRAND	Trent-800,B777-300,B777-200,B777	24-11-83	AEG Bilbao
764978-B	INSERT		UNK		AEG Bilbao
764988A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B737/B737-900B737-800B737-700B737-600	24-00-00	AEG Bilbao
764988B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B737/B737-900B737-800B737-700B737-600	24-00-00	AEG Bilbao
764988C	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B737/B737-900B737-800B737-700B737-600	24-00-00	AEG Bilbao
764277A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	CRJ900 Regional Jet-900,CRJ1000 Regional Jet-3000,CRJ-300,CRJ-440	24-21-12	AEG Sevilla
764277A	Integrated Drive Generator			24-21-12	AEG Sevilla
764277B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	CRJ900 Regional Jet-900,CRJ1000 Regional Jet-3000,CRJ-300,CRJ-440	24-21-12	AEG Bilbao
764277B	Integrated Drive Generator			24-21-12	AEG Sevilla
764283A	Generator Control Unit			24-23-25	AEG Sevilla
764283B	Generator Control Unit			24-23-25	AEG Sevilla
764283C	Generator Control Unit			24-23-25	AEG Sevilla
764361A	Inboard Flap Actuator Assembly			27-52-07	AEG Sevilla
764361B	Inboard Flap Actuator Assembly			27-52-07	AEG Sevilla
764361C	Inboard Flap Actuator Assembly			27-52-07	AEG Sevilla
764361D	Inboard Flap Actuator Assembly			27-52-07	AEG Sevilla
764363A	Midboard Right Flap Actuator Assembly			27-52-19	AEG Sevilla
764363B	Midboard Right Flap Actuator Assembly			27-52-19	AEG Sevilla
764363C	Midboard Right Flap Actuator Assembly			27-52-19	AEG Sevilla
764363D	Midboard Right Flap Actuator Assembly			27-52-19	AEG Sevilla
764365A	Midboard Left Flap Actuator Assembly			27-52-20	AEG Sevilla
764365B	Midboard Left Flap Actuator Assembly			27-52-20	AEG Sevilla
764365C	Midboard Left Flap Actuator Assembly			27-52-20	AEG Sevilla
764365D	Midboard Left Flap Actuator Assembly			27-52-20	AEG Sevilla
764369A	Outboard Left Flap Actuator Assembly			27-52-22	AEG Sevilla
764369B	Outboard Left Flap Actuator Assembly			27-52-22	AEG Sevilla
764369C	Outboard Left Flap Actuator Assembly			27-52-22	AEG Sevilla
764385A	Outboard Slat Actuator Assembly			27-81-18	AEG Sevilla
764385B	Outboard Slat Actuator Assembly			27-81-18	AEG Sevilla
764385C	Outboard Slat Actuator Assembly			27-81-18	AEG Sevilla
764441 SERIES	STATOR HOUSING		A330, A340		AEG Bilbao
764461A	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
764461B	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
764461C	STATOR HOUSING	HAMILTON	A319,A320	24-17-31	AEG Bilbao
767091A	7.5 HP 6-POLE AC MOTOR	SUNDSTRAND	B737,CRJ-700	29-20-42	AEG Sevilla
76710 SERIES	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400	24	AEG Bilbao
76710A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
76710B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
76710C	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
76710D	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
76710E	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
76710F	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
76710G	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
76710H	ROTOR BALANCE ASSEMBLY	HAMILTON	B777,B767-400	24	AEG Bilbao
76710I	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	UNK		AEG Bilbao
767114B	WOUND GENERATOR MAIN FIELD	HAMILTON	B767-400	24	AEG Bilbao
767114C	WOUND GENERATOR MAIN FIELD	SUNDSTRAND	UNK	24-26-10	AEG Bilbao
767114D	WOUND GENERATOR MAIN FIELD	H.S	UNK		AEG Bilbao
767146A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B767-400,B767,B777,B777-200	24-21-11	AEG Bilbao
767173 SERIES	STATOR HOUSING		A330, A340		AEG Bilbao
767173A	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
767173B	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
767173C	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
767188 SERIES	ROTOR BALANCE ASSEMBLY	HAMILTON	B777	24	AEG Bilbao
767188A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
767188B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
767188C	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
767192E	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A320,B737	24-26-15	AEG Bilbao
767192G	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A320,B737	24-26-15	AEG Bilbao
768094-1	Probes			28-41-04	AEG Sevilla
768271-2	Probes			28-41-04	AEG Sevilla
768272-3	Probes			28-41-04	AEG Sevilla
768273-2	Probes			28-41-04	AEG Sevilla
768274-3	Probes			28-41-04	AEG Sevilla

768282-4	Probes				28-41-04	AEG Sevilla
768283-2	Probes				28-41-04	AEG Sevilla
768284-2	Probes				28-41-04	AEG Sevilla
768616A	Mid Slot Actuator Assembly				27-81-20	AEG Sevilla
768616B	Mid Slot Actuator Assembly				27-81-20	AEG Sevilla
768616C	Mid Slot Actuator Assembly				27-81-20	AEG Sevilla
768656-1	Probes				28-41-04	AEG Sevilla
768657-1	Probes				28-41-04	AEG Sevilla
769068A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B767-400,B777/B767		24-11-87	AEG Bilbao
769437D	ROTOR BALANCE ASSEMBLY	HAMILTON SUNDSTRAND	B737-600		24-26-12	AEG Bilbao
769437E	ROTOR BALANCE ASSEMBLY	HAMILTON SUNDSTRAND	A330, A340		24	AEG Bilbao
770604A	ROTOR BALANCE ASSEMBLY	UTC	B777 / A330		24-26-10	AEG Bilbao
772181A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	CFM56-		24-00-00	AEG Bilbao
772183A	STATOR AND HOUSING ASSEMBLY	HAMILTON SUNDSTRAND	A320, A3240-200, A340-300, A340-		24-17-50	AEG Bilbao
772183B	STATOR AND HOUSING ASSEMBLY	HAMILTON SUNDSTRAND	A320, A3240-200, A340-300, A340-		24-17-50	AEG Bilbao
772294A	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A320		24-17-51	AEG Bilbao
772295A	EXCITER STATOR HOUSING ASSEMBLY	HAMILTON SUNDSTRAND	UNK			AEG Bilbao
7743-00256-08T016	Command Processor/Inpud Module					AEG Sevilla
7743-00257-05	Analogue Acquisition					AEG Sevilla
7743-00257-06	Analogue Acquisition					AEG Sevilla
7743-00258-01	Airinc 429 Module					AEG Sevilla
7743-00259	Output/Common Services					AEG Sevilla
7743-00260-10	Monitor Processor/Inpud					AEG Sevilla
7743-00260-11	Monitor Processor/Inpud					AEG Sevilla
7743-00260-12	Monitor Processor/Inpud					AEG Sevilla
7743-00260-13	Monitor Processor/Inpud					AEG Sevilla
7743-00272	Output/Common Services					AEG Sevilla
7743-00272-01	Output/Common Services					AEG Sevilla
7743-00272-02	Output/Common Services					AEG Sevilla
7743-00315-01	Analogue Acquisition					AEG Sevilla
7746-00259	Output/Common Services					AEG Sevilla
778-2996-004	AMPLIFIER	COLLINS	P/O 67IU-4AN			AEG Sevilla
778695-1	Pressure Regulating and Shutoff Valve				21-32-07	AEG Sevilla
778695-3	Pressure Regulating and Shutoff Valve				21-32-07	AEG Sevilla
778696-1	Wing Isolation Check Valve				21-32-24	AEG Sevilla
778697-1	Trim Zone Temperature Valve				21-61-46	AEG Sevilla
7800403-1	Aircraft Vacuum Generator Assembly				38-30-46	AEG Sevilla
780401-1	Flap System Control Lever Assembly				27-61-03	AEG Sevilla
78169-01	AUTO BRAKE MODULE	PARKER HANNIFIN	B747-400/B737-300,B737-400,B737-500,B737-600,B737-700,B737-800,B737-900		32-40-01	AEG Sevilla
78169-02	AUTO BRAKE MODULE	PARKER HANNIFIN	B747-400/B737-300,B737-400,B737-500,B737-600,B737-700,B737-800,B737-900		32-40-01	AEG Sevilla
78169-03	AUTO BRAKE MODULE	PARKER HANNIFIN	B747-400/B737-300,B737-400,B737-500,B737-600,B737-700,B737-800,B737-900		32-40-01	AEG Sevilla
78169-04	AUTO BRAKE MODULE	PARKER HANNIFIN	B747-400/B737-300,B737-400,B737-500,B737-600,B737-700,B737-800,B737-900		32-40-01	AEG Sevilla
78-16923	STATOR ASSEMBLY	HYDROAIRE	UNK		28	AEG Sevilla
782100-1	HP Bleed Pressure Switch				21-61-46	AEG Sevilla
782100-4	HP Bleed Pressure Switch				21-61-46	AEG Sevilla
785922A	INTEGRATED DRIVE GENERATOR	HAMILTON SUNDSTRAND	A330, A340			AEG Bilbao
7901067F	3/4 INCH SPV WITH PRESSURE RELIEF	EATON LTD	C-212			AEG Sevilla
7970-161-401	SWITCHING UNIT, AUDIO	FOKKER SERVICES BV	F27		23	AEG Sevilla
797800-1	Pressure Regulating Valve Shutdown Override				21-32-12	AEG Sevilla
798021-02-03	PRESELECTOR	SMITHS	A300, A300-600, A310, A318, A319, A320, A321, A322, A330, A330-300, A340, A340-300		28-42-45	AEG Sevilla
798840-1-0	Fuel Temperature Sensor				28-42-15	AEG Sevilla
798882-1-1	Refuel Defuel Panels				28-25-18	AEG Sevilla
798883-1-1	Refuel Defuel Panels				28-25-18	AEG Sevilla
799746-1	Overtemperature Switch				21-61-29	AEG Sevilla
799746-2	Overtemperature Switch				21-61-29	AEG Sevilla
80000000-12	STAB TRIM LIM SW & POS XMTR	MOOG COMPONENT GROUP	B767,B757		27-41-01	AEG Sevilla
8000282Y00	TAXI LIGHT	ZODIAC - TELEFLEX	A320 NEO		33-46-02	AEG Sevilla
8000283Y00	TAKE OFF LIGHT	ECE - TELEFLEX	A318,B737,A321,A320,A319		33-46-01	AEG Sevilla
8000351Y00	AUTOTRANSFORMER, EQUIPPED	ECE - TELEFLEX SYN	A330, A340		33-43-03	AEG Sevilla
800036through841564	Overboard Discharge Connectors				32-30-56	AEG Sevilla
800300Series	Spoiler Cable Tension Regulator				27-60-01	AEG Sevilla
80-044-03	Score Sensors and Target				27-60-02	AEG Sevilla
80-044-04	Score Sensors and Target				27-60-02	AEG Sevilla
80-047-01	Score Sensors and Target				27-60-02	AEG Sevilla
80-0535-1	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-13	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-16	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-19	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-23	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-25	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-29	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-31	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-33	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-35	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-37	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-39	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
80-0535-9	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEG Sevilla
800600Series	Oil Cooler Actuator				79-21-31	AEG Sevilla
801400-1Series	Cable Tension Regulator				27-31-11	AEG Sevilla
801400-2Series	Cable Tension Regulator				27-31-16	AEG Sevilla
8-020-10	Proximity Sensor				27-60-02	AEG Sevilla
802186-4	Ducts				21-62-43	AEG Sevilla
806224-1	Fan Housing				21-62-46	AEG Sevilla
808445-1	Overtemperature Switch				21-61-29	AEG Sevilla
81000-15001	LOGO LIGHT ASSEMBLY	KOITO MFG CO	B757,B767,B737		33-45-01	AEG Sevilla
81000-15002	LOGO LIGHT ASSEMBLY	KOITO MFG CO	B767,B737		33-45-01	AEG Sevilla
81000-15003	LOGO LIGHT ASSEMBLY	KOITO MFG CO	B767,B737		33-45-01	AEG Sevilla
81000-15004	LOGO LIGHT ASSEMBLY	MANUFACTURING CO	B767,B737		33-45-01	AEG Sevilla
81000-15005	LOGO LIGHT ASSEMBLY	MANUFACTURING CO	B767,B737		33-45-01	AEG Sevilla
81000-15006	LOGO LIGHT ASSEMBLY	KOITO MFG CO	B767,B737		33-45-01	AEG Sevilla
81000-17501	LIGHT ASSY	KIOTO	B737, B747		33	AEG Sevilla
81000-17502	MAP LIGHT	KOITO MFG CO	B737		33-11-01	AEG Sevilla
81000-37601	LOGO LIGHT ASSY	KOITO	B-737		33-45-04	AEG Sevilla
81000-37602	LOGO LIGHT ASSY	MANUFACTURING CO	B-737		33-45-04	AEG Sevilla
81000-37703	WING ILLUMINATION LIGHT ASSEMBLY	KOITO MFG CO	B767,B757,B747,B737		33-41-02	AEG Sevilla
81000-37704	WING ILLUMINATION LIGHT ASSEMBLY	KOITO MFG CO	B737		33-41-02	AEG Sevilla
81000-37801	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	A300,B737		33-61-04	AEG Sevilla
81000-37802	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	A300,B737		33-61-04	AEG Sevilla
81000-37901	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	A321A320,A319,A318,B737		33-61-04	AEG Sevilla
81000-38201	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	A321A320,A319,A318,B737		33-61-04	AEG Sevilla
81000-38202	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	A321A320,A319,A318,B737		33-61-04	AEG Sevilla
81000-38203	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	A321A320,A319,A318,B737		33-61-04	AEG Sevilla
81000-38204	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	C-130,B737		33-61-04	AEG Sevilla
81000-38301	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	C-130,B737		33-61-04	AEG Sevilla
81000-41601	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	188,B737-200,B727,B737		33-61-04	AEG Sevilla
81000-41602	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B727,B777,B767,B757,B747,B737		33-61-04	AEG Sevilla
81-025-01	Battery Charger				24-31-08	AEG Sevilla
811588010101	AFT Safety Valve				21-30-37	AEG Sevilla
811588010201	AFT Safety Valve				21-30-37	AEG Sevilla
811CA01	3 PDT No Contactor				24-61-03	AEG Sevilla
8120562 RM	MAIN ROTOR		A320			AEG Bilbao
8120562/S1	ROTOR AND SHAFT ASSEMBLY, MACHINED	LUCAS	A330, A340			AEG Bilbao
8120562/S1RM	ROTOR AND SHAFT ASSEMBLY	LUCAS	A320			AEG Bilbao
8120562RM	ROTOR AND SHAFT ASSEMBLY	LUCAS	A320			AEG Bilbao
81207367/S/S2/S4/S5/S6	FINISHED ROTOR ASSEMBLY		A320			AEG Bilbao
81207367/S1	FINISHED ROTOR ASSEMBLY		A320			AEG Bilbao
81207367/S1/S2	FINISHED ROTOR ASSEMBLY	GOODRICH	A320			AEG Bilbao
81207367/S1/S2/S3	FINISHED ROTOR ASSEMBLY	GOODRICH	A320			AEG Bilbao
81207367/S1/S2/S3/S4	FINISHED ROTOR ASSEMBLY	GOODRICH	A320			AEG Bilbao

81207660/SV52/S3	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/SV52/S3/S4	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/SV52/S4	FINISHED ROTOR ASSEMBLY		A320	24-23-51	AEG Bilbao
81207660/SV53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/SV53/S4	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/SV54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/S2	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207660/S2/S3	FINISHED ROTOR ASSEMBLY	DEFAULT	A320		AEG Bilbao
81207660/S2/S3/S4	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207660/S2/S4	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/S3	FINISHED ROTOR ASSEMBLY	SAFRAN	A320	24-23-51	AEG Bilbao
81207660/S3/S4	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207660/S4	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207690/S1	STATOR ASSEMBLY, MAIN WOUND	GOODRICH	A330, A340		AEG Bilbao
81207690/S1	STATOR ASSEMBLY MAIN WOUND		A330 A340		AEG Bilbao
81207706/S8	ROTOR ASSEMBLY, FINISHED		A330, A340	24-23-53	AEG Bilbao
81207735/S1	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207735/S1/S2	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207735/S2	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207735/S2/S2	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
812624010001	Dual Heat Exchanger			21-51-93	AEG Sevilla
8127597/S1	APU GEN ROTOR		A320		AEG Bilbao
8127597/S1/S2	APU GEN ROTOR		A320		AEG Bilbao
8127597/S2	APU GEN ROTOR		A320		AEG Bilbao
812CA01	3 PDT Contactor 100 A			24-21-31	AEG Sevilla
812CA01	Contactor			24-21-29	AEG Sevilla
8160-530	STARTER GENERATOR	THALES AVIONICS ELECTRICAL SYSTEMS	CN-235, C-295	24	AEG Sevilla
816101-2	Temperature Controller			21-61-73	AEG Sevilla
816101-4	Temperature Controller			21-61-73	AEG Sevilla
8171-1	DIMMABLE ELECTRONIC FLUORESCENT LAMP BALLAST	AUTECH	A320,B737-300,B747- 300,B747-400,B777-300,B777- 300ER	33-20-01	AEG Sevilla
8171-1 MOD A	DIMMABLE ELECTRONIC FLUORESCENT LAMP BALLAST	AVTECH	A330, A340	33-20-01	AEG Sevilla
8171-1A	DIMMABLE ELECTRONIC FLUORESCENT LAMP BALLAST		747	33	AEG Sevilla
8178-1	BALLAST	AVTECH	M6,B737-300,M11B747- 300,B747-400,B777-300,B777- 300ER	33-20-05	AEG Sevilla
8184-1	BALLAST UNIT	AUTECH	B747-300,B747-400, B777-300,B777-300ER	33-20-08	AEG Sevilla
8184-1 MOD A	BALLAST UNIT	AVTECH	B757,B767,B747,B777,B757	33-20-08	AEG Sevilla
8184-1 MOD A	BALLAST UNIT	AVTECH	737, 757, 767		AEG Sevilla
8184-1A	ELECTRONIC BALLAST	AVTECH	737, 757, 767	33-20-08	AEG Sevilla
8184-1MODA	BALLAST	AVTECH	B737-300,B747-200,B777,B767,B757	33	AEG Sevilla
818818-1	Water Separator-Aircraft Air Conditioning Custom			21-73-04	AEG Sevilla
818818-2	Water Separator-Aircraft Air Conditioning Custom			21-73-04	AEG Sevilla
820029-1-000	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-001	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-002	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-003	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-004	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-005	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-006	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-4-005	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-4-006	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
8204-16-0000-01	STEAM OVEN ASSY	SELL	A340,A330,A319,A320,A300,A322,A318,A345 30	25-36-86	AEG Sevilla
8204-16-0000-XX	STEAM OVEN ASSY	SELL	A330, A340		AEG Sevilla
8204-66-0000-01	STEAM OVEN ASSY	SELL	A319,A321,A318,A320	25-36-86	AEG Sevilla
8204-66-0000-XX	STEAM OVEN ASSY	SELL	A330, A340		AEG Bilbao
820507-1	BRUSH BLOCK HOUSING ASSEMBLY	HAMILTON CINDUCTRAM	A330, A340	61	AEG Sevilla
820909-1	Fan Inlet Diffuser Housing			21-53-11	AEG Sevilla
820916-1	Ducts			21-52-43	AEG Sevilla
820917-1	Ducts			21-52-43	AEG Sevilla
820918-1	Ducts			21-52-43	AEG Sevilla
820921-1	Ducts			21-52-43	AEG Sevilla
820922-1	Ducts			21-52-43	AEG Sevilla
820926-2	Check Valve			21-53-09	AEG Sevilla
820932-1	Ducts			21-52-43	AEG Sevilla
820934-2	Check Valve			21-53-08	AEG Sevilla
820938-1	Ducts			21-52-43	AEG Sevilla
820940-1	Ducts			21-52-43	AEG Sevilla
820941-1	Ducts			21-52-43	AEG Sevilla
820942-1	Ducts			21-52-43	AEG Sevilla
820943-1	Ducts			21-52-43	AEG Sevilla
820944-1	Ducts			21-52-43	AEG Sevilla
820946-1	Ducts			21-52-43	AEG Sevilla
820948-2	Check Valve			21-53-14	AEG Sevilla
820967-1	Check Valve			21-53-07	AEG Sevilla
820975-1	Oil Cooler Ejector			79-21-01	AEG Sevilla
8210-161-X	Overspeed Governor Assembly			61-20-16	AEG Sevilla
8210-180	Gear Pump Assembly			61-20-20	AEG Sevilla
821451-1	Ducts			21-52-43	AEG Sevilla
821489-1	Ducts			21-52-43	AEG Sevilla
821545-1	Ducts			21-52-43	AEG Sevilla
821547-1	Ducts			21-52-43	AEG Sevilla
8-240	Proximity Switch			52-70-02	AEG Sevilla
82410615-003	ADVISORY SIGN/PASSENGER WARNING LAMP ASSEMBLY	BOMBARDIER	UNK		AEG Sevilla
82410615-005	ADVISORY SIGN/PASSENGER WARNING LAMP ASSEMBLY	BOMBARDIER	DASH8	31-51-26	AEG Sevilla
82410615-007	ADVISORY SIGN/PASSENGER WARNING LAMP ASSEMBLY	BOMBARDIER	A330, A340	31-51-26	AEG Sevilla
82410615-961	ADVISORY SIGN/PASSENGER WARNING LAMP ASSEMBLY	BOMBARDIER	UNK		AEG Sevilla
825CE02Y00	External Power Monitor PCB			24-51-47	AEG Sevilla
825CE02Y01	External Power Monitor PCB			24-51-47	AEG Sevilla
8260-160	STARTER GENERATOR	AUXILEC	CN-235,C-295	24	AEG Sevilla
83000-0502	HEAT CONTROL UNIT	KOITO MFG CO	B747,B757	30	AEG Sevilla
83000-0503	HEAT CONTROL UNIT	KOITO MFG CO	B747,B757	30	AEG Sevilla
83000-0504	HEAT CONTROL UNIT	KOITO MFG CO	B747,B757	30	AEG Sevilla
83000-05601	HEAT CONTROL UNIT	KOITO MANUFACTURING CO	MDBRU DC-31B,C-295,DC- 31,B737-300,B747-300,B747- 400,B777-300,B777-300ER	30-40-03	AEG Sevilla
83000-05605	WINDOW HEAT CONTROL UNIT	KOITO		30-40-04	AEG Sevilla
83000-0564	HEAT CONTROL UNIT	KOITO MFG CO	B747,B757	30	AEG Sevilla
830CE02Y00	Left Dc Power Center PCB			24-62-17	AEG Sevilla
830CE02Y01	Left Dc Power Center PCB			24-62-17	AEG Sevilla
8315-05601	TRANSFORMER	CILL	UNK		AEG Sevilla
83-216-01	Tire Pressure Sensor/Fill Valve			32-49-12	AEG Sevilla
835760-401	ALTERNATING CURRENT MOTOR	WEBER AIRCRAFT	MD-80,DC-10	38-30-41	AEG Sevilla
835CE02Y00	Right Dc Power Center PCB			24-63-19	AEG Sevilla
835CE02Y01	Right Dc Power Center PCB			24-63-19	AEG Sevilla
8-372-01	PROXIMITY SENSOR	CRANE	A320/A330/A340	32-10-03	AEG Sevilla
8-372-02	PROXIMITY SENSOR	CRANE AEROSPACE	A310,A330,A321,A319,A320	32-10-03	AEG Sevilla
8-372-04	PROXIMITY SENSOR	CRANE AEROSPACE	A350,A340,A310,A320	32-10-03	AEG Sevilla
8-372-05	PROXIMITY SENSOR	CRANE	A320, A321, A330	32	AEG Sevilla
8396-2	HSTA			27-42-06	AEG Sevilla
8-405-06	Proximity Switch			52-70-02	AEG Sevilla
8-405-08	Proximity Switch			52-70-02	AEG Sevilla
8-405-34	Proximity Switch			52-70-02	AEG Sevilla
8-405-36	Proximity Switch			52-70-02	AEG Sevilla
8-405-44	Proximity Switch			52-70-02	AEG Sevilla
8-405-46	Proximity Switch			52-70-02	AEG Sevilla
8-410	Proximity Switch			32-61-11	AEG Sevilla
8-411	Sensor			32-61-21	AEG Sevilla
8423-001	ACCUMULATOR HYDRAULIC	YORK	C-130	29-40A	AEG Sevilla
8423-030	ACCUMULATOR HYDRAULIC	YORK INDUSTRIES	C-130	29-10D	AEG Sevilla
8423-030-1	ACCUMULATOR HYDRAULIC	YORK INDUSTRIES	C-130	29-10D	AEG Sevilla
8425-030	ACCUMULATOR HYDRAULIC	YORK INDUSTRIES	C-130	29-10D	AEG Sevilla
8426-001	ACCUMULATOR HYDRAULIC	YORK INDUSTRIES	C-130	29-10D	AEG Sevilla
8454-1	HSTA			27-42-02	AEG Sevilla

92148C010101	Cabin Indication Module				21-30-33	AEG Sevilla
92148D010101	Cabin Indication Module				21-30-33	AEG Sevilla
930070-5	Hydraulic Fluid To Air Heat Exchanger					AEG Sevilla
933402 / MPEV3-011-E	PUMP-HYDR MOTOR DRIVEN			CN-235, CN-295		AEG Sevilla
933402 / MPEV3-011-E	PUMP-DC ELEC MOTOR			CN-235, CN-295		AEG Sevilla
937958-103	STRUT ASSEMBLY, MLG SHOCK	LOCKHEED		P3 ORIGN		AEG Sevilla
93835-SO-CN-90012-1	50 Cubic Inch Hydraulic Accumulator Assembly	ACROMULTRON				AEG Sevilla
93835-SO-CN-900122-	100 Cubic Inch Hydraulic Accumulator Assembly					AEG Sevilla
9387MAP01	ROTOR ASSEMBLY	PACIFIC SCIENTIFIC		A320	73-21-81	AEG Bilbao
9387MAP02	ROTOR ASSEMBLY	PACIFIC SCIENTIFIC		A320	73-21-81	AEG Bilbao
9387MAP03	FADEC GEN ROTOR	PACIFIC SCIENTIFIC		A330	73-21-81	AEG Bilbao
9387MTP0 SERIES	STATOR			B737 A320		AEG Bilbao
9387MTP01	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC		DC-10	73-21-81	AEG Bilbao
9387MTP02	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC		DC-10	73-21-81	AEG Bilbao
9387MTP04	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC		DC-10	73-21-81	AEG Bilbao
9387MTP05	STATOR AND HOUSING ASSEMBLY	GE		DC-10	73-21-81	AEG Bilbao
9387MTP06	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC		A330, A340, A320	73-21-81	AEG Bilbao
9387MTP07	FADEC GEN STATOR	PACIFIC SCIENTIFIC		CFM56/CF6	73-21-81	AEG Bilbao
9387MTP08	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC		A340	73-21-81	AEG Bilbao
9387MTP09	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC		A330, A340	73-21-81	AEG Bilbao
9401D02000	Double Rotary Actuator				21-30-40	AEG Sevilla
9405A01000	Electrical Actuator				21-31-34	AEG Sevilla
940732	HYDRAULIC MOTORPUMP ASSEMBLY	EATON		B737	29-11-26	AEG Sevilla
940D412-2	EXCITER ROTOR	WESTINGHOUSE		A330, A340	24-20-74	AEG Bilbao
943D367	SEMICONDUCTOR DEVICE SET			A330, A340		AEG Sevilla
943D367-SERIES	SEMICONDUCTOR DEVICE SET	HAMILTON		A330, A340	24	AEG Sevilla
943D724-4	STATOR EXCITER	CLINDETRAND		A330, A340		AEG Bilbao
945173-3	Pressure Manifold Assy					AEG Sevilla
945173-3	Pressure Manifold Assy					AEG Sevilla
945174-1	Return Filter Manifold					AEG Sevilla
945174-1	Return Filter Manifold					AEG Sevilla
945175-1	Case Drain Filter					AEG Sevilla
945175-1	Case Drain Filter					AEG Sevilla
9-464-06	FUEL FLOW / FUEL USED INDICATOR	ELDEC CORPORATION		CN235		AEG Sevilla
9-464-40 MOD B	INDICATOR, LIQUID QTY			CN-235, C-295		AEG Sevilla
9-464-40 MOD D	INDICATOR, RATE OF FL			CN-235, C-295		AEG Sevilla
946F77	SEMICONDUCTOR DEVICE SET			A330, A340		AEG Sevilla
946F77-1	SEMICONDUCTOR	WESTINGHOUSE		B737	24-20-77	AEG Bilbao
946F77-SERIES	SEMICONDUCTOR DEVICE SET			A330, A340		AEG Sevilla
946J498-2	AC GENERATOR	HAMILTON		UNK		AEG Bilbao
946J598-1	AC GENERATOR	HAMILTON		UNK		AEG Bilbao
947F226-3	EXCITER ARMATURE CAPACITOR AND DIODE ASSEMBLY	HAMILTON		A330, A340	8A6-8-11-	AEG Bilbao
948F463-4	10 KVA GENERATOR	HAMILTON		UNK	8A6-5-10-	AEG Bilbao
949F283	SEMICONDUCTOR DEVICE SET			A330, A340		AEG Sevilla
95050XX	Port/STBD Door Surround Assembly				53-10-08	AEG Sevilla
9506111-501	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-502	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-503	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-504	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-505	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-506	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-507	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-508	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-509	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-510	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-511	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-512	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-513	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-514	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-515	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-516	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-517	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-518	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-519	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-520	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-521	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-522	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-523	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-524	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-525	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-526	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-527	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-528	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-529	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-530	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-531	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
9506111-532	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE		(DHC)Dash 8-400;(DHC)Dash 8-300;(DHC)Dash 8-200;(DHC)Dash 8-100	25	AEG Sevilla
950F236-5	ARMATURE ASSEMBLY			A330, A340		AEG Bilbao
954732-2	CONTROL VALVE ASSEMBLY	ABS		C-212	32	AEG Sevilla
9550493-1	WHEEL LANDING GEAR			UNK		AEG Sevilla
955064L	SKID CONTROL VALVE UNIT	MEGGITT AIRCRAFT		B737	32-48-02	AEG Sevilla
95-94064-0001	DOUBLE SEAT			C-295		AEG Sevilla
95-94064-0001B01	SEAT DOUBLE ASSY	AIRBUS		C-295		AEG Sevilla
95-94064-0001B05	DOUBLE SEAT			A330, A340		AEG Sevilla
95-94064-0001E03	SEAT DOUBLE ASSY	AIRBUS		C-295		AEG Sevilla
95-94064-0002	SEAT DOUBLE ASSY	AIRBUS		C-295		AEG Sevilla
95-94064-0003	SEAT DOUBLE ASSY			UNK		AEG Sevilla
95-94064-0003B01	SEAT DOUBLE ASSY	AIRBUS		C-295		AEG Sevilla
95-94064-0003B05	SEAT DOUBLE ASSY	AIRBUS		C-295		AEG Sevilla
95-94064-0003E03	SEAT DOUBLE ASSY	AIRBUS		C-295		AEG Sevilla
9600-16-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
9600-26-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
9600-32-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
9600-40-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
9600-44-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
9600-61-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
9600-65-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
96042-1	Engine Vibration Isolation System				71-20-57	AEG Sevilla
96042-5	Engine Vibration Isolation System				71-20-57	AEG Sevilla
96042-6	Engine Vibration Isolation System				71-20-57	AEG Sevilla
96042-7	Engine Vibration Isolation System				71-20-57	AEG Sevilla
96042-8	Engine Vibration Isolation System				71-20-57	AEG Sevilla
960448-1	System 1 Hydraulic Fluid Reservoir					AEG Sevilla
960449-1	Reservoir Assembly, Hydraulic System 2					AEG Sevilla
960450-1	Reservoir Assembly, Hydraulic System No. 2					AEG Sevilla
96109-31-105	CORE, EMS, PPU, FWD, SIDE	HUTCHINSON		A400M		AEG Bilbao
96109-31-107	BOLT ASSY, PPU, FWD, SIDE & TOP	HUTCHINSON		A400M		AEG Bilbao
96109-31-109	BOLT ASSY, PPU, FWD, SIDE & TOP	HUTCHINSON		A400M		AEG Bilbao
96109-32-105	CORE, EMS, PPU, FWD, TOP	HUTCHINSON		A400M		AEG Bilbao
96109-32-107	BOLT ASSY, PPU, FWD, SIDE & TOP	HUTCHINSON		A400M		AEG Bilbao
96109-32-109	BOLT ASSY, PPU, FWD, SIDE & TOP	HUTCHINSON		A400M		AEG Bilbao
96109-33-101	AFT MOUNT - PYLON FASTENERS	HUTCHINSON		A400M		AEG Bilbao
96109-33-103	AFT MOUNT - PYLON FASTENERS	HUTCHINSON		A400M		AEG Bilbao
96109-33-105	AFT MOUNT - PYLON FASTENERS	HUTCHINSON		A400M		AEG Bilbao
961627	HYDRAULIC MOTORPUMP ASSEMBLY	EATON		B737	29-11-26	AEG Sevilla
965C380-2	STATOR MOTOR	WESTINGHOUSE		B737	29	AEG Sevilla
970500-7	Cable Tension Regulator (Aileron Control)					AEG Sevilla
970500-7SERIES	Cable Tension Regulator(Aileron Control)					AEG Sevilla
970500-8	Cable Tension Regulator (Aileron Control)					AEG Sevilla

BFI-0010-005	Return To Seat Sign (Lav)				33-21-45	AEG Sevilla
BFI-0010-006	Return To Seat Sign (Lav)				33-21-45	AEG Sevilla
BFI-0011-101	Overhead Emergency Exit Sign Fwd				33-21-94	AEG Sevilla
BFI-0039-001	Overhead Emergency Exit Sign Fwd				33-21-95	AEG Sevilla
BFI-0044-004	Emergency Exit Sign				33-21-38	AEG Sevilla
BFS-0018-001	Emergency Exit Sign RH				33-21-34	AEG Sevilla
BFS-0018-002	Emergency Exit Sign RH				33-21-34	AEG Sevilla
BH38XAH	CONTACTOR CALTERNA 50A	HARTMAN ELECTRICAL		CN-235		AEG Sevilla
BJI-0017-001	Staircase Light				33-41-98	AEG Sevilla
BJI-0021-003	Wing Inspection Light LH				33-40-88	AEG Sevilla
BJI-0021-004	Wing Inspection Light LH				33-40-88	AEG Sevilla
BJI-0027-002	Cargo Light Assy				33-41-99	AEG Sevilla
BPF-5/8	COVER			UNK		AEG Bilbao
BP57-3	BATTERY POWER SUPPLY	RADIANT ILLUMINATION	A320,B737-300,B747-200,B737-900,B777,B767-300,B767-300,B767-300		25-65-02	AEG Sevilla
BR703	Cargo Light Assy				33-31-32	AEG Sevilla
BR9070Series	Exit & Information Sign				33-21-51	AEG Sevilla
BYLF50313	Temperature Sensor Assembly				F-19259	AEG Sevilla
C	5 Channel Selcal Decoder				23-20-24	AEG Sevilla
C12842AB04	Stall Protection Module				27-33-01	AEG Sevilla
C12842AB05	Stall Protection Module				27-33-01	AEG Sevilla
C12842AB06	Stall Protection Module				27-33-01	AEG Sevilla
C12842AB07	Stall Protection Module				27-33-01	AEG Sevilla
C148659-1	Flap Actuators				27-52-16	AEG Sevilla
C148660-1	Flap Actuators				27-52-16	AEG Sevilla
C148661-1	Flap Actuators				27-52-16	AEG Sevilla
C159993-1-001	Flap Control Unit				27-51-01	AEG Sevilla
C16298AA	TEMPERATURE IND	THALES		A330, A340		AEG Sevilla
C20105000	TACH GENERATOR	SAFRAN MESSIER-BUGATTI		A300-	77	AEG Sevilla
C20105000-1	TACHOMETER	MESSIER-BUGATTI	A300,A310,A319,A320,A330,A340,A350		32	AEG Sevilla
C20105000-2	TACHOMETER	MESSIER-BUGATTI	A300,A310,A319,A320,A330,A340		32	AEG Sevilla
C20105300	TACHOMETER	MESSIER-BUGATTI	MURU A300,A310,A319,A320,A330,A340		32,32-46-15	AEG Sevilla
C20259000	AXLE SLEEVE	MESSIER		A318,A320	32	AEG Sevilla
C20288000-1	RETURN ACCUMULATOR	MESSIER-BUGATTI		340,A340,A330	32-46-06	AEG Sevilla
C20288000-2	RETURN ACCUMULATOR	MESSIER-BUGATTI	340,A340,A330,A320,A330-342		32-46-06	AEG Sevilla
C20374000-1	VALVE-SERVO BRAKE	MESSIER-BUGATTI	C-130,B737-300,B737-400,B737-800,A320,A330,A340,A350,A300,A310,A319,A320,A330,A340		32-43-15	AEG Sevilla
C23005	PITCH DAMPER	MESSIER		A310,A300-600,A300	32-11-15	AEG Sevilla
C23005-2	PITCH DAMPER	MESSIER		A310,A300-600,A300	32-11-15	AEG Sevilla
C23097-106	SHOCK ABSORBER			UNK		AEG Sevilla
C2310610	TELESCOPIC STRUT	MESSIER-DOWTY		A310,A300	32	AEG Sevilla
C2310610-2	TELESCOPIC STRUT	MESSIER-DOWTY		B767,A310,A300	32	AEG Sevilla
C2310810	TELESCOPIC STRUT	MESSIER-DOWTY SA		A310	32-34-57	AEG Sevilla
C24592020	MASTER CYLINDER	MESSIER-BUGATTI	A321,A320,A319,A318,A340-313,A330		32-32-44-11	AEG Sevilla
C24592020-1	MASTER CYLINDER	MESSIER-BUGATTI	A321,A320,A319,A318,A330		32-44-11	AEG Sevilla
C24703001	PARKING BRAKE SELECTOR VALVE	MESSIER-BUGATTI	A318,B777,B767		32-47-24	AEG Sevilla
C24703001-3	PARKING BRAKE SELECTOR VALVE	MESSIER-BUGATTI	11,8767,8767,A310,A300,A319,A318,A320		32-47-24	AEG Sevilla
C24703001-4	PARKING BRAKE SELECTOR VALVE	MESSIER-BUGATTI	11,8767,8767,A310,A300,A319,A318,A320		32-47-24	AEG Sevilla
C24703003	PARKING BRAKE SELECTOR VALVE	MESSIER	A321,A319,A318,A320-232,A320		32-47-24	AEG Sevilla
C24703000-2	UPLock ASSEMBLY	MESSIER-BUGATTI	A321,A320,A319,A318		32-37-09	AEG Sevilla
C24703000-3	UPLock ASSY-DOOR	MESSIER-BUGATTI	A321,A320,A319,A318		32-37-09	AEG Sevilla
C24703000-4	UPLock ASSEMBLY	MESSIER-BUGATTI	A321,A320,A319,A318		32-37-09	AEG Sevilla
C24703000-5	UPLock ASSEMBLY	MESSIER-BUGATTI	A321,A320,A319,A318		32-37-09	AEG Sevilla
C24703001-4	UPLock ASSEMBLY	MESSIER-BUGATTI	A321,A319,A318,B777,A320		32-37-08	AEG Sevilla
C24703001-6	NLG UPLock ASSY	MESSIER	A330,A321,A319,A318,B777,A320		32-37-08	AEG Sevilla
C247030100	NLG DOOR UPLock ASSY	MESSIER	A330,A321,A319,A318,A320		32-37-09	AEG Sevilla
C247030100-1	UPLock ASSEMBLY	MESSIER-BUGATTI	A321,A320,A319,A318,A320-221,A320-232		32-37-09	AEG Sevilla
C247030100-2	UPLock ASSEMBLY	MESSIER	A321,A318,A330,A320,A319		32-37-09	AEG Sevilla
C247030100-3	UPLock ASSEMBLY	MESSIER-BUGATTI SA	A321,A318,A330,A320,A320-200,A319		32-37-09	AEG Sevilla
C24736000	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	B707,A319,A320,A318		32-57-01	AEG Sevilla
C24736000-0-1	SERVO CONTROL	MESSIER-BUGATTI	A319,A320,A318		32-57-01	AEG Sevilla
C24736000-0-2	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A320,A318		32-57-01	AEG Sevilla
C24736000-1	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A318,A320,A319		32-57-01	AEG Sevilla
C24736000-2	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A318,A320,A319		32-57-01	AEG Sevilla
C24736001	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A320,A318		32-57-01	AEG Sevilla
C24736001-0-1	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A320,A318		32-57-01	AEG Sevilla
C24736001-0-2	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A320,A318		32-57-01	AEG Sevilla
C24736001-1	SERVO CONTROL	MESSIER-BUGATTI	A319,A320,A318,A320-221		32-57-01	AEG Sevilla
C24736001-2	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A320,A318,A320-232		32-57-01	AEG Sevilla
C24736001-3	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A320,A318		32-57-01	AEG Sevilla
C247360100-1	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A318,A310,A320		32-57-01	AEG Sevilla
C24747000	VALVE_SELECTOR	MESSIER	A318,A321,A319,A320		32,32-57-04,32-57-01	AEG Sevilla
C24747000-1	VALVE_SELECTOR	MESSIER	A318,A321,A319,A320		32,32-57-04,32-57-01	AEG Sevilla
C2483701	HOLDSING/BRAKE MANIFOLD	MESSIER-BUGATTI - EARDAM, GROUND	A318,A321,A319,A320-232,B747,A320		32-47-45	AEG Sevilla
C2483701-1	MANIFOLD-NORMAL BRAKE ASSY	MESSIER-BUGATTI	A318,A321,A319,B747,A320		32-47-45	AEG Sevilla
C2483701-3	BRAKE MANIFOLD ASSY	MESSIER	A318,A321,A319,B747,A320		32-47-45	AEG Sevilla
C2483701-4	MANIFOLD ASSY	MESSIER-BUGATTI	A318,A321,A319,A320-232,B747,A320		32-47-45	AEG Sevilla
C24998000	SWIVEL SELECTOR VALVE	MESSIER-BUGATTI	C-130,A318,A321,A319,A340,A330,A320		32-57-15	AEG Sevilla
C2-96000-8	ACTUATOR, WINDSHIELD WIPER	NAVAIR		A330, A340	29	AEG Sevilla
CS116-03	STARTER MOTOR TYPE CS16 SERIES	SAFRAN		Boeing 747-400	49-40-01	AEG Bilbao
CS116-04	STARTER MOTOR TYPE CS16 SERIES	SAFRAN		Boeing 747-400	49-40-01	AEG Bilbao
CS116-05	STARTER MOTOR TYPE CS16 SERIES	SAFRAN		Boeing 747-400	49-40-01	AEG Bilbao
CS116-06	STARTER MOTOR TYPE CS16 SERIES	SAFRAN		Boeing 747-400	49-40-01	AEG Bilbao
CS116-07	STARTER MOTOR TYPE CS16 SERIES	SAFRAN		Boeing 747-400	49-40-01	AEG Bilbao
CS116-08	STARTER MOTOR TYPE CS16 SERIES	SAFRAN		Boeing 747-400	49-40-01	AEG Bilbao
CS116-09	STARTER MOTOR TYPE CS16 SERIES	SAFRAN		Boeing 747-400	49-40-01	AEG Bilbao
CS116-10	STARTER MOTOR TYPE CS16 SERIES	SAFRAN		Boeing 747-400	49-40-01	AEG Bilbao
CS116-11	STARTER MOTOR TYPE CS16 SERIES	SAFRAN		Boeing 747-400	49-40-01	AEG Bilbao
CS120-1	STARTER MOTOR TYPE CS120	SAFRAN		Boeing 747-400	80-10-34	AEG Bilbao
CS120-2	STARTER MOTOR TYPE CS120	SAFRAN			80-10-34	AEG Bilbao
CS120-3	STARTER MOTOR TYPE CS120	SAFRAN			80-10-34	AEG Bilbao
CS1M0020	RESERVOIR FILLING VALVE	GOODRICH ILLUMINATION SYSTEMS SCA	C-130,A310,A300-800,A300,A318,A320-201,A320-202,A320,A320,A310		29-16-67	AEG Sevilla
C93R13-601	Canister				28-24-09	AEG Sevilla
C93R25-601	Canister				28-13-45	AEG Sevilla
C93R38-608	Crossflow Pump Canister				28-23-03	AEG Sevilla
C99-26-001	Crossflow Inlet Screen				28-13-49	AEG Sevilla
CAU3932A**	Remote Control Audio Unit				23-51-71	AEG Sevilla
CDK463	Night Vision Goggles System Cockpit Door				52-51-16	AEG Sevilla
CDSP70000-1	Aft Cargo Tie Down				50-22-17	AEG Sevilla
CE400150-0001	FUEL TRANSFER EJECTOR PUMP	CESA		C-295	28-22-01	AEG Sevilla
CE400150-0001 Amdt	FUEL TRANSFER EJECTOR PUMP	CESA		C-295	28-22-01	AEG Sevilla
CE400150-0001 Amdt A	FUEL TRANSFER EJECTOR PUMP	CESA		C-295	28-22-01	AEG Sevilla
CGFP-02	REPAIR MANUAL FOR FLOOR PANELS OF CL-400, CHALLENGER, CL-401, B-1, CL-430, CL-440				CGFP-02	AEG Sevilla
CMM-030	Floor Panels Repairs				53-00-47	AEG Sevilla
CP1200-2	CONTROL PENDANT			CN-235, C-295		AEG Sevilla
CRA49044	LEG ASSY-NLG	SAFRAN LANDING SYSTEMS		A340		AEG Sevilla
CRA49045	LEG ASSY-NLG	SAFRAN LANDING SYSTEMS		A340		AEG Sevilla
CRA49219	LEG ASSY-NLG	SAFRAN LANDING SYSTEMS		A340		AEG Sevilla
CRA49220	LEG ASSY-NLG	SAFRAN LANDING SYSTEMS		A340		AEG Sevilla
CRA49221	LEG ASSY-NLG	SAFRAN LANDING SYSTEMS		A340		AEG Sevilla
CYC-AP502007-101(C)	Fiberglass Ducts				21-54-69	AEG Sevilla
D102740	MOTOR TYPE 160-45-511	AIRCREW HOWDEN		A330, A340	32,32-43-05	AEG Sevilla
D106300-4	ARMATURE	STEINHEIL OPTRONIK		A330, A340		AEG Bilbao
D23064000	LEG STRUCTURE	MESSIER DOWTY SA	A321,A320,A319,A318		32	AEG Sevilla
D23064000-10	LEG STRUCTURE	MESSIER DOWTY SA	A321,A320,A319,A318		32	AEG Sevilla
D23064000-11	LEG STRUCTURE	MESSIER DOWTY SA	A321,A320,A319,A318		32	AEG Sevilla
D23064000-12	LEG STRUCTURE	MESSIER DOWTY SA	A321,A320,A319,A318		32	AEG Sevilla
D23064000-13	LEG STRUCTURE	MESSIER DOWTY SA	A321,A320,A319,A318		32	AEG Sevilla
D23064000-14	LEG STRUCTURE	MESSIER DOWTY SA	A321,A320,A319,A318		32	AEG Sevilla
D23064000-15	LEG STRUCTURE	MESSIER DOWTY SA	A321,A320,A319,A318		32	AEG Sevilla
D23064000-16	LEG STRUCTURE	MESSIER DOWTY SA	A321,A320,A319,A318		32	AEG Sevilla

D23582300-2	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-205	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330			AEG Sevilla
D23582300-206	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330			AEG Sevilla
D23582300-207	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330			AEG Sevilla
D23582300-208	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330			AEG Sevilla
D23582300-209	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330			AEG Sevilla
D23582300-210	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330			AEG Sevilla
D23582300-211	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330			AEG Sevilla
D23582300-3	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-306	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-307	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-308	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-309	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-310	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-4	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-5	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-6	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-7	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-8	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23582300-9	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		32-23-24	AEG Sevilla
D23585000	BOX & ELECTRICAL HARNESS TOWBA	MESSIER DOWTY SA	A330		32-57-12	AEG Sevilla
D23585000-100	BOX & ELECTRICAL HARNESS TOWBA	MESSIER-DOWTY	A340,A330		32-57-21	AEG Sevilla
D23591920-5	BARREL STRUCTURE	MESSIER	A321A320,A319,A318			AEG Bilbao
D23596000	FORESTAY ASSEMBLY	MESSIER DOWTY SA	A321A319,A318,A320		32	AEG Sevilla
D23607000-1	LEG FITTINGS	MESSIER DOWTY SA	A321A319,A318,A320		32	AEG Sevilla
D2361000	NLG LOCKING SPRING	MESSIER-DOWTY	A321A319,A318,B747,A320		32-27-27	AEG Sevilla
D236270 SERIES	1M UPPER HARNESS	SAFRAN LANDING	A318/A319/A320/		32-07-09	AEG Sevilla
D23627000	1M UPPER HARNESS	MESSIER-DOWTY SA	A330,A321A319,A318,A320		32-07-09	AEG Sevilla
D236290 SERIES	INTERMEDIATE HARNESS	SAFRAN LANDING	A318/A319/A320/		32-07-13	AEG Sevilla
D236300 SERIES	LOWER HARNESS	SAFRAN LANDING	A318/A319/A320/		32-07-12	AEG Sevilla
D23630000	LOWER HARNESS	MESSIER-DOWTY SA	A330,A321A319,A318,A320		32-07-12	AEG Sevilla
D236600 SERIES	2M UPPER HARNESS	SAFRAN LANDING	A318/A319/A320/		32-07-10	AEG Sevilla
D24005000	ALTERNATE BRAKE MANFOLD ASSY	SAFRAN	A318 - A321		32	AEG Sevilla
D24005000-1	ALTERNATE BRAKE MANFOLD ASSY	SAFRAN	A318 - A321		32	AEG Sevilla
D24006000	ALTERNATE BRAKE MANFOLD ASSEMBLY	SAFRAN	A318, A319, A320, A321		32-47-54	AEG Sevilla
D24006000-1	ALTERNATE BRAKE MANFOLD ASSEMBLY	SAFRAN	A318, A319, A320, A321		32-47-54	AEG Sevilla
D24029000-3	NORMAL BRAKE MANIFOLD ASSEMBLY	F6137	A340		32	AEG Sevilla
D2461083	LANDING GEAR CUT-OUT VALVE	LUCAS AEROSPACE	A340		32	AEG Sevilla
D2461084	CUT OUT VALVE	LUCAS AEROSPACE	A340		32	AEG Sevilla
D3216501000000	NUT ASSY - PINTLE PIN	AIRBUS	A321A320		32	AEG Sevilla
D322101600000	ROD ASSY	AIRBUS INDUSTRIE	A320		32-22-11	AEG Sevilla
D322101600100	ROD ASSY	AIRBUS INDUSTRIE	A320		32-22-11	AEG Sevilla
D322101600400	ROD ASSY	AIRBUS INDUSTRIE	A320		32-22-11	AEG Sevilla
D455-07-001	ENGINE FIRE SHUT-OFF SWITCH	AIRBUS	B747-200,B767,B757,A320,B747-400		26-21-15	AEG Sevilla
D455-08-001	ENGINE FIRE SHUT-OFF SWITCH	AIRBUS	B747-200,B767,B757		26-21-15	AEG Sevilla
D5282000100551	ELEVATOR ASSY	AIRBUS	B737,A318,A319,A300,A320,A321		65-56-21-15	AEG Sevilla
D59881	APEX PIN	UNKNOWON	A320		32	AEG Sevilla
D6000-5	HYDRAULIC ACTUATOR WINDSHIELD WIPER	MARQUET	A330, A340		REF-41	AEG Sevilla
D61366	AXLES NUT	AIRBUS	A320		32	AEG Sevilla
D61530-1	PIN	MESSIER	A321A320,A319,A318		32	AEG Sevilla
D61686	RETRACTION ACTUATOR PIN	MESSIER-DOWTY	A330		32-23-06	AEG Sevilla
D62660	TORQUE LINK APEX PIN	MESSIER-DOWTY	A330		32-23-21	AEG Sevilla
D63996	MAIN FITTING	SAFRAN	A330		32-23-24	AEG Sevilla
D64000	UPPER FLANGE	SAFRAN	A330		32-23-21	AEG Sevilla
D64001	LOWER TORQUE LINK	SAFRAN	A330		32-23-12	AEG Sevilla
D64002	UPPER TORQUE LINK	SAFRAN	A330		32-23-12	AEG Sevilla
D64003	MAIN FITTING HINGE PIN	MESSIER-DOWTY	A330		32-23-12	AEG Sevilla
D64005	LOWER TORQUE LINK PIN	MESSIER-DOWTY SA	A330		32-23-21	AEG Sevilla
D64006	UPPER TORQUE LINK PIN	MESSIER-DOWTY	A330		32-23-21	AEG Sevilla
D64034	DRAG STAY UPPER PIN	MESSIER-DOWTY	A330		32-23-18	AEG Sevilla
D64036	DRAG STAY CENTER PIN	MESSIER-DOWTY SA	A330		32-23-18	AEG Sevilla
D64037	DRAG STAY LOWER ARM	SAFRAN	A330		32-23-22	AEG Sevilla
D64433	APEX PIN	13951	A321A319,A318,A320,A320-221		32-21-31	AEG Sevilla
D65046	SLIDING TUBE	SAFRAN	A330		32-23-21	AEG Sevilla
D65051	CYLINDER	MESSIER-DOWTY	A330		32-23-21	AEG Sevilla
D65233	BARREL	MESSIER	A321A319,A318,A320		32	AEG Sevilla
D65644	END FITTING	MESSIER	A321A320,A319,A318		32	AEG Sevilla
D65989	RING	MESSIER-DOWTY	A320			AEG Sevilla
D66331	DRAG STAY LVWR ARM MAIN FITTING	MESSIER-DOWTY	A330		32-23-21	AEG Sevilla
D67201	SLIDING TUBE	SAFRAN	A330		32-23-21	AEG Sevilla
D67237	RESTRICTOR VALVE	SAFRAN	A330			AEG Sevilla
D67241	RESTRICTOR	SAFRAN	A330			AEG Sevilla
D67247-1	LOWER TORQUE LINK PIN	SAFRAN	A330			AEG Bilbao
D67634	TURNING SLEEVE	SAFRAN	A330		32-23-12	AEG Sevilla
D67802	FORESTAY LOWER LINK	MESSIER	A321A320,A319,A318		32-27-23	AEG Sevilla
D68053-1	RESTRICTOR VALVE	SAFRAN	A330		32-23-21	AEG Sevilla
D68100-1	SUPPORT TUBE	KO654	A330		32-23-21	AEG Sevilla
D68346	RESTRICTOR VALVE	SAFRAN	A330		32-23-21	AEG Sevilla
D68347	RESTRICTOR	KO654	A330			AEG Sevilla
D68797	APEX PIN	SAFRAN MESSIER-BUNAT	A321A320,A319,A318		32-27-20	AEG Sevilla
D771-01-001	EMERGENCY POWER SUPPLY	PAGE AEROSPACE	B737-300,B747-200,B757-200,B757-300,B767-300,B777-300		24-35-01	AEG Sevilla
D771-02-001	EMERGENCY POWER SUPPLY	PAGE AEROSPACE	B737-300,B747-200,B757-200,B757-300,B767-300,B777-300		24-35-01	AEG Sevilla
D771-02-030	EMERGENCY POWER SUPPLY	PAGE AEROSPACE LIM	B737-300,B747-200,B757-200,B757-300,B767-300,B777-300		24-35-01	AEG Sevilla
D94412	FAN	AIRSCREW HOWDEN	A330, A340		21	AEG Sevilla
D98A07-401	Pressure Sensor				28-42-07	AEG Sevilla
D98C07-405	Pressure Sensor				28-42-10	AEG Sevilla
D98C07-607	Pressure Sensor				28-42-10	AEG Sevilla
D98C09-402	Pressure Sensor				28-42-04	AEG Sevilla
D98C09-403	Pressure Sensor				28-42-04	AEG Sevilla
DK250-001-1	Oil Indicator Unit				79-31-11	AEG Sevilla
DL2428M24	Actuator, Linear				27-30-01	AEG Sevilla
DL2428M4	Actuator, Linear				27-30-01	AEG Sevilla
DL2428MAMOD1	Actuator, Linear				27-30-01	AEG Sevilla
DL412	INDICADOR DE NI	VDO	UNK		77	AEG Sevilla
DM1172	Tres and Tubes					AEG Sevilla
DS1-421/106	DIRECT READING PRESSURE GAGE		A330, A340			AEG Sevilla
DS11421/106	INDICATOR		UNK			AEG Sevilla
DS1421/106	DIRECT READING PRESS	KDG INSTRUMENTS	A330, A340		77	AEG Sevilla
DS1-421/106	DIRECT READING PRESSURE GAGE		A330, A340			AEG Sevilla
E13035AA01	Central Processing Unit (CPU)					AEG Sevilla
E13036AA	Extension Board					AEG Sevilla
E13081AA	Interface Board					AEG Sevilla
E13081AB	Interface Board					AEG Sevilla
E13081FA	Interface Board					AEG Sevilla
E13081HA	Interface Board					AEG Sevilla
E13081HB	Interface Board					AEG Sevilla
E13185BA	Extension A/B Com Boards				27-61-27	AEG Sevilla
E13185BA	Extension A/B Com Boards				27-61-27	AEG Sevilla
E13185BB	Extension A/B Com Boards				27-61-27	AEG Sevilla
E13186BA01	CPU A Programmed Board				27-61-17	AEG Sevilla
E13188BA	Extension A/B Mon Boards				27-61-30	AEG Sevilla
E13188BB	Extension A/B Mon Boards				27-61-30	AEG Sevilla
E13190BA	Extension A/B Com Boards				27-61-27	AEG Sevilla
E13190BA	Extension A/B Com Boards				27-61-27	AEG Sevilla
E13190BB	Extension A/B Com Boards				27-61-27	AEG Sevilla
E13190BB	Extension A/B Com Boards				27-61-27	AEG Sevilla
E13191BA01	CPU B Programmed Board				27-61-21	AEG Sevilla
E13193BA	Extension A/B Mon Boards				27-61-30	AEG Sevilla
E13193BB	Extension A/B Mon Boards				27-61-30	AEG Sevilla

E1410CA	Display Module			23-81-10	AEG Sevilla
E1410FA	Display Module			23-81-10	AEG Sevilla
E1735AA	Power Supply A/B Boards			27-61-25	AEG Sevilla
E1735AA	Power Supply A/B Boards			27-61-25	AEG Sevilla
E21330000	DIRECT DRIVE VALVE	SAFRAN	A318, A319, A320, A321	32-47-55	AEG Sevilla
E21330000-1	ABS MANIFOLD	MESSIER BUGATTI	A320	32-47-55	AEG Sevilla
E21330001-1	DIRECT DRIVE VALVE	SAFRAN	A319, A320, A321	32-47-63	AEG Sevilla
E21330000	SENSOR BOX	MESSIER	A321,A320,A319,A318	32-57-14	AEG Sevilla
E2588M42	ARMATURE		UNK		AEG Bilbao
E4187	Proximity Sensing System Fuel & Utility Systems			32-60-XX	AEG Sevilla
E520002-20IA	Junction Box No. 2				AEG Sevilla
E520002-20IB	Junction Box No. 2				AEG Sevilla
E520003-20IB	Junction Box No. 3				AEG Sevilla
E520003-20IC	Junction Box No. 3				AEG Sevilla
E520004-20IA	Junction Box No. 10				AEG Sevilla
E520004-20IB	Junction Box No. 10				AEG Sevilla
E520004-20IC	Junction Box No. 10				AEG Sevilla
E520005-20IA	Junction Box No. 11				AEG Sevilla
E520005-20IB	Junction Box No. 11				AEG Sevilla
E709-01-001	CEILING LIGHT	PAGE AEROSPACE	B737-300,B767,B737	33-21-02	AEG Sevilla
E709-01-100	CEILING LIGHT	PAGE AEROSPACE	A320,B737-300,B767,B737	33-21-02	AEG Sevilla
E709-03-001	CEILING LIGHT	PAGE AEROSPACE	B737-300,B767,B737	33-21-02	AEG Sevilla
E709-04-001	CEILING LIGHT	PAGE AEROSPACE	B747-200,B727,B767,B737	33-21-02	AEG Sevilla
EM48-6	ELECTRIC MOTOR	ELUMTECH TECHNOLOGY	CN-235		AEG Sevilla
EM48-6-1	ELECTRIC MOTOR	ELUMTECH TECHNOLOGY	CN-235/CN-295		AEG Sevilla
EV7AS23-1	Gasper Fan			21-25-11	AEG Sevilla
F97-13-402	Self-Clean Filter			28-22-02	AEG Sevilla
FE210-008A	Quadrant Indicator			76-11-01	AEG Sevilla
FE210-008C	Quadrant Indicator			76-11-01	AEG Sevilla
FE210-302	Quadrant Indicator			76-11-01	AEG Sevilla
FE247-000	Engine Throttle Quadrant Unit			76-11-02	AEG Sevilla
FE258-000	Aileron Control Cable Tension Regulator				AEG Sevilla
FE258-001	Aileron Control Cable Tension Regulator				AEG Sevilla
FE259-000	Elevator Control Cable Tension Regulator				AEG Sevilla
FE259-001	Elevator Control Cable Tension Regulator				AEG Sevilla
FE263-000	Rudder Load Limiters			27-20-02	AEG Sevilla
FE264-000	Rudder Load Limiters			27-20-02	AEG Sevilla
FE265-000	Rudder Load Limiters			27-20-02	AEG Sevilla
FE266-000	Elevator Load Limiters			27-30-01	AEG Sevilla
FE267-000	Elevator Load Limiters			27-30-01	AEG Sevilla
FE268-000	Cable Tension Regulator				AEG Sevilla
FE278	Elevator Trim Indicator			27-32-16	AEG Sevilla
FE279	Park Brake Control Modulw			32-44-21	AEG Sevilla
FE280	Power Quadrant			76-10-01	AEG Sevilla
FE281	Condition Control Module			76-10-06	AEG Sevilla
FE282	Flap Control Module			27-51-06	AEG Sevilla
FE284000004	Throttle Quadrant			76-11-03	AEG Sevilla
FE284000005	Throttle Quadrant			76-11-03	AEG Sevilla
FE289	Load Limiter Elevator			27-31-02	AEG Sevilla
FE290	PCU Elevator Input Bungee			27-31-03	AEG Sevilla
FE335000000	Load Limiter			27-21-01	AEG Sevilla
FE336000000	Elevator Force- Sensor Rod			27-30-02	AEG Sevilla
FE336000002	Elevator Force- Sensor Rod			27-30-02	AEG Sevilla
FE336000003	Elevator Force- Sensor Rod			27-30-02	AEG Sevilla
FE337000000	Rudder Force- Sensor Rods			27-20-04	AEG Sevilla
FE338000000	Aileron Quadrant Assy				AEG Sevilla
FE338001000	Aileron Quadrant Assy				AEG Sevilla
FE338500000	Aileron Force- Sensor Rods				AEG Sevilla
FE338500001	Aileron Force- Sensor Rods				AEG Sevilla
FE338500002	Aileron Force- Sensor Rods				AEG Sevilla
FE338500004	Aileron Force- Sensor Rods				AEG Sevilla
FE338500005	Aileron Force- Sensor Rods				AEG Sevilla
FE338600000	Aileron Link				AEG Sevilla
FE339	Aileron Quadrant Assy				AEG Sevilla
FE340000000	Electronic Control Unit				AEG Sevilla
FV295	Flap Actuator Ballscrew			27-50-03	AEG Sevilla
FV295000000	Flap Actuator Ballscrew			27-50-03	AEG Sevilla
G4-1505-1429	LIGHT ANTI-COLLISION		ATR-42, ATR-72		AEG Sevilla
G5944	CONTROL INTERCOM	GABLES	UNK		AEG Sevilla
G7490-33	FLIGHT ID/ATC/CAS Control Panel	GABLES ENGINEERING	A330, A340	34	AEG Sevilla
GB46-6-20	QUANTITY MEASURING FUSE ASSEMB	PARKER	B737	32-40-01	AEG Sevilla
GB400A37-24	LIGHT	GRIMES	ATR	33-40-21	AEG Sevilla
G-8400A-37-24	AIRCRAFT NAVIGATIONAL ROTATING	GRIMES	A330, A340	33	AEG Sevilla
G-8895-1	LANDING LIGHT	GRIMES	A330, A340	33-06-01,33-6-1	AEG Sevilla
G-8895-4559	LANDING LIGHT	HONEYWELL	A330, A340	33-06-01	AEG Sevilla
GA43612	BARREL	MESSIER	A321,A320,A319,A318,A320-221	32-21-17	AEG Sevilla
GA43843-1	BODDY ASSY	KO654	A330	32-33-30	AEG Sevilla
GA4-473	FLANGE UPPER BUSHED	MESSIER-DOWTY	A330	32-23-12	AEG Sevilla
GA4-477	LINK LOWER BUSHED TORQUE	MESSIER-DOWTY	A330	32-23-12	AEG Sevilla
QB1520AA0	Check Valve			36-11-27	AEG Sevilla
QB1520AA1	Check Valve			36-11-27	AEG Sevilla
QC15461	Generator Control Unit			24-20-15	AEG Sevilla
QG431-2008-6	Pieram			21-52-01	AEG Sevilla
QG436-1008-6	Cross-Bleed Valve			36-12-06	AEG Sevilla
QG436-1008-7	Cross-Bleed Valve			36-12-06	AEG Sevilla
QG436-2003-1	Pack Inlet Flow Sensor			21-51-20	AEG Sevilla
QG436-2004-1	Pack Inlet Pressure Sensor			21-51-21	AEG Sevilla
QG436-2015-3	Temperature Sensor			21-52-25	AEG Sevilla
QG436-2029-1	Bulkhead Check Valve			21-21-17	AEG Sevilla
QG436-2033-1	Anti Icing Pressure Sensor			21-52-41	AEG Sevilla
QG436-4004-5	Wai Isolation Valve				AEG Sevilla
QG436-4004-7	Wai Isolation Valve				AEG Sevilla
QG670-80001-1	High Pressure Valve			36-12-10	AEG Sevilla
QG670-80001-3	High Pressure Valve			36-12-10	AEG Sevilla
QG670-80002-5	High Pressure Valve			36-11-91	AEG Sevilla
QG670-80002-7	High Pressure Valve			36-11-91	AEG Sevilla
QG670-80005-1	Temperature Sensor			36-12-11	AEG Sevilla
QG670-80005-3	Temperature Sensor			36-12-11	AEG Sevilla
QG670-80013-3	Temperature Sensor				AEG Sevilla
QG670-80013-5	Temperature Sensor				AEG Sevilla
QG670-80013-7	Temperature Sensor				AEG Sevilla
QG670-80013-9	Temperature Sensor				AEG Sevilla
QG670-95*****	Underfloor Low Pressure Ducting - LXT Series			21-51-64	AEG Sevilla
QG670-95003-3	Flow Control Valve			21-51-62	AEG Sevilla
QG670-95003-5	Flow Control Valve			21-51-62	AEG Sevilla
QG670-95019-1	Ram Air Valve			21-53-70	AEG Sevilla
QG670-95026-3	Air Conditioning System Controller			21-60-24	AEG Sevilla
QG670-95026-5	Air Conditioning System Controller			21-60-24	AEG Sevilla
QG670-95027-3	Avionics Cooling Fan			21-23-15	AEG Sevilla
QG670-95028-3	Lavatory And Galley Fan			21-23-16	AEG Sevilla
QG670-95033-5	Low Flow Sensor			21-23-19	AEG Sevilla
QG670-98003-3	Outflow Valve			21-31-28	AEG Sevilla
QG670-98003-5	Outflow Valve			21-31-28	AEG Sevilla
QG670-98005-1	Safety Valve			21-31-30	AEG Sevilla
QG670-98006-1	Pressure Equalization Valve			21-51-66	AEG Sevilla
QG690-95*****	Underfloor Low Pressure Ducting - LXT Series			21-51-64	AEG Sevilla
QG690-95026-1	Air Conditioning System Controller			21-60-24	AEG Sevilla
QG690-95026-3	Air Conditioning System Controller			21-60-24	AEG Sevilla
QG698-95026-1	Air Conditioning System Controller			21-51-60	AEG Sevilla

GG698-95048-1	Left Precooler Assembly				36-12-31	AEG Sevilla
GG698-95048-2	Right Precooler Assembly				36-12-32	AEG Sevilla
GG698-98001-1	Cabin Pressure Control Panel				21-31-70	AEG Sevilla
GG698-98005-1	Safety Valve				21-31-69	AEG Sevilla
H10-56	HEADSET CABIN INTERCOMM	DAVID CLARK		C-212, CN-235, C-295	23-50-00	AEG Sevilla
H3412-19	Handle Assy, Galley				52-41-03	AEG Sevilla
H3412-21	Handle Assy, Galley				52-41-03	AEG Sevilla
H3412-25	Handle Assy, Galley				52-41-03	AEG Sevilla
H3412-29	Handle Assy, Galley				52-41-03	AEG Sevilla
H3412-31	Handle Assy, Galley				52-41-03	AEG Sevilla
H3412-5	Handle Assy, Galley				52-41-03	AEG Sevilla
H3412-7	Handle Assy, Galley				52-41-03	AEG Sevilla
H3414-23	Flush Handle Latch Assembly				52-11-03	AEG Sevilla
H3414-25	Flush Handle Latch Assembly				52-11-03	AEG Sevilla
H3414-29	Flush Handle Latch Assembly				52-11-03	AEG Sevilla
H3414-33	Flush Handle Latch Assembly				52-11-03	AEG Sevilla
H3414-37	Flush Handle Latch Assembly				52-11-03	AEG Sevilla
H3414-9	Flush Handle Latch Assembly				52-11-03	AEG Sevilla
H3415-23	Flush Handle Latch Assembly				52-31-03	AEG Sevilla
H3415-31	Flush Handle Latch Assembly				52-31-03	AEG Sevilla
H3417-1	Handle Assy, Alt Comp				52-43-03	AEG Sevilla
H3417-5	Handle Assy, Alt Comp				52-43-03	AEG Sevilla
H3417-7	Handle Assy, Alt Comp				52-43-03	AEG Sevilla
H3419-27	Flush Handle Latch Assembly				52-22-03	AEG Sevilla
H3419-31	Flush Handle Latch Assembly				52-22-03	AEG Sevilla
H3419-33	Flush Handle Latch Assembly				52-22-03	AEG Sevilla
H3419-35	Flush Handle Latch Assembly				52-22-03	AEG Sevilla
H3419-37	Flush Handle Latch Assembly				52-22-03	AEG Sevilla
H3445-1	Flush Handle Latch Assembly				52-42-03	AEG Sevilla
H3445-3	Flush Handle Latch Assembly				52-42-03	AEG Sevilla
H3445-5	Flush Handle Latch Assembly				52-42-03	AEG Sevilla
H3939-1	Flush Handle Latch Assembly				52-11-07	AEG Sevilla
H3939-3	Flush Handle Latch Assembly				52-11-07	AEG Sevilla
H3939-5	Flush Handle Latch Assembly				52-11-07	AEG Sevilla
H3939-7	Flush Handle Latch Assembly				52-11-07	AEG Sevilla
HA653-1	Pressure Relief Latch Assembly				52-44-01	AEG Sevilla
HA653-3	Pressure Relief Latch Assembly				52-44-01	AEG Sevilla
HP133200	Brake Control Valve				32-41-02	AEG Sevilla
HTE978	2 IN Butterfly Valve				21-20-03	AEG Sevilla
ID6638/U	INDICATOR, BEARING			UNK		AEG Sevilla
ID9-464-40	INDICATOR, LIQUID QTY			UNK		AEG Sevilla
JP3924AA02	Jack Panel				23-51-76	AEG Sevilla
JP3935AA02	Jack Panel				23-51-77	AEG Sevilla
JP3935AA03	Jack Panel				23-51-78	AEG Sevilla
K97-63-607	Refuel/Defuel Adapter				28-25-05	AEG Sevilla
K97-63-617	Refuel/Defuel Adapter				28-25-05	AEG Sevilla
K98G3-202	Refuel Adapter Cap				28-24-22	AEG Sevilla
L83A13-634	Water Drain Valve					AEG Sevilla
L85-38-601	Check Valve				28-21-04	AEG Sevilla
L92B13-602	Transfer Shut-Off Valve Cartridge				28-13-43	AEG Sevilla
L92B13-605	Transfer Shut-Off Valve Cartridge				28-13-43	AEG Sevilla
L93E38-601	Shut-Off Valve Housing				28-25-07	AEG Sevilla
L94L38-651	Valve Module				28-25-06	AEG Sevilla
L94L38-653	Valve Module				28-25-06	AEG Sevilla
L96-26-601	Check Valve				28-22-04	AEG Sevilla
L97-63-601	Pressure Relief Valve					AEG Sevilla
L97-63-602	Pressure Relief Valve					AEG Sevilla
L97-63-605	Pressure Relief Valve					AEG Sevilla
L97-63-606	Pressure Relief Valve					AEG Sevilla
L98B623	Magnetic Level Indicator				28-41-15	AEG Sevilla
L98B624	Magnetic Level Indicator				28-41-15	AEG Sevilla
L98B625	Magnetic Level Indicator				28-41-15	AEG Sevilla
LH10B	Light DimmerPower Supply Unit				24-30-06	AEG Sevilla
LJ-15-0455	Remote Magnetic Compensator (Installation Manual)				LJ-15-0455	AEG Sevilla
LM320SA12	BRACKET SIDE			C-212, CN-235		AEG Sevilla
LM320-SA12	BRACKET-SIDE			UNK		AEG Sevilla
LM-320-SA12	FRONT SIDE MOUNTING ASSEMBLY			A330, A340	71	AEG Sevilla
LM320SA13	BRACKET-ENGINE FRONT TOP			CN-235		AEG Sevilla
LM-320-SA13	FRONT TOP MOUNTING ASSEMBLY			A330, A340		AEG Sevilla
LM320SA14	BRACKET-UPPER	LORD CORP AEROSPACE PRODUCTS		CN-235		AEG Sevilla
LM320SA18	MOUNTING-REAR			CN-235		AEG Sevilla
LM-320-SA18	FRONT LEFT AND RIGHT SIDE MOUNTING ASSEMBLY			A330, A340		AEG Sevilla
LM320SA19	MOUNTING-REAR			CN-235, C-295		AEG Sevilla
LM-320-SA19	MOUNTING-REAR			A330, A340		AEG Sevilla
LM-431	Engine Mounts				71-20-01	AEG Sevilla
LM-431F	Engine Mounts				71-20-18	AEG Sevilla
LT-100	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Sevilla
LT103	POWER SUPPLY	KGS ELECTRONICS		UNK		AEG Sevilla
LT-103	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Sevilla
LT100CCYY-2000	GuideU				33-51-07	AEG Sevilla
LT62A	CONVERTER	KGS ELECTRONICS		C-212, CN-235, C-295		AEG Sevilla
LT-52A	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00,24,33	AEG Sevilla
LT-53	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Sevilla
LT53A	CONVERTER			UNK		AEG Sevilla
LT-70	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Sevilla
LT-73	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Sevilla
M036M2-10	Starter Motor				49-40-00	AEG Sevilla
M464IP-2Aw#MotorM	Vaneaxial Fan				M464IP-2A	AEG Sevilla
M732591	AIR COOLING FAN	HAMILTON CLIMBTECH INC		A330, A340	21	AEG Sevilla
M732591 SERIES	AIR COOLING FAN	HAMI		A330, A340	21	AEG Sevilla
M732591DF	FAN ASSEMBLY-AIR COOLING	SUNDSTRAND		B747, B767,DASH8	21-58-02	AEG Sevilla
M762620C	VSCF	SUNDSTRAND		B777	24-25-20	AEG Bilbao
M766385A	Outboard Slat Actuator Assembly				27-81-18	AEG Sevilla
M768016A	Mid Slat Actuator Assembly				27-81-20	AEG Sevilla
MCP-016	Inspection Criteria For DH Seage Head Assembly				MCP-016	AEG Sevilla
MF20SERIES	Crew Oxygen Mask				SPM-20-10	AEG Sevilla
MM-011SASCO113Series	Blowers				MM-0113	AEG Sevilla
MODEL 5318	ALTERNATING CURRENT GENERATOR			A330, A340		AEG Bilbao
Model5690-1	Vertical Accelerometer				Model 5690-1	AEG Sevilla
Model811B	Clock				Model 811B	AEG Sevilla
Model811B-1	Clock, newer version of 811B				Model 811B-1	AEG Sevilla
Models1536-F-181A	High Temp. Ovens				Models 1536-F-1 & 1A	AEG Sevilla
MPEV3-011-8UJ2B	PUMP-HYDR.MOTOR DRV	EATON		C-295,CN-235,MD-11,0747,823,6, A330, A340	29,29-10-49	AEG Sevilla
MPEV3-011-8UJ2C	PUMP-HYDR.MOTOR DRV	EATON		C-295,CN-235	29	AEG Sevilla
MPEV3-012-2B	HYDRAULIC PUMP	EATON		Challenges:CRJ-700,CRJ Regional Jet-200,CRJ Regional Jet	29-10-45	AEG Sevilla
MR-10021NAA	Crewmember PBE				PRM-02	AEG Sevilla
MR-10022NAA	Crewmember PBE				PRM-02	AEG Sevilla
MS14218T4-12	REMACHE			UNK		AEG Sevilla
MS17401-1	ALTIMETER PRESSURE	MILITARY		UNK		AEG Sevilla
MS3452W145-75	CONNECTOR RECEPTACULO	MATRIX		UNK		AEG Sevilla
MT830	Maintenance Terminal User Manual for MT830 Software with 6200-0101 and 6200-0102				23-35-45	AEG Sevilla
N539-8071	DH-1030-115/3-1200-SS IID				24-20-07	AEG Sevilla
N539-8074	DH-1030-24-3-CS IID				24-20-08	AEG Sevilla
N539-8075	DH-1030-24-600-CS IIB				24-20-06	AEG Sevilla
N717-8017	GC-1010-24-5D III				24-30-02	AEG Sevilla
N719-8106	BP-1010-24-8D				24-30-X	AEG Sevilla
N719-8106	BP-1010-24-8E				24-31-03	AEG Sevilla
NAS6610D43	CARDAN BRACKET BOLT	STANDARD		A320-221	32-11-20	AEG Sevilla
NC6-P-1A	ROTOR			UNK		AEG Bilbao

NN-233C	D.C. SPDT Contactor					AEG Sevilla
NN449B	Relay				24-30-02	AEG Sevilla
NP19321	Cockpit Windshield				56-11-01	AEG Sevilla
NP19322	Cockpit Side Window				56-11-02	AEG Sevilla
NP-157901	Main windshield				56-10-01	AEG Sevilla
NP-157902-13	Left Hand Window, Right Hand Window				56-10-16	AEG Sevilla
NP-157902-14	Left Hand Window, Right Hand Window				56-10-16	AEG Sevilla
NP-184903	Cabin Windows				56-20-01	AEG Sevilla
NP-197601	Cabin Windows				56-20-01	AEG Sevilla
Obsolete	Obsolete				33-41-41	AEG Sevilla
PI1487	RELAY, ELECTROMAGNETIC	NONE		UNK		AEG Sevilla
P610365	Electric Fan				24-31-03	AEG Sevilla
P93A25-602	Bi-Crossflow Pump Cartridge				28-13-47	AEG Sevilla
P93C13-604	APU Fuel-Feed Pump				28-24-08	AEG Sevilla
P99C25-603	Fuel Booster Pump				28-20-77	AEG Sevilla
PBMS	PBMS Software User Manual				23-35-48	AEG Sevilla
PBMS	PBMS Software User Manual for Windows 10 <small>www.boeing.com/content/dam/boeing/boeing-737/737max/PBMS%20Software%20User%20Manual%20for%20Windows%2010.pdf</small>				23-35-49	AEG Sevilla
PL100LHX	GuideU				33-51-07	AEG Sevilla
PL130XLH00	GuideU				33-51-07	AEG Sevilla
PL1400LHX	GuideU				33-51-07	AEG Sevilla
PL1500LHX	GuideU				33-51-07	AEG Sevilla
PL1600LHX	GuideU				33-51-07	AEG Sevilla
PL1900LHX	GuideU				33-51-07	AEG Sevilla
PL1901LHX	GuideU				33-51-07	AEG Sevilla
PLTXXOYYLZZZ	GuideU				33-51-07	AEG Sevilla
PLTXXOYYWZZZ	GuideU				33-51-07	AEG Sevilla
PLTXXCYYYS	GuideU				33-51-07	AEG Sevilla
PL88-900LH88	GuideU				33-51-07	AEG Sevilla
PMP3V-3-05	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER		8757,B767	29-11-30	AEG Sevilla
PMP3V-3-06	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER		8757,B767	29-11-30	AEG Sevilla
PMP3V-3-07	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER		B747,B757,B767,B777	29-11-30	AEG Sevilla
PMP3V-3-08	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER		B747,B757,B767,B777	29-11-30	AEG Sevilla
PU90-42IR3	Smoke Detector					AEG Sevilla
PV3-044-48	HYDRAULIC PUMP	EATON		CRJ,CRJ200	29-10-44	AEG Sevilla
RB126	Bumper				24-20-XX	AEG Sevilla
RB56423	BRUSH			UNK		AEG Sevilla
RBC6	U.P.S. SALA FUSION			UNK		AEG Sevilla
RCS60-L	INDICATOR AIR SPEED	AEROSONIC				AEG Sevilla
RR53160	Centrif Fuel Boost Pump				28-21-00	AEG Sevilla
S231T260-1	INDICATOR PRESSURE OXYG			UNK		AEG Sevilla
S2741T20-10	ANTISKID	GE		8757, B767, B737	32-42-01	AEG Sevilla
S27W813-11	FUSE ASSEMBLY, FLOW RATE	TRUMPT ACTUATION SYSTEM - YAGATA		B-777		AEG Sevilla
S28IA001-101	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE		B737NG/Boeing 737 MAX	24-11-85.	AEG Bilbao
S28IA001-103	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE		B737NG/Boeing 737 MAX	24-11-85.	AEG Bilbao
S28IW001-20	INTEGRATED DRIVE GENERATOR	COLLINS AEROSPACE		B777	24-21-11	AEG Bilbao
S28IW401-1	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-10	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-11	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-12	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-14	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-15	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-16	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-17	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-20	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-21	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-22	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-23	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-4	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-5	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-6	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-7	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-8	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S28IW401-9	VSCF GENERATOR	COLLINS AEROSPACE		B777	24-25-20	AEG Bilbao
S282T003-3	BATTERY CHARGER	CRANE / ELDEC		747-400	24-31-04	AEG Sevilla
S283A313-103	NAVIGATION LIGHT	BOEING		B737-300,B737-600,B777,B737	33-42-06	AEG Sevilla
S283A325-1	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S283A325-10	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S283A325-2	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S283A325-3	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S283A325-4	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S283A325-5	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S283A325-6	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S283A325-7	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S283A325-8	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S283A325-9	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B737	33-51-04	AEG Sevilla
S369-100	ACCUMULATORS	TELEDYNE		A330, A340	75-23-100	AEG Sevilla
S369-50	ACCUMULATORS	TELEDYNE		A330, A340	75-23-50	AEG Sevilla
S400V3	Flight Attendant Panel				25	AEG Sevilla
S417A501-609	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
S417A501-610	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
S417A501-611	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
S417A501-612	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
S417A501-613	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
S417A501-614	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
S417A501-615	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
S417A501-616	CEILING LIGHT ASSEMBLY	B/E AEROSPACE		B737	33	AEG Sevilla
S417T102-1	WASTE SYSTEM VACUUM BLOWER	THE BOEING		BOEING 777-200	38-32-02	AEG Sevilla
S4-3300955	ACTUATOR	LIEBHERR		A340,A330	32-31-19	AEG Sevilla
S4-3300955 AMDT. A	NOSE LANDING GEAR DOOR ACTUATOR			A-330, A-340		AEG Sevilla
S4-3300955 AMDT. AE	NOSE LANDING GEAR DOOR ACTUATOR			A-330, A-340		AEG Sevilla
S4-3300955 AMDT. B	NOSE LANDING GEAR DOOR ACTUATOR			A-330, A-340		AEG Sevilla
S462-25	ACCUMULATORS	SPRAGUE		A330, A340	9H1-2-14-	AEG Sevilla
S462-50	ACCUMULATORS	SPRAGUE		A330, A340	9H1-2-14-	AEG Sevilla
S463-100	ACCUMULATORS	TELEDYNE		A330, A340	75-23-100	AEG Sevilla
S463-50	ACCUMULATORS	TELEDYNE		A330, A340	75-23-50	AEG Sevilla
S477-100	ACCUMULATORS	TELEDYNE		A330, A340	75-23-100	AEG Sevilla
S477-200	ACCUMULATORS	TELEDYNE		A330, A340	75-23-200	AEG Sevilla
S477-50	ACCUMULATORS	TELEDYNE		A330, A340	75-23-50	AEG Sevilla
S512-25	ACCUMULATORS	TELEDYNE		A330, A340	75-23-25	AEG Sevilla
S513-100	ACCUMULATORS	MIL		A330, A340	9H1-2-14-	AEG Sevilla
S513-200	ACCUMULATORS	SPRAGUE		A330, A340	9H1-2-14-	AEG Sevilla
S513-50	ACCUMULATORS	MIL		A330, A340	9H1-2-14-	AEG Sevilla
S618-A	ACCUMULATORS	SPRAGUE		AERONAUTICAL SYSTEMS		AEG Sevilla
SAS261-019	FLUID PRESS REG VALVE			UNK		AEG Sevilla
SCD130	Passenger Address and Cabin Interphone				23-30-02	AEG Sevilla
SD1582	ROTOR BALANCE ASSEMBLY	HAMILTON KIMBLESTAND		B777	24-26-10	AEG Bilbao
SEL-OC2S	Torque Indicator				77-10-31	AEG Sevilla
SEL-OC19EK	Interurbine Temperature Indicator				77-20-24	AEG Bilbao
SEL-OC29DA	NH% RPM Indicator				77-12-01	AEG Bilbao
SEL-OC29DF	NH% RPM Indicator				77-12-01	AEG Bilbao
SEL-OC29DJ	NL% RPM Indicator				77-12-04	AEG Bilbao
SEL-OC29DK	NL% RPM Indicator				77-12-04	AEG Bilbao
Series2	Left AC Contactor Box Galley Opt 2				24-23-03	AEG Sevilla
Series2	Left AC Contactor Box (No Galley Option)				24-24-06	AEG Sevilla
Series2	Right AC Contactor Box (No Galley Option)				24-24-07	AEG Sevilla
Series3	Left AC Contactor Box Galley Opt 2				24-23-03	AEG Sevilla
Series3	Left AC Contactor Box (No Galley Option)				24-24-06	AEG Sevilla
Series3	Right AC Contactor Box (No Galley Option)				24-24-07	AEG Sevilla
Series4	Left AC Contactor Box Galley Opt 2				24-23-03	AEG Sevilla

Series4	Left AC Contactor Box (No Galley Option)			24-24-06	AEG Sevilla
Series4	Right AC Contactor Box (No Galley Option)			24-24-07	AEG Sevilla
SETL-OC420F	Cabin Pressure Indicator			21-30-03	AEG Sevilla
SETL-OC420G	CABIN PRESSURIZATION INDICATOR	AMETEK	CN-235, 757	21	AEG Sevilla
SETL-OC420Y	CABIN PRESSURIZATION INDICATOR	AMETEK	UNK	21	AEG Sevilla
SH670-50550	Spring Loaded Sensor Assembly			52-70-10	AEG Sevilla
SL40933	WASHER-LOCK	SAFRAN	A330		AEG Sevilla
SOP6-01-05	Permaswage Tube Connection System			SOP6-01-05	AEG Sevilla
SOP604-008	Permalite Tube Connection System Installation			SOP604-008	AEG Sevilla
SOP604-030	Permaswage DIT Tool Maintenance Procedures and Standard Practices			SOP604-030	AEG Sevilla
SP					AEG Sevilla
SPC-10V	Static Inverter			24-20-43	AEG Sevilla
SRDL-OC12F	Dual Hydraulic Quantity Ind			29-30-19	AEG Sevilla
ST-10AAB	TRANSMITTER DUCT PRESSURE	AMETEK	B727, A300, B737, B747	36,31-02-02,31	AEG Sevilla
ST-107R	HYDRAULIC PRESSURE TRANSMITTER	AMETEK	B737, B727,B767, B777	31,29,29-30-04,31	AEG Sevilla
ST-109C	SYNCHRONOUS TRANSMITTER	AMETEK	C-130,MD80,DC-8,DC-9	21,40,31,1,40	AEG Sevilla
STM3758V08-4 / 7	RESMACHE/PASADOR		UNK	31-1-59	AEG Sevilla
SY1520A00	Low Pressure Ground Connection			21-20-34	AEG Sevilla
SY1520A00	Low Pressure Ground Connection			21-20-34	AEG Sevilla
SY1520C00	Low Pressure Ground Connection			21-20-02	AEG Sevilla
SYL250970	Windshield Temperature Controller			F-19,495	AEG Sevilla
T99A38-602	Fwd Scavenge Ejector			28-13-21	AEG Sevilla
T99B38-601	Transfer Ejector			28-13-01	AEG Sevilla
TRU3502	Transformer Rectifier Unit			24-31-01	AEG Sevilla
TY741	Pitch Feel Unit			27-30-02	AEG Sevilla
TY910	Pitch Feel Simulator			27-30-03	AEG Sevilla
TY910-50A	Pitch Feel Simulator			27-30-03	AEG Sevilla
TY910-51A	Pitch Feel Simulator			27-30-03	AEG Sevilla
TY2148-10A	Isolating Control Valve			78-32-09	AEG Sevilla
TY2148-11A	Isolating Control Valve			78-32-09	AEG Sevilla
TY2149-15A	Directional Control Valve			78-32-01	AEG Sevilla
TY2149-20A	Directional Control Valve			78-32-01	AEG Sevilla
TY2150-15A	Lock Control Valve			78-32-15	AEG Sevilla
TY2151-15A	Locking Actuator			78-32-03	AEG Sevilla
TY2151-16A	Locking Actuator			78-32-03	AEG Sevilla
TY2152-15A	Feedback Actuator			78-32-05	AEG Sevilla
TY2152-16A	Feedback Actuator			78-32-05	AEG Sevilla
TY2152A60	Feedback Actuator			78-32-05	AEG Sevilla
TY2152B60	Feedback Actuator			78-32-05	AEG Sevilla
TY2153-01A	Manual Drive			78-32-11	AEG Sevilla
TY2231-01A	Slow Switch			78-31-01	AEG Sevilla
TY2232-01A	Control Microswitch			78-31-03	AEG Sevilla
TY2614	Pitch Feel Unit			27-30-07	AEG Sevilla
TYE200-CV	AUTOTRANSFORMADOR VARIABLE		A330, A340		AEG Bilbao
VI-4360-2	HYD VALVE FUSE		B767	32-32-01	AEG Sevilla
V09A15-001	Motive Flow Venturi			28-22-07	AEG Sevilla
VA4110	EXTRACTION FAN	AOA	A330, A330F, A340, AST	21-21-18	AEG Sevilla
VD3810	MIXED FLOW FAN	AOA	A300-600, A310, A318, A319, A320, A321, A320, A320, A316, A316, A319, A320, A310, A310, A310C	21-21-12	AEG Sevilla
VD3820-01	MIXED FLOW FAN	AOA	A300, A300, A316, A316, A319, A320, A310, A310, A310C	21-21-11	AEG Sevilla
VP0615A00	Shut-Off Valve			21-24-03	AEG Sevilla
VP0615B00	Shut-Off Valve			21-24-03	AEG Sevilla
VP0615E00	Shut-Off Valve			21-24-03	AEG Sevilla
VP0615F00	Shut-Off Valve			21-24-03	AEG Sevilla
VP1240BA0	Dual Position Valve			21-21-10	AEG Sevilla
VP1240C00	Dual Position Valve			21-21-10	AEG Sevilla
VP1240D00	Inboard Valve			21-24-04	AEG Sevilla
VP1240E00	Dual Position Valve			21-21-10	AEG Sevilla
VR3910	EXTRACTION FAN	AOA	A320 NEO	21	AEG Sevilla
WE3888446-1	Igniter Accessory			49-41-24	AEG Sevilla
WE3888446-1	Igniter Accessory			X	AEG Sevilla
WE3888474-1	Harness Assembly			49-15-01	AEG Sevilla
WHEEL RIMS	WHEEL RIMS, SHOCK ABSORBERS, MOTOR		A330, A340		AEG Sevilla
WK3805059-1	Gearbox			49-27-40	AEG Sevilla
WL 102AM51	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Sevilla
WL 102AM52	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Sevilla
WL 102AM53	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Sevilla
WL 102AM54	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Sevilla
WL 102AM55	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Sevilla
WL 102AM56	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Sevilla
Z212H000010	CONTROL UNIT	AIRBUS	A321A319,A318,A320	30-70-01	AEG Sevilla
Z212H000110	CONTROL UNIT	AIRBUS	A321A319,A318,A320,A320-221A,320-232	30-70-01	AEG Sevilla
Z212H000210	CONTROL UNIT	AIRBUS	A321A319,A318,A320	30-70-01	AEG Sevilla
Z212H000310	CONTROL UNIT	AIRBUS	A321A319,A318,A320	30-70-01	AEG Sevilla
Z212H000410	CONTROL UNIT	AIRBUS	A321A319,A318,A320	30-70-01,25	AEG Sevilla
Z212H000510	CONTROL UNIT	KID SYSTEME	A321A319,A318,A320	30-70-01	AEG Sevilla
Z212H000710	CONTROL UNIT	AIRBUS	A320,A319	30-70-	AEG Sevilla
Z212H000910	CONTROL UNIT	AIRBUS	A321A319,A318,A320	30-70-01	AEG Sevilla
Z212H010110	CONTROL UNIT	AIRBUS	A321A319,A318,A320	30-70-01	AEG Sevilla
Z220H000010	CONTROL UNIT DRAINMAST	AIRBUS	A321A319,A320,B737	30-71-04	AEG Sevilla
Z220H000110	CONTROL UNIT DRAINMAST	AIRBUS	A321A319,A320,B737	30-71-04	AEG Sevilla
Z220H000210	CONTROL UNIT DRAINMAST	AIRBUS	A319,A310,A320,B737,A320-221,A320-232,A320,300	30-71-04	AEG Sevilla