



EASA PART 145 NO ES.145.046
FAA NO E4UY980J
TCCA NO 816-04

aegfq@aegeurope.net
T +34 946363711

PN	Description	Manufacturer	Aircraft Types	ATA	AEG Spain Shop
102	Pitch Feel Trim Assembly			27-32-01	AEG Sevilla
244	Fire Detection Cable				AEG Sevilla
244	Fire Detection Cable				AEG Sevilla
294	Fire Detection Cable				AEG Sevilla
394	Crew Seats				AEG Sevilla
644	Fire Detection Cable				AEG Sevilla
744	Fire Detection Cable				AEG Sevilla
760	Airman Headset			23-50-06	AEG Sevilla
760	Airman Headset			23-50-06	AEG Sevilla
1272	INDICATOR, HEIGHT	SIERRA NETWORKS	UNK		AEG Sevilla
1462	BALLAST UNIT	GE	UNK	72-09-03	AEG Sevilla
1827	D.C. Power Supply, Dimmable			33-10-03	AEG Sevilla
1849	Hydraulic Relief Valve				AEG Sevilla
2107	Attendant Seats				AEG Sevilla
2113	CASING / STATOR ASSY	ELGIN	Dash 8,DHC8	31	AEG Sevilla
2489	Flight Station Door Lock Assembly			52-50-13	AEG Sevilla
2630	Temperature Switch and Associated valves				AEG Sevilla
2634	Hydraulic Bleed / Relief Valve			29-13-33	AEG Sevilla
2640	Valve, Pressure Relief				AEG Sevilla
2768	AIRCRAFT BATTERY	SAFT BATTERIES	A310,A300,A321A319,A320,A320-221A320-232A320-200	24-38-SI	AEG Sevilla
4131	Valve, Solenoid, 3- Way, 2-Position, Normally Closed			32-41-15	AEG Sevilla
4307	Lock Assembly			52-50-19	AEG Sevilla
4323	Lock Assembly			52-50-12	AEG Sevilla
4638	HYDRAULIC, PRIORITY RELIEF CARTRIDGE VALVE	PNEUDRAU	8737-800,MD-8737-500,8737-500,8737-300,8737-900,8737-800,8737-700,8737-600,8737-500,8737-400,8737-300,8737-200,8737-100,8737-00	32-30-02	AEG Sevilla
4620	Executive Aircraft Toilets			MM4460	AEG Sevilla
4622	Free Reverse Flow, Balanced Outlet, Relief Valve			32-30-04	AEG Sevilla
4760	BALLAST	AVTECH	UNK	22	AEG Sevilla
6069	VALVES,HYDRAULIC SHUTTLE	PNEUDRAULICS	8737-200,8737-500,8737-400,8737-300,8737-900,8737-800,8737-700,8737-600,MD-80-83,8737	32	AEG Sevilla
6060	Audio Integrating System			23-50-07	AEG Sevilla
6061	Audio Integrating System			23-50-07	AEG Sevilla
6062	Audio Integrating System			23-50-07	AEG Sevilla
6063	Audio Integrating System			23-50-07	AEG Sevilla
6064	Audio Integrating System			23-50-07	AEG Sevilla
6079	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
6082	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
6083	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
6088	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
6089	Passenger Address and Cabin Interphone System			23-30-02	AEG Sevilla
6116	BALLAST	AVTECH	UNK	33-21-17,33	AEG Sevilla
6116	BALLAST	THORIGHT ACCESSORY SERVICES	UNK	5115	AEG Sevilla
6283	Interphone Handset			23-30-05	AEG Sevilla
6287	Attendant No. 2 Control Unit			23-30-12	AEG Sevilla
6289	Attendant No. 1 Control Unit			23-30-13	AEG Sevilla
6383	Interphone Handset/Cradle			23-30-10	AEG Sevilla
6774	Floor Mounted Electroluminescent Eel System			33-50-01	AEG Sevilla
6880	Floor Mounted Electroluminescent Eel System			33-50-01	AEG Sevilla
6262	FUSE, HYDRAULIC QUANTITY MEASU	PNEUDRAU	8737-600,8737-100,8737-500,8737-400,8737-300,8737-A310,A300,8737	36-27-05	AEG Sevilla
6262	Hydraulic Quantity Measuring Fuse With Bypass - CMM			32-40-03	AEG Sevilla
6267	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	8737-600,8737-500,8737-400,8737-300,A310,A300,8737	36-27-05	AEG Sevilla
6271	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	8737-500,8737-400,8737-300,DC-10,8737,8737	36-27-07	AEG Sevilla
6362	Hydraulic Fuse, Volumetric, With Bypass			32-41-05	AEG Sevilla
6504	Fire and Overheat Detection System Control Module				AEG Sevilla
7301	Temperature Switch and Associated valves				AEG Sevilla
8200	Noise Landing Gear Drag Strut Assembly			32-20-02	AEG Sevilla
8300	Noise Landing Gear Retraction Actuator Assembly			32-30-05	AEG Sevilla
8400	NLG Drag Strut Actuator			32-30-06	AEG Sevilla
8402	STEAM OVEN	HEYCO PRODUCTS	A319-A320-A330		AEG Bilbao
8414	Linear Actuator			49-14-16	AEG Sevilla
8464	HSTA			27-42-02	AEG Sevilla
8800	Noise Landing Gear Shock Strut Assembly			32-20-01	AEG Sevilla
8960	Centering Mechanism			32-50-07	AEG Sevilla
9649	Electronic Faucet Assembly, Relay Timed			38-20-16	AEG Sevilla
9681	Lavatory Potable Water System			38-12-14	AEG Sevilla
10013	Fuel Quantity Primary Indicator			28-41-56	AEG Sevilla
10014	Fuel Quantity Repeater Indicator			28-41-55	AEG Sevilla
10048	Fuel Quantity Primary Indicator			28-41-56	AEG Sevilla
10049	Fuel Quantity Repeater Indicator			28-41-55	AEG Sevilla
10091	Fuel Quantity Primary Indicator			28-41-56	AEG Sevilla
10092	Fuel Quantity Repeater Indicator			28-41-55	AEG Sevilla
10100	Shock Strut			32-10-01	AEG Sevilla
10100	Main Landing Gear Shock Strut Assembly			32-10-06	AEG Sevilla
10116	Fuel Quantity Primary Indicator			28-41-56	AEG Sevilla
10116	Fuel Quantity Repeater Indicator			28-41-55	AEG Sevilla
10190	Main Landing Gear Shock Strut Assembly			32-10-07	AEG Sevilla
10200	Main Landing Gear Drag Strut Assembly			32-10-02	AEG Sevilla
10200	Main Landing Gear Drag Strut Assembly			32-10-08	AEG Sevilla
10200	Main Landing Gear Drag Strut Assembly			32-10-12	AEG Sevilla
10300	Main Landing Gear Yoke Assembly			32-10-03	AEG Sevilla
10300	Main Landing Gear Yoke Assembly			32-10-09	AEG Sevilla
10300	Main Landing Gear Yoke Assembly			32-10-14	AEG Sevilla
10400	Main Landing Gear Stabilizer Stay Assembly			32-10-04	AEG Sevilla
10400	Main Landing Gear Stabilizer Stay Assembly			32-10-13	AEG Sevilla
10600	MLG Auxiliary Actuator			32-30-02	AEG Sevilla
10700	MLG Stabilizer Actuator			32-30-03	AEG Sevilla
11000	Rudder Damper Assembly			27-20-01	AEG Sevilla
12000	Rudder Actuator			27-20-01	AEG Sevilla
13300	Main Landing Gear Uplock Assembly			32-30-21	AEG Sevilla
12300	Executive Aircraft Toilets			MM4460	AEG Sevilla
14100	Shock Strut			32-10-01	AEG Sevilla
14200	Shock Strut			32-10-01	AEG Sevilla
14475	Crew				AEG Sevilla

16838	Water Level And Monitoring System			38-18-03	AEG Seville
17279	MLG Uplock And Actuator Assembly			32-30-16	AEG Seville
20022	Fuel Quantity Units			28-40-51	AEG Seville
20067	Fuel Quantity Units			28-40-51	AEG Seville
20068	Fuel Quantity Units			28-40-51	AEG Seville
22082	STATOR	LUCAS	UNK	25	AEG Seville
22216	STATOR	LUCAS	FALCON	25	AEG Seville
23066	DC STARTER GENERATOR	GOODRICH	Gulfstream,Falcon	72, 80	AEG Seville
23079	DC STARTER GENERATOR	GOODRICH	King,1900,441,Jetstream 31	72, 80	AEG Seville
29146	ANTENNE DESMONTABLE		UNK		AEG Seville
30146	Proximity Sensor Electronics Unit			32-60-01	AEG Seville
30210	ACCUMULATOR HYDRAULIC	TRIUMPH ACTUATION	B737	32-40-01	AEG Seville
30220	ACCUMULATOR HYDRAULIC	TELEDYNE	F-15,C-130,B-737-800,B-737-400,B-737-300,B-737-200,B-737-100,B-737-700	32-40-02	AEG Seville
37078	AC Generator			24-20-53	AEG Seville
33862	MODULAR TX / RX		UNK		AEG Seville
34265	COCKPIT LIGHT	HONEYWELL	A350,A318,A320,A300-600,B777,B737-400,A321XLR,A320XLR	33-10-23	AEG Seville
40130	Restow Pump			24-23-22	AEG Seville
40143	PUMP & MOTOR PACKAGE ASSEMBLY	HAYDON SWITCH	C-212	M.S.27	AEG Seville
40180	ELECTRIC HYD PUMP	PARKER	A300, A310	29-23-20	AEG Seville
42011	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	50,A320,F50	29-10-04	AEG Seville
42334	Motor Driven Hydraulic Pump			29-20-38	AEG Seville
44787	Variable Frequency AC Motor			29-13-03	AEG Seville
48348	STARTER MOTOR	ALLIED SIGNAL	A330, A340	2-200	AEG Seville
48378	ENGINE STARTER MOTOR	AIRESEARCH	UNK	49-41-04	AEG Seville
60309	Bus Bar Protect Unit			24-30-18	AEG Seville
60608	Current Transformer				AEG Seville
61149	Hydraulic Power Transfer Unit			29-22-03	AEG Seville
61644	VARIABLE DELIVERY HYDRAULIC PUMP ASSEMBLY	PARKER	CF34-10E,CF34-8E	29-12-10	AEG Seville
61666	PUMP MOTOR PACKAGE	PARKER	ERJ 170/190	29-12-11	AEG Seville
61839	DC Generator Control Unit			24-30-29	AEG Seville
61608	AC Generator Control Unit			24-20-51	AEG Seville
63013	Pilot Hand Control			32-51-05	AEG Seville
63108	Hydraulic Pump		A220		AEG Seville
63200	Valve, Power Brake			32-40-01	AEG Seville
66980	SERVED ALTITUDE INDICATOR	GE	B-737		AEG Seville
66980	INDICATOR	SMITHS	MD-80,DC-9,DC-8,B707	34-12-04,34-34-10,34-	AEG Seville
67186	PUMP MOTOR PACKAGE	PARKER HANNIFIN	C-130,B-737-400,B-737-300,B-737-200,B-737-100,B-737-700,B-737-800,B-737-900,B-737-300,B-737-200,B-737-100,B-737-700,B-737-800,B-737-900	29-20-15	AEG Seville
67346	ALTIMETER	SMITHS	B727,B747-200,B737-200	34-12-12,34	AEG Seville
67377	SERVED ALTITUDE INDICATOR	SMITHS	B737	34	AEG Seville
67377	SERVED ALTITUDE INDICATOR	SMITHS	B747-200,B737,B737-200	34-12-12,34	AEG Seville
67435	Pressure Differential Indicator			24-16-04	AEG Seville
68570	Valve			32-44-11	AEG Seville
69111	FLAP POSITION INDICATOR	SMITH INDUSTRIES	B727,B737	27-50-03	AEG Seville
69141	FLAP POSITION INDICATOR	SMITH INDUSTRIES	B727,B737	27-50-03	AEG Seville
67180	Solenoid Operated (MLG) Hydraulic Valve			32-30-02	AEG Seville
61800	DEBOOST VALVE ASSEMBLIES	BERTEA	MD80	32-40-02	AEG Seville
62380	Nose Gear Bay Door			32-30-56	AEG Seville
66005	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER AEROSPACE	Bell	29-10-30	AEG Seville
66007	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER AEROSPACE	A330, A340	29-10-31	AEG Seville
66087	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	B737-300/400/500, B737-800/900,B727	29-20-16	AEG Seville
66173	Variable Delivery Hydraulic Pump				AEG Seville
66182	Electrical Motor Driven Hydraulic Pump			29-20-40	AEG Seville
66490	Second Stage Flap Dump			27-14-26	AEG Seville
67054	SERVED MACH AIRSPEED IND	GE AVIATION-SMITHS	B737	34-12-02	AEG Seville
67086	SERVED MACH AIRSPEED IND	SMITHS AEROSPACE	737	34-12-02	AEG Seville
67116	SERVED MACH AIRSPEED IND	SMITHS AEROSPACE	737	34-12-02	AEG Seville
69210	Hydraulic Sequence Mechanical Valve			32-10-41	AEG Seville
69220	Hydraulic Mechanically Operated L.G. Bypass Valve			32-30-46	AEG Seville
69730	Valve			27-60-20	AEG Seville
71234	PUMP HYDRAULIC HAND	CRANE AEROSPACE & ELECTRONICS	Aircraft: Boeing 727/Boeing 737 Classic	29-20-65	AEG Seville
71404	DUAL BRAKE METERING VALVE	EATON	C-130,B-737-400,B-737-300,B-737-200,B-737-100,B-737-700,B-737-800,B-737-900	71-21-02	AEG Seville
83427	COFFELAVATORY PUMP	MICRO PUMP	CRJ440,CRJ Regional Jet-200,A300	38,38-83-27,7364	AEG Seville
83427	Pump, Water, Warm Water Wash System			38-11-00	AEG Seville
87006	STATOR	PACIFIC SCIENTIFIC	737		AEG Bilbao
88304	GCU/Pacific Scientific			24-26-05	AEG Seville
99167	GCU/Pacific Scientific			24-26-05	AEG Seville
100162	Ni-Cd Aircraft Battery 4080	AVIONIC INSTRUMENTS	AT-802	24	AEG Seville
100344	Ni-Cd Aircraft Battery 8050	SIMMONDS		28-41-77	AEG Seville
100463	Ni-Cd Aircraft Battery 40182	SAFT		25-60-33	AEG Seville
100504	Ni-Cd Aircraft Battery 1277	HONEYWELL AEROSPACE		27-60-03,27-60-04	AEG Seville
100866	Battery Power Supply			33-21-70	AEG Seville
102390	Ni-Cd Aircraft Battery 4071	GENERAL DYNAMICS		33-11-14	AEG Seville
102446	Ni-Cd Aircraft Battery 4076	GENERAL DYNAMICS		33-11-14	AEG Seville
103261	Ni-Cd Aircraft Battery 2500	HONEYWELL		76	AEG Seville
106428	Ni-Cd Aircraft Battery 2376				AEG Seville
12972	Ni-Cd Aircraft Battery 2375	BOEING		57-53-06	AEG Seville
114099	Ni-Cd Aircraft Battery 4000A1	GE AVIATION		32-31-35	AEG Seville
114628	Ni-Cd Aircraft Battery 40183	SAFT		24	AEG Seville
114760	Ni-Cd Aircraft Battery 4050A1-1	SAFT		24	AEG Seville
114765	Ni-Cd Aircraft Battery 2376-1	SAFT		24	AEG Seville
114769	Ni-Cd Aircraft Battery 1656-1	BOEING		57-43-02	AEG Seville
115944	Ni-Cd Aircraft Battery 1277-1	SAFT		24	AEG Seville
115967	Ni-Cd Aircraft Battery 4076-1	BOEING	A320	57-15-01	AEG Seville
116104	Ni-Cd Aircraft Battery 4000A1-1	SAFT			AEG Seville
116105	Ni-Cd Aircraft Battery 4000A1-1	SAFT		24	AEG Seville
116110	Ni-Cd Aircraft Battery 25106	SAFT		24	AEG Seville
116129	Ni-Cd Aircraft Battery 25106-1	GRIMES		33-21-42	AEG Seville
117926	Ni-Cd Aircraft Battery 4076-3	ZODIAC		33	AEG Seville
119708	Ni-Cd Aircraft Battery 25106-2	PESCO			AEG Seville
124856	FUEL CONTROL UNIT		UNK		AEG Seville
124853	DC VOLTMETER	DAVID CLARK	707, 727, 737	23	AEG Seville
128182	PRESSURE SENSOR	NABTESCO AEROSPACE	UNK	32	AEG Seville
160229	Ni-Cd Aircraft Battery 4076-2	SAFT	A320	49-20-00-	AEG Seville
160371	Auxiliary Power Unit			49-20-00-	AEG Bilbao
160371	Auxiliary Power Unit			49-20-00-	AEG Bilbao
160786	Ni-Cd Aircraft Battery 23476	SAFT		24	AEG Seville
161185	Ni-Cd Aircraft Battery 1606	SAFT		28-20-02	AEG Seville
162041	Ni-Cd Aircraft Battery 4006A	SAFT		24	AEG Seville
162707	Ni-Cd Aircraft Battery 4006A-1	SAFT		24	AEG Seville
162708	Ni-Cd Aircraft Battery 4006A-1	SAFT		24	AEG Seville
162899	Ni-Cd Aircraft Battery 2371-2	SAFT	A320	24	AEG Seville
164747	Ni-Cd Aircraft Battery 1656-2	SAFT		24	AEG Seville
166603	Ni-Cd Aircraft Battery 2376-2	SAFT	A320	24	AEG Seville
166130	Ni-Cd Aircraft Battery 2778	SAFT		24	AEG Seville
166131	Ni-Cd Aircraft Battery 4079	SAFT		24	AEG Seville
166185	Ni-Cd Aircraft Battery 40208	SAFT		24	AEG Seville
166186	Ni-Cd Aircraft Battery A40209	SAFT		24	AEG Seville
166409	Ni-Cd Aircraft Battery 40208-1	SAFT	A320	24	AEG Seville
166731	Ni-Cd Aircraft Battery 4071-2	SAFT	A320	24	AEG Seville
166768	Ni-Cd Aircraft Battery 40100-1	SAFT		24	AEG Seville
166861	Ni-Cd Aircraft Battery 2378	SAFT		24	AEG Seville
166906	Ni-Cd Aircraft Battery 40306	SAFT		24	AEG Seville
167300	Auxiliary Power Unit System			Bullefin40C7BSYS	AEG Seville
167467	Engine Control Harness Assembly			49-10-24	AEG Bilbao
167468	Ni-Cd Aircraft Battery 40206-2	SAFT	A320	24	AEG Seville
167856	Ni-Cd Aircraft Battery 4076-9	SAFT	A320	24-30-22	AEG Seville
167898	Ni-Cd Aircraft Battery 1666-1	SAFT		24	AEG Seville
171800	Heated Side Panel, Unheated Side Panel			56-10-04	AEG Seville
171900	Heated Side Panel, Unheated Side Panel			56-10-04	AEG Seville

186489	MOTOR HYDRAULIC		UNK		AEG Seville
218513	STATOR, ASSEMBLY	INTERTECHNIQUE	UNK		AEG Bilbao
228078	Canister			28-20-79	AEG Seville
229432	SUMERGED FUEL BOOSTER PUMP	INOI	F100,F70,F28	28,28-06-50	AEG Seville
233400	Rudder Actuator Assembly			27-20-36	AEG Seville
237400	Rudder Pressure-Off Damper			27-20-41	AEG Seville
237900	Rudder Dual-Pressure Regulator			27-20-56	AEG Seville
240300	Flight Spoiler Lift Dump Signal Solenoid Valve Assembly			27-14-21	AEG Seville
273104	Cable Tension Regulator			27-31-04	AEG Seville
273302	Centering Spring Cartridge			27-33-02	AEG Seville
341983	NOSE LANDING GEAR UNLOCK ASSEMBLY	LOCKHEED	C-130	16L1-3-10	AEG Seville
360900	SWITCH		UNK		AEG Seville
371380	VARIABLE DISPLACEMENT HYDRAULIC PUMP	VICKERS AEROSPACE	B/37-F/000,C-130,M/D80,DC-8,B/37-200,09E	29-10-18	AEG Seville
371688	FUEL CONTROL UNIT	HONEYWELL INTERNATIONAL	UNK		AEG Seville
381785	ROTOR	EATON AEROSPACE	727, 737	29-10-49	AEG Bilbao
390600	Rudder Power Control Unit (PCU) Assembly			27-21-04	AEG Seville
390600	Elevator Power Control Unit (PCU) Assembly			27-31-02	AEG Seville
390700	Power Control Unit(PCU) Spoiler Actuator Assembly			27-60-04	AEG Seville
390780	Spoiler Toggle Link Assembly			27-60-05	AEG Seville
394324	FLOW DIVIDER AND DRAIN		UNK		AEG Seville
394390	FLOW DIVIDER AND DRAIN		UNK		AEG Seville
398800	Spoiler Lift Dump Signal Solenoid Valve Assembly			27-66-03	AEG Seville
398900	Elevator Power Control Unit(PCU) Compensator Assembly			27-32-04	AEG Seville
394000	Spoiler Unload Valve Assembly			27-66-04	AEG Seville
394342	ELECTRIC MOTOR ASSEMBLY	EATON / 62983	A300, DC-10, MD-80	29-21-08	AEG Seville
394800	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	707, E3, E8, E6	75	AEG Seville
398600	Flight Control System Electronic Control Unit			27-00-01	AEG Seville
399200	Pitch Feel Trim Assembly			27-32-01	AEG Seville
399300	Pitch Feel, Electromechanical Linear actuator			27-32-02	AEG Seville
399600	Rudder Feel Trim Unit Assembly			27-22-01	AEG Seville
399600	Rudder Trim, Electromechanical Linear Actuator			27-22-02	AEG Seville
399700	Aileron Trim Centering Assembly				AEG Seville
399800	Aileron Trim, Electromechanical Linear Actuator				AEG Seville
406300	Steering Control Unit			32-50-03	AEG Seville
406300	Pilot Hand Control Assembly			32-50-04	AEG Seville
410022	Ni-Cd Aircraft Battery 23378	TEAM		24	AEG Seville
410076	Ni-Cd Aircraft Battery 1608-1	SAFT		24	AEG Seville
410089	Ni-Cd Aircraft Battery 40208-2	SAFT	A320	24	AEG Seville
410090	Ni-Cd Aircraft Battery 4078-1	SAFT	A320	24	AEG Seville
41018	Ni-Cd Aircraft Battery 40209-2	SAFT	A320	24	AEG Seville
410138	Ni-Cd Aircraft Battery 4079-1	SAFT	A320	24	AEG Seville
410231	Ni-Cd Aircraft Battery 1658-2	SAFT		24	AEG Seville
410378	Ni-Cd Aircraft Battery 1656-5	SAFT		24	AEG Seville
410386	Ni-Cd Aircraft Battery 1658	SAFT		24	AEG Seville
410407	Ni-Cd Aircraft Battery 1608	SAFT		24	AEG Seville
410421	Ni-Cd Aircraft Battery 4078-5	SAFT	A320	24	AEG Seville
410422	Ni-Cd Aircraft Battery 40408	SAFT		24	AEG Seville
410426	Ni-Cd Aircraft Battery 23491	SAFT		24	AEG Seville
410630	Ni-Cd Aircraft Battery 2371-4	SAFT	A320	24	AEG Seville
410677	Ni-Cd Aircraft Battery 40208-4	SAFT	A320	24	AEG Seville
410687	Ni-Cd Aircraft Battery 40208-5	SAFT	A320	24	AEG Seville
410689	Ni-Cd Aircraft Battery 606	SAFT		24	AEG Seville
410696	Ni-Cd Aircraft Battery 2371-6	SAFT	A320	24	AEG Seville
410706	Ni-Cd Aircraft Battery 666	SAFT		24	AEG Seville
410766	Ni-Cd Aircraft Battery 615	SAFT		24	AEG Seville
410860	Ni-Cd Aircraft Battery 40576	BENDIX	C-130	9H4-4-2-1	AEG Seville
410861	Ni-Cd Aircraft Battery 23491-3	SAFT	A320	24	AEG Seville
410868	Ni-Cd Aircraft Battery 2778-5	SAFT	A320	24	AEG Seville
411103	Ni-Cd Aircraft Battery 16156-1	TEAM		24	AEG Seville
411105	Ni-Cd Aircraft Battery 16158	SAFT		24	AEG Seville
411146	Ni-Cd Aircraft Battery 616	SAFT		24	AEG Seville
411179	Ni-Cd Aircraft Battery 40142	SAFT		24	AEG Seville
412100	Ni-Cd Aircraft Battery 40042	EATON	C-130,B727,B737	29-10-18	AEG Seville
412147	Ni-Cd Aircraft Battery 2371-5	SAFT	A320	24	AEG Seville
412148	Ni-Cd Aircraft Battery 4008-1	SAFT		24	AEG Seville
412282	Ni-Cd Aircraft Battery 27278-2	SAFT		24	AEG Seville
412289	Ni-Cd Aircraft Battery 40278-2	SAFT	A320	24	AEG Seville
413393	Ni-Cd Aircraft Battery 40371	SAFT		24	AEG Seville
414131	Ni-Cd Aircraft Battery 16258	SAFT		24	AEG Seville
414621	Ni-Cd Aircraft Battery 2708-1	SAFT	A320	24	AEG Seville
414662	Ni-Cd Aircraft Battery 40342	TEAM		24	AEG Seville
417777	Ni-Cd Aircraft Battery 2371-7	SAFT	A320	24	AEG Seville
41826	Ni-Cd Aircraft Battery 23678-1	SAFT	A320	24	AEG Seville
41978	Ni-Cd Aircraft Battery 40208-6	SAFT	A320	24	AEG Seville
422212	Ni-Cd Aircraft Battery 2708-2	TEAM	A320	24	AEG Seville
42437	Ni-Cd Aircraft Battery 4078-13	SAFT	A320	24	AEG Seville
42473	Ni-Cd Aircraft Battery 40300	SAFT		24	AEG Seville
42646	Ni-Cd Aircraft Battery 23678-2	SAFT	A320	24	AEG Seville
42686	Ni-Cd Aircraft Battery 40778-7	SAFT		24	AEG Seville
42670	Ni-Cd Aircraft Battery 2506-2	SAFT		24	AEG Seville
427700	Rudder Shut-Off Valve Assembly			27-21-05	AEG Seville
42755	Ni-Cd Aircraft Battery 27478	SAFT			AEG Seville
42786	Ni-Cd Aircraft Battery 4076-15	SAFT	A320	24	AEG Seville
42811	Ni-Cd Aircraft Battery 23478	SAFT		24	AEG Seville
42826	Ni-Cd Aircraft Battery 16108-1	SAFT		24	AEG Seville
42977	Ni-Cd Aircraft Battery 6206	SAFT		24	AEG Seville
42920	Ni-Cd Aircraft Battery 2522	SAFT		24	AEG Seville
42951	Ni-Cd Aircraft Battery 4072	SAFT		24	AEG Seville
42942	Ni-Cd Aircraft Battery 2376-7	SAFT	A320	24	AEG Seville
43104	Ni-Cd Aircraft Battery 4076-16	SAFT	A320	24	AEG Seville
431021	Ni-Cd Aircraft Battery 23678-3	SAFT	A320	24	AEG Seville
431034	Ni-Cd Aircraft Battery 4079-9	SAFT	A320	24	AEG Seville
431041	Ni-Cd Aircraft Battery 40778-11	SAFT	A320	24	AEG Seville
431042	Ni-Cd Aircraft Battery 4076-17	SAFT	Gulfstream,A320	24	AEG Seville
431095	Ni-Cd Aircraft Battery 40208-7	SAFT	A320	24	AEG Seville
43174	Ni-Cd Aircraft Battery A40209-1	SAFT		24	AEG Seville
43203	Ni-Cd Aircraft Battery 40508-1	SAFT	A320	24	AEG Seville
43210	Ni-Cd Aircraft Battery 4079-6	SAFT	A320	24	AEG Seville
43211	Ni-Cd Aircraft Battery 2778-10	SAFT	A320	24	AEG Seville
43228	Ni-Cd Aircraft Battery 4078-18	SAFT	A320	24	AEG Seville
43329	Ni-Cd Aircraft Battery 2778-15	SAFT	A320	24	AEG Seville
43336	Ni-Cd Aircraft Battery 26308-1	SAFT	A320	24	AEG Seville
43337	Ni-Cd Aircraft Battery 4078-16	SAFT	A320	24	AEG Seville
43384	Ni-Cd Aircraft Battery 26408-1	SAFT	A320	24	AEG Seville
43466	Ni-Cd Aircraft Battery 2376-8	SAFT	A320	24	AEG Seville
43565	Ni-Cd Aircraft Battery 23498-1	SAFT SA	A320	24	AEG Seville
44092	Ni-Cd Aircraft Battery 26108-3	SAFT	A320	24	AEG Seville
44140	Ni-Cd Aircraft Battery 1277-3	SAFT		24	AEG Seville
44162	Ni-Cd Aircraft Battery 4002	TEAM		24	AEG Seville
44184	Ni-Cd Aircraft Battery 26108-5	SAFT AMERICA ELECTRONIC	A320	24	AEG Seville
44219	Ni-Cd Aircraft Battery 4078	SAFT		24	AEG Seville
44264	Ni-Cd Aircraft Battery 181CH	SAFT	A320	24	AEG Seville
44279	Ni-Cd Aircraft Battery 40100-2	SAFT		24	AEG Seville
44377	Ni-Cd Aircraft Battery 40778-21	SAFT		24	AEG Seville
44446	Ni-Cd Aircraft Battery 178	SAFT		24	AEG Seville
44469	ELECTRIC MOTOR ASSEMBLY	EATON / 62983	C-130,DC-10,A310,A300	29-21-08	AEG Seville
44612	Ni-Cd Aircraft Battery 26508	SAFT		24	AEG Seville
44647	Ni-Cd Aircraft Battery 19V03KH B	SAFT		24	AEG Seville
44648	Ni-Cd Aircraft Battery 20V03KH B	SAFT		24	AEG Seville

414690	Ni-Cd Aircraft Battery 40200-1	SAFT	A320	24	AEG Sevilla
414732	Ni-Cd Aircraft Battery 2760H	SAFT			AEG Sevilla
414742	Ni-Cd Aircraft Battery 26608	SAFT			AEG Sevilla
414746	Ni-Cd Aircraft Battery 23491-4	SAFT	A320	24	AEG Sevilla
418067	Ni-Cd Aircraft Battery 407CH5	SAFT		24	AEG Sevilla
418188	Ni-Cd Aircraft Battery 272CH1	SAFT	A320	24	AEG Sevilla
418223	Ni-Cd Aircraft Battery B153CH1	SAFT		24	AEG Sevilla
418257	Ni-Cd Aircraft Battery 151CH2	SAFT		24-33	AEG Sevilla
418241	Ni-Cd Aircraft Battery 345CD1	SAFT		24	AEG Sevilla
418243	Ni-Cd Aircraft Battery 26108-7	SAFT	A320	24	AEG Sevilla
418444	Ni-Cd Aircraft Battery B1513CH1	SAFT		24	AEG Sevilla
418509	Ni-Cd Aircraft Battery A26908	NAVIR	P-3	24	AEG Sevilla
418738	Ni-Cd Aircraft Battery 40278-14	SAFT	A320	24	AEG Sevilla
418779	Ni-Cd Aircraft Battery 2760H7	SAFT	A320	24	AEG Sevilla
418808	Ni-Cd Aircraft Battery A2750H1	SAFT		24	AEG Sevilla
418907	Ni-Cd Aircraft Battery 505CH3	UNKNOOWN	A320	24	AEG Sevilla
418956	Ni-Cd Aircraft Battery 405CH3	SAFT	A320	24	AEG Sevilla
418957	Ni-Cd Aircraft Battery 2760CH10	SAFT	A320	24	AEG Sevilla
418999	Ni-Cd Aircraft Battery 2760CH23	SAFT	A320	24	AEG Sevilla
41607	Ni-Cd Aircraft Battery 4410CH1	SAFT		24	AEG Sevilla
416266	Ni-Cd Aircraft Battery A2609-1	SAFT		24	AEG Sevilla
416381	Aircraft Battery			24-30-53	AEG Sevilla
416441	Ni-Cd Aircraft Battery 447CH3	SAFT			AEG Sevilla
416614	Ni-Cd Aircraft Battery V5035C4	SAFT		24	AEG Sevilla
424244	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS	C-130, C-130H, C-130J, C-130K, C-130L, C-130M, C-130N, C-130P, C-130Q, C-130R, C-130S, C-130T, C-130U, C-130V, C-130W, C-130X, C-130Y, C-130Z, C-130AA, C-130AB, C-130AC, C-130AD, C-130AE, C-130AF, C-130AG, C-130AH, C-130AI, C-130AJ, C-130AK, C-130AL, C-130AM, C-130AN, C-130AO, C-130AP, C-130AQ, C-130AR, C-130AS, C-130AT, C-130AU, C-130AV, C-130AW, C-130AX, C-130AY, C-130AZ, C-130BA, C-130BB, C-130BC, C-130BD, C-130BE, C-130BF, C-130BG, C-130BH, C-130BI, C-130BJ, C-130BK, C-130BL, C-130BM, C-130BN, C-130BO, C-130BP, C-130BQ, C-130BR, C-130BS, C-130BT, C-130BU, C-130BV, C-130BW, C-130BX, C-130BY, C-130BZ, C-130CA, C-130CB, C-130CC, C-130CD, C-130CE, C-130CF, C-130CG, C-130CH, C-130CI, C-130CJ, C-130CK, C-130CL, C-130CM, C-130CN, C-130CO, C-130CP, C-130CQ, C-130CR, C-130CS, C-130CT, C-130CU, C-130CV, C-130CW, C-130CX, C-130CY, C-130CZ, C-130DA, C-130DB, C-130DC, C-130DD, C-130DE, C-130DF, C-130DG, C-130DH, C-130DI, C-130DJ, C-130DK, C-130DL, C-130DM, C-130DN, C-130DO, C-130DP, C-130DQ, C-130DR, C-130DS, C-130DT, C-130DU, C-130DV, C-130DW, C-130DX, C-130DY, C-130DZ, C-130EA, C-130EB, C-130EC, C-130ED, C-130EE, C-130EF, C-130EG, C-130EH, C-130EI, C-130EJ, C-130EK, C-130EL, C-130EM, C-130EN, C-130EO, C-130EP, C-130EQ, C-130ER, C-130ES, C-130ET, C-130EU, C-130EV, C-130EW, C-130EX, C-130EY, C-130EZ, C-130FA, C-130FB, C-130FC, C-130FD, C-130FE, C-130FF, C-130FG, C-130FH, C-130FI, C-130FJ, C-130FK, C-130FL, C-130FM, C-130FN, C-130FO, C-130FP, C-130FQ, C-130FR, C-130FS, C-130FT, C-130FU, C-130FV, C-130FW, C-130FX, C-130FY, C-130FZ, C-130GA, C-130GB, C-130GC, C-130GD, C-130GE, C-130GF, C-130GG, C-130GH, C-130GI, C-130GJ, C-130GK, C-130GL, C-130GM, C-130GN, C-130GO, C-130GP, C-130GQ, C-130GR, C-130GS, C-130GT, C-130GU, C-130GV, C-130GW, C-130GX, C-130GY, C-130GZ, C-130HA, C-130HB, C-130HC, C-130HD, C-130HE, C-130HF, C-130HG, C-130HH, C-130HI, C-130HJ, C-130HK, C-130HL, C-130HM, C-130HN, C-130HO, C-130HP, C-130HQ, C-130HR, C-130HS, C-130HT, C-130HU, C-130HV, C-130HW, C-130HX, C-130HY, C-130HZ, C-130IA, C-130IB, C-130IC, C-130ID, C-130IE, C-130IF, C-130IG, C-130IH, C-130II, C-130IJ, C-130IK, C-130IL, C-130IM, C-130IN, C-130IO, C-130IP, C-130IQ, C-130IR, C-130IS, C-130IT, C-130IU, C-130IV, C-130IW, C-130IX, C-130IY, C-130IZ, C-130JA, C-130JB, C-130JC, C-130JD, C-130JE, C-130JF, C-130JG, C-130JH, C-130JI, C-130JJ, C-130JK, C-130JL, C-130JM, C-130JN, C-130JO, C-130JP, C-130JQ, C-130JR, C-130JS, C-130JT, C-130JU, C-130JV, C-130JW, C-130JX, C-130JY, C-130JZ, C-130KA, C-130KB, C-130KC, C-130KD, C-130KE, C-130KF, C-130KG, C-130KH, C-130KI, C-130KJ, C-130KK, C-130KL, C-130KM, C-130KN, C-130KO, C-130KP, C-130KQ, C-130KR, C-130KS, C-130KT, C-130KU, C-130KV, C-130KW, C-130KX, C-130KY, C-130KZ, C-130LA, C-130LB, C-130LC, C-130LD, C-130LE, C-130LF, C-130LG, C-130LH, C-130LI, C-130LJ, C-130LK, C-130LL, C-130LM, C-130LN, C-130LO, C-130LP, C-130LQ, C-130LR, C-130LS, C-130LT, C-130LU, C-130LV, C-130LW, C-130LX, C-130LY, C-130LZ, C-130MA, C-130MB, C-130MC, C-130MD, C-130ME, C-130MF, C-130MG, C-130MH, C-130MI, C-130MJ, C-130MK, C-130ML, C-130MN, C-130MO, C-130MP, C-130MQ, C-130MR, C-130MS, C-130MT, C-130MU, C-130MV, C-130MW, C-130MX, C-130MY, C-130MZ, C-130NA, C-130NB, C-130NC, C-130ND, C-130NE, C-130NF, C-130NG, C-130NH, C-130NI, C-130NJ, C-130NK, C-130NL, C-130NM, C-130NN, C-130NO, C-13		

720566	ROTOR BALANCE ASSEMBLY	HAMILTON SUNDSTRAND	B757	24-11-68	AEG Bilbao
720722	AUXILIARY GENERATOR	SUNDSTRAND	A300-600,A310,A300,CF6-80C2	24-00-00	AEG Bilbao
720826	INTEGRATED DRIVE GENERATOR	HAMILTON	B757, B767	24	AEG Bilbao
730732	HOUSING - WOBLER	JAIR AIRCRAFT COMBONENT REDUCER	B767	24	AEG Bilbao
731633	Constant Speed Drive				AEG Bilbao
731691	EXCITER ROTOR ASSEMBLY	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
731840	Hydraulic Motorpump Assembly				AEG Sevilla
731879	Ejector Pump			24-15-55	AEG Sevilla
731966	VAR. DISPLACEMENT HYDRAULIC MOTOR	EATON HYDRAULIC PUMPS INC.	B777-300,B767-300,B767-200,B777- 200,B747-300,B737-800	27-50-01	AEG Sevilla
732036	MOTOR HOUSING AND STATOR SUBASSEMBLY	SUNDSTRAND	A330, A340	29-21-22	AEG Sevilla
732654	Center Housing			24-17-07	AEG Sevilla
732678	Governor And Support				AEG Sevilla
733492	WOBLER CONTROL ARM	UNKNOOOWN	UNK		AEG Sevilla
734181	Flap Drive Actuator Assembly			27-50-10	AEG Sevilla
734183	Flap Drive Transfer Gearbox Assembly			27-50-08	AEG Sevilla
734186	Flap Drive Torque Sensor Assembly			27-50-06	AEG Sevilla
734187	Flap Drive Torque Tube Assembly			27-50-04	AEG Sevilla
734374	Flap Drive Actuator Assembly			27-50-10	AEG Sevilla
734378	Flap Drive Torque Tube Assembly			27-50-04	AEG Sevilla
734390	Flap Drive Torque Tube Assembly			27-50-04	AEG Sevilla
734392	Flap Drive Torque Tube Assembly			27-50-04	AEG Sevilla
734393	Flap Drive Torque Tube Assembly			27-50-04	AEG Sevilla
734394	Flap Drive Torque Tube Assembly			27-50-04	AEG Sevilla
734396	Flap Drive Torque Tube Assembly			27-50-04	AEG Sevilla
734398	Flap Drive Torque Tube Assembly			27-50-04	AEG Sevilla
735343	RACE - ROLLER BEARING	UNKNOWN	UNK	24-14-03	AEG Bilbao
735410	Flexible Shaft Coupling Assembly			27-50-15	AEG Sevilla
735961	Direct Current Motor Assembly			27-50-03	AEG Sevilla
737060	IDG	HAMILTON SUNDSTRAND	UNK		AEG Bilbao
738151	STATOR ASSEMBLY - PMG	HAMILTON SUNDSTRAND	DC-10	24	AEG Bilbao
738290	STATOR HOUSING ASSEMBLY		UNK		AEG Bilbao
738292	DUAL FUEL GAGE AMPLIFIER	ZODIAC	A330, A340	28	AEG Sevilla
738299	ROTOR	SUNDSTRAND	A330, A340	24-26-04	AEG Bilbao
738301	SHAFT AND ROTOR ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
738690	INPUT HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
738965	EXCITER STATOR, ASSEMBLY	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
739616	INTEGRATED DRIVE GENERATOR	HAMILTON HAMILTON	B747-300, B747-400, B767,A320, A340	24-00-00	AEG Bilbao
741434	ELECTRICAL HARNESS	HAMILTON SUNDSTRAND	A330, A340	24	AEG Sevilla
741439	STATOR HOUSING ASSEMBLY	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
741766	STATOR HOUSING ASSEMBLY	HAMILTON SUNDSTRAND	A330, A340	24-27-08	AEG Bilbao
741766	Stator Housing Assembly			24-27-08	AEG Sevilla
741788	ASSEMBLY-EXCITER STATOR	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
742051	ROTOR	SUNDSTRAND	A330, A340	24	AEG Bilbao
743407	Flap Drive Drag Brake Assembly			27-50-01	AEG Sevilla
744041	INTEGRATED DRIVE GENERATOR	HAMILTON	B747/B757/B767/CF6-80/CF6-80C2/BB211- 60/A300/ILX6	24-00-00	AEG Bilbao
744976	Flap Drive Transfer Gearbox Assembly			27-50-08	AEG Sevilla
746329	INTEGRATED DRIVE GENERATOR	HAMILTON	B757,B747-400,B747-300,B767,B747	24-11-76	AEG Bilbao
746681	Flexible Shaft Assembly			27-50-14	AEG Sevilla
746683	Flexible Shaft Assembly			27-50-14	AEG Sevilla
746693	Flexible Shaft Assembly			27-50-14	AEG Sevilla
747194	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
747632	HOUSING - WOBLER - VARIABLE		UNK		AEG Bilbao
747633	PLATE - BEARING	UNKNOOOWN	UNK		AEG Sevilla
747636	PLATE - BEARING	THALES	UNK		AEG Sevilla
747642	HOUSING - WOBLER - VARIABLE		UNK		AEG Sevilla
747739	COVER	13951	UNK		AEG Sevilla
747740	STATOR HOUSING	SUNDSTRAND	A320	24-17-31	AEG Bilbao
747766	ELECTRICAL HARNESS	HAMILTON SUNDSTRAND	A-320, A321	24-18-12	AEG Sevilla
747768	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A320,A300,B747,B767,B757	24-26-01	AEG Bilbao
748169	EXCITER STATOR	HAMILTON SUNDSTRAND	UNK		AEG Bilbao
749436	DEAERATOR	HAMILTON SUNDSTRAND	UNK		AEG Sevilla
760860	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	MD-11,A320,CF6-80C2	24-11-80	AEG Bilbao
760876	INTEGRATED DRIVE GENERATOR	HAMILTON	MD-11,CF6-80C2	24-11-80	AEG Bilbao
761202	ELECTRICAL HARNESS	HAMILTON SUNDSTRAND	A-320, A321	24-18-12	AEG Sevilla
761341	EXCITER STATOR	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
761344	ROTOR ASSEMBLY, EXCITER	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
762063	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A330, A340	24-26-08	AEG Bilbao
762167	INTEGRATED DRIVE GENERATOR	HAMILTON	G,CFM56-5C,A340	24-11-81,24	AEG Bilbao
762168	INTEGRATED DRIVE GENERATOR	HAMILTON	Trent-700,A330,CFM56-5C	24-21-00	AEG Bilbao
763088	HOUSING ASSY		UNK		AEG Sevilla
763383	STATOR ASSEMBLY-GENERATOR	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
763386	STATOR ASSEMBLY, PMG	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
764267	RESISTOR	SUNDSTRAND	UNK		AEG Sevilla
765017	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	A321,A330	24-11-82	AEG Bilbao
765067	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A300	24-18-16	AEG Sevilla
765369	INTEGRATED DRIVE GENERATOR	HAMILTON	B757/B757-900,B757-800,B757-700,B757- 400,B737,B747,A300,B747	24-00-00	AEG Bilbao
765469	IDG	HAMILTON SUNDSTRAND	CRJ Regional Jet-200,CRJ Regional Jet-100	24	AEG Bilbao
765469	Integrated Drive Generator			24-21-08	AEG Sevilla
765676	HSG Input - Matched Set			24-17-36	AEG Sevilla
765691	Electrical Harness			24-18-15	AEG Sevilla
765704	Pump And Motor			24-14-14	AEG Sevilla
765961	ROTOR BALANCE ASSEMBLY	HAMILTON SUNDSTRAND	B777	24	AEG Bilbao
766168	Flap Drive Torque Sensor Assembly			27-50-13	AEG Sevilla
766400	PMG STATOR	HAMILTON SUNDSTRAND	A340	24	AEG Bilbao
766583	IDG	SUNDSTRAND	Trent-800,B777-300,B777-200,B777	24-11-83	AEG Bilbao
766699	APU GENERATOR	HAMILTON	GTPC331-500B,B777	24-21-15	AEG Bilbao
766642	WOUND ASSEMBLY	HAMILTON SUNDSTRAND	B757	24	AEG Bilbao
766662	Air Driven Generator			24-15-51	AEG Sevilla
766690	ROTOR ASSEMBLY EXCITER	HAMILTON SUNDSTRAND	A300-600,B767,B757,B747,A300	24	AEG Bilbao
766692	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A300-600,A320,A300,B747,B767,B757	24-26-01	AEG Bilbao
766722	Solenoid Valve Assembly			49-92-01	AEG Sevilla
766866	Center Housing			24-17-07	AEG Sevilla
766911	EXCITER AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A330	24-17-37	AEG Bilbao
767000	Gen And Strut			24-26-02	AEG Sevilla
767030	ROTOR BALANCE ASSEMBLY	HAMILTON SUNDSTRAND	UNK	24	AEG Bilbao
767060	EXCITER STATOR	HAMILTON SUNDSTRAND	UNK		AEG Bilbao
767811	ELECTRICAL HARNESS	HAMILTON SUNDSTRAND	B757	24	AEG Sevilla
768922	INTEGRATED DRIVE GENERATOR	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
768926	AC GENERATOR	SUNDSTRAND	A330, A340	24-22-06	AEG Bilbao
769768	INTEGRATED DRIVE GENERATOR	HAMILTON	A300/A310	24-00-00	AEG Bilbao
761343	ADG Ejection Jack And Hose Assembly			24-23-07	AEG Sevilla
761346	ADG Unlock Assembly			24-23-28	AEG Sevilla
761674	INTEGRATED DRIVE GENERATOR	HAMILTON	B757-900,B757-800,B757-700,B757- 400,B737,A300,A340	24-00-00	AEG Bilbao
762109	STATOR ASSEMBLY - MAIN GENERATOR	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
762359	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	737	24-26-12	AEG Bilbao
762367	GENERATOR MAIN FIELD WOUND ASSEMBLY	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
762620	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
763061	Support Bearing			27-52-13	AEG Sevilla
763410	Support Bearing			27-52-13	AEG Sevilla
763467	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	MD-11,CF6-80C2	24-11-80	AEG Bilbao
763776	ELECTRICAL HARNESS	SUNDSTRAND	B767	24-18-03	AEG Sevilla
764294	STATOR ASSEMBLY-PMG	HAMILTON SUNDSTRAND	B737	24	AEG Bilbao
764637	ADG Strut/Generator Assembly			24-23-04	AEG Sevilla
764939	IDG	SUNDSTRAND	Trent-800,B777-300,B777-200,B777	24-11-83	AEG Bilbao
766480	Variable Frequency AC Motor			29-13-03	AEG Sevilla
766088	INTEGRATED DRIVE GENERATOR	HAMILTON	B757/B757-900,B757-800,B757-700,B757- 400,B737,B747,A300,A340	24-00-00	AEG Bilbao
766091	Cylinder Block and Piston	SUNDSTRAND		24	AEG Bilbao
766277	Integrated Drive Generator			24-21-12	AEG Sevilla
766283	Generator Control Unit			24-23-25	AEG Sevilla

766288	GENERATOR ASSEMBLY	HAMILTON	CH9000 Regional 387-9000,CH9000 Discontinued, Int. 3000,CH91,3000,CH94,800	24-22-13	AEG Bilbao
766288	Generator Assembly			24-22-13	AEG Sevilla
766369	Outboard Left Flap Actuator Assembly			27-52-22	AEG Sevilla
766386	Outboard Slat Actuator Assembly			27-81-18	AEG Sevilla
766461	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
766634	Auto Deploy Control Unit			24-23-35	AEG Sevilla
767173	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilbao
767188	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
767226	Pump And Motor Assembly			24-14-22	AEG Sevilla
767910	STATOR ASSEMBLY, GENERATOR	HAMILTON	A330, A340	24	AEG Bilbao
767916	STATOR HOUSING	SUNDSTRAND	B737	24-17-50	AEG Bilbao
768342	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	ARJ21	24-26-16	AEG Bilbao
768342	Rotor Balance Assembly			24-26-16	AEG Sevilla
768616	Mid Slat Actuator Assembly			27-81-20	AEG Sevilla
769068	IDG	HAMILTON	B767-400,B777	24	AEG Bilbao
769883	EXCITER STATOR	SUNDSTRAND	B737	24	AEG Bilbao
770401	EXCITER ROTOR	HAMILTON	A330	24	AEG Bilbao
770402	PMG STATOR	PRATT&WHITNEY	A330,A321	72-53-16	AEG Bilbao
770404	STATOR ASSEMBLY, EXCITER	PRATT	A320,B767,B777,B737,B747	75-21-01	AEG Bilbao
770504	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
777051	Generator Assembly			24-22-13	AEG Sevilla
772170	Input Housing Assembly			24-17-52	AEG Sevilla
772181	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	CFM56- E, A340, A320, A330, A319, A320, CFM56	24-00-00	AEG Bilbao
772183	STATOR HOUSING ASSEMBLY	SUNDSTRAND	737	24-17-50	AEG Bilbao
772292	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	V2500,A319,A321,A320,CFM56-5B	24-21-00	AEG Bilbao
772294	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A321	24-17-51	AEG Bilbao
772295	EXCITER STATOR HOUSING ASSEMBLY	SUNDSTRAND	UNK	24	AEG Bilbao
778496	Wing Isolation Check Valve			23-32-24	AEG Sevilla
778497	Trim Zone Temperature Valve			21-61-46	AEG Sevilla
782100	HP Bleed Pressure Switch			21-51-46	AEG Sevilla
786922	INTEGRATED DRIVE GENERATOR	HAMILTON SUNDSTRAND	A330, A340		AEG Bilbao
796242	RACE - ROLLER BEARING		UNK		AEG Bilbao
798894	Fuel Computer Tray			28-41-21	AEG Sevilla
802600	Windshield			56-10-01-Obsolete	AEG Sevilla
802600	Windshield			56-10-12	AEG Sevilla
820029	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820909	Fan Inlet Diffuser Housing			21-53-11	AEG Sevilla
820967	Check Valve			21-53-07	AEG Sevilla
820976	Oil Cooler Ejector			79-21-01	AEG Sevilla
821480	Fog Nozzle			21-74-03	AEG Sevilla
841923	AC ROTOR ASSEMBLY	HONEYWELL	F-27		AEG Bilbao
848364	VARIABLE DISPLACEMENT	VICKERS	B777,A340-500,A340-500,MD- 11,B767,B747,A310,A300,A340,A330,A320	29-10-41	AEG Sevilla
849667	Hydraulic Motorpump Assembly		MD-11,CFM56- 3,A320,B767,B737,B747,C-17,B737,800,B737	82-22-51	AEG Sevilla
849689	VARIABLE DISPLACEMENT HYDRAULIC PUMP	EATON	A300	29-10-47	AEG Sevilla
861861	MOTOR HOUSING AND STATOR SUBASSEMBLY	EATON/VICKERS	UNK		AEG Sevilla
869843	FLUID PRESSURE REGULATING VALVE		UNK		AEG Sevilla
878829	ARMATURE ASSEMBLY	BENDIX	A330, A340	24	AEG Bilbao
887111	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS	A318,320,V2500,B747-400,MD-11,DC- 800,A320,A320,A319,A320,A319	38-30-05	AEG Sevilla
887477	AC DRIVEN MOTORPUMP ASSEMBLY	VICKERS	B737-800,B747-400,B747-300-200,B737- 300,E-173,B737,400,B737-300,B737	29-10-49	AEG Sevilla
887479	AC DRIVEN MOTORPUMP ASSEMBLY	EATON VICKERS FLUID POWER	B737-200,B737-100,B747,B727,B737	29-10-51	AEG Sevilla
887480	AC DRIVEN MOTORPUMP ASSEMBLY	EATON AIR CONTROLS	F-27,B777,B727,B737	29-10-52	AEG Sevilla
887673	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS	320,V2500,DC-10-10,A321-200,A321- 300,A320-200,A320,300,1-300,B767	27-50-10	AEG Sevilla
896380	TORQUE LIMITER ASSEMBLY		UNK		AEG Bilbao
900094	25 Cubic Inch Accumulator			29-22-04- accumulator 4 in. 20	AEG Sevilla
900096	Hydraulic Accumulator			29-10-41	AEG Sevilla
933402	HYD MOTOR PUMP	EATON	CN-235, CN-295	29-10-41	AEG Sevilla
946169	Manifold Assembly, Filter, Hydraulic				AEG Sevilla
946170	Filter, Pressure, Hydraulic				AEG Sevilla
946190	Filter, Case Drain, Hydraulic				AEG Sevilla
960441	Hydraulic Reservoir Assembly				AEG Sevilla
960442	Hydraulic Reservoir Assembly				AEG Sevilla
960443	System 3 Hydraulic Reservoir Assembly				AEG Sevilla
971633	DC ELECTRIC MOTORPUMP ASSEMBLY	VICKERS	A330, A340	29-10-60	AEG Sevilla
971808	HIDRAULIC PUMP	VICKERS	EMB-135/-145, DHC-8	29-11-15	AEG Sevilla
971808	Variable Displacement Hydraulic Pump				AEG Sevilla
971844	VARIABLE DISPLACEMENT	VICKERS	1166F-700,DC-8,A340-500,A340- 500,A320,A320,A319,CFM56,3,CFM56,8C	29-10-41	AEG Sevilla
972424	HYDRAULIC PUMP ASSEMBLIES	VICKERS	B747,B767,B777,CF6-80C2	29-11-00	AEG Sevilla
972630	VARIABLE DISPLACEMENT	VICKERS	A340-600,A340- 500,A340,320,A319,A319,A,CFM56,8C	29-10-41	AEG Sevilla
972962	HYDRAULIC PUMP ASSEMBLIES	VICKERS	B777-300,B767-400,B777- 300,B767,B777,B747,CF6,80C2	29-11-00	AEG Sevilla
974014	MOTOR PUMP ASSY	EATON	A321,A330,A320,A318	29	AEG Sevilla
974540	HYDRAULIC PUMP	EATON	A340-600,A340-500,A321,A319,A316,A320- 200,A320-200,B767,B747,A340,A320,A320	29-10-72	AEG Sevilla
974541	Reservoir Level Switch Assembly				AEG Sevilla
974541	Reservoir Level Switch - NewPart Number -			41-29-02	AEG Sevilla
974800	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS	B757,B777,B727,1166F-700,A340-600,A340- 500,A340,A320,C345-500,DC- 800,B767,B777,B747,CF6,80C2	29-10-55	AEG Sevilla
974947	VARIABLE DISPLACEMENT	VICKERS	1166F-700,DC-8,A340-500,A340- 500,A340,500,A340,A320,CFM56	29-10-41	AEG Sevilla
974976	VARIABLE DISPLACEMENT	VICKERS	1166F-700,DC-8,A340-500,A340- 500,A340,500,A340,A320,CFM56	29-10-41	AEG Sevilla
976247	Valve Assembly, PTU Select, Hydraulic				AEG Sevilla
976260	Valve, Bypass, Heat Exchanger				AEG Sevilla
976263	Valve Assembly, Isolation, Hydraulic				AEG Sevilla
976264	Hydraulic Balanced Relief Valve				AEG Sevilla
976267	Valve Assembly, Accumulator Isolation, Hydraulic				AEG Sevilla
976278	Automatic Qty. Measuring Fuse				AEG Sevilla
1066350	PRESSURE CONTROL VALVE	PARKER	LC-8,B727-400,B727-100,B757,B707,MU- 50,80	29-20-15	AEG Sevilla
112258	ROTOR	BENDIX	UNK		AEG Bilbao
112289	ARMATURE ASSEMBLY	NATIONAL	F-27	27	AEG Sevilla
1139568	CVR Audio Mixer			23-71-05	AEG Sevilla
1185777	AUDIO PANEL CONTROL	AVTECH	B737-300,B737	23-50-17	AEG Sevilla
1186237	AUDIO PANEL CONTROL	SAFT	UNK	24	AEG Sevilla
1227217	Audio Remote Electronic Unit			23-50-28	AEG Sevilla
1241078	INDICATOR HYDRAULIC PRESSURE	GRIMES		27-00-00	AEG Sevilla
1263742	Audio Electronic Control Unit (AECU)			23-50-34	AEG Sevilla
1263744	Audio Electronic Control Unit (AECU)			23-50-34	AEG Sevilla
126426	Audio Control Panel (CMM With IPL)			23-50-57	AEG Sevilla
126427	Audio Control Panel (CMM With IPL)			23-50-57	AEG Sevilla
1308673	Interphone Handset/Cradle			23-30-23	AEG Sevilla
1344826	Passenger Address/Cabin Interphone Controller			23-31-11	AEG Sevilla
1670421	Servovalve Spooler			27-64-00	AEG Sevilla
7700899	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilbao
7700896	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
7701317	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	ERU,CH9000 Regional 387-9000,CH9000 Discontinued, Int. 3000,CH96,300,CH98	24	AEG Bilbao
7701317	Integrated Drive Generator			24-21-12	AEG Sevilla
7701320	GENERATOR ASSEMBLY	HAMILTON	ERU,CH9000 Regional 387-9000,CH9000 Discontinued, Int. 3000,CH96,300,CH98,8C	24-22-13	AEG Bilbao
7701410	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
7701422	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
7701469	PMG AND SUPPORT ASSEMBLY	SUNSTRAD	CL-601	24	AEG Bilbao
7701482	STATOR	HAMILTON SUNDSTRAND	737	24	AEG Bilbao
7701483	STATOR ASSEMBLY	HAMILTON	B757,A310	24-22-03	AEG Bilbao
7701487	STATOR ASSEMBLY-PMG	SUNDSTRAND	B737	24	AEG Bilbao
7701736	Input Housing Assembly			24-17-52	AEG Sevilla
7701766	VSCF GEN	SUNDSTRAND	B777	24-25-00	AEG Bilbao
7701768	VSCF GEN	SUNDSTRAND	B777-300,B777-200,B777	24-25-00	AEG Bilbao
7701863	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
7701926	ADG Strut/Generator Assembly			24-23-04	AEG Sevilla
7701931	Pump And Motor Assembly			24-14-22	AEG Sevilla
7702369	EXCITER ROTOR ASSEMBLY	HAMILTON SUNDSTRAND	737	24	AEG Bilbao
7702370	EXCITER ROTOR ASSEMBLY	HAMILTON SUNDSTRAND	B777,A330	24	AEG Bilbao
7702377	ROTOR ASSEMBLY, EXCITER	HAMILTON SUNDSTRAND	A340,MD-11	24	AEG Bilbao
7702690	STATOR ASSEMBLY - AC GENERATOR	SUNSTRAD	737	24	AEG Bilbao
7702711	STATOR ASSEMBLY, ALTERNATING CURRENT	SUNDSTRAND	B757,B747,A320,B767	24-11-79	AEG Bilbao

4233488	TAKE OFF LIGHT	ECE - TELEFLEX	C-150,B777,B737,A318,A320-	33-46-01	AEG Sevilla
4235664	TAXI LIGHT	ECE - TELEFLEX	A300,C-150,DC-3,D38-B747-	33-46-02	AEG Sevilla
4264964	AUTOTRANSFORMER, ASSY	ECE-TELEFLEX	300,306,310,313,318,A318,A320-	33-49-14	AEG Sevilla
4273501	TAKE-OFF AND TAXI LIGHT	ECE-TELEFLEX	A320,A321,A318,A319,A320,A300-	33-43-31,33	AEG Sevilla
4273527	TAKE-OFF AND TAXI LIGHT	ECE-TELEFLEX	A320,A321,A318,A319,A320,A300-	33-43-31,33,35-	AEG Sevilla
4289452	WING SCAN LIGHT	TELEFLEX	A321,A318,A330,A310,A300,A340	33-49-26	AEG Sevilla
4289468	WING SCAN LIGHT	TELEFLEX	A321,A318,A330,A310,A300,A340	33-49-26	AEG Sevilla
4292209	LANDING LIGHT	ZODIAC	A350,F100,A321,A318,A330,A320,A330-	33-42-14	AEG Sevilla
4292491	LOGO LIGHT	ECE-TELEFLEX	A350,A320,A321,A318,A340,A330	33-47-11,33-43-	AEG Sevilla
4295078	ENGINE SCAN LIGHT	IN SERVICES	A321,A318,A340,A330	33-49-28	AEG Sevilla
4295085	ENGINE SCAN LIGHT	TELEFLEX SYNERAVIA	A321,A318,A340,A330	33-49-28	AEG Sevilla
4295092	ENGINE SCAN LIGHT	IN SERVICES	A321,A318,A340,A330	33-49-28	AEG Sevilla
4295107	ENGINE SCAN LIGHT	IN SERVICES	A321,A318,A340,A330	33-49-28	AEG Sevilla
4295114	ENGINE SCAN LIGHT	IN SERVICES	A321,A318,A340,A330	33-49-28	AEG Sevilla
4295121	ENGINE SCAN LIGHT	IN SERVICES	A321,A318,A340,A330	33-49-28	AEG Sevilla
4298117	TAKE-OFF AND TAXI LIGHT	ECE-TELEFLEX	A330-ZULU-C	33-46-12	AEG Sevilla
4299172	AUTOTRANSFORMER	ECE / OLAR BAN	A330, A340	33	AEG Sevilla
4315642	RETRACTABLE LANDING LIGHT	ECE	C-150,A318,ATR 72,ATR 42,B737,A300-	33-42-12	AEG Sevilla
4326173	AUTOTRANSFORMER	ECE - TELEFLEX SYN	A330, A340	33-43-03	AEG Sevilla
4328733	LOGO LIGHT	ECE-TELEFLEX	A330, A340, A320	33-47-11,33-43-	AEG Sevilla
4331772	RETRACTABLE LANDING LIGHT	ECE	A350,DC-8,A318,B737,B737,A300-	33-42-12	AEG Sevilla
4333302	LOGO LIGHT	ECE	A300,A320,A330,A340,A300,A320-	33	AEG Sevilla
4333318	LOGO LIGHT	ECE	B757	33	AEG Sevilla
4333325	LOGO LIGHT	ECE	B757	33	AEG Sevilla
4333332	LOGO LIGHT	ECE	B757	33	AEG Sevilla
4339107	Nose Gear Landing Light	ECE-TELEFLEX		33-41-08	AEG Sevilla
4358532	LOGO LIGHT	ECE-TELEFLEX	A340, A330, A320	33-47-11, 33-43-11	AEG Sevilla
4359996	Wiper Blade Assembly			30-42-13	AEG Sevilla
4359925	Wiper/Stall Panel Switch			30-42-18	AEG Sevilla
4363682	Windshield Wiper System			30-42-00	AEG Sevilla
4364686	Electrical Harness			30-42-19	AEG Sevilla
4376625	Electronic Control Unit			30-42-12	AEG Sevilla
4603066	Auxiliary Power Unit			49-20-100-	AEG Bilbao
4603066	Auxiliary Power Unit			49-20-100-	AEG Bilbao
4603090	Engine Control Harness Assembly			49-10-08	AEG Bilbao
4603140	Fuel Pump Assembly			49-32-07	AEG Sevilla
4603216	Auxiliary Power Unit			49-20-100-	AEG Bilbao
4603216	Auxiliary Power Unit			49-20-100-	AEG Bilbao
4603236	Engine Control Harness Assembly			49-10-25	AEG Bilbao
4604616	FCU	110UMPT ACCESSORY			AEG Sevilla
4624682	SERVO FUEL INJECTOR MODEL RSA-10ED1		LYCOMING ENGINES		AEG Sevilla
4681008	Lavatory Floor Assy			53-10-04	AEG Sevilla
4681013	Lavatory Door Assy			52-50-01	AEG Sevilla
4682006	FORWARD LAVATORY SECTION ASSEMBLY			53-10-02	AEG Sevilla
4682006	Lavatory Forward Section Assy			53-10-02	AEG Sevilla
4682007	Lavatory Side And Upper Structure Assy			53-10-03	AEG Sevilla
4682008	Lavatory Floor Assy			53-10-04	AEG Sevilla
4682046	Lavatory Fluorescent Light Lens Assy			33-20-01	AEG Sevilla
4683006	FORWARD LAVATORY SECTION ASSEMBLY			53-10-02	AEG Sevilla
4684008	Lavatory Floor Assy			53-10-04	AEG Sevilla
4636001	Cockpit Door Assy			52-51-10	AEG Sevilla
4960029	STARTER MOTOR	SUNDSTRAND	T-82T-4/CL, T62T-46C1, 46C2, 46C2A, 46C2B, 46C2C, 46C2D, 46C2E, 46C2F, 46C2G, 46C2H, 46C2I, 46C2J, 46C2K, 46C2L, 46C2M, 46C2N, 46C2O, 46C2P, 46C2Q, 46C2R, 46C2S, 46C2T, 46C2U, 46C2V, 46C2W, 46C2X, 46C2Y, 46C2Z, 46C2AA, 46C2AB, 46C2AC, 46C2AD, 46C2AE, 46C2AF, 46C2AG, 46C2AH, 46C2AI, 46C2AJ, 46C2AK, 46C2AL, 46C2AM, 46C2AN, 46C2AO, 46C2AP, 46C2AQ, 46C2AR, 46C2AS, 46C2AT, 46C2AU, 46C2AV, 46C2AW, 46C2AX, 46C2AY, 46C2AZ, 46C2BA, 46C2BB, 46C2BC, 46C2BD, 46C2BE, 46C2BF, 46C2BG, 46C2BH, 46C2BI, 46C2BJ, 46C2BK, 46C2BL, 46C2BM, 46C2BN, 46C2BO, 46C2BP, 46C2BQ, 46C2BR, 46C2BS, 46C2BT, 46C2BU, 46C2BV, 46C2BW, 46C2BX, 46C2BY, 46C2BZ, 46C2CA, 46C2CB, 46C2CC, 46C2CD, 46C2CE, 46C2CF, 46C2CG, 46C2CH, 46C2CI, 46C2CJ, 46C2CK, 46C2CL, 46C2CM, 46C2CN, 46C2CO, 46C2CP, 46C2CQ, 46C2CR, 46C2CS, 46C2CT, 46C2CU, 46C2CV, 46C2CW, 46C2CX, 46C2CY, 46C2CZ, 46C2DA, 46C2DB, 46C2DC, 46C2DD, 46C2DE, 46C2DF, 46C2DG, 46C2DH, 46C2DI, 46C2DJ, 46C2DK, 46C2DL, 46C2DM, 46C2DN, 46C2DO, 46C2DP, 46C2DQ, 46C2DR, 46C2DS, 46C2DT, 46C2DU, 46C2DV, 46C2DW, 46C2DX, 46C2DY, 46C2DZ, 46C2EA, 46C2EB, 46C2EC, 46C2ED, 46C2EE, 46C2EF, 46C2EG, 46C2EH, 46C2EI, 46C2EJ, 46C2EK, 46C2EL, 46C2EM, 46C2EN, 46C2EO, 46C2EP, 46C2EQ, 46C2ER, 46C2ES, 46C2ET, 46C2EU, 46C2EV, 46C2EW, 46C2EX, 46C2EY, 46C2EZ, 46C2FA, 46C2FB, 46C2FC, 46C2FD, 46C2FE, 46C2FF, 46C2FG, 46C2FH, 46C2FI, 46C2FJ, 46C2FK, 46C2FL, 46C2FM, 46C2FN, 46C2FO, 46C2FP, 46C2FQ, 46C2FR, 46C2FS, 46C2FT, 46C2FU, 46C2FV, 46C2FW, 46C2FX, 46C2FY, 46C2FZ, 46C2GA, 46C2GB, 46C2GC, 46C2GD, 46C2GE, 46C2GF, 46C2GG, 46C2GH, 46C2GI, 46C2GJ, 46C2GK, 46C2GL, 46C2GM, 46C2GN, 46C2GO, 46C2GP, 46C2GQ, 46C2GR, 46C2GS, 46C2GT, 46C2GU, 46C2GV, 46C2GW, 46C2GX, 46C2GY, 46C2GZ, 46C2HA, 46C2HB, 46C2HC, 46C2HD, 46C2HE, 46C2HF, 46C2HG, 46C2HH, 46C2HI, 46C2HJ, 46C2HK, 46C2HL, 46C2HM, 46C2HN, 46C2HO, 46C2HP, 46C2HQ, 46C2HR, 46C2HS, 46C2HT, 46C2HU, 46C2HV, 46C2HW, 46C2HX, 46C2HY, 46C2HZ, 46C2IA, 46C2IB, 46C2IC, 46C2ID, 46C2IE, 46C2IF, 46C2IG, 46C2IH, 46C2II, 46C2IJ, 46C2IK, 46C2IL, 46C2IM, 46C2IN, 46C2IO, 46C2IP, 46C2IQ, 46C2IR, 46C2IS, 46C2IT, 46C2IU, 46C2IV, 46C2IW, 46C2IX, 46C2IY, 46C2IZ, 46C2JA, 46C2JB, 46C2JC, 46C2JD, 46C2JE, 46C2JF, 46C2JG, 46C2JH, 46C2JI, 46C2JJ, 46C2JK, 46C2JL, 46C2JM, 46C2JN, 46C2JO, 46C2JP, 46C2JQ, 46C2JR, 46C2JS, 46C2JT, 46C2JU, 46C2JV, 46C2JW, 46C2JX, 46C2JY, 46C2JZ, 46C2KA, 46C2KB, 46C2KC, 46C2KD, 46C2KE, 46C2KF, 46C2KG, 46C2KH, 46C2KI, 46C2KJ, 46C2KL, 46C2KM, 46C2KN, 46C2KO, 46C2KP, 46C2KQ, 46C2KR, 46C2KS, 46C2KT, 46C2KU, 46C2KV, 46C2KW, 46C2KX, 46C2KY, 46C2KZ, 46C2LA, 46C2LB, 46C2LC, 46C2LD, 46C2LE, 46C2LF, 46C2LG, 46C2LH, 46C2LI, 46C2LJ, 46C2LK, 46C2LL, 46C2LM, 46C2LN, 46C2LO, 46C2LP, 46C2LQ, 46C2LR, 46C2LS, 46C2LT, 46C2LU, 46C2LV, 46C2LW, 46C2LX, 46C2LY, 46C2LZ, 46C2MA, 46C2MB, 46C2MC, 46C2MD, 46C2ME, 46C2MF, 46C2MG, 46C2MH, 46C2MI, 46C2MJ, 46C2MK, 46C2ML, 46C2MM, 46C2MN, 46C2MO, 46C2MP, 46C2MQ, 46C2MR, 46C2MS, 46C2MT, 46C2MU, 46C2MV, 46C2MW, 46C2MX, 46C2MY, 46C2MZ, 46C2NA, 46C2NB, 46C2NC, 46C2ND, 46C2NE, 46C2NF, 46C2NG, 46C2NH, 46C2NI, 46C2NJ, 46C2NK, 46C2NL, 46C2NM, 46C2NO, 46C2NP, 46C2NQ, 46C2NR, 46C2NS, 46C2NT, 46C2NU, 46C2NV, 46C2NW, 46C2NX, 46C2NY, 46C2NZ, 46C2OA, 46C2OB, 46C2OC, 46C2OD, 46C2OE, 46C2OF, 46C2OG, 46C2OH, 46C2OI, 46C2OJ, 46C2OK, 46C2OL, 46C2OM, 46C2ON, 46C2OO, 46C2OP, 46C2OQ, 46C2OR, 46C2OS, 46C2OT, 46C2OU, 46C2OV, 46C2OW, 46C2OX, 46C2OY, 46C2OZ, 46C2PA, 46C2PB, 46C2PC, 46C2PD, 46C2PE, 46C2PF, 46C2PG, 46C2PH, 46C2PI, 46C2PJ, 46C2PK, 46C2PL, 46C2PM, 46C2PN, 46C2PO, 46C2PP, 46C2PQ, 46C2PR, 46C2PS, 46C2PT, 46C2PU, 46C2PV, 46C2PW, 46C2PX, 46C2PY, 46C2PZ, 46C2QA, 46C2QB, 46C2QC, 46C2QD, 46C2QE, 46C2QF, 46C2QG, 46C2QH, 46C2QI, 46C2QJ, 46C2QK, 46C2QL, 46C2QM, 46C2QN, 46C2QO, 46C2QP, 46C2QQ, 46C2QR, 46C2QS, 46C2QT, 46C2QU, 46C2QV, 46C2QW, 46C2QX, 46C2QY, 46C2QZ, 46C2RA, 46C2RB, 46C2RC, 46C2RD, 46C2RE, 46C2RF, 46C2RG, 46C2RH, 46C2RI, 46C2RJ, 46C2RK, 46C2RL, 46C2RM, 46C2RN, 46C2RO, 46C2RP, 46C2RQ, 46C2RR, 46C2RS, 46C2RT, 46C2RU, 46C2RV, 46C2RW, 46C2RX, 46C2RY, 46C2RZ, 46C2SA, 46C2SB, 46C2SC, 46C2SD, 46C2SE, 46C2SF, 46C2SG, 46C2SH, 46C2SI, 46C2SJ, 46C2SK, 46C2SL, 46C2SM, 46C2SN, 46C2SO, 46C2SP, 46C2SQ, 46C2SR, 46C2SS, 46C2ST, 46C2SU, 46C2SV, 46C2SW, 46C2SX, 46C2SY, 46C2SZ, 46C2TA, 46C2TB, 46C2TC, 46C2TD, 46C2TE, 46C2TF, 46C2TG, 46C2TH, 46C2TI, 46C2TJ, 46C2TK, 46C2TL, 46C2TM, 46C2TN, 46C2TO, 46C2TP, 46C2TQ, 46C2TR, 46C2TS, 46C2TT, 46C2TU, 46C2TV, 46C2TW, 46C2TX, 46C2TY, 46C2TZ, 46C2UA, 46C2UB, 46C2UC, 46C2UD, 46C2UE, 46C2UF, 46C2UG, 46C2UH, 46C2UI, 46C2UJ, 46C2UK, 46C2UL, 46C2UM, 46C2UN, 46C2UO, 46C2UP, 46C2UQ, 46C2UR, 46C2US, 46C2UT, 46C2UU, 46C2UV, 46C2UW, 46C2UX, 46C2UY, 46C2UZ, 46C2VA, 46C2VB, 46C2VC, 46C2VD, 46C2VE, 46C2VF, 46C2VG, 46C2VH, 46C2VI, 46C2VJ, 46C2VK, 46C2VL, 46C2VM, 46C2VN, 46C2VO, 46C2VP, 46C2VQ, 46C2VR, 46C2VS, 46C2VT, 46C2VU, 46C2VV, 46C2VW, 46C2VX, 46C2VY, 46C2VZ, 46C2WA, 46C2WB, 46C2WC, 46C2WD, 46C2WE, 46C2WF, 46C2WG, 46C2WH, 46C2WI, 46C2WJ, 46C2WK, 46C2WL, 46C2WM, 46C2WN, 46C2WO, 46C2WP, 46C2WQ, 46C2WR, 46C2WS, 46C2WT, 46C2WU, 46C2WV, 46C2WW, 46C2WX, 46C2WY, 46C2WZ, 46C2XA, 46C2XB, 46C2XC, 46C2XD, 46C2XE, 46C2XF, 46C2XG, 46C2XH, 46C2XI, 46C2XJ, 46C2XK, 46C2XL, 46C2XM, 46C2XN, 46C2XO, 46C2XP, 46C2XQ, 46C2XR, 46C2XS, 46C2XT, 46C2XU, 46C2XV, 46C2XW, 46C2XX, 46C2XY, 46C2XZ, 46C2YA, 46C2YB, 46C2YC, 46C2YD, 46C2YE, 46C2YF, 46C2YG, 46C2YH, 46C2YI, 46C2YJ, 46C2YK, 46C2YL, 46C2YM, 46C2YN, 46C2YO, 46C2YP, 46C2YQ, 46C2YR, 46C2YS, 46C2YT, 46C2YU, 46C2YV, 46C2YW, 46C2YX, 46C2YY, 46C2YZ, 46C2ZA, 46C2ZB, 46C2ZC, 46C2ZD, 46C2ZE, 46C2ZF, 46C2ZG, 46C2ZH, 46C2ZI, 46C2ZJ, 46C2ZK, 46C2ZL, 46C2ZM, 46C2ZN, 46C2ZO, 46C2ZP, 46C2ZQ, 46C2ZR, 46C2ZS, 46C2ZT, 46C2ZU, 46C2ZV, 46C2ZW, 46C2ZX, 46C2ZY, 46C2ZZ		

81207412	HOUSING AND STATOR ASSEMBLY	LUCAS	A330, A340		AEG Bilbao
81207425	ROTOR ASSEMBLY, FINISHED	LUCAS	A320	24-23-51	AEG Bilbao
81207426	ROTOR AND SHAFT ASSEMBLY, MACHINED	LUCAS	A320	24-23-51	AEG Bilbao
81207444	HOUSING AND STATOR ASSEMBLY	LUCAS	A330, A340		AEG Bilbao
81207461	MACHINED ROTOR & SHAFT ASSEMBLY	GOODRICH	A330, A340		AEG Bilbao
81207474	ROTOR ASSEMBLY, FINISHED	LUCAS	A330	REWIND	AEG Bilbao
81207486	STATOR ASSEMBLY, MAIN WOUND	LUCAS	A330, A340		AEG Bilbao
81207491	MAIN FRAME, STATOR ASSEMBLY	GOODRICH	A330, A340		AEG Bilbao
81207504	NAMEPLATE		UNK		AEG Sevilla
81207540	STATOR ASSEMBLY, MAIN WOUND	GOODRICH	A330, A340	24-23-53	AEG Bilbao
81207562	ROTOR ASSEMBLY, FINISHED ME	GOODRICH	A330, A340	24-23-53	AEG Bilbao
81207562	ROTOR ASSEMBLY, FINISHED	GOODRICH	A330, A340	24-23-53	AEG Bilbao
81207563	ROTOR ASSEMBLY FINISHED	LUCAS	A330, A340		AEG Bilbao
81207671	ROTOR ASSEMBLY, FINISHED	GOODRICH	A330, A340	24-23-53	AEG Bilbao
81207687	MAIN WOUND STATOR ASSEMBLY	LUCAS	A330, A340		AEG Bilbao
81207697	APU GEN ROTOR	LUCAS	A320,A319, A321	24-23-51	AEG Bilbao
81207613	ROTOR AND SHAFT ASSEMBLY, MACHINED	SAFRAN POWER	A330, A340	24-20-72	AEG Bilbao
81207659	EXCITER ROTOR	SAFRAN (GOODRICH)	A330, A340	24-23-51	AEG Bilbao
81207650	ROTOR ASSEMBLY, FINISHED	GOODRICH	A320	REWIND	AEG Bilbao
81207673	AMENDMENT PLATE	LUCAS UK	UNK		AEG Sevilla
81207690	STATOR ASSEMBLY, MAIN WOUND	GOODRICH	A330, A340		AEG Bilbao
81207704	ROTOR ASSEMBLY, FINISHED	LUCAS	A330, A340	24-23-53	AEG Bilbao
81207706	ROTOR ASSEMBLY, FINISHED	LUCAS	A330, A340	24-23-53	AEG Bilbao
81207707	ROTOR ASSEMBLY, FINISHED ME	LUCAS	A330, A340	24-23-53	AEG Bilbao
81207736	FINISHED ROTOR ASSEMBLY	GOODRICH	A330, A340	24-20-72	AEG Bilbao
81207741	STATOR, MAIN, WOUND ASSEMBLY		UNK		AEG Bilbao
81207743	MAIN FRAME AND STATOR ASSEMBLY		UNK		AEG Bilbao
81207799	NAMEPLATE		UNK		AEG Sevilla
90001201	Brake Assembly			32-45-12	AEG Sevilla
90001273	Anti-Skid Control Unit			32-48-56	AEG Sevilla
90005642	Main Wheel			32-41-44	AEG Sevilla
90005643	Brake			32-44-94	AEG Sevilla
90005613	Drive Cap			32-48-99	AEG Sevilla
90005664	A/S Control Unit			32-48-97	AEG Sevilla
114079001	ELECTRO-HYDRAULIC SELECTOR	SMITHS	A318,A321,A319,A320	32-31-34	AEG Sevilla
114079002	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A318,A321,A319,A320	32-31-34	AEG Sevilla
114079006	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A318,A321,A319,A320	32-31-34	AEG Sevilla
114079006	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A318,A321,A319,A320	32-31-34	AEG Sevilla
114079009	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A300,A318,A321,A319,A320	32-31-34	AEG Sevilla
114079010	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A318,A321,A319,A320	32-31-34	AEG Sevilla
114079012	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A300,A318,A321,A319,A320	32-31-34	AEG Sevilla
114079013	ELECTRO-HYDRAULIC SELECTORS	GEAVIATION	A300,A318,A321,A319,A320	32-31-34	AEG Sevilla
114079014	ELECTRO-HYDRAULIC SELECTORS	GEAVIATION	A318,A321,A319,A320	32-31-34	AEG Sevilla
114079016	ELECTRO-HYDRAULIC SELECTORS	MESSIER	A318,A321,A319,A320,A320-221	32-31-34	AEG Sevilla
114079016	SELECTOR-DOOR,ELECTRO-HYDRAULIC	MESSIER	A330,A318,A321,A319,A320,A320-221,A320-232	32-31-34	AEG Sevilla
114079017	ELECTRO-HYDRAULIC SELECTORS	MESSIER	A330,A318,A321,A319,A320,A320-232	32-31-34	AEG Sevilla
114079018	ELECTRO-HYDRAULIC SELECTORS	MESSIER	A330,A318,A321,A319,A320	32-31-34	AEG Sevilla
114079019	ELECTRO-HYDRAULIC SELECTORS	SMITHS	A330,A318,A321,A319,A320	32-31-25	AEG Sevilla
114087001	BYPASS VALVE	SMITHS	10, A330, A310, A300, A301, A310, A318, A320, A330,A310,A300,A321,A319,A318,A320	32-31-25	AEG Sevilla
114087002	BYPASS VALVE	SMITHS	10, A330, A310, A300, A301, A310, A318, A320, A330,A310,A300,A321,A319,A318,A320	32-31-25	AEG Sevilla
114087003	BYPASS VALVE	SMITHS	10, A330, A310, A300, A301, A310, A318, A320, A330,A310,A300,A321,A319,A318,A320	32-31-25	AEG Sevilla
114087004	BYPASS VALVE	GENERAL ELECTRIC	10, A330, A310, A300, A301, A310, A318, A320, A330,A310,A300,A321,A319,A318,A320	32-31-25	AEG Sevilla
114087006	BYPASS VALVE	GENERAL ELECTRIC	DC-10,A330,A321,A319,A318,A320-221,A320-232,A300	32-31-25	AEG Sevilla
114087006	BYPASS VALVE	GENERAL ELECTRIC	DC-10,A330,A321,A319,A318,A320-221,A320-232,A300	32-31-25	AEG Sevilla
114087007	BYPASS VALVE	GENERAL ELECTRIC	A330,A321,A319,A318,A320	32-31-25	AEG Sevilla
114087008	VALVE, BYPASS	MESSIER	A321,A319,A318,A320	32-31-25	AEG Sevilla
114087009	BYPASS VALVE	TRIUMPH ACTUATION SYSTEMS	A321,A320,A319,A318	32-31-25	AEG Sevilla
114087010	BYPASS VALVE	MESSIER SERVICES	A321,A320,A319,A318	32-11-21	AEG Sevilla
114095001	MLG LOCK STAY ACTUATOR	MESSIER SERVICES	F100,A318,A321,A319,A320	32-11-21	AEG Sevilla
114095002	LOCK STAY ACTUATOR	MESSIER SERVICES	A318,A321,A319,A320	32-11-21	AEG Sevilla
114095003	LOCK STAY ACTUATOR	MESSIER SERVICES	A318,A321,A319,A320	32-11-21	AEG Sevilla
114095004	LOCK STAY ACT.	MESSIER SERVICES	A330,A318,A321,A320-221,A320-232,A300,A310,A300,A321,A319,A318,A320	32-11-21	AEG Sevilla
114122002	MLG DOOR ACTUATOR	GE AVIATION	A340,A330,A310,A300,A321,A320,A319,A31	32-31-35	AEG Sevilla
114122003	MLG DOOR ACTUATOR	GE AVIATION	A340,A330,A310,A300,A321,A320,A319,A31	32-31-35	AEG Sevilla
114122004	MLG DOOR ACTUATOR	GE AVIATION	A340,A330,A310,A300,A321,A320,A319,A31	32-31-35	AEG Sevilla
114122006	MLG DOOR ACTUATOR	GE AVIATION SYSTEMS	A340,A330,A310,A300,A321,A320,A319,A31	32-31-35	AEG Sevilla
114122007	MLG DOOR ACTUATOR	GE AVIATION	A340,A330,A310,A300,A321,A320,A319,A31	32-31-35	AEG Sevilla
114122008	MLG DOOR ACTUATOR	GE AVIATION SYSTEMS	A340,A330,A310,A300,A321,A320,A319,A31	32-31-35	AEG Sevilla
114122009	MLG DOOR ACTUATOR	GE AVIATION SYSTEMS	A340,A330,A310,A300,A321,A320,A319,A318,A32	32-31-35	AEG Sevilla
114122010	MLG DOOR ACTUATOR	SMITHS	A340,A330,A310,A300,A321,A320,A319,A318,A32	32-31-35	AEG Sevilla
114122011	MLG DOOR ACTUATOR	GE AVIATION	A340,A330,A310,A300,A321,A320,A319,A31	32-31-35	AEG Sevilla
114122012	MLG DOOR ACTUATOR	GE AVIATION	A340,A330,A310,A300,A321,A320,A319,A31	32-31-35	AEG Sevilla
114193010	RETRACTION ACTUATOR	MESSIER - DOWTY	A318,A321,A319,A320	32	AEG Sevilla
114193637	RETRACTION ACTUATOR-PIN	SAFRAN	A321,A320,A319,A318,A320-221	32-31-84	AEG Sevilla
114265320	CYLINDER	SAFT	A340	24	AEG Bilbao
201042776	HOSE ASSEMBLY	K0654	A330/340		AEG Sevilla
201042777	HOSE ASSEMBLY	K0654	A330/340		AEG Sevilla
201042778	HOSE ASSEMBLY	K0654	A330		AEG Sevilla
201042880	HOSE ASSEMBLY	UNKNOWN	A330		AEG Sevilla
201042913	HOSE ASSEMBLY	K0654	A330		AEG Sevilla
201042914	HOSE ASSEMBLY	K0654	A330/340	32	AEG Sevilla
201042916	HOSE ASSY	K0654	A330		AEG Sevilla
201042977	HOSE ASSEMBLY	FAP92	A330/340		AEG Sevilla
201042998	HOSE ASSY	FAP92	A330/340		AEG Sevilla
201042201	HOSE ASSEMBLY	K0654	A320		AEG Sevilla
201042203	HOSE ASSY	FAP92	A330/340		AEG Sevilla
201042298	HOSE ASSEMBLY	K0654	A330		AEG Sevilla
201042322	HOSE ASSY	FAP92	A330/340		AEG Sevilla
201042669	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042670	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042676	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-86	AEG Sevilla
201042676	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-86	AEG Sevilla
201042677	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-86	AEG Sevilla
201042681	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-86	AEG Sevilla
201042687	BOGIE HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-87	AEG Sevilla
201042688	BOGIE HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-87	AEG Sevilla
201042689	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042690	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042633	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-81	AEG Sevilla
201042636	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-81	AEG Sevilla
201042636	W&B BOGIE HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-82	AEG Sevilla
201042637	W&B BOGIE HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-82	AEG Sevilla
201042640	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042641	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042642	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042643	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042644	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042646	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042646	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042647	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042669	BOGIE HARNESS	ULTRA ELECTRONICS PRECISION	A330-2000-3000	32-11-84	AEG Sevilla
201042660	BOGIE HARNESS	ULTRA ELECTRONICS PRECISION	A330-2000-3000	32-11-84	AEG Sevilla
201042661	W&B BOGIE HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-82	AEG Sevilla
201042662	W&B BOGIE HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-82	AEG Sevilla
201042670	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042671	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042681	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042682	STRUT HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-83	AEG Sevilla
201042694	W&B BOGIE HARNESS	SAFRAN LANDING	A330-2000-3000	32-11-82	AEG Sevilla

201042695	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Seville
201042726	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Seville
201042726	BOGIE HARNESS	ULTRA-ELECTRONICS	A330-200F-300	32-11-84	AEG Seville
201042727	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Seville
201042728	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Seville
201042731	BOGIE HARNESS	ULTRA-ELECTRONICS	A330-200F-300	32-11-84	AEG Seville
201042760	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042761	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042778	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042779	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042780	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042781	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042786	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042787	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042788	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042789	STRUT HARNESS	SAFRAN LANDING	A330-200F-300	32-11-83	AEG Seville
201042794	BOGIE HARNESS	ULTRA-ELECTRONICS	A330-200F-300	32-11-84	AEG Seville
201042795	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Seville
201042796	BOGIE HARNESS	ULTRA-ELECTRONICS	A330-200F-300	32-11-84	AEG Seville
201042797	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Seville
201042798	W&B BOGIE HARNESS	SAFRAN LANDING	A330-200F-300	32-11-82	AEG Seville
201064909	PIN LOCK STAY CARDAN	MESSIER DOWTY	A321A320A320-221	32-11-21	AEG Seville
201067304	TRIANGULATION LINK	MESSIER	A321A319A318A320	32	AEG Seville
201067311	UPPER PIN (SPRINGS)	MESSIER	A321A319A318A320	32	AEG Seville
201067623	CLIFF PIN	MESSIER	A321A319A318A320	32	AEG Seville
201067626	LOWER PIN (SPRINGS)	MESSIER	A321A319A318A320	32	AEG Seville
201067627	LOCK LINK LOWER PIN	MESSIER DOWTY	A321A319A318A320A320-221	32-11-39	AEG Seville
201067634	CLIFF	MESSIER	A321A319A318A320	32	AEG Seville
201067644	PIN (LOCK LINK/BANANA LINK)	MESSIER	A321A319A318A320	32	AEG Seville
201069001	LOCK SPRING	MESSIER DOWTY	B757A321A319A318A320-221A320	32-11-19	AEG Seville
20134007	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20134008	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20134016	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20134016	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20168001	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20168002	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20168003	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20168004	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20168007	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20168008	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169001	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169002	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169003	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169004	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169007	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169008	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20160331	MAIN FITTING (LH)	SAFRAN	A320		AEG Seville
20160332	MAIN FITTING (RH)	SAFRAN	A320		AEG Seville
20161001	DRESSING-MLG	MESSIER DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161002	DRESSING-MLG	MESSIER DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161003	DRESSING-MLG	MESSIER DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161004	DRESSING-MLG	MESSIER DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161006	LH MLG DRESSINGS	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161006	RH MLG DRESSING	MESSIER-DOWTY	A320	32-11-32	AEG Seville
20161007	DRESSING-MLG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161008	DRESSING-MLG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161009	LH MLG DRESSING	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161010	RH MLG DRESSINGS	MESSIER-DOWTY	A320	32-11-32	AEG Seville
20161011	DRESSING-MLG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161012	DRESSING-MLG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161013	DRESSING-MLG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161014	DRESSING-MLG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161015	DRESSING-MLG	MESSIER DOWTY	A321A319A318A320	32-11-24	AEG Seville
20161016	DRESSING-MLG	MESSIER DOWTY	A321A319A318A320	32-11-32	AEG Seville
20161616	BRACKET LH	MESSIER	A321A320A319A318		AEG Seville
20163001	BASIC SIDE STAY	MESSIER DOWTY	A321A319A318A320	32	AEG Seville
20163002	BASIC SIDE STAY	MESSIER DOWTY	A321A319A318A320	32	AEG Seville
20163003	BASIC SIDE STAY	MESSIER DOWTY	A321A319A318A320	32	AEG Seville
20163004	BASIC SIDE STAY	MESSIER DOWTY	A321A319A318A320-221A320	32	AEG Seville
20163309	CLIFF	MESSIER	A321A320A319A318		AEG Seville
20163605	UPPER CARDAN	MESSIER	A321A320A319A318		AEG Seville
20163609	SIDE STAY PIVOT PIN	MESSIER DOWTY	A321A319A318A320A320-221	32-11-38	AEG Seville
20163948	UPPER CARDAN	K0654	A320		AEG Seville
20163949	UPPER CARDAN	K0654	A320		AEG Seville
20169007	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169008	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169014	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169016	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169018	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169019	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169020	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169021	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20169022	HARNESSES - MAIN LANDING GEAR	MESSIER SERVICES	A321A319A318A320	32-11-43	AEG Seville
20172722	CABLE BONDING	MESSIER-DOWTY	A321A319A318A320	32	AEG Seville
20169699	TORQUE LINK APEX PIN NUT	SAFRAN	A330	32-12-02	AEG Seville
201727201	BOFIE ASSEMBLY	SAFRAN	A330	32-11-74	AEG Seville
201727203	BOGIE ASSEMBLY	#N/D	A330		AEG Seville
201727204	BOGIE ASSEMBLY	#N/D	A330		AEG Seville
201727248	BOGIE BEAM AND AXLE SUBASSEMBL	SAFRAN	A330	32-11-74	AEG Seville
201727696	LOCK BOLT, FWD PINTLE PIN	K0654	A330	32-12-02	AEG Seville
20171001	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20171002	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20171003	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20171004	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20171006	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20171006	RH MAIN LANDING GEAR	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20171008	MAIN LANDING GEAR LEG	MESSIER-DOWTY	A321A319A318A320	32-11-32	AEG Seville
20174001	MAIN LANDING GEAR	MESSIER	A320	32	AEG Seville
20174002	MAIN LANDING GEAR	MESSIER	A320	32	AEG Seville
20176001	MAIN LANDING GEAR	MESSIER	A321A319A318A320	32-11-32	AEG Seville
20176002	MAIN LANDING GEAR	MESSIER	A321A319A318A320	32-11-32	AEG Seville
20176003	MAIN LANDING GEAR	MESSIER	A321A320A319A318	32-11-32	AEG Seville
20176004	MAIN LANDING GEAR	MESSIER	A321A319A318A320	32-11-32	AEG Seville
20176005	MAIN LANDING GEAR	MESSIER	A321A319A318A320	32-11-32	AEG Seville
20176006	MAIN LANDING GEAR	MESSIER	A321A319A318A320	32-11-32	AEG Seville
20176007	MAIN LANDING GEAR	MESSIER DOWTY	A321A319A318A320	32-11-32	AEG Seville
20176008	R/H MAIN LDG	MESSIER DOWTY	A321A319A318A320	32-11-32	AEG Seville
20176009	MAIN LANDING GEAR ASSY	MESSIER DOWTY	A321A319A318A320	32-11-32	AEG Seville
20176010	MLG RH	MESSIER DOWTY	A321A319A318A320	32-11-32	AEG Seville
20176062	R/H MLG LEG ASSY	K0654	A320		AEG Seville
20176001	MAIN LANDING GEAR	MESSIER DOWTY	A319A318A320	32	AEG Seville
20176002	MAIN LANDING GEAR	MESSIER-DOWTY	A319A318A320	32-11-32	AEG Seville
20183001	MAIN LANDING GEAR LEG	MESSIER	A321	32-11-83	AEG Seville
20183002	MAIN LANDING GEAR LEG	MESSIER	A321	32-11-83	AEG Seville
20183304	Cardan bracket (LH)	SAFRAN	A320		AEG Seville
20183306	Cardan Bracket (RH)	SAFRAN	A320		AEG Seville
20183604	Upper torque link pin	MESSIER	A321A320A319A318	32	AEG Seville
20183606	LOWER TORQUE LINK PIN	MESSIER	A321A320A319A318	32	AEG Seville
20183628	FORWARD PINTLE PIN LOCK BOLT	MESSIER	A321A320A319A318		AEG Seville

201387001	MLG LEG AND DRESSINGS	AIRBUS	A321	32	AEG Seville
201387002	MLG LEG AND DRESSINGS	AIRBUS	A321	32	AEG Seville
201388001	MAIN LANDING GEAR INST.L	UNKNNOOWN	A321	32-11-81	AEG Seville
201388002	R/H MAIN LANDING GEAR INTLL	UNKNNOOWN	A321	32-11-81	AEG Seville
201389001	SIDE STAY BASIC	UNKNNOOWN	A320	32-11-86	AEG Seville
201390001	SIDE STAY COMPLETE	MESSIER	A321	32	AEG Seville
201390002	SIDE STAY COMPLETE	MESSIER-DOWTY	A321	32-11-85	AEG Seville
201399001	LEG HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-88	AEG Seville
201399002	LEG HARNESS	MESSIER-BUGATTI-DOWTY	A320,A321	32-11-88	AEG Seville
201399003	LEG HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-88	AEG Seville
201399004	LEG HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-82	AEG Seville
201399006	HARNESS IM AND 2M	ULTRA ELECTRONICS	A319,A318,A320	32	AEG Seville
201399006	HARNESS IM AND 2M	SAFRAN	A320	32-12-11	AEG Seville
201400001	LEG HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-82	AEG Seville
201400002	LEG HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-82	AEG Seville
201400003	HARNESS IM AND 2M	ULTRA ELECTRONICS	A319,A318,A320	32-11-45	AEG Seville
201400004	HARNESS IM AND 2M	ULTRA ELECTRONICS	A319,A318,A320	32-11-45	AEG Seville
201402001	AXLE HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-11	AEG Seville
201402002	AXLE HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-11	AEG Seville
201402001	2M AXLES ENHANCED HARNESS	MESSIER-DOWTY	A321,A319,A318,A320	32	AEG Seville
201402002	AXLE HARNESS IM AND 2M	SAFRAN	A320	32	AEG Seville
201402003	AXLE HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-89	AEG Seville
201402004	AXLE HARNESS	MESSIER-BUGATTI-DOWTY	A320	32-11-89	AEG Seville
201402006	MAIN LDG & AXLE HARNESS	ULTRA ELECTRONICS	A320	32-11-44	AEG Seville
201402006	MAIN LDG & AXLE HARNESS	ULTRA ELECTRONICS	A320	32-11-44	AEG Seville
201402007	AXLE HARNESS IM AND 2M	SAFRAN	A320	32	AEG Seville
201403500	LOWER LOCK LINK	MESSIER	A321,A320,A319,A318		AEG Seville
201419001	DAMPER	MESSIER SERVICES	B757,A318,A321,A319,A320,B747	32-11-93	AEG Seville
201414102	UPPER SPRING BRACKET	K0654	A330	32-11-91	AEG Seville
201414104	LOWER SPRING BRACKET	SAFRAN	A330	32-11-91	AEG Seville
201414101	WASHER	FAF92	A330		AEG Seville
201442606	CONNECTING LINK	SAFRAN	A330	32-11-92	AEG Seville
201442609	PIVOT LINK	SAFRAN	A330	32-11-92	AEG Seville
201442613	LOWER SPRING/PIVOT LINK PIN	SAFRAN	A330	32-11-92	AEG Seville
201442616	CONNECTING LINK/PIVOT LINK PIN	SAFRAN	A330	32-11-92	AEG Seville
201442633	CONNECTING LINK/LOCK LINK UPPE	SAFRAN	A330	32-11-92	AEG Seville
201442661	PIVOT LINK CENTER PIN	SAFRAN	A330	32-11-90	AEG Seville
201480002	BOGIE PITCH TRIMMER	#N/D	A330		AEG Seville
201481001	UNLOCK ACTUATOR	MESSIER-DOWTY LANDING GEAR	A340,A330	32	AEG Seville
201482001	LOCK LINK	MESSIER-DOWTY	A330	32-12-08	AEG Seville
201482306	LOWER LOCK LINK	SAFRAN	A330	32-12-08	AEG Seville
201482609	LOCK LINK/SIDE STAY PIN	MESSIER-DOWTY	A330	32-12-06	AEG Seville
201483001	SIDE STAY	MESSIER-DOWTY	A330	32-12-07	AEG Seville
201483214	BRACKET ASSEMBLY	SAFRAN	A330	32-12-07	AEG Seville
201484001	SIDE STAY LH	HONEYWELL	A330	32-12-06	AEG Seville
201484002	SIDE STAY RH	NONE SPECIFIED	A330	32-12-06	AEG Seville
201484606	BRACKET SINGLE TARGET	SAFRAN	A330	32-12-06	AEG Seville
201485001	BOGIE ASSEMBLY	#N/D	A330		AEG Seville
201487001	SHOCK STRUT	MESSIER-DOWTY	A330	32-12-03	AEG Seville
201487214	PISTON ASSY	SAFRAN	A330	32-12-03	AEG Seville
201487216	PISTON SLIDING	SAFRAN	A330	32-12-03	AEG Seville
201487219	PISTON SLIDING	SAFRAN	A330	32-12-03	AEG Seville
201487300	SLIDING PISTON	MESSIER	A330	32-11-96	AEG Seville
201487307	SLIDING PISTON	MESSIER	A330	32-11-96	AEG Seville
201487309	PISTON SLIDING	MESSIER	A330	32-11-96	AEG Seville
201488002	RH MAIN STRUT	SAFRAN	A330		AEG Seville
201488204	LINK SUBASSEMBLY, LOWER	MESSIER-DOWTY	A330	32-12-02	AEG Seville
201488337	MAIN FITTING (LH)	SAFRAN	A330	32-12-02	AEG Seville
201488660	PIN SM9	MESSIER-DOWTY	A330	32-12-02	AEG Seville
201488661	PIN SM8	MESSIER-DOWTY	A330	32-12-02	AEG Seville
201489242	SLEEVE SUBASSEMBLY LUBRICATION	K0654	A330	32-12-02	AEG Seville
201489304	LOWER TORQUE LINK	SAFRAN	A330	32-12-02	AEG Seville
201489780	ROLLER, UPLOCK	K0654	A330	32-11-71	AEG Seville
201820001	MAIN LDG & AZLE HARNESS	MESSIER SERVICES	A318,A320	32-11-44	AEG Seville
201820002	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A319,A318,A320	32,32-11-11,32-11-11	AEG Seville
201820003	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A318,A320	32,32-11-11,32-11-11	AEG Seville
201820004	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A319,A318,A320	32,32-11-11,32-11-11	AEG Seville
201820006	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A330,A319,A320	32,32-11-11,32-11-11	AEG Seville
201820006	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A330,A319,A320	32,32-11-11,32-11-11	AEG Seville
201820007	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A330,A319,A320	32,32-11-11,32-11-11	AEG Seville
201820008	MAIN LDG & AXLE HARNESS	MESSIER SERVICES	A321,A330,A319,A320	32,32-11-11,32-11-11	AEG Seville
201821001	MAIN LANDING GEAR COMPLETE	UNKNNOOWN	A318	32	AEG Seville
201821002	MAIN LANDING GEAR COMPLETE	UNKNNOOWN	A318	32	AEG Seville
201821003	MAIN LANDING GEAR COMPLETE	SAFRAN	A321	32	AEG Seville
201821004	MAIN LANDING GEAR COMPLETE	SAFRAN	A321	32	AEG Seville
201822001	MAIN LANDING GEAR LEG	SAFRAN	A321,A320	32	AEG Seville
201822002	MAIN LANDING GEAR LEG	SAFRAN	A321,A320	32	AEG Seville
201822003	MAIN LANDING GEAR LEG	SAFRAN	A321,A320	32	AEG Seville
201822004	MAIN LANDING GEAR LEG	SAFRAN	A321,A320	32	AEG Seville
201822300	MAIN FITTING (LH)	K0654	A320		AEG Seville
201822301	MAIN FITTING (RH)	K0654	A320		AEG Seville
201822302	UPPER TORQUE LINK	K0654	A320		AEG Seville
201822303	LOWER TORQUE LINK	K0654	A320		AEG Seville
201822340	MAIN FITTING (RH)	K0654	A320		AEG Seville
201822600	FORWARD PNTLE PIN	MESSIER	A321,A320,A319,A318	32-12-22	AEG Seville
201823001	MLG LEG AND DRESSINGS	AIRBUS	A320,A321	29	AEG Seville
201823002	RH MLG	AIRBUS	A320,A321	32	AEG Seville
201823003	MAIN LANDING GEAR LEG AND DRES	AIRBUS	A320,A321	32	AEG Seville
201823004	MAIN LANDING GEAR LEG AND DRES	AIRBUS	A320,A321	32	AEG Seville
201824001	STAY ASSY-SIDE.MLG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Seville
201824002	STAY ASSY-SIDE.MLG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Seville
201826001	STAY-SIDE	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Seville
201826300	UPPER SIDE STAY	MESSIER	A321,A320,A319,A318		AEG Seville
201826301	LOWER SIDE STAY	MESSIER	A321,A320,A319,A318		AEG Seville
201826302	LOWER CARDAN	MESSIER	A321,A320,A319,A318	32-12-14	AEG Seville
201831001	STAY-LOCK	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Seville
201831600	UPPER LOCK LINK	MESSIER	A321,A320,A319,A318		AEG Seville
201820003	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A319,A318,A320	32	AEG Seville
201820004	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A319,A318,A320	32	AEG Seville
201820006	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A319,A318,A320	32	AEG Seville
201820007	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A320,A319,A318	32-12-24	AEG Seville
201820008	MAIN LANDING GEAR LEG AND DRES	MESSIER DOWTY	A321,A320,A319,A318	32-12-24	AEG Seville
201840001	LH MLG GEAR COMPLETE	MESSIER DOWTY	A321	32-12-20	AEG Seville
201840002	RH MLG GEAR COMPLETE	MESSIER DOWTY	A321	32-12-20	AEG Seville
201887001	MAIN LANDING GEAR LEG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Seville
201887002	MAIN LANDING GEAR LEG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Seville
201887003	MAIN LANDING GEAR LEG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Seville
201887004	MAIN LANDING GEAR LEG	MESSIER DOWTY	A321,A320,A319,A318	32	AEG Seville
201887303	UPPER TORQUE LINK	MESSIER	A321,A320,A319,A318		AEG Seville
201887304	LOWER TORQUE LINK	MESSIER	A321,A320,A319,A318		AEG Seville
201887602	FORWARD PNTLE PIN STUB BOLT	MESSIER	A321,A320,A319,A318	32-12-22	AEG Seville
201887608	FORWARD PNTLE PIN STUB BOLT	MESSIER	A321,A320,A319,A318	32	AEG Seville
201887610	FORWARD PNTLE PIN STUB BOLT	MESSIER	A321,A320,A319,A318	32	AEG Seville
201887611	FORWARD PNTLE PIN STUB BOLT	MESSIER	A321,A320,A319,A318	32	AEG Seville
201890001	RETRACTION ACTUATOR	MESSIER SERVICES	A330,A321,A320,A319,A318	32-31-86	AEG Seville
201890002	RETRACTION ACTUATOR	MESSIER SERVICES	L-1011,A321,A320,A319,A318	32-31-86	AEG Seville
201890003	RETRACTION ACTUATOR	MESSIER SERVICES	A330,B767,B757,A321,A320,A319,A318	32-31-86	AEG Seville
201890004	RETRACTION ACTUATOR	MESSIER DOWTY	A321,A319,A318,A320	32-31-86	AEG Seville
201890906	CYLINDER	MESSIER - DOWTY	A321,A320,A319,A318	32-31-86	AEG Seville

201890909	PISTON	MESSIER	A321A319,A318,A320-221A320	32-31-86	AEG Seville
201890910	NUT	MESSIER	A321A319,A318,A320-221A320	32-31-86	AEG Seville
201890913	GLAND	MESSIER	A321A319,A318,A320-221A320	32-31-86	AEG Seville
201656166	BOGIE HARNESS	ULTRA ELECTRONICS	A330-200J-300	32-11-84	AEG Seville
201656176	BOGIE HARNESS	ULTRA ELECTRONICS	A330-200J-300	32-11-84	AEG Seville
201659001	MAIN LANDING GEAR	MESSIER DOWTY	A321	32-12-20	AEG Seville
201659002	MAIN LANDING GEAR	MESSIER DOWTY	A321	32-12-20	AEG Seville
201659003	MAIN LANDING GEAR COMPLETE	SAFRAN	A321		AEG Seville
201659004	MAIN LANDING GEAR COMPLETE	SAFRAN	A321		AEG Seville
201661001	SIDE STAY COMPLETE	MESSIER DOWTY	A321A320,A319,A318	32	AEG Seville
201661001	STAY-SIDE	MESSIER DOWTY	A321A320,A319,A318	32	AEG Seville
201661300	UPPER SIDE STAY	MESSIER	A321A320,A319,A318		AEG Seville
201661301	LOWER SIDE STAY	MESSIER	A321A320,A319,A318	32	AEG Seville
201661302	CUFF	MESSIER	A321A320,A319,A318		AEG Seville
201661304	BANANA LINK	MESSIER	A321A320,A319,A318		AEG Seville
201661601	SIDE STAY PIVOT PIN	MESSIER	A321A320,A319,A318		AEG Seville
201661602	CUFF	MESSIER	A321A320,A319,A318		AEG Seville
201661603	SIDE STAY LOWER CARDAN PIN	MESSIER	A321A320,A319,A318		AEG Seville
201661610	UPPER CARDAN NUT	MESSIER	A321A320,A319,A318		AEG Seville
201661611	LOWER CARDAN NUT	MESSIER	A321A320,A319,A318		AEG Seville
201661613	CUFF	MESSIER	A321A320,A319,A318		AEG Seville
201676201	ROLLER SUBASSEMBLY UPLOCK	KO654	A330	32-11-71	AEG Seville
400070000	Manual Selector Landing Gear Valve			32-30-01	AEG Seville
400070000	Manual Bypass Valve			32-30-02	AEG Seville
499008003	Feathering Pump			61-21-24	AEG Seville
760004000	Manual Bypass & Runaround Valve			32-30-03	AEG Seville
760006000	NLG Selector Valve			32-30-05	AEG Seville
760004000	NLG Selector Valve			32-30-04	AEG Seville
860186002	Accumulator				AEG Seville
860186002	Accumulator, 75 Cubic Inch			32-41-04	AEG Seville
860186004	Accumulator, 75 Cubic Inch			32-41-04	AEG Seville
860190003	Accumulator				AEG Seville
860197001	Accumulator			32-40-10	AEG Seville
860199001	Accumulator				AEG Seville
860204001	Accumulator			32-40-09	AEG Seville
860206001	Accumulator				AEG Seville
860207001	Accumulator				AEG Seville
860218001	Accumulator				AEG Seville
860219001	Accumulator				AEG Seville
8701000000	REP Y CALIBRACION EQ MEDIDA		UNK		AEG Seville
2,98038E+12	Lavatory Water Faucet			38-11-04	AEG Seville
2,98038E+12	Lavatory Water Faucet			38-11-04	AEG Seville
2,98038E+12	Lavatory Water Faucet			38-11-04	AEG Seville
3,6E+86	STARTER	ALLIED SIGNAL	C-130		AEG Seville
2,8E+100	Oil Cooler-Heat Exchanger Assembly			79-20-11	AEG Seville
0089-0008-3	Nipple Check Valve			80-00-04	AEG Seville
0071-0007-3	Fitting Nipple Assembly			38-11-01	AEG Seville
018389-02	Water Level And Monitoring System			38-18-03	AEG Seville
01848E-2	Fan Inlet Temperature Transmitter (T2)		CF34-8C,CF34-8E	74-32-00	AEG Seville
018700-000	Ni-Cd Aircraft Battery 1656	SAFT	ATR 72,ATR 42	24	AEG Seville
018838-01	Water Level And Monitoring System			38-18-03	AEG Seville
018839-01	Water Level And Monitoring System			38-18-03	AEG Seville
018840-01	Water Level And Monitoring System			38-18-03	AEG Seville
018840-02	Water Level And Monitoring System			38-18-03	AEG Seville
017444-000	Ni-Cd Aircraft Battery 16156	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
018090-000	Ni-Cd Aircraft Battery 16156-1	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
018718-000	Ni-Cd Aircraft Battery 4078	SAFT	ATR 72,ATR 42	24	AEG Seville
018804-000	Ni-Cd Aircraft Battery 2376-4	SAFT	A320	24	AEG Seville
018962-000	Ni-Cd Aircraft Battery 23576-1	SAFT	A300	24	AEG Seville
019600-000	Ni-Cd Aircraft Battery 4076-12	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
019613-000	Ni-Cd Aircraft Battery 4071-2	SAFT	A320	24	AEG Seville
019616-000	Ni-Cd Aircraft Battery 401076	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
019654-000	Ni-Cd Aircraft Battery 40253	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
020413-000	Ni-Cd Aircraft Battery 12277-2	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
020678-000	Ni-Cd Aircraft Battery 4078-6	SAFT	A320	24	AEG Seville
0218-0032-1through10	4-Inch Waste System Drain Valve			38-37-10	AEG Seville
021937-000	Ni-Cd Aircraft Battery 4078-9	SAFT	A320	24	AEG Seville
022019-000	Ni-Cd Aircraft Battery 4078-10	SAFT	Embraer A320	24	AEG Seville
023167-000	Ni-Cd Aircraft Battery 4078-14	SAFT	A320,B737	24	AEG Seville
023322-000	Ni-Cd Aircraft Battery 4076-13	SAFT	A320	24	AEG Seville
023470-000	Ni-Cd Aircraft Battery 1756	SAFT	Ball		AEG Seville
023476-000	Ni-Cd Aircraft Battery M8175719- 2	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
023498-000	Ni-Cd Aircraft Battery 23676-2	SAFT	A320	24	AEG Seville
023626-000	Ni-Cd Aircraft Battery 23576-2	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
023663-000	Ni-Cd Aircraft Battery 40576-14	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
023694-000	Ni-Cd Aircraft Battery 4078-19	SAFT	B737	24	AEG Seville
023773-000	Ni-Cd Aircraft Battery 2386-1	SAFT	A320,MD-90	24	AEG Seville
023789-000	Ni-Cd Aircraft Battery 4070CH-1	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
023828-000	Ni-Cd Aircraft Battery 2376-10	SAFT	Sikorsky A320	24-31-07	AEG Seville
024227-000	Ni-Cd Aircraft Battery 4018CH1	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
024470-000	Ni-Cd Aircraft Battery 27578-2	SAFT	A320	24	AEG Seville
024656-000	Ni-Cd Aircraft Battery 4076-15	SAFT	Bel A320		AEG Seville
024904-000	Ni-Cd Aircraft Battery 44170H4	SAFT	B737	24	AEG Seville
024947-000	Ni-Cd Aircraft Battery 4070CH9	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
025654-000	Ni-Cd Aircraft Battery 5512CH1	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
025776-000	Ni-Cd Aircraft Battery 4371CH4	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
026897-000	Ni-Cd Aircraft Battery 176CH	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
026899-000	Ni-Cd Aircraft Battery 438CH2	SAFT	VARIOUS AIRCRAFTS	24	AEG Seville
026930-000	Ni-Cd Aircraft Battery 4371CH1		VARIOUS AIRCRAFTS		AEG Seville
026101-11	DRIVE SHAFT	NONE SPECIFIED			AEG Seville
02-6101-11	DRIVE SHAFT	FLIGHT INDUSTRIES		33	AEG Seville
03-6101-13	DRIVE SHAFT	FLIGHT INDUSTRIES		33-49-20	AEG Seville
04-1606-1429	STROBE LIGHT P5	BRUCE INDUSTRIES	ATR 42,ATR 72		AEG Seville
0514RJ81	Relay Junction Box			24-50-01	AEG Seville
0656-11	DC GEAR MOTOR				AEG Bilbao
0618910G	ADAPTER BELL OUTPUT BAL ASSY				AEG Bilbao
0623006D	ADAPTER BELL OUTPUT BAL ASSY				AEG Bilbao
064-01064-30	VHF COMMUNICATIONS TRANSCIVERS	WULFSBERG		23	AEG Seville
064-1016-01	KTR 953 Receiver / Exciter			23-20-08	AEG Seville
064-1016-X	KCU 951 Control Unit			23-20-04	AEG Seville
064-1017-X	KAC 952 POWER Amplifier / Antenna Coupler			23-20-07	AEG Seville
064-1047-61	RECEIVER, TRANSMITTER	TRONAIR			AEG Seville
06-6010-6600	ENGINE OIL SERVICE UNIT		CN-235		AEG Seville
066-01066-SERIES	RDM JDS A DISTANCES MEASURING EQUIPMENT	KING		34	AEG Seville
066-01067-0000	RADAR RECEIVER				AEG Seville
066-03063	K1227 ADF INDICATOR				AEG Seville
066-03063-SERIES	K1227 ADF INDICATOR	KING RADIO		KMA24H	AEG Seville
066-1093-SERIES	RDM JDS A DISTANCES MEASURING EQUIPMENT	KING		34,N/A	AEG Seville
066-3069-00	INDICATOR ADF	KING			AEG Seville
069-1024	VHF NAV/COMM TRANSCIVER				AEG Seville
069-1026	VHF NAV/COMM TRANSCIVER				AEG Seville
0711480-001	VALVE, SHUTOFF HYDRAULIC	ARKWIN INDUSTRIES	A340,A320	78	AEG Seville
0711480-003	VALVE, SHUTOFF HYDRAULIC	ARKWIN INDUSTRIES	A340,A320	78	AEG Seville
0711480-004	VALVE, SHUTOFF HYDRAULIC		A340,A320		AEG Seville
080-20710-01	Windshield Heat Controller			30-40-03	AEG Seville
08-60162	Cubic Inch Accumulator			32-40-11	AEG Seville
0860163001V002	Accumulator				AEG Seville
0860164001V002	Accumulator- Hydraulic System #3				AEG Seville
0871818	Ice Detector		CRJ-700,CRJ900 Regional Jet-900	30-81-29	AEG Seville

087HY6	Ice Detector		CRJ-700,CRJ900 Regional Jet-900	30-80-01	AEG Seville
09-TI46-63	TM-400 Trim Servo Assembly				AEG Seville
100-0221-01	Battery Charger 100-0221-01		600-2819,Challenger 601,Challenger 400,CRJ-700,CRJ-900 CRJ-1 Regional Jet	24-35-02	AEG Seville
100-0221-02	Battery Charger		600-2819,Challenger 601,Challenger 400,CRJ-700,CRJ-900 Regional Jet	24-32-06	AEG Seville
10-0066	EMERGENCY EXIT LIGHT	GRIMES / HONEYWELL			AEG Seville
10-0066 SERIES	EMERGENCY EXIT LIGHT	GRIMES		33-50-28	AEG Seville
10-0066-1	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230,Dash 8	33-50-28	AEG Seville
10-0066-11	LIGHT, EMERGENCY	GRIMES	C-295,CN-235,Dash 8	33-50-28	AEG Seville
10-0066-13	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-16	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-17	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-19	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-21	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-23	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-25	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-3	LIGHT, EMERGENCY	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-6	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-7	EMERGENCY EXIT LIGHT	GRIMES	DHC8,CN-235,C-295,230	33-50-28	AEG Seville
10-0066-9	EMERGENCY EXIT LIGHT	SAFT	DHC8,CN-235,C-295,230	24	AEG Seville
1-002-0102-1652	SERIES LIGHT DIMMER	SIMMONDS	8777,8747,8737	28	AEG Seville
10-0341	Closest Light			33-30-06	AEG Seville
10-0341-1	Closest Light		8767,8747,8777,8767	33-30-06	AEG Seville
10-0341-13	Closest Light		8747,8777,8767,8767	33-30-06	AEG Seville
10-0341-16	Closest Light		8767,8767,8747,8777	33-30-06	AEG Seville
10-0341-3	Closest Light		8767,8747,8777,8767	33-30-06	AEG Seville
10-0341-6	Closest Light		8747,8767,8767,8777	33-30-06	AEG Seville
10-0341-7	Closest Light		8767,8767,8747	33-30-06	AEG Seville
10-0661-11	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-12	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-13	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-14	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-16	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-16	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-17	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-18	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-19	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-1VA38	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-20	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-21	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-3	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-4	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-5	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-6	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-7	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-8	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0661-9	Baggage Door Warning Sign			33-29-26	AEG Seville
10-0488	Floodlight			33-23-04	AEG Seville
10-0488-1	Floodlight			33-23-04	AEG Seville
10-0488-11	Floodlight			33-23-04	AEG Seville
10-0488-13	Floodlight			33-23-04	AEG Seville
10-0488-16	Floodlight			33-23-04	AEG Seville
10-0488-17	Floodlight			33-23-04	AEG Seville
10-0488-19	Floodlight			33-23-04	AEG Seville
10-0488-21	Floodlight			33-23-04	AEG Seville
10-0488-23	Floodlight			33-23-04	AEG Seville
10-0488-27	Floodlight			33-23-04	AEG Seville
10-0488-29	Floodlight			33-23-04	AEG Seville
10-0488-3	Floodlight			33-23-04	AEG Seville
10-0488-6	Floodlight			33-23-04	AEG Seville
10-0488-7	Floodlight			33-23-04	AEG Seville
10-0488-9	Floodlight			33-23-04	AEG Seville
10079-01	LOAD SELECT CONTROL UNIT		8767-300,8767-200,8767,8767,8747-400		AEG Seville
101-000-137	RECEIVER, RADIO	SAFRAN LANDING			AEG Seville
10-100101-014	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-016	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-023	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-024	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-026	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-026	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-027	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-028	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-029	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-030	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-031	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-032	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-033	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-034	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-036	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-036	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-037	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-038	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-039	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-040	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-041	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100101-042	GEAR-NOSE LANDING	SAFRAN			AEG Seville
10-100102	NOSE LANDING GEAR	SAFRAN			AEG Seville
10-100102-001	NOSE LANDING GEAR (WV10)	SAFRAN			AEG Seville
10-100102-002	NOSE LANDING GEAR (WV10)	SAFRAN			AEG Seville
10-100102-003	NOSE LANDING GEAR (WV10)	SAFRAN			AEG Seville
10-100102-004	NOSE LANDING GEAR (WV10)	SAFRAN			AEG Seville
10-100102-006	NOSE LANDING GEAR (WV10)	SAFRAN			AEG Seville
10-100102-006	NOSE LANDING GEAR (WV10)	SAFRAN			AEG Seville
10-100102-007	NOSE LANDING GEAR	SAFRAN LANDING			AEG Seville
10-100103-000	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-001	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-002	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-003	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-004	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-006	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-006	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-007	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-008	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-009	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-010	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-011	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-012	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-013	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-014	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-016	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-016	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-017	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-018	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-019	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-020	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-021	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-022	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-023	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-024	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville
10-100103-026	GEAR-NOSE LANDING	SAFRAN LANDING			AEG Seville

10-10103-026	GEAR-NOSE LANDING				AEG Seville
10103-04-01	MECHANISM ASSY	SAFRAN	UNK		AEG Seville
10-101001	2M UPPER HARNESS	SAFRAN	A340	32-09-91	AEG Seville
10-101001-003	HARNESS, 2M UPPER	SAFRAN	A340	32-09-91	AEG Seville
10-101001-004	HARNESS, 2M UPPER	SAFRAN	A340	32-09-91	AEG Seville
10-101001-006	HARNESS, 2M UPPER	MESSIER-BUGATTI- DOWNTY-ERCA-MIL-KRAL	A340	32-09-92	AEG Seville
10-10101	1M LOWER ELECTRICAL HARNESS	SAFRAN	A340	32-09-92	AEG Seville
10-10101-000	HARNESS, 1M LOWER ELECTRICAL	GRIMES	A340	335036	AEG Seville
10-1014-1	INTERIOR ILLUMINATED EMERGENCY EXIT	GRIMES	UNK	335036	AEG Seville
10-1014-3	INTERIOR ILLUMINATED EMERGENCY EXIT	GRIMES	UNK	335036	AEG Seville
10-1014-5	INTERIOR ILLUMINATED EMERGENCY EXIT	GRIMES	UNK	335036	AEG Seville
10-1014-7	INTERIOR ILLUMINATED EMERGENCY EXIT	SAFRAN	UNK		AEG Seville
10-101702-000	UPPER DRAG STAY	SAFRAN	A340		AEG Seville
10-101902	LOCK LINK	SAFRAN	A340		AEG Seville
10-101902-000	LOCK LINK	MESSIER-DOWTY SA	A340	32-33-41	AEG Seville
10-102001-001	UNLOCKING ACTUATOR	SAFRAN	A340		AEG Seville
10-102101-000	DOWNLOCK SPRING	SAFRAN	A340		AEG Seville
10-102701-002	RETRACTION ACTUATOR ASSEMBLY	SAFRAN	A340		AEG Seville
10-102701-003	RETRACTION ACTUATOR ASSEMBLY	SAFRAN	A340		AEG Seville
10-102701-004	RETRACTION ACTUATOR ASSEMBLY	MESSIER-DOWTY SA	A340	32	AEG Seville
10-102701-005	RETRACTION ACTUATOR ASSEMBLY	SAFRAN	A340		AEG Seville
10-103002	TOWING FITTING	SAFRAN	A340		AEG Seville
10-103002-000	TOW FITTING	SAFRAN	A340		AEG Seville
10-103002-001	TOW FITTING	SAFRAN	A340		AEG Seville
10-103301-003	HARNESS, NLG LEFT GS ANTENNA	SAFRAN	A340		AEG Seville
10-103301-004	HARNESS, NLG LEFT GS ANTENNA	SAFRAN	A340		AEG Seville
10-103601-003	HARNESS, NLG RIGHT GS ANTENNA	SAFRAN	A340		AEG Seville
10-103601-004	HARNESS, NLG RIGHT GS ANTENNA		A340		AEG Seville
101-0400	Pilot's Guide (Optional)			TP101	AEG Seville
101-0401	Pilot's Guide (Optional)			TP101	AEG Seville
101-0402	Pilot's Guide (Optional)			TP101	AEG Seville
1010630 SERIES	CYLINDRAL HYD PRESS ACCUM	SAFRAN	UNK		AEG Seville
101-0600	Pilot's Guide (Optional)			TP101	AEG Seville
101-0601	Pilot's Guide (Optional)			TP101	AEG Seville
101-0603	Pilot's Guide (Optional)			TP101	AEG Seville
10-1081-1	Passenger Service Unit			33-20-34	AEG Seville
10-1081-11	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-12	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-1M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-2	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-2M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-3	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-3M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-4	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-4M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-5	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-6M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-6	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-6M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-7	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-7M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-8	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1081-8M	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-34	AEG Seville
10-1096-01	Pneumatic Detector		A320		AEG Seville
10-1096-02	Pneumatic Detector		A320		AEG Seville
10-1097-01	Pneumatic Detector				AEG Seville
10-1097-02	Pneumatic Detector		A320		AEG Seville
10-1098	Pneumatic Detector				AEG Seville
10-1099	Pneumatic Detector		A320		AEG Seville
10-110105	CENTER LANDING GEAR	SAFRAN	A340		AEG Seville
10-110105-002	CENTER LANDING GEAR	SAFRAN	A340		AEG Seville
10-110105-003	CENTER LANDING GEAR	SAFRAN	A340		AEG Seville
10-110105-004	CENTER LANDING GEAR	SAFRAN	A340		AEG Seville
10-110105-005	CENTER LANDING GEAR	SAFRAN	A340		AEG Seville
10-110105-006	CENTER LANDING GEAR	SAFRAN	A340		AEG Seville
10-110105-007	CENTER LANDING GEAR	SAFRAN	A340		AEG Seville
10-110105-008	CENTER LANDING GEAR	SAFRAN	A340		AEG Seville
10-110105-009	CENTER LANDING GEAR	SAFRAN	A340		AEG Seville
10-110207	MAIN FITTING SHOCK ABSORBER, S	SAFRAN	A340		AEG Seville
10-110207-002	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Seville
10-110207-003	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Seville
10-110207-004	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Seville
10-110207-005	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Seville
10-110207-006	MAIN STRUT AND DRESSINGS	SAFRAN	A340		AEG Seville
10-110302	DRAG STAY COMPLETE	SAFRAN	A340		AEG Seville
10-110302-000	DRAG STAY COMPLETE	SAFRAN	A340		AEG Seville
10-110501-006	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-007	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-014	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-015	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-016	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-017	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-018	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-019	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-020	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-021	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110501-022	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110602-000	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110602-001	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110602-002	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110602-003	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110602-004	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110602-006	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110603	MAIN FITTING SHOCK ABSORBER ST	SAFRAN	A340		AEG Seville
10-110604	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110604-001	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110604-002	MAIN FITTING SHOCK ABSORBER	SAFRAN	A340		AEG Seville
10-110604-003	MAIN FITTING SHOCK ABS STRUCTU	SAFRAN	A340		AEG Seville
10-110604-004	MAIN FITTING SHOCK ABS STRUCTU	SAFRAN	A340		AEG Seville
10-110604-103	MAIN FITTING SHOCK ABS STRUCTU	SAFRAN	A340		AEG Seville
10-110604-104	MAIN FITTING SHOCK ABS STRUCTU	SAFRAN	A340		AEG Seville
10-110607	MAIN FITTING SHOCK ABSORBER ST	SAFRAN	A340		AEG Seville
10-110605	MAIN FITTING SHOCK ABSORBER DR	SAFRAN	A340		AEG Seville
10-110605-001	MAIN FITTING SHOCK ABS DRESSIN	SAFRAN	A340		AEG Seville
10-110605-002	MAIN FITTING SHOCK ABS DRESSIN	SAFRAN	A340		AEG Seville
10-110803	BOGIE BEAM DRESSING	SAFRAN	A340		AEG Seville
10-110803-000	BOGIE BEAM DRESSING	SAFRAN	A340		AEG Seville
10-110803-001	BOGIE BEAM DRESSING	SAFRAN	A340		AEG Seville
10-111102	LOCK LINK	SAFRAN	A340		AEG Seville
10-111102-000	LOCK LINK	SAFRAN	A340		AEG Seville
10-111201-000	LOCK SPRING	SAFRAN	A340		AEG Seville
10-111301-002	ACTUATOR-UNLOCK,CLG	MESSIER-DOWTY SA	A340	32	AEG Seville
10-111301-003	UNLOCK ACTUATOR	GRIMES AEROSPACE	A340	32-00	AEG Seville
10-111301-004	UNLOCK ACTUATOR	SAFRAN	A340		AEG Seville
1111402	DRAG STAY DRESSING	SAFRAN	A340		AEG Seville
1111402-000	DRAG STAY DRESSING	SAFRAN	A340		AEG Seville
10-111702	1M STRUT HARNESS	MESSIER-DOWTY SA	A340	32-09-93	AEG Seville
10-111702-000	1M STRUT HARNESS	MESSIER-DOWTY SA	A340	32-09-93	AEG Seville
10-111702-001	1M STRUT HARNESS	SAFRAN	A340		AEG Seville

10-17703	1M STRUT HARNESS	MESSIER-DOWTY SA	A340		32-09-93	AEG Seville
10-17703-000	1M STRUT HARNESS	SAFRAN	A340			AEG Seville
10-17704	1M STRUT HARNESS	MESSIER-DOWTY SA	A340		32-09-93	AEG Seville
10-17704-000	1M STRUT HARNESS	MESSIER-DOWTY SA	A340		32-09-94	AEG Seville
10-17801	2M STRUT HARNESS	MESSIER-DOWTY SA	A340		32-09-94	AEG Seville
10-17801-002	2M STRUT HARNESS	SAFRAN	A340		32-09-94	AEG Seville
10-17801-003	2M STRUT HARNESS	SAFRAN	A340			AEG Seville
10-17802	2M STRUT HARNESS	MESSIER-DOWTY SA	A340		32-09-94	AEG Seville
10-17802-000	2M STRUT HARNESS	SAFRAN	A340			AEG Seville
10-17803	2M STRUT HARNESS	MESSIER-DOWTY SA	A340		32-09-94	AEG Seville
10-17803-000	2M STRUT HARNESS	SAFRAN LANDING	A340		32	AEG Seville
10-17901-002	1M BOGIE HARNESS	SAFRAN LANDING	A340		32	AEG Seville
10-17901-003	1M BOGIE HARNESS	SAFRAN LANDING	A340		32	AEG Seville
10-17901-004	1M BOGIE HARNESS	SAFRAN LANDING	A340		32	AEG Seville
10-17901-005	1M BOGIE HARNESS	SAFRAN LANDING	A340		32	AEG Seville
10-17902-000	1M BOGIE HARNESS	SAFRAN	A340		32-09-96	AEG Seville
10-18001-001	2M BOGIE HARNESS	SAFRAN	A340		32-09-96	AEG Seville
10-18001-002	2M BOGIE HARNESS	SAFRAN	A340			AEG Seville
10-18001-003	2M BOGIE HARNESS	SAFRAN	A340		32-09-96	AEG Seville
10-18001-004	2M BOGIE HARNESS	SAFRAN	A340			AEG Seville
10-18002-000	2M BOGIE HARNESS	SAFRAN	A340			AEG Seville
10-18302	BOGIE AND DRESSING	SAFRAN	A340			AEG Seville
10-18302-000	BOGIE AND DRESSING	SAFRAN	A340			AEG Seville
10-18302-001	BOGIE AND DRESSING	SAFRAN	A340			AEG Seville
10-18302-002	BOGIE AND DRESSING	SAFRAN	A340			AEG Seville
10-18303	BOGIE AND DRESSING	MESSIER-DOWTY SA	A340		32-33-44	AEG Seville
10-18501-011	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-012	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-028	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-029	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-030	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-031	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-032	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-033	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-034	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-035	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-036	CENTER LANDING GEAR LEG	MESSIER-DOWTY SA	A340			AEG Seville
10-18501-037	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-038	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-039	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-040	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-041	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-042	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-043	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-044	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-045	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-046	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-047	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-048	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-049	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-050	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-051	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-052	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-053	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-054	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-055	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-056	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-057	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18501-058	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-003	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-004	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-020	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-021	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-022	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-023	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-024	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-025	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-026	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-027	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-028	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-029	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-030	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-031	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-032	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-033	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-034	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-035	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-036	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-037	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-038	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-039	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-040	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-041	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-042	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-043	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-044	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-045	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-046	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-047	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-048	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-049	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18502-050	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18506	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18506-002	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18506-003	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18506-004	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18506-005	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18506-006	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18506-007	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18506-008	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18506-009	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-000	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-001	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-002	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-003	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-004	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-005	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-006	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-007	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-008	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-009	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18507-010	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18508-000	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18508-001	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18508-002	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18508-003	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18508-004	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18508-005	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville
10-18508-006	CENTER LANDING GEAR LEG	SAFRAN	A340			AEG Seville

10-1808-007	CENTER LANDING GEAR LEG	SAFRAN	A340			AEQ Seville
10-1808-008	CENTER LANDING GEAR LEG	SAFRAN	A340			AEQ Seville
10-1808-009	CENTER LANDING GEAR LEG	SAFRAN	A340			AEQ Seville
10-1808-010	CENTER LANDING GEAR LEG	GRIMES	A340		33-50-66	AEQ Seville
10-1776	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-1	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-11	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-13	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-16	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-17	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-19	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-21	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-23	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-26	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-27	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-29	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-3	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-31	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-33	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-36	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-37	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-39	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-41	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-43	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-46	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-47	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-49	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-6	EMERGENCY EXIT LIGHT	GRIMES	UNK			AEQ Seville
10-1776-61	EMERGENCY EXIT LIGHT	GRIMES	UNK			AEQ Seville
10-1776-63	EMERGENCY EXIT LIGHT	GRIMES	UNK			AEQ Seville
10-1776-66	EMERGENCY EXIT LIGHT	GRIMES	UNK			AEQ Seville
10-1776-67	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-7	EMERGENCY EXIT LIGHT	GRIMES	UNK		335066	AEQ Seville
10-1776-9	EMERGENCY EXIT LIGHT	SAFRAN	UNK			AEQ Seville
10-180-1	Stairway Tread Light				33-20-71	AEQ Seville
10-180-6	Stairway Tread Light				33-20-71	AEQ Seville
10-18301	BOGIE PITCH TRIMMER ASSEMBLY	SAFRAN	A340			AEQ Seville
10-18301-003	BOGIE PITCH TRIMMER	MESSIER-DOWTY SA	A340		32-00	AEQ Seville
10-18301-004	BOGIE PITCH TRIMMER	MESSIER-DOWTY SA	A340		32	AEQ Seville
10-18301-005	BOGIE PITCH TRIMMER	MESSIER-DOWTY SA	A340		32-00	AEQ Seville
10-18301-006	BOGIE PITCH TRIMMER	MESSIER-DOWTY SA	A340		32-00	AEQ Seville
10-18301-007	BOGIE PITCH TRIMMER	SAFRAN	A340			AEQ Seville
10-18302	BOGIE PITCH TRIMMER ASSEMBLY	MESSIER-DOWTY SA	A340		32-00	AEQ Seville
10-18302-000	PITCH TRIMMER ASSEMBLY	MESSIER-DOWTY SA	A340		32-15-15	AEQ Seville
10-18601-003	PITCH TRIMMER MANIFOLD	SAFRAN	A340			AEQ Seville
10-18601-004	PITCH TRIMMER MANIFOLD	SAFRAN	A340			AEQ Seville
10-18601-005	PITCH TRIMMER MANIFOLD	MESSIER-DOWTY SA	A340		32-15-15	AEQ Seville
10-18601-006	PITCH TRIMMER MANIFOLD	MESSIER-DOWTY SA	A340		32-15-15	AEQ Seville
10-18601-007	PITCH TRIMMER MANIFOLD	MESSIER-DOWTY SA	A340		32-09-97	AEQ Seville
10-18801-001	1M DRAG STAY HARNESS	SAFRAN	A340			AEQ Seville
10-18802-000	1M DRAG STAY HARNESS	SAFRAN	A340		32-09-98	AEQ Seville
10-18901-001	2M DRAG STAY HARNESS	SAFRAN	A340			AEQ Seville
10-18902-000	2M DRAG STAY HARNESS	SAFRAN LARKINS ELECTRIC	A340			AEQ Seville
10-20602-017	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-018	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-019	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-020	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-021	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-022	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-023	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-024	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-025	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-026	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-027	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-008	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-009	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-010	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-011	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-012	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-013	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-014	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-016	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-016	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-017	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-018	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-017	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-018	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-019	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-020	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-021	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-022	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-023	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-024	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-026	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-026	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20602-027	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-008	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-009	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-010	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-011	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-012	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-013	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-014	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-016	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-016	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-017	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-20603-018	MAIN STRUT AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-12M03-002	SHOCK STRUT ASSEMBLY	SAFRAN	A340			AEQ Seville
10-12M03-003	SHOCK STRUT ASSEMBLY	SAFRAN	A340			AEQ Seville
10-12M03-004	SHOCK STRUT ASSEMBLY	SAFRAN	A340			AEQ Seville
10-12302	BOGIE AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-12303	BOGIE AND DRESSINGS	SAFRAN	A340			AEQ Seville
10-12304	BOGIE AND DRESSING	SAFRAN	A340			AEQ Seville
10-12304-000	BOGIE & DRESSINGS	SAFRAN	A340			AEQ Seville
10-12702-000	BOGIE ASSEMBLY	SAFRAN	A340			AEQ Seville
10-12702-001	BOGIE ASSEMBLY	SAFRAN	A340			AEQ Seville
10-12702-002	BOGIE ASSEMBLY	SAFRAN	A340			AEQ Seville
10-12702-003	BOGIE ASSEMBLY	SAFRAN	A340			AEQ Seville
10-12702-004	BOGIE ASSEMBLY	SAFRAN	A340			AEQ Seville
10-12702-006	BOGIE ASSEMBLY	SAFRAN	A340			AEQ Seville
10-121901	SIDE STAY COMPLETE	SAFRAN	A340			AEQ Seville
10-121902	SIDE STAY COMPLETE	SAFRAN	A340			AEQ Seville
10-121902-000	SIDE STAY COMPLETE (LH)	SAFRAN	A340			AEQ Seville
10-121902-001	SIDE STAY COMPLETE (LH)	SAFRAN	A340			AEQ Seville
10-122301	LOCK LINK	SAFRAN	A340			AEQ Seville
10-122301-000	LOCK LINK	SAFRAN	A340			AEQ Seville
10-122301-001	LOCK LINK	K0654	A340		32	AEQ Seville
10-12301-001	ACTUATOR-RETRACTION	MESSIER-DOWTY	A340		32	AEQ Seville
10-12301-003	ACTUATOR-RETRACTION M/G	MESSIER-DOWTY	A340		32-31-87	AEQ Seville

10-123101-004	RETRACTION ACTUATOR ASSY	SAFRAN	A330		AEG Seville
10-124102	1M LEFT HAND ELECTRICAL HARNES	SAFRAN	A340		AEG Seville
10-124102-002	1M STRUT HARNESS (LH)	SAFRAN	A340		AEG Seville
10-124103	1M LEFT HAND ELECTRICAL HARNES	SAFRAN	A340		AEG Seville
10-124103-002	1M STRUT HARNESS (LH)	SAFRAN LANDING EVELEAC	A340	32	AEG Seville
10-124103-003	1M STRUT HARNESS (LH)	SAFRAN	A340		AEG Seville
10-124203	1M RIGHT HAND ELECTRICAL HARNE	SAFRAN	A340		AEG Seville
10-124203-003	1M STRUT HARNESS (RH)	SAFRAN	A340		AEG Seville
10-124204	1M RIGHT HAND ELECTRICAL HARNE	SAFRAN	A340		AEG Seville
10-124204-002	1M STRUT HARNESS (RH)	SAFRAN	A340		AEG Seville
10-124204-003	1M STRUT HARNESS (RH)	SAFRAN	A340		AEG Seville
10-124302	2M LEFT HAND ELECTRICAL HARNES	SAFRAN	A340		AEG Seville
10-124302-001	2M STRUT HARNESS (LH)	SAFRAN	A340		AEG Seville
10-124302-002	2M STRUT HARNESS (LH)	SAFRAN	A340		AEG Seville
10-124303	2M LEFT HAND ELECTRICAL HARNES	SAFRAN	A340		AEG Seville
10-124303-000	2M STRUT HARNESS (LH)	SAFRAN	A340		AEG Seville
10-124303-001	2M STRUT HARNESS (LH)	SAFRAN	A340		AEG Seville
10-124403	2M RIGHT HAND ELECTRICAL HARNE	SAFRAN	A340		AEG Seville
10-124403-001	2M STRUT HARNESS (RH)	SAFRAN	A340		AEG Seville
10-124403-002	2M STRUT HARNESS (RH)	SAFRAN	A340		AEG Seville
10-124404	2M RIGHT HAND ELECTRICAL HARNE	SAFRAN	A340		AEG Seville
10-124404-000	2M STRUT HARNESS (RH)	SAFRAN	A340		AEG Seville
10-124404-001	2M STRUT HARNESS (RH)	SAFRAN	A340		AEG Seville
10-124405	2M RIGHT HAND ELECTRICAL HARNE	SAFRAN	A340		AEG Seville
10-124405-000	2M STRUT HARNESS (RH)	MESSIER SERVICES	A340	32-12-41	AEG Seville
10-124501-000	1M BOGIE HARNESS	MESSIER SERVICES	A340	32-12-41	AEG Seville
10-124501-001	1M BOGIE HARNESS	MESSIER SERVICES	A340	32-12-41	AEG Seville
10-124501-002	1M BOGIE HARNESS	MESSIER SERVICES	A340	32-12-41	AEG Seville
10-124502-000	1M BOGIE HARNESS	SAFRAN	A340		AEG Seville
10-124701	2M ELECTRICAL HARNESS	SAFRAN	A340		AEG Seville
10-124701-000	2M BOGIE HARNESS	SAFRAN	A340		AEG Seville
10-124701-001	2M BOGIE HARNESS	SAFRAN	A340		AEG Seville
10-124701-002	2M BOGIE HARNESS	SAFRAN	A340		AEG Seville
10-124701-003	2M BOGIE HARNESS	SAFRAN	A340		AEG Seville
10-124702	2M ELECTRICAL HARNESS	SAFRAN	A340		AEG Seville
10-124702-000	2M BOGIE HARNESS	HONEYWELL AEROSPACE GOODRICH	A340 B737-300,B737-400,B737-800,B737-800,B737-300,B737-400,B737-800,B737-800	33-20-51	AEG Seville
10-1327-9	FLUORESCENT WINDOW LIGHT	GOODRICH		32-46-27	AEG Seville
10-133X	Interior Illuminated Window And Exit Sign	HONEYWELL AEROSPACE		33-20-52	AEG Seville
101-380096-1	MAIN LANDING GEAR BRAKE ASSEMBLY		CN-235	33-21-39,33-32-21-30	AEG Seville
10-1418-1	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-69	AEG Seville
10-1418-11	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-69	AEG Seville
10-1418-12	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-69	AEG Seville
10-1418-2	Passenger Service Unit		(DHC)Dash 8-100,(DHC)Dash 8-300	33-20-69	AEG Seville
10167N01W00	Torque Indicator		DHC8,Dash 8,(DHC)Dash 8-100	77-10-36	AEG Bilbao
10167N02W00	Torque Indicator		DHC8,Dash 8,(DHC)Dash 8-100	77-10-36	AEG Bilbao
10169N01R00	Prop RPM Indicator		DHC8,Dash 8,(DHC)Dash 8-100,(DHC)Dash 8-300	77-12-06	AEG Bilbao
10170N01R00	NH% RPM Indicator		DHC8,Dash 8,(DHC)Dash 8-100	77-12-07	AEG Bilbao
10-1733-1	FLUORESCENT WINDOW LIGHT	HONEYWELL AEROSPACE	B737-300,B737-400,B737-800,B737-800	33-21-39	AEG Seville
10-1733-2	FLUORESCENT WINDOW LIGHT	HONEYWELL AEROSPACE	B737-300,B737-400,B737-800,B737-800	33-21-39	AEG Seville
10-1733-3	FLUORESCENT WINDOW LIGHT	HONEYWELL AEROSPACE	B737-300,B737-400,B737-800,B737-800	33-21-39	AEG Seville
10-1733-4	FLUORESCENT WINDOW LIGHT	HONEYWELL AEROSPACE	B737-300,B737-400,B737-800,B737-800	33-21-39	AEG Seville
10-1733-5	FLUORESCENT WINDOW LIGHT	HONEYWELL AEROSPACE	B737-300,B737-400,B737-800,B737-800	33-21-39	AEG Seville
10174N01W01	Engine Torque Indicator	MESSIER-DOWTY	Dash 8,Dash 7	77-10-33	AEG Bilbao
10174N02W01	Engine Torque Indicator		DHC8,Dash 8,(DHC)Dash 8-300	77-10-33	AEG Bilbao
10174N03W02	Engine Torque Indicator		Dash 8	77-10-42	AEG Bilbao
10174N04W02	Engine Torque Indicator		DHC8,Dash 8,(DHC)Dash 8-300	77-10-42	AEG Bilbao
10174N05W03	Engine Torque Indicator		DHC8,Dash 8,Dash 7	77-10-53	AEG Bilbao
10174N06W03	Engine Torque Indicator		DHC8,Dash 8,(DHC)Dash 8-300	77-10-53	AEG Bilbao
10174N07W04	Torque Indicator		DHC8,Dash 8	77-10-56	AEG Bilbao
10174N08W04	Torque Indicator		DHC8,Dash 8,Dash 7	77-10-56	AEG Bilbao
10174N09W05	Engine Torque Indicator		Dash 7,Dash 8	77-10-53	AEG Bilbao
10174N10W03	Torque Indicator		DHC8,Dash 8,(DHC)Dash 8-300	77-10-56	AEG Bilbao
10176N01T00	Interurbine Temperature Indicator		DHC8,Dash 8,(DHC)Dash 8-300,(DHC)Dash 8-300	77-20-28	AEG Bilbao
10176N01R00	NL% RPM Indicator		Dash 8,Dash 7	77-12-08	AEG Bilbao
10177N01R00	NH% RPM Indicator		DHC8,Dash 8,(DHC)Dash 8-200,(DHC)Dash 8-300	77-12-07	AEG Bilbao
10178N01T01	Static/flex Air temperature Indicator		Dash 8	77-20-27	AEG Bilbao
10178N02T01	Static/flex Air temperature Indicator		Dash 8	77-20-27	AEG Bilbao
10-204-4-T-2	VHF Glide slope Blade Antennas				AEG Seville
10-208-16-B-2	VHF Navigation (Marker) Blade Antennas				AEG Seville
102-1090	Standby Control Panel		Jetstream 31,Jetstream 41		AEG Seville
10-20901-001	SHOCK STRUT ASSEMBLY	MESSIER-DOWTY	A340	32-12-62	AEG Seville
10-20901-002	SHOCK STRUT ASSEMBLY	MESSIER-DOWTY	A330	32-12-62	AEG Seville
10-20901-003	SHOCK STRUT ASSEMBLY	SAFRAN	A330		AEG Seville
10-20901-004	SHOCK STRUT ASSEMBLY	MESSIER	A330	32-31-90	AEG Seville
10-21031-001	ACTUATOR, MLG RETRACTION	MESSIER-DOWTY	A330	32-12-63	AEG Seville
10-21051-001	BOGIE AND DRESSINGS, MLG	SAFRAN LANDING EVELEAC	A330	32-12-63	AEG Seville
10-21051-002	BOGIE AND DRESSINGS, MLG	SAFRAN	A330		AEG Seville
10-21051-004	BOGIE AND DRESSINGS, MLG	SAFRAN LANDING EVELEAC	A330	32-12-64	AEG Seville
10-21071-000	BOGIE ASSEMBLY	SAFRAN LANDING EVELEAC	A330-300	32-12-64	AEG Seville
10-21071-001	BOGIE ASSEMBLY	SAFRAN LANDING EVELEAC	A330	32-12-64	AEG Seville
10-21071-002	BOGIE ASSEMBLY	SAFRAN LANDING EVELEAC	A330	32-12-64	AEG Seville
10-21071-003	BOGIE ASSEMBLY	SAFRAN	A330		AEG Seville
10-21071-004	BOGIE ASSEMBLY	MESSIER-DOWTY	A330	32-12-66	AEG Seville
10-22201-000	SIDE STAY BASIC	MESSIER-DOWTY	A330	32-12-66	AEG Seville
10-22201-001	SIDE STAY BASIC	MESSIER-DOWTY	A330	32-31-88	AEG Seville
10-22702-000	TRIMMER, MLG BOGIE PITCH	SAFRAN	A330		AEG Seville
10-22901	1M STRUT HARNESS	SAFRAN LANDING EVELEAC	A330-2007-3000	32-12-68	AEG Seville
10-22901-000	1M STRUT HARNESS	SAFT	A330	24	AEG Seville
10-23501 SERIES	1M STRUT HARNESS	SAFRAN LANDING EVELEAC	A330-2007-3000	32-12-68	AEG Seville
10-23501	1M & 2M BOGIE HARNESS	SAFRAN LANDING EVELEAC	A330-2007-3000	32-11-70	AEG Seville
10-235701 SERIES	1M & 2M BOGIE HARNESS	SAFRAN LANDING EVELEAC	A330-2007-3000	32-11-70	AEG Seville
10-260-9-B-2	VHF Navigation Blade Antennas				AEG Seville
103068-14	Cabin Air Pressure Outflow/Safety Valve		DHC8	21-31-74	AEG Seville
103-1090	Standby Control Panel		Jetstream 31,Jetstream 41		AEG Seville
103-1290	Standby Control Panel		Jetstream 31,Jetstream 41		AEG Seville
103672-1	Valve, Outflow/Safety			21-31-72	AEG Seville
103672-2	Valve, Outflow/Safety			21-31-72	AEG Seville
10-376401-000	2M UPPER ELECTRICAL HARNESS (EV)	SAFRAN LANDING EVELEAC	A318/A319/A320V	32-27-75 (EV)	AEG Seville
10-376501-000	1M UPPER ELECTRICAL HARNESS (EV)	SAFRAN LANDING EVELEAC	A318/A319/A320V	32-27-83 (EV)	AEG Seville
10-376301-000	1M UPPER ELECTRICAL HARNESS (EV)	SAFRAN LANDING EVELEAC	A318/A319/A320V	32-27-82 (EV)	AEG Seville
10-377001-000	LOWER ELECTRICAL HARNESS (EV)	SAFRAN LANDING EVELEAC	A318/A319/A320V	32-27-84 (EV)	AEG Seville
103770-1	Cabine Air Pressure Outflow Valve		CRJ Regional Jet-100,B757	21-32-32	AEG Seville
103770-3	Cabine Air Pressure Outflow Valve		CRJ Regional Jet-100,B757	21-32-32	AEG Seville
103770-4	Cabine Air Pressure Outflow Valve		CRJ Regional Jet-100	21-32-32	AEG Seville
103770-5	Cabine Air Pressure Outflow Valve		CRJ Regional Jet-100,B757	21-32-32	AEG Seville
103770-6	Cabine Air Pressure Outflow Valve		CRJ Regional Jet-100	21-32-32	AEG Seville
103770-7	Cabine Air Pressure Outflow Valve		CRJ Regional Jet-100	21-32-32	AEG Seville
103770-8	Cabine Air Pressure Outflow Valve		CRJ Regional Jet-100,B757	21-32-32	AEG Seville
103772-6	Outflow Valve, Cabin Air Pressure		CRJ Regional Jet-100,B757	21-32-34	AEG Seville
103772-7	Outflow Valve, Cabin Air Pressure		CRJ Regional Jet-100,B757	21-32-34	AEG Seville
103772-8	Outflow Valve, Cabin Air Pressure		CRJ Regional Jet-100,B757	21-32-34	AEG Seville
103772-9	Outflow Valve, Cabin Air Pressure		CRJ Regional Jet-100,B757	21-32-34	AEG Seville
10600-100series	Main Landing Gear Retraction Actuator			32-30-01	AEG Seville
10600-600series	Main Landing Gear Retraction Actuator			32-30-10	AEG Seville
10600-650series	Main Landing Gear Retraction Actuator			32-30-11	AEG Seville
1065-82-0ZZ-A	V/UHF ANTENNA	TEXTRON	UNK	32-40-0	AEG Seville
10-40656-10	PUMP MOTOR PACKAGE	PARKER	B727,B747,B737	29-20-15	AEG Seville
10-40656-12	PUMP MOTOR PACKAGE	PARKER	B747-400,B727,B747,B737	29-20-15	AEG Seville
10-40656-15	PUMP MOTOR PACKAGE	PARKER	B747-400,B727,B747,B737	29-20-15	AEG Seville
10-40656-16	PUMP MOTOR PACKAGE	PARKER	B747-400,B727,B747,B737	29-20-15	AEG Seville

10-00666-17	PUMP MOTOR PACKAGE	PARKER	B747-400,B727,B747,B737	29-20-15	AEG Seville
10-00666-18	PUMP MOTOR PACKAGE	PARKER HANNIFIN	B747-400,B727,B747,B737		AEG Seville
10-00666-19	PUMP MOTOR PACKAGE	THE BOEING	UNK	29-20-15	AEG Seville
10-00666-20	PUMP MOTOR PACKAGE	THE BOEING	B747-400,B737-400,B737-300,B737-200,B737-800	29-20-15	AEG Seville
10-00666-30	PUMP MOTOR PACKAGE	PARKER	B727,B747,B737	29-20-15	AEG Seville
10-00666-6	PUMP MOTOR PACKAGE	PNEUDRAULICS	B737-100,B727,B747,B737	32-30-02	AEG Seville
10-00699-1	HYDRAULIC PRIORITY RELIEF CART	SARGENT	B737,B737-600,B737-500,B737-400,B707	32-30-01	AEG Seville
10-01213-1	LANDING GEAR SELECTOR VALVE ASSEMBLY	BOEING	B737	30-40-14	AEG Seville
10-01292-4	HYDRAULIC MOTORPUMP ASSEMBLY	EATON	B737	29-11-26,	AEG Seville
10-01292-5	HYDRAULIC MOTORPUMP ASSEMBLY	EATON	B737	29-11-26,	AEG Seville
10-01329-31	WINDSHIELD WIPER MOTOR CONVERTER	BOEING	B747,B737	30-40-14	AEG Seville
10-01329-32	WINDSHIELD WIPER MOTOR CONVERTER	BOEING	B747,B737	30-40-14	AEG Seville
10-01329-37	WINDSHIELD WIPER MOTOR CONVERTER	BOEING	B747,B737	30-40-14	AEG Seville
10-01329-38	WINDSHIELD WIPER MOTOR CONVERTER	BOEING	B747,B737	30-40-14	AEG Seville
10-01329-39	WINDSHIELD WIPER MOTOR CONVERTER	BOEING	B747,B737	30-40-14	AEG Seville
10-01329-40	WINDSHIELD WIPER MOTOR CONVERTER	GOODRICH	B747,B737	30-40-14	AEG Seville
10-01329-41	WINDSHIELD WIPER MOTOR CONVERTER	BOEING	B747,B737	30-40-14	AEG Seville
10-01329-42	WINDSHIELD WIPER MOTOR CONVERTER	BOEING	B747,B737	30-40-04	AEG Seville
10-01833-7	WINDOW HEAT CONTROL UNIT	THE BOEING	B737	32-40-18	AEG Seville
10-02204-17	ANTI-KID VOLUMETRIC FUSE ASSEMBLY	SAWYER INDUSTRIES	BOEING 777-200	27	AEG Seville
1067858100	Motor Assembly		B707,B727,B737,B747,B767,B777,DC-9,MID-80,M800	28-20-10	AEG Seville
1067884182	Actuator			28-20-09	AEG Seville
1067884210	Actuator		B747,Dash 8,C-130,DHC8	28-20-07	AEG Seville
107-120	ARMATURE	COLLINS / HUGHES	UNK	23-33-46	AEG Seville
1-09731-00-01	Enclosure			49-11-00	AEG Seville
1-09731-01-00	Enclosure Assy			49-11-01	AEG Seville
1-09731-01-01	Enclosure Assy			49-11-02	AEG Seville
1-09731-02-00	Door Assy		CRJ Regional Jet-200	49-11-03	AEG Seville
1-09731-02-01	Panel		CRJ Regional Jet-200	49-11-04	AEG Seville
103480-121	SEAT ELECTRONICS BOX	ROCKWELL COLLINS	B767	23-33-48	AEG Seville
103860-120-02	SEAT ELECTRONIC BOX	BENDIX	UNK		AEG Seville
108-11	Pilot / Co-Pilot Seat				AEG Seville
108-17	Pilot / Co-Pilot Seat				AEG Seville
108-19	Pilot / Co-Pilot Seat				AEG Seville
108-21	Pilot / Co-Pilot Seat				AEG Seville
108-23	Pilot / Co-Pilot Seat				AEG Seville
108-26	Pilot / Co-Pilot Seat				AEG Seville
108-27	Pilot / Co-Pilot Seat				AEG Seville
108-5	Pilot / Co-Pilot Seat				AEG Seville
108-7	Pilot / Co-Pilot Seat				AEG Seville
108-9	Pilot / Co-Pilot Seat				AEG Seville
110-6AD	Pilot And Co-Pilot Seat				AEG Seville
110-6AG	Pilot And Co-Pilot Seat				AEG Seville
110-7AD	Pilot And Co-Pilot Seat				AEG Seville
110-7AG	Pilot And Co-Pilot Seat				AEG Seville
1139-2	50 Cubic Inch Hydraulic Accumulator Assembly				AEG Seville
1140-2	100 Cubic Inch Hydraulic Accumulator Assembly				AEG Seville
1140-2	Photoluminescent Floor Proximity Emergency Egress Route Marking			33-62-13	AEG Seville
1140-2	Hydraulic Flow Regulator Valve				AEG Seville
1140-010-SERIES	ROCKWELL-COLLINS	SMITHS	767	32-31-34	AEG Seville
1140-0122	Fuel Stick			28-40-07	AEG Seville
114095004-010	ACTUATOR-LOCK STAY	SAFT AMERICA BATTERIES	A330,A321,A319,A318,A320,A320-200		AEG Seville
1147622-7	TRACK ASSY-MAIN, INBD SS 282.91	HONEYWELL TORONTO	B-737	24	AEG Seville
1151536-1	Wing Anti-Ice Temperature Controller				AEG Seville
1152090-6Series1	Left AC Contactor Box Galley Opt 2			24-23-03	AEG Seville
1152092-3Series1	AC generator Control Unit (Auxilec)			24-23-02	AEG Seville
1152092-4Series1	AC generator Control Unit (Auxilec)			24-23-02	AEG Seville
115212-2Series1	40 Amp Hour Battery			24-34-01	AEG Seville
1152124-6	Right AC Contactor Box Galley Opt 2 Series 1, 2, 3, 4, 5, 6, 7, 8			24-24-04	AEG Seville
1152130-6Series1	Left AC Contactor Box (No Galley Option)			24-24-06	AEG Seville
1152148-6Series1	Right AC Contactor Box (No Galley Option)			24-24-07	AEG Seville
1152230-3Series1Series1	DC Contactor Box			24-24-10	AEG Seville
1152230-4Series1Series1	DC Contactor Box			24-24-10	AEG Seville
1152268-1	Sintered-Plate Nickel-Cadmium Battery (17 AMP)			24-34-03	AEG Seville
1152346-1Series1	400 AMP DC Current Shunt			24-24-17	AEG Seville
1152424-1Series1	200 AMP DC Current Shunt			24-24-18	AEG Seville
1153-1	ELECTRIC MOTOR	SAFT	FALCON 20	24	AEG Bilbao
11-5833-1	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B-737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Seville
11-5833-3	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B-737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Seville
11-5833-5	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B-737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Seville
11-5833-7	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B-737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Seville
11-5833-9	INTERIOR ILLUMINATED SIGN LIGHT	HONEYWELL	B-737, B737-700, B737-800, B737-200, B737-300	33-20-67	AEG Seville
11546260-1	FUSE IN - TRUNNION SUPP - FWD	SAFT	B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	24	AEG Seville
11-6537-1	PASSENGER SERVICE UNIT CIRCUIT CARD	GRIMES	B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	33-21-42	AEG Seville
11-6537-3	PASSENGER SERVICE UNIT CIRCUIT CARD	HONEYWELL	B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	33-21-42	AEG Seville
11-6537-5	PASSENGER SERVICE UNIT CIRCUIT CARD	HONEYWELL	B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	33-21-42	AEG Seville
11-6537-7	PASSENGER SERVICE UNIT CIRCUIT CARD	ACERSWAVE	B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	33-21-42	AEG Seville
11-6537-9	PASSENGER SERVICE UNIT CIRCUIT CARD	ACERSWAVE	B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	33-21-42	AEG Seville
11-6537-9	PASSENGER SERVICE UNIT CIRCUIT CARD	SAFT	B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	24	AEG Seville
117007000	RETRACTABLE LANDING LIGHT	AVTECH	A318, A319, A320, A321	23	AEG Seville
1200008-000MODA	5 Channel Selcal Decoder			23-20-24	AEG Seville
1200008-000MODA	CSD-714 Selcal			23-21-01	AEG Seville
1200008-00X	CSD-714 Selcal			23-20-04	AEG Seville
12210-3	SCREW	SUNDSTRAND	DC-10,CF6-50,B727,A300	28	AEG Seville
122-4608	FIELD ASSEMBLY	SUNDSTRAND	UNK	28	AEG Seville
122-6607	ARMATURE	UNK			AEG Bilbao
122723-SERIES	FUEL BOOST PUMP	HONEYWELL	UNK	49	AEG Seville
123690-2-1	One And One-Half Inch Diameter Check Valve			21-20-27	AEG Seville
124536 SERIES	FUEL CONTROL UNIT	MROGOI	UNK	31-09-02,24,31	AEG Seville
125079-13	HEADSET ELECTRICAL	AVTECH	UNK	29-20-25,29	AEG Seville
1261-1	MOTOR	PARKER	A300,SAAB 340	29-20-25,29	AEG Seville
1261-2	MOTOR	SIERRA NETWORKS	A300		AEG Seville
126842-2-1	Diffuser Vane Actuator		CRJ Regional Jet-200,CRJ Regional Jet-300,B737	49-60-59	AEG Seville
1272-2700	INDICATOR, HEIGHT		UNK		AEG Seville
12D1006	Valve, Drain,Water System Lavatory			38-21-01	AEG Seville
12D1006	Valve, Drain,Water System Galley		A320	38-11-19	AEG Seville
130009AG	Electric Motor Operated Actuator		EMB-190		AEG Seville
130009G	Electric Motor Operated Actuator Assembly		B777,CRJ-700		AEG Seville
130168-1-1	Air Check Valve		B0,100,A320,CRJ Regional Jet-200,100,F50,CRJ Regional Jet-300,B737-400,B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	21-30-70	AEG Seville
130622-1	Control		B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	21-31-68	AEG Seville
130622-2	Control		B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	21-31-68	AEG Seville
131410-1	Pump		B737-300,B737-200,B737-100,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100	21-31-76	AEG Seville
1316200-3	BRAKE METERING VALVE	GE	B737,B757	77-12-23	AEG Seville
131868B	Extension A/B Com Boards			27-61-27	AEG Seville
1321-634260	Level Control Valve				AEG Seville
1321M39P02	STATOR ALTERNATOR	MESSIER BOGOTTI-FRANCO	767, A300, A310, CF6-80C2, MD-11	32-32-49-12	AEG Seville
1338-1460	PRESSURE TRANSDUCER	UNK	A320 NEO	21-50-10	AEG Seville
138612-4	STATOR	LEAR SIEGLER	UNK		AEG Bilbao
140-067	Wheel Speed Anti Skid System			32-42-77	AEG Seville
140-067-1	Wheel Speed Anti Skid System			32-42-77	AEG Seville
140-067-2	Wheel Speed Anti Skid System			32-42-77	AEG Seville
1404020-1	SPRING-STRUT ASSY,M/LG UPLOCK	MUNOGRAM S.A. INNOVATION	A330	38-31-13	AEG Seville
14300-010	MOTOR PUMP FILTER ASSEMBLY	A/C BRAKE CO	A320		AEG Seville
14300-061	HOUSING AND STATOR ASSY WITH CONNECTOR PLATE	MONOGRAM	UNK	38-31-13	AEG Seville
14300-084	MOTOR PUMP FILTER ASSEMBLY	MONOGRAM	A320	38-31-13	AEG Seville
14300-092	MOTOR PUMP FILTER ASSEMBLY	MONOGRAM	A320	38-31-13	AEG Seville
14300-136	MOTOR PUMP FILTER ASSEMBLY	MONOGRAM	UNK	38-31-13	AEG Seville
14300-137	MOTOR PUMP FILTER ASSEMBLY	MUNOGRAM SYSTEMS - HYDRAULIC EQUIPMENT	A320,A300,MD-80-83	38-34-17	AEG Seville
14330-360	VACCLUM GENERATOR ASSEMBLY	MONOGRAM SYSTEMS	B727,B747-400,ERJ-170,ERJ-175,A320,A321,A319,A318,A300,A300-200	38-34-29	AEG Seville
14350-007	Toilet Assembly		CRJ Regional Jet-200	38-35-04	AEG Seville

16300-109	Steering Actuator/Swivel				32-50-12	AEG Sevilla
16330-107	Shock Strut NLG/Shock Strut Subassy and Swivel			B757	32-20-04	AEG Sevilla
16330-109	Shock Strut NLG/Shock Strut Subassy and Swivel			C-130	32-20-04	AEG Sevilla
1646-1-6	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH		B737-300,B737-200,B737	33-10-04	AEG Sevilla
1646-1-6 MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH		DC-9,DC-8,B737-200,B727,B737	33	AEG Sevilla
1646-1-6 MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH		DC-9,DC-8,B737-200,B727,B737	33	AEG Sevilla
1646-1-6A	FLUORESCENT LAMP CNTRLER	AVTECH		B737	33	AEG Sevilla
1646-1-6B	FLUORESCENT LAMP CNTRLER	AVTECH		B737	33	AEG Sevilla
1646-1-6MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH		B737	33	AEG Sevilla
1646-1-7	FLUORESCENT LAMP CONTROL	AVTECH		A320,B737-300,B737-200,B737	33-10-04	AEG Sevilla
1646-1-7 MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH		B737-300,B737	33	AEG Sevilla
1646-1-7 MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH		B737-300,B737	33	AEG Sevilla
1646-1-7A	FLUORESCENT LAMP CONTROLLER	AVTECH		B737	33	AEG Sevilla
1646-1-7B	FLUORESCENT LAMP CONTROLLER	AVTECH		B737	33	AEG Sevilla
1646-1-7MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH		B737	33	AEG Sevilla
16480-101	NLG Steering Manifold			CL-601,CRJ Regional Jet-100,CRJ Regional Jet-700	32-50-16	AEG Sevilla
165E0948-00	Voice Recorder/Microphone/Unit/Voice Recorder				23-70-02	AEG Sevilla
165E233-00	Voice Recorder/Microphone/Unit/Voice Recorder				23-70-03	AEG Sevilla
1660-101	Steering Control Module Assembly			B757,C-130	32-50-13	AEG Sevilla
16789-101	Hydraulic Compensator Assembly			CRJ-700,CL-601	32-50-14	AEG Sevilla
16900-101	Electronic Control Unit				32-50-15	AEG Sevilla
16902-03	Electronic Control Unit				32-50-15	AEG Sevilla
16902-04	Electronic Control Unit				32-50-15	AEG Sevilla
700089 SERIES	ROTOR BALANCE ASSEMBLY			B777,B767-400		AEG Bilbao
700089A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND		B777,B767-400,B767	24-26-14	AEG Bilbao
700089B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND		B777,B767-400,B767	24-26-14	AEG Bilbao
70102B	Lube And Scavenge Pump				79-21-01	AEG Sevilla
70137A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND		CRJ,CRJ900 Regional Jet-900,CRJ1000	24	AEG Bilbao
70137A	Integrated Drive Generator			A320,X319,B737-100,CRJ900 Regional Jet-900,B767-300,CRJ1000	24-21-12	AEG Sevilla
701320B	GENERATOR ASSEMBLY	UTC AEROSPACE		CRJ900 Regional Jet-900,CRJ-700	24	AEG Bilbao
701320C	GENERATOR ASSEMBLY	UTC AEROSPACE		CRJ900 Regional Jet-900,CRJ-700	24-22-13	AEG Bilbao
701410 SERIES	ROTOR BALANCE ASSEMBLY			B777	24	AEG Bilbao
701410A	ROTOR BALANCE ASSEMBLY	UTC		B777	24-26-10	AEG Bilbao
702719A	STATOR	SUNDSTRAND		A330		AEG Bilbao
703381-01	DIODE PACK	SUNDSTRAND		B737	24-26-12	AEG Sevilla
704600-1	VALVE PRESSURE REDUCING 8	NABTESCO AEROSPACE		L-1011,B737-500,B737-400,B737-300,MID-80-23,B767-300,B777-300,CRJ Regional Jet-100,CRJ Regional Jet-700,C-130	27-22-01	AEG Sevilla
7061-101	MLG Uplock And Actuator Assembly				32-30-15	AEG Sevilla
708064A	DIODE PACKAGE ASSEMBLY	HAMILTON		UNK		AEG Sevilla
708899A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND		A320,B757	24-26-15	AEG Bilbao
708899B	ROTOR			A320	24-11-88	AEG Bilbao
71001-30	PLACA, CIRCUITOS C			UNK		AEG Sevilla
712028A	Outboard Slat Actuator Assembly			CRJ-700	27-81-18	AEG Sevilla
712056A	Inboard Flap Actuator Assembly				27-52-07	AEG Sevilla
712607A	Midboard Right Flap Actuator Assembly				27-52-19	AEG Sevilla
712607B	Midboard Right Flap Actuator Assembly				27-52-19	AEG Sevilla
712609A	Midboard Left Flap Actuator Assembly			CRJ-700	27-52-20	AEG Sevilla
712609B	Midboard Left Flap Actuator Assembly			CRJ-700	27-52-20	AEG Sevilla
712613A	Outboard Left Flap Actuator Assembly				27-52-22	AEG Sevilla
712613B	Outboard Left Flap Actuator Assembly				27-52-22	AEG Sevilla
713346A	Slat Brake/Position Sensor Unit				27-81-21	AEG Sevilla
713700A	Mid Slat Actuator Assembly				27-81-20	AEG Sevilla
714309A	Type A Right-Hand Inboard & Left-Hand Outboard Slat				27-81-28	AEG Sevilla
714311A	Type B Right-Hand Outboard and Left-Hand Inboard Slat				27-81-29	AEG Sevilla
71861-01	PCU	BE AVONICS		UNK	23-33-82	AEG Sevilla
721000A	EXCITER STATOR HOUSING ASSEMBLY	HAMILTON		UNK		AEG Bilbao
721393A	STATOR AND HOUSING ASSEMBLY	SUNDSTRAND/HAMILTON		A320, A3240-200, A340-300, A340-500, A340-600, A350-600, A350-900	24-17-50	AEG Bilbao
72800-1	Cabin Windows				56-20-00	AEG Sevilla
72800-11	Cabin Windows				56-20-00	AEG Sevilla
72800-13	Cabin Windows				56-20-00	AEG Sevilla
72800-3	Cabin Windows				56-20-00	AEG Sevilla
72800-5	Cabin Windows				56-20-00	AEG Sevilla
72800-7	Cabin Windows				56-20-00	AEG Sevilla
72900-1	Cabin Windows				56-20-00	AEG Sevilla
7319-105	MLG Auxiliary Assembly			CRJ Regional Jet-200,B757	32-30-13	AEG Sevilla
73227-502	VIDEO DISTRIBUTION BOX			UNK		AEG Sevilla
73395-02	DISPLAY			UNK		AEG Sevilla
756-1	Main Battery			A320	24-32-06	AEG Sevilla
756-3	Main Battery				24-32-06	AEG Sevilla
76200-204	Self Contained Hand Flushing Toilet Assembly				38-31-12	AEG Sevilla
784389-653	COMPASS, GYROSYN	SPERRY		DC-9,DC-8,B737-200,B727	34-33-00	AEG Sevilla
788A010003	Duct Ground Connection HP				36-12-19	AEG Sevilla
79100-2	STARTER MOTOR	SUNDSTRAND		T-621-47C1, T621-46C1, 46C2, 46C2A, 46C2B, 46C2C, 46C2D, 46C2E, 46C2F, 46C2G, 46C2H, 46C2I, 46C2J, 46C2K, 46C2L, 46C2M, 46C2N, 46C2O, 46C2P, 46C2Q, 46C2R, 46C2S, 46C2T, 46C2U, 46C2V, 46C2W, 46C2X, 46C2Y, 46C2Z, 46C2AA, 46C2AB, 46C2AC, 46C2AD, 46C2AE, 46C2AF, 46C2AG, 46C2AH, 46C2AI, 46C2AJ, 46C2AK, 46C2AL, 46C2AM, 46C2AN, 46C2AO, 46C2AP, 46C2AQ, 46C2AR, 46C2AS, 46C2AT, 46C2AU, 46C2AV, 46C2AW, 46C2AX, 46C2AY, 46C2AZ, 46C2BA, 46C2BB, 46C2BC, 46C2BD, 46C2BE, 46C2BF, 46C2BG, 46C2BH, 46C2BI, 46C2BJ, 46C2BK, 46C2BL, 46C2BM, 46C2BN, 46C2BO, 46C2BP, 46C2BQ, 46C2BR, 46C2BS, 46C2BT, 46C2BU, 46C2BV, 46C2BW, 46C2BX, 46C2BY, 46C2BZ, 46C2CA, 46C2CB, 46C2CC, 46C2CD, 46C2CE, 46C2CF, 46C2CG, 46C2CH, 46C2CI, 46C2CJ, 46C2CK, 46C2CL, 46C2CM, 46C2CN, 46C2CO, 46C2CP, 46C2CQ, 46C2CR, 46C2CS, 46C2CT, 46C2CU, 46C2CV, 46C2CW, 46C2CX, 46C2CY, 46C2CZ, 46C2DA, 46C2DB, 46C2DC, 46C2DD, 46C2DE, 46C2DF, 46C2DG, 46C2DH, 46C2DI, 46C2DJ, 46C2DK, 46C2DL, 46C2DM, 46C2DN, 46C2DO, 46C2DP, 46C2DQ, 46C2DR, 46C2DS, 46C2DT, 46C2DU, 46C2DV, 46C2DW, 46C2DX, 46C2DY, 46C2DZ, 46C2EA, 46C2EB, 46C2EC, 46C2ED, 46C2EE, 46C2EF, 46C2EG, 46C2EH, 46C2EI, 46C2EJ, 46C2EK, 46C2EL, 46C2EM, 46C2EN, 46C2EO, 46C2EP, 46C2EQ, 46C2ER, 46C2ES, 46C2ET, 46C2EU, 46C2EV, 46C2EW, 46C2EX, 46C2EY, 46C2EZ, 46C2FA, 46C2FB, 46C2FC, 46C2FD, 46C2FE, 46C2FF, 46C2FG, 46C2FH, 46C2FI, 46C2FJ, 46C2FK, 46C2FL, 46C2FM, 46C2FN, 46C2FO, 46C2FP, 46C2FQ, 46C2FR, 46C2FS, 46C2FT, 46C2FU, 46C2FV, 46C2FW, 46C2FX, 46C2FY, 46C2FZ, 46C2GA, 46C2GB, 46C2GC, 46C2GD, 46C2GE, 46C2GF, 46C2GG, 46C2GH, 46C2GI, 46C2GJ, 46C2GK, 46C2GL, 46C2GM, 46C2GN, 46C2GO, 46C2GP, 46C2GQ, 46C2GR, 46C2GS, 46C2GT, 46C2GU, 46C2GV, 46C2GW, 46C2GX, 46C2GY, 46C2GZ, 46C2HA, 46C2HB, 46C2HC, 46C2HD, 46C2HE, 46C2HF, 46C2HG, 46C2HH, 46C2HI, 46C2HJ, 46C2HK, 46C2HL, 46C2HM, 46C2HN, 46C2HO, 46C2HP, 46C2HQ, 46C2HR, 46C2HS, 46C2HT, 46C2HU, 46C2HV, 46C2HW, 46C2HX, 46C2HY, 46C2HZ, 46C2IA, 46C2IB, 46C2IC, 46C2ID, 46C2IE, 46C2IF, 46C2IG, 46C2IH, 46C2II, 46C2IJ, 46C2IK, 46C2IL, 46C2IM, 46C2IN, 46C2IO, 46C2IP, 46C2IQ, 46C2IR, 46C2IS, 46C2IT, 46C2IU, 46C2IV, 46C2IW, 46C2IX, 46C2IY, 46C2IZ, 46C2JA, 46C2JB, 46C2JC, 46C2JD, 46C2JE, 46C2JF, 46C2JG, 46C2JH, 46C2JI, 46C2JJ, 46C2JK, 46C2JL, 46C2JM, 46C2JN, 46C2JO, 46C2JP, 46C2JQ, 46C2JR, 46C2JS, 46C2JT, 46C2JU, 46C2JV, 46C2JW, 46C2JX, 46C2JY, 46C2JZ, 46C2KA, 46C2KB, 46C2KC, 46C2KD, 46C2KE, 46C2KF, 46C2KG, 46C2KH, 46C2KI, 46C2KJ, 46C2KK, 46C2KL, 46C2KM, 46C2KN, 46C2KO, 46C2KP, 46C2KQ, 46C2KR, 46C2KS, 46C2KT, 46C2KU, 46C2KV, 46C2KW, 46C2KX, 46C2KY, 46C2KZ, 46C2LA, 46C2LB, 46C2LC, 46C2LD, 46C2LE, 46C2LF, 46C2LG, 46C2LH, 46C2LI, 46C2LJ, 46C2LK, 46C2LL, 46C2LM, 46C2LN, 46C2LO, 46C2LP, 46C2LQ, 46C2LR, 46C2LS, 46C2LT, 46C2LU, 46C2LV, 46C2LW, 46C2LX, 46C2LY, 46C2LZ, 46C2MA, 46C2MB, 46C2MC, 46C2MD, 46C2ME, 46C2MF, 46C2MG, 46C2MH, 46C2MI, 46C2MJ, 46C2MK, 46C2ML, 46C2MN, 46C2MO, 46C2MP, 46C2MQ, 46C2MR, 46C2MS, 46C2MT, 46C2MU, 46C2MV, 46C2MW, 46C2MX, 46C2MY, 46C2MZ, 46C2NA, 46C2NB, 46C2NC, 46C2ND, 46C2NE, 46C2NF, 46C2NG, 46C2NH, 46C2NI, 46C2NJ, 46C2NK, 46C2NL, 46C2NM, 46C2NN, 46C2NO, 46C2NP, 46C2NQ, 46C2NR, 46C2NS, 46C2NT, 46C2NU, 46C2NV, 46C2NW, 46C2NX, 46C2NY, 46C2NZ, 46C2OA, 46C2OB, 46C2OC, 46C2OD, 46C2OE, 46C2OF, 46C2OG, 46C2OH, 46C2OI, 46C2OJ, 46C2OK, 46C2OL, 46C2OM, 46C2ON, 46C2OO, 46C2OP, 46C2OQ, 46C2OR, 46C2OS, 46C2OT, 46C2OU, 46C2OV, 46C2OW, 46C2OX, 46C2OY, 46C2OZ, 46C2PA, 46C2PB, 46C2PC, 46C2PD, 46C2PE, 46C2PF, 46C2PG, 46C2PH, 46C2PI, 46C2PJ, 46C2PK, 46C2PL, 46C2PM, 46C2PN, 46C2PO, 46C2PP, 46C2PQ, 46C2PR, 46C2PS, 46C2PT, 46C2PU, 46C2PV, 46C2PW, 46C2PX, 46C2PY, 46C2PZ, 46C2QA, 46C2QB, 46C2QC, 46C2QD, 46C2QE, 46C2QF, 46C2QG, 46C2QH, 46C2QI, 46C2QJ, 46C2QK, 46C2QL, 46C2QM, 46C2QN, 46C2QO, 46C2QP, 46C2QQ, 46C2QR, 46C2QS, 46C2QT, 46C2QU, 46C2QV, 46C2QW, 46C2QX, 46C2QY, 46C2QZ, 46C2RA, 46C2RB, 46C2RC, 46C2RD, 46C2RE, 46C2RF, 46C2RG, 46C2RH, 46C2RI, 46C2RJ, 46C2RK, 46C2RL, 46C2RM, 46C2RN, 46C2RO, 46C2RP, 46C2RQ, 46C2RR, 46C2RS, 46C2RT, 46C2RU, 46C2RV, 46C2RW, 46C2RX, 46C2RY, 46C2RZ, 46C2SA, 46C2SB, 46C2SC, 46C2SD, 46C2SE, 46C2SF, 46C2SG, 46C2SH, 46C2SI, 46C2SJ, 46C2SK, 46C2SL, 46C2SM, 46C2SN, 46C2SO, 46C2SP, 46C2SQ, 46C2SR, 46C2SS, 46C2ST, 46C2SU, 46C2SV, 46C2SW, 46C2SX, 46C2SY, 46C2SZ, 46C2TA, 46C2TB, 46C2TC, 46C2TD, 46C2TE, 46C2TF, 46C2TG, 46C2TH, 46C2TI, 46C2TJ, 46C2TK, 46C2TL, 46C2TM, 46C2TN, 46C2TO, 46C2TP, 46C2TQ, 46C2TR, 46C2TS, 46C2TT, 46C2TU, 46C2TV, 46C2TW, 46C2TX, 46C2TY, 46C2TZ, 46C2UA, 46C2UB, 46C2UC, 46C2UD, 46C2UE, 46C2UF, 46C2UG, 46C2UH, 46C2UI, 46C2UJ, 46C2UK, 46C2UL, 46C2UM, 46C2UN, 46C2UO, 46C2UP, 46C2UQ, 46C2UR, 46C2US, 46C2UT, 46C2UU, 46C2UV, 46C2UW, 46C2UX, 46C2UY, 46C2UZ, 46C2VA, 46C2VB, 46C2VC, 46C2VD, 46C2VE, 46C2VF, 46C2VG, 46C2VH, 46C2VI, 46C2VJ, 46C2VK, 46C2VL, 46C2VM, 46C2VN, 46C2VO, 46C2VP, 46C2VQ, 46C2VR, 46C2VS, 46C2VT, 46C2VU, 46C2VV, 46C2VW, 46C2VX, 46C2VY, 46C2VZ, 46C2WA, 46C2WB, 46C2WC, 46C2WD, 46C2WE, 46C2WF, 46C2WG, 46C2WH, 46C2WI, 46C2WJ, 46C2WK, 46C2WL, 46C2WM, 46C2WN, 46C2WO, 46C2WP, 46C2WQ, 46C2WR, 46C2WS, 46C2WT, 46C2WU, 46C2WV, 46C2WW, 46C2WX, 46C2WY, 46C2WZ, 46C2XA, 46C2XB, 46C2XC, 46C2XD, 46C2XE, 46C2XF, 46C2XG, 46C2XH, 46C2XI, 46C2XJ, 46C2XK, 46C2XL, 46C2XM, 46C2XN, 46C2XO, 46C2XP, 46C2XQ, 46C2XR, 46C2XS, 46C2XT, 46C2XU, 46C2XV, 46C2XW, 46C2XX, 46C2XY, 46C2XZ, 46C2YA, 46C2YB, 46C2YC, 46C2YD, 46C2YE, 46C2YF, 46C2YG, 46C2YH, 46C2YI, 46C2YJ, 46C2YK, 46C2YL, 46C2YM, 46C2YN, 46C2YO, 46C2YP, 46C2YQ, 46C2YR, 46C2YS, 46C2YT, 46C2YU, 46C2YV, 46C2YW, 46C2YX, 46C2YY, 46C2YZ, 46C2ZA, 46C2ZB, 46C2ZC, 46C2ZD, 46C2ZE, 46C2ZF, 46C2ZG, 46C2ZH, 46C2ZI, 46C2ZJ, 46C2ZK, 46C2ZL, 46C2ZM, 46C2ZN, 46C2ZO, 46C2ZP, 46C2ZQ, 46C2ZR, 46C2ZS, 46C2ZT, 46C2ZU, 46C2ZV, 46C2ZW, 46C2ZX, 46C2ZY, 46C2ZZ		

201876007-010	MAIN LANDING GEAR	MESSIER DOWTY	A320	32	AEG Seville
201876007-020	LH MAIN LANDING GEAR	MESSIER DOWTY	A320	32	AEG Seville
201876007-030	LH LEG ASSY M/LG	MESSIER DOWTY	A320	32-11-32	AEG Seville
201876007-036	MAIN LANDING GEAR	MESSIER DOWTY	A320	32	AEG Seville
201876007-040	LH M/LG	MESSIER DOWTY	A320,A320-221	32-11-11	AEG Seville
201876008-010	RH LEG ASSEMBLY M/LG	MESSIER DOWTY	A320	32-11-32	AEG Seville
201876008-020	RH LEG ASSEMBLY M/LG	MESSIER DOWTY	A320	32-11-32	AEG Seville
201876008-030	RH LEG ASSY MAIN LG	MESSIER DOWTY	A320,A320-221	32-11-11	AEG Seville
201876008-036	RH LEG ASSEMBLY M/LG	MESSIER DOWTY	A320	32	AEG Seville
201876008-040	RH MAIN LANDING GEAR	MESSIER DOWTY	A320	32-11-32	AEG Seville
201876001-010	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-020	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-030	LH M/LDG	MESSIER-DOWTY	A320	32-11-82	AEG Seville
201876001-040	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-050	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-060	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-070	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-080	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-090	LH M/LG	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-100	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-110	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876001-120	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876002-010	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876002-020	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876002-030	RH M/LDG	MESSIER-DOWTY	A320	32-11-82	AEG Seville
201876002-040	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876002-050	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876002-060	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876002-090	RH LMG	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876002-100	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876002-110	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201876002-120	M/LG LEG AND DRESSINGS	MESSIER-DOWTY	A321	32-11-82	AEG Seville
201999 SERIES	MAIN LANDING GEAR HARNESS	SAFRAN LANDING GEAR HARNESS	A320,A320-220	32-11-88	AEG Seville
201400 SERIES	MAIN LANDING GEAR HARNESS	SAFRAN LANDING GEAR HARNESS	A321	32-12-28	AEG Seville
201401 SERIES	M/LG LEG AND AXLE HARNESS	ULTRA PCS LIMITED SAFRAN LANDING	A318/A319/A320	32-11-44	AEG Seville
201402 SERIES	AXLE HARNESS	ULTRA PCS LIMITED SAFRAN LANDING	A321	32-12-29	AEG Seville
20191001-020	DAMPER	MOORE & WATSON	A318,A321,A320,A319,B747	32	AEG Seville
201480002-010	BOGIE PITCH TRIMMER	#N/D	A330		AEG Seville
201480002-016	BOGIR PITCH TRIMMER	MESSIER DOWTY	A340,A330	32-12-09	AEG Seville
201480002-020	BOGIE PITCH TRIMMER	MESSIER DOWTY	A340,A330	32-12-09	AEG Seville
201481001-006	UNLOCK ACTUATOR	MESSIER DOWTY	A340,A330	32	AEG Seville
201484001-006	STAY-COMPLETE SIDE LH	MESSIER-DOWTY	A330	32-12-06	AEG Seville
201484001-010	STAY-COMPLETE SIDE LH	MESSIER-DOWTY	A330	32-12-06	AEG Seville
201484001-016	STAY-COMPLETE SIDE LH	MESSIER-DOWTY	A330	32-12-06	AEG Seville
201484002-006	M/LG SIDE STAY COMPLETE	MESSIER-DOWTY	A330	32-12-06	AEG Seville
201487001-010	STRUT-SHOCK	HONEYWELL	A330		AEG Seville
201620 SERIES	M/LG LEG AND AXLE HARNESS	SAFRAN LANDING GEAR HARNESS	A318/A319/A320	32-11-44	AEG Seville
201624001-030	SIDE STAY COMPLETE	SAFRAN	A320	32	AEG Seville
201690002-020	RETRACTION ACTUATOR	MESSIER SERVICES	CRJ Regional Jet-200,A318,A320-221,A320-200,A320,A320,A320	32-32-31-86	AEG Seville
201640001-010	STAY ASSY-SIDE M/LG	MESSIER-DOWTY	A320	32-12-13	AEG Seville
20219-0101	HYDRAULIC OIL QUANTITY TRANSMITTER	SIMMONDS PRECISION	B737-700,CRJ Regional Jet-200,B737-400,B737-800	29-30-24	AEG Seville
20220-01	COMPENSATOR		UNK		AEG Seville
20220-0101	QTY TRANSMITTER	SIMMONDS PRECISION	CRJ Regional Jet-200,B737-800,B737-400,B737	29-30-24	AEG Seville
2041207-2	STATOR	ALLIED SIGNAL AEROSP	UNK		AEG Bilbao
2046M63P01	ALTERNATOR		UNK		AEG Bilbao
2046M63P02	ALTERNATOR		UNK		AEG Bilbao
204790-1-1	TURBINE DRIVEN CENTRIFUGAL COMPRESSOR	HONEYWELL	P-3	3-30AK-94	AEG Seville
204790-2-1	COMPRESSOR CENTRIFUGA	HONEYWELL	P-3	3-30AK-94	AEG Seville
2067693-2657	VHF NAV RECEIVER	BENDIX	B737-300,M80,DC-10,DC-9,DC-8	34	AEG Seville
2070943-0101	ANTENNA COP	BENDIX	B737-300,DC-10,DC-9,DC-8,A320,B747-400,B737-200,A320,B737-800	34-41-22	AEG Seville
209A10	CONTROL UNIT-INTE		UNK		AEG Seville
2100140-003	Throttle Gearbox Assembly			76-10-04	AEG Seville
2100140-006	Throttle Gearbox Assembly			76-10-04	AEG Seville
2100140-007	Throttle Gearbox Assembly			76-10-04	AEG Seville
2107-1A	Attendant Seats				AEG Seville
2107-1AB	Attendant Seats				AEG Seville
2107-1AC	Attendant Seats				AEG Seville
2107-1AD	Attendant Seats				AEG Seville
2107-1AE	Attendant Seats				AEG Seville
2107-1AF	Attendant Seats				AEG Seville
2107-1AG	Attendant Seats				AEG Seville
2107807Y01	CONTROL LEVER	ZODIAC	A321,A319,A320-221,A340-315,A320-200,B747-400,A320,A320	32	AEG Seville
2102MN-372M	Fault Indicator			2102MN-372M	AEG Seville
219764-2	Selector, Cabin Pressure		CRJ Regional Jet-100	21-32-30	AEG Seville
219764-4	Selector, Cabin Pressure		CRJ Regional Jet-100	21-32-30	AEG Seville
219764-6	Selector, Cabin Pressure		CRJ Regional Jet-100,CRJ Regional Jet-200	21-32-30	AEG Seville
219764-6	Selector, Cabin Pressure		CRJ Regional Jet-100,CRJ Regional Jet-200	21-32-30	AEG Seville
21C223-176	HYDRAULIC PRESSURE SWITCH	CONDEC / CONSOLIDATED	B747-200,B777,B757,B767,B737,B767	29-09-01,29	AEG Seville
21C223-177	HYDRAULIC PRESSURE SWITCH	CONDEC / CONSOLIDATED	CRJ-700,B747-400	32-29-09-01,29	AEG Seville
21C223-178	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B777,B747,B757,B767	29-09-01	AEG Seville
21C223-199	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-200	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-203	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-208	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-209	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-211	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	DC-10,DC-9,DC-8,B737-200	29-09-02	AEG Seville
21C223-212	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-214	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-216	HYDRAULIC PRESSURE SWITCH	EATON/CONDEC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-262	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-263	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-276	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-297	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-301	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-312	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-319	HYDRAULIC PRESSURE SWITCH	CONDEC / CONSOLIDATED	B707/CRJ Regional Jet-200,B737-200	29-09-01	AEG Seville
21C223-320	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-321	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-322	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-323	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-324	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B707/CRJ Regional Jet-200,B737-200	29-09-02	AEG Seville
21C223-326	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	CRJ Regional Jet-200,B737-200,B767,B757	29-09-03	AEG Seville
21C223-327	HYD PRESSURE SWITCH	EATON AEROSPACE LLC	B737-300,A300,B767,B747,B757-200,B757	29-09-03	AEG Seville
21C223-341	HYDRAULIC SWITCH PRESSURE	EATON	B757,B777,B737	29	AEG Seville
21C223-461A	SWITCH-PRESSURE	EATON	B737-300,CRJ Regional Jet-200,CRJ Regional Jet-100	29-34-01,29	AEG Seville
21C223-461A	Pressure Switch	EATON	B737-300,CRJ Regional Jet-200,CRJ Regional Jet-100	29-34-01	AEG Seville
21C223-416	HYD PRESSURE SWITCH	EATON ELECTRICAL ELECTRICAL CONTROLS	B737-300,B757-300,B737-800,B737-400,B737-200,B737-800	29-09-04	AEG Seville
21C223-418	HYDRAULIC PRESSURE SWITCH	EATON	B737-300,B757-300,B737-800,B737-400,B737-200	29-09-05	AEG Seville
21C223-419	HYDRAULIC PRESSURE SWITCH	CUSTOM CONTROLS	B777,B767,B757,B737	29-09-05	AEG Seville
21C223-420	HYDRAULIC PRESSURE SWITCH	EATON	B777,B757,B737,B767	29-09-05	AEG Seville
21C223-421	HYDRAULIC PRESSURE SWITCH	EATON/CONDEC	B767,B777,B757,B737	29-09-05	AEG Seville
21C223-422	HYDRAULIC PRESSURE SWITCH	EATON	B767,B777,B757,B737	29-09-05	AEG Seville
21C223-423	HYDRAULIC PRESSURE SWITCH	EATON	B767,B777,B757,B737	29-09-05	AEG Seville
21C223-424	HYDRAULIC PRESSURE SWITCH	EATON	B777,B767,B757,B737	29-09-05	AEG Seville
21C223-426	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B737,B767,B757	29-09-06,29	AEG Seville
21C223-427	HYDRAULIC PRESSURE SWITCH	BOEING	B737-300,B737-900,B737-800,B737-700,B737-400,B737-200,B737-800	29-09-05	AEG Seville
21C223-428	HYDRAULIC PRESSURE SWITCH	EATON AEROSPACE LLC	B737,B777,B767,B757	29-09-06,29	AEG Seville

21IC223-634	HYDRAULIC PRESSURE SWITCH	EATON ELECTRICAL	CRJ Regional Jet	29-09-04	AEG Sevilla
21IC223-635	HYDRAULIC PRESSURE SWITCH	EATON	7B73.B747.B767	29-09-07.29	AEG Sevilla
21IC223-XXX	HYDRAULIC PRESSURE SWITCH	EATON	8737-500.8737-400.8737-300.8767.8757	29	AEG Sevilla
21IRJ78A001	Photoluminescent floor Proximity Emergency			33-52-13	AEG Sevilla
21IRJ78A002	Photoluminescent floor Proximity Emergency			33-52-13	AEG Sevilla
214001-10	PANEL CONTROL, ELECTRIC		UNK		AEG Sevilla
2-1466-3	Main Brake Assembly			32-42-17	AEG Sevilla
2-1466-4	Main Brake Assembly			32-42-17	AEG Sevilla
2-1466-5	Main Brake Assembly			32-42-17	AEG Sevilla
214C40-1-116	ALTITUDE SWITCH	EATON	A320.8737-300.8747-	34-11-01	AEG Sevilla
214C40-1-71	SWITCH	EATON	A320.8737-300.8747-	34-11-01	AEG Sevilla
214C40-1-75	PRUSSURE SPARE PARTS	EATON	A320.8737-300.8747-	34-11-01	AEG Sevilla
214C40-1-77	ALTITUDE SWITCH	EATON	A320.8737-300.8747-	34-11-01	AEG Sevilla
2-1517	Main Brake Assembly			32-46-70	AEG Sevilla
2-1565	Main Landing Gear Brake Assembly			32-46-88	AEG Sevilla
2-1576	MAIN LANDING GEAR BRAKE ASSEMBLY	BFG	King CN-235. King Air 200	32-46-27	AEG Sevilla
216TS07Y00	LEVER	ZODIAC	A340.A330.A321.A319.A320	32-31-13	AEG Sevilla
2-1605	MLG Brake Assembly			32-48-33	AEG Sevilla
2-1605-1	MLG Brake Assembly			32-48-33	AEG Sevilla
2-1605-2	MLG Brake Assembly			32-48-33	AEG Sevilla
218066-1	APU FUEL PUMP	ZODIAC	8737-200. 8737-300. 8737-400. 8737-500.	28.28-25-04	AEG Sevilla
218066-2	APU FUEL PUMP	ZODIAC	8737-200. 8737-300. 8737-400. 8737-500.	28.28-25-04	AEG Sevilla
218066-3	APU FUEL PUMP	ZODIAC	8737-200. 8737-300. 8737-400. 8737-500.	28.28-25-04	AEG Sevilla
21C1-1-158	PRESSURE SWITCH	EATON	8777.A300	79-34-11	AEG Sevilla
21C1-3-21	FUEL PRESS SWITCH	AEROSPACE	8747-400.8767.8757.8747.8737	28-42-01	AEG Sevilla
21C1-3-22	FUEL PRESS SWITCH	AEROSPACE	8737-84N.8767.8757.8747.8757	28-42-01	AEG Sevilla
21SN04-104A	PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-104B	PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-104D	SCAVENGE OIL FILTER DIFFERENTIAL	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-104E	PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-104F	PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-168A	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-168B	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-168C	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-168D	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-169	ENGINE FUEL LOW PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-169A	ENGINE FUEL LOW PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-169B	ENGINE FUEL LOW PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-169C	ENGINE FUEL LOW PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-169D	ENGINE FUEL LOW PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-207A	SWITCH-OIL	CONDEC	CF6-80C2.8737-300.8747.8737.CFM56-3	79-09-03	AEG Sevilla
21SN04-211	PRESSURE SWITCH	CONDEC	8737-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-21A	PRESSURE SWITCH	CONDEC	8737-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-223	FUEL PRESSURE SWITCH	EATON / 02750	A320.A330.A321.A319.A320	79-21-25	AEG Sevilla
21SN04-224	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	A320.A330.A321.A319.A320	79-34-02	AEG Sevilla
21SN04-225	SWITCH-OIL PRESSURE	EATON AEROSPACE LLC	A320.A330.A321.A319.A320	79-34-02	AEG Sevilla
21SN04-226	PRESSURE SWITCH	CONDEC	8737-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-226A	PRESSURE SWITCH	CONDEC	8737-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-23F	PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-23G	PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-23H	PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-23J	LOW OIL PRESS WIRING SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-23K	PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-24F	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-24G	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-24H	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-24J	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-24K	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-25F	ENGINE FUEL LOW PRESSURE SWITCH	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-25G	ENGINE FUEL LOW PRESSURE SWITCH	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-25H	ENGINE FUEL LOW PRESSURE SWITCH	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-25J	ENGINE FUEL LOW PRESSURE SWITCH	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-25K	ENGINE FUEL LOW PRESSURE SWITCH	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-26E	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-26F	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-26G	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-26H	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-26J	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON	8737.8747-200L-101L.8777.8767.8757.8747	31-09-01	AEG Sevilla
21SN04-26K	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE LLC	A-320		AEG Sevilla
21SN04-276A	LOW OIL PRESSURE SWITCH	EATON	8757.A318.A320.V2500	79-34-15	AEG Sevilla
21SN04-298A	SCAVENGE FILTER PRESSURE SWITCH	EATON	CF6-80C2.A318.A320.V2500	79-35-16	AEG Sevilla
21SN04-300B	HYDRAULIC PRESSURE SWITCH	EATON	CF6-80C2.8737-300.V2500.A320.V2500-	73-34-15	AEG Sevilla
21SN04-306	LP OIL WARNING PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-306A	LP OIL WARNING PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-306B	LP OIL WARNING PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-306C	LP OIL WARNING PRESSURE SWITCH	EATON AEROSPACE LLC	8747-200.8777.8767.8757.8737.8747	31-09-01	AEG Sevilla
21SN04-323A	FUEL PRESSURE SWITCH	EATON / 02750	A320.A330.A321.A319.A320	79-21-25	AEG Sevilla
21SN04-324	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	A320.A330.A321.A319.A320	79-34-02	AEG Sevilla
21SN04-325	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	A320.A330.A321.A319.A320	79-34-02	AEG Sevilla
21SN04-333	FUEL PRESSURE SWITCH	EATON / 02750	A320.A330.A321.A319.A320	79-21-25	AEG Sevilla
21SN04-334	DIFFERENTIAL PRESSURE SWITCH	AIRBUS INDUSTRIES	A320	79-34-02	AEG Sevilla
21SN04-337A	ENGINE FUEL LOW PRESSURE SWITCH	EATON	8747.A330	73-33-11	AEG Sevilla
21SN04-338	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON	A330.8737	73-33-11	AEG Sevilla
21SN04-339C	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE	EATON	A330. A340	73-33-11	AEG Sevilla
21SN04-340	SCAVENGE OIL FILTER DIFFERENTIAL	EATON	A330	73-33-11.79-09-01	AEG Sevilla
21SN04-341A	SCAVENGE OIL FILTER DIFFERENTIAL	EATON	A340.A320	73-33-11	AEG Sevilla
21SN04-359A	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SN04-359B	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SN04-402	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SN04-403	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SN04-414	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SN04-415	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SN04-460	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SN04-461	SWITCH PRESSURE	EATON	PW4000	79-21-26	AEG Sevilla
21SN04-466	FUEL PRESSURE SWITCH	EATON / 02750	A320.8737-900.8737-800.8737-700.8737-	79-21-25	AEG Sevilla
21SN04-467	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	8747.8737.8767.8757.8737.8747	79-34-02	AEG Sevilla
21SN04-468	DIFFERENTIAL PRESSURE SWITCH	EATON AEROSPACE LLC	8747.8737.8767.8757.8737.8747	79-34-02	AEG Sevilla
21SN04-XXX	SCAVENGE OIL FILTER DIFFERENTIAL	EATON	DC-10.8747	72	AEG Sevilla
21SN41-42	PRESSURE SWITCH	CONSOLIDATED	8747.8737.8767	80-21-03	AEG Sevilla
21SN41-52	SWITCH-THERMAL ANTI ICE	CONSOLIDATED	8737-100.8737-300.8737-400.8737-500.	80-21-03	AEG Sevilla
21SN41-84	PRESSURE SWITCH	CONSOLIDATED	8747.8737.8747-400.8767	80-21-03	AEG Sevilla
226T4-1	Fuel Booster Pump		Challenger.CRJ-700	28-20-77	AEG Sevilla
226T4-3	Fuel Booster Pump		Challenger.CRJ-700	28-20-77	AEG Sevilla
226T5-1	Canister			28-20-78	AEG Sevilla
226T5-2	Canister			28-20-78	AEG Sevilla
226T5-3	Canister			28-20-78	AEG Sevilla
226T5-4	Canister			28-20-78	AEG Sevilla
226T5-5	Canister			28-20-78	AEG Sevilla
226T5-6	Canister			28-20-78	AEG Sevilla
226T5-7	Canister			28-20-78	AEG Sevilla
226T5-8	Canister			28-20-78	AEG Sevilla
226T5-9	Canister			28-20-78	AEG Sevilla
226T5-10	Canister			28-20-78	AEG Sevilla
226T5-11	Canister			28-20-78	AEG Sevilla
226T5-12	Canister			28-20-78	AEG Sevilla
226T5-13	Canister			28-20-78	AEG Sevilla
226T5-14	Canister			28-20-78	AEG Sevilla
226T5-15	Canister			28-20-78	AEG Sevilla
226T5-16	Canister			28-20-78	AEG Sevilla
226T5-17	Canister			28-20-78	AEG Sevilla
226T5-18	Canister			28-20-78	AEG Sevilla
226T5-19	Canister			28-20-78	AEG Sevilla
226T5-20	Canister			28-20-78	AEG Sevilla
226T5-21	Canister			28-20-78	AEG Sevilla
226T5-22	Canister			28-20-78	AEG Sevilla
226T5-23	Canister			28-20-78	AEG Sevilla
226T5-24	Canister			28-20-78	AEG Sevilla
226T5-25	Canister			28-20-78	AEG Sevilla
226T5-26	Canister			28-20-78	AEG Sevilla
226T5-27	Canister			28-20-78	AEG Sevilla
226T5-28	Canister			28-20-78	AEG Sevilla
226T5-29	Canister			28-20-78	AEG Sevilla
226T5-30	Canister			28-20-78	AEG Sevilla
226T5-31	Canister			28-20-78	AEG Sevilla
226T5-32	Canister			28-20-78	AEG Sevilla
226T5-33	Canister			28-20-78	AEG Sevilla
226T5-34	Canister			28-20-78	AEG Sevilla
226T5-35	Canister			28-20-78	AEG Sevilla
226T5-36	Canister			28-20-78	AEG Sevilla
226T5-37	Canister			28-20-78	AEG Sevilla
226T5-38	Canister			28-20-78	AEG Sevilla
226T5-39	Canister			28-20-78	AEG Sevilla
226T5-40	Canister			28-20-78	AEG Sevilla
226T5-41	Canister			28-20-78	AEG Sevilla
226T5-42	Canister			28-20-78	AEG Sevilla
226T5-43	Canister			28-20-78	AEG Sevilla
226T5-44	Canister			28-20-78	AEG Sevilla
226T5-45	Canister			28-20-78	AEG Sevilla
226T5-46	Canister			28-20-78	AEG Sevilla
226T5-47	Canister			28-20-78	AEG Sevilla
226T5-48	Canister			28-20-78	AEG Sevilla
226T5-49	Canister			28-20-78	AEG Sevilla
226T5-50	Canister			28-20-78	AEG Sevilla
226T5-51	Canister			28-20-78	AEG Sevilla
226T5-52	Canister			28-20-78	AEG Sevilla
226T5-53	Canister			28-20-78	AEG Sevilla
226T5-54	Canister			28-20-78	AEG Sevilla
226T5-55	Canister			28-20-78	AEG Sevilla
226T5-56	Canister			28-20-78	AEG Sevilla
226T5-57	Canister			28-20-78	AEG Sevilla
226T5-58	Canister			28-20-78	AEG Sevilla
226T5-59	Canister			28-20-78	AEG Sevilla
226T5-60	Canister			28-20-78	AEG Sevilla
226T5-61	Canister			28-20-78	AEG Sevilla
226T5-62	Canister			28-20-78	AEG Sevilla
226T5-63	Canister			28-20-78	AEG Sevilla
226T5-64	Canister		</		

23066-SERIES	DC STARTER GENERATOR	GOODRICH	Helix/Corporate		AEQ Seattle
23066-1620	DRIVE SHAFT	NONE SPECIFIED	UNK		AEQ Seattle
23069-SERIES	DC STARTER GENERATOR	LEAR SIEGLER	C-212		AEQ Seattle
23078-003	DC STARTER GENERATOR	LUCAS AEROSPACE/ASI	Hawker	24	AEQ Seattle
23078-003-1	DC STARTER GENERATOR	LUCAS AEROSPACE/ASI	Hawker	24	AEQ Seattle
23078-005	DC STARTER GENERATOR	LUCAS AEROSPACE/ASI	Hawker Merlin	24	AEQ Seattle
23078-006-1	DC STARTER GENERATOR	LUCAS AEROSPACE/ASI	Hawker	24	AEQ Seattle
23078-006	DC STARTER GENERATOR	LUCAS AEROSPACE/ASI	Hawker Cessna	24	AEQ Seattle
23078-007	DC STARTER GENERATOR	GOODRICH MONROE	Hawker	24-30-06,24	AEQ Seattle
23078-008	DC STARTER GENERATOR	LUCAS AEROSPACE/ASI	Hawker	24	AEQ Seattle
23078-009	DC STARTER GENERATOR	LUCAS AEROSPACE/ASI	Hawker Embraer	24	AEQ Seattle
23078-010	DC STARTER GENERATOR	GOODRICH MONROE	Hawker/1900,Cessna,Caravan	72, 80	AEQ Seattle
23078-011	DC STARTER GENERATOR	LUCAS	Hawker/1900,Cessna,Caravan	72, 80	AEQ Seattle
23078-012	DC STARTER GENERATOR	GOODRICH MONROE	Hawker/1900,Cessna,Caravan	72, 80	AEQ Seattle
23078-020	STARTER GENRATOR	GOODRICH MONROE	Hawker/1900,Cessna,Caravan	72, 80	AEQ Seattle
23089-100X	DC Starter-Generator			24-30-20	AEQ Seattle
231M-15	Windshield Wiper Motor			30-42-06	AEQ Seattle
231M-16	Windshield Wiper Motor			30-42-10	AEQ Seattle
231M-16	Windshield Wiper Motor			30-42-10	AEQ Seattle
231M-17	Windshield Wiper Motor			30-42-10	AEQ Seattle
231M-41	Windshield Wiper Converter Assembly			30-43-03	AEQ Seattle
2313M-227-1	Windshield Wiper Motor-Converter			30-40-12	AEQ Seattle
2313M-227-2	Windshield Wiper Motor-Converter			30-40-12	AEQ Seattle
2313M-248-1	Windshield Wiper Motor-Converter Assembly		BT47	30-40-01	AEQ Seattle
2313M-340-2	Windshield Wiper Motor-Converter		CRJ Regional Jet-200	30-40-10	AEQ Seattle
2313M-341-2	Windshield Wiper Motor-Converter		CRJ Regional Jet-200,CRJ-700	30-40-10	AEQ Seattle
2316M08-2	Blade Assy			30-44-06	AEQ Seattle
2316M-84-2	Windshield Wiper Blade Assembly			30-44-08	AEQ Seattle
2321H000-002	Hydraulic System, Landing Gear			32-30-09	AEQ Seattle
2321H000-003	Hydraulic System, Landing Gear			32-30-09	AEQ Seattle
2322H000-4	Hydraulic System		CRJ-700	32-30-04	AEQ Seattle
2322H000-5	Hydraulic System		CRJ-700	32-30-04	AEQ Seattle
2333A201	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BOEING	BT37	30-09-05	AEQ Seattle
2333A201-11	WINDOW AND PITOT HEAT MODULE ASSEMBLY	THE BOEING	BT37-300,BT37-600,BT37	30-09-05	AEQ Seattle
2333A201-12	WINDOW AND PITOT HEAT MODULE ASSEMBLY	THE BOEING	BT37-300,BT37-600,BT37	30-09-05	AEQ Seattle
2333A201-13	WINDOW/PITOT HEAT MODULE ASSY	BAE SYSTEMS	BT37-300,BT37,BT37-600	30-09-05	AEQ Seattle
2333A201-14	WINDOW/PITOT HEAT MODULE ASSY	BAE SYSTEMS	BT37-300,BT37,BT37-600	30-09-05	AEQ Seattle
2333A201-2	WINDOW PITOT HEAT MODULE	THE BOEING	BT37-300,BT37-600,BT37	30-09-05	AEQ Seattle
2333A201-302	WINDOW PITOT HEAT MODULE	BAE SYSTEMS	BT37-300,BT37,BT37-86N	30-09-05	AEQ Seattle
2333A201-306	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BAE SYSTEMS	BT37-300,BT37,BT37-683	30-09-05	AEQ Seattle
2333A201-306	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BAE SYSTEMS	BT37-300,BT37	30-09-05	AEQ Seattle
2333A201-307	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BAE SYSTEMS	BT37-300,BT37	30-09-05	AEQ Seattle
2333A201-307 MOD A	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BAE SYSTEMS	737	30-09-05	AEQ Seattle
2333A201-309	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BAE SYSTEMS	BT37-300,BT37	30-09-05	AEQ Seattle
2333A201-309 MOD A	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BAE SYSTEMS	737	30-09-05	AEQ Seattle
2333A201-311	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BAE SYSTEMS	BT37-300,BT37	30-09-05	AEQ Seattle
2333A201-311 MOD A	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BAE SYSTEMS	737	30-09-05	AEQ Seattle
2333A201-312	WINDOW AND PITOT HEAT MODULE ASSEMBLY	BAE SYSTEMS	737	30-09-05	AEQ Seattle
2333M21-1041	BATTERY/STANDBY POWER PANEL ASSEMBLY	BAE SYSTEMS	BT67,BT87	24-33-72,31	AEQ Seattle
2333M21-1042	BATTERY/STANDBY POWER PANEL ASSEMBLY	BAE SYSTEMS	BT67,BT87	24-33-72	AEQ Seattle
2333M21-1046	BATTERY/STANDBY POWER PANEL ASSEMBLY	BAE SYSTEMS	BT67,BT87	24-33-72	AEQ Seattle
2333M21-1300	BATTERY/STANDBY POWER PANEL ASSEMBLY	BAE SYSTEMS	BT67,BT87	24-33-72	AEQ Seattle
2333M21-1301	BATTERY/STANDBY POWER PANEL ASSEMBLY	BAE SYSTEMS	BT67,BT87	24-33-72	AEQ Seattle
2333M21-1302	BATTERY/STANDBY POWER PANEL ASSEMBLY	BAE SYSTEMS	BT67,BT87	24-33-72	AEQ Seattle
2333M21-1303	BATTERY/STANDBY POWER PANEL ASSEMBLY	BAE SYSTEMS	BT67,BT87	24-33-72	AEQ Seattle
2333M21-1304	BATTERY/STANDBY POWER PANEL ASSEMBLY	BAE SYSTEMS	BT67,BT87	24-33-72	AEQ Seattle
2333M21-1306</					

[illegible]

[illegible]

286T0664-3 MOD. E	VOR CONTROL PANEL	BAE SYSTEMS	767, 767		AEG Seville
286T0664-3A	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-3B	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-3C	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-3D	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-3E	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-4	VOR CONTROL PANEL	THE BOEING	8767,B757	34-51-61	AEG Seville
286T0664-4A	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-5	VOR/DME CONTROL PANEL	THE BOEING	8767,B757	34-51-61	AEG Seville
286T0664-5 MOD. A	VOR CONTROL PANEL	BAE SYSTEMS	767, 767		AEG Seville
286T0664-5 MOD. B	VOR CONTROL PANEL	BAE SYSTEMS	767, 767		AEG Seville
286T0664-5 MOD. C	VOR CONTROL PANEL	BAE SYSTEMS	767, 767		AEG Seville
286T0664-5 MOD. D	VOR CONTROL PANEL	BAE SYSTEMS	767, 767		AEG Seville
286T0664-5 MOD. E	VOR CONTROL PANEL	BAE SYSTEMS	767, 767		AEG Seville
286T0664-5A	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-5B	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-5C	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-5D	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-5E	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-6	VOR CONTROL PANEL	THE BOEING	8757-200,B767,B757	34-51-61	AEG Seville
286T0664-6 MOD. A	VOR CONTROL PANEL	BAE SYSTEMS	767, 767		AEG Seville
286T0664-6 MOD. AE	VOR CONTROL PANEL	BAE SYSTEMS	767, 767		AEG Seville
286T0664-6A	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-6AB	VOR CONTROL PANEL	BOEING	767, 767		AEG Seville
286T0664-6B	VOR CONTROL PANEL	BAE SYSTEMS	767, 767		AEG Seville
286T0667-1	ADF CONTROL PANEL	BOEING	8767,B757	34-57-42	AEG Seville
286T0667-2	ADF CONTROL PANEL	BOEING	A320,B727,B767,B757	34-57-42	AEG Seville
286T0662	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	UNK		AEG Seville
286T0662-1	KEYPAD COCKPIT DOOR ACCESS	THE BOEING	B737-300,B747-300,B757-300,B767-300,B777-300,B787-300,B797-300,B757-300,B767-300,B777-300,B787-300,B797-300	52-51-03	AEG Seville
286T0662-1 MOD A	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	UNK		AEG Seville
286T0662-1 MOD AB	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	UNK		AEG Seville
286T0662-1A	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	UNK		AEG Seville
286T0662-1B	FLIGHT DECK ACCESS MODULE KEYPAD	BAE SYSTEMS	UNK		AEG Seville
286T0665-1	CONTROLLER FDAS	BOEING	B747-400,B737-400,B757-400,B767-400,B777-400,B787-400,B797-400	52-51-04	AEG Seville
286T0665-6	FLIGHT DECK ACCESS SYSTEM CONTROLLER	BAE SYSTEMS	B777	52-51-04	AEG Seville
286T1104-1	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-10	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-11	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-13	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-16	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-17	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-17 MOD B	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	B-767-B-757	27-32-52	AEG Seville
286T1104-17 MOD BC	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	B-767-B-757	27-32-52	AEG Seville
286T1104-17 MOD C	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	B-767-B-757	27-32-52	AEG Seville
286T1104-17B	WARNING ELECTRONIC UNIT STALL		B-767-B-757		AEG Seville
286T1104-17BC	WARNING ELECTRONIC UNIT STALL		B-767-B-757		AEG Seville
286T1104-17C	WARNING ELECTRONIC UNIT STALL		B-767-B-757		AEG Seville
286T1104-18	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-18 MOD A	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	B-767-B-757	27-32-52	AEG Seville
286T1104-18 MOD AB	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	B-767-B-757	27-32-52	AEG Seville
286T1104-18 MOD B	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	B-767-B-757	27-32-52	AEG Seville
286T1104-18A	WARNING ELECTRONIC UNIT STALL		B-767-B-757		AEG Seville
286T1104-18AB	WARNING ELECTRONIC UNIT STALL		B-767-B-757		AEG Seville
286T1104-18B	WARNING ELECTRONIC UNIT STALL		B-767-B-757		AEG Seville
286T1104-18B	WARNING ELECTRONIC UNIT STALL		B-767-B-757		AEG Seville
286T1104-19	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-21	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-22	PC ASSY - STALL WARNING	BOEING	8757,B767	27-32-52	AEG Seville
286T1104-23	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-24	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	B-767-B-757	27-32-52	AEG Seville
286T1104-9	WARNING ELECT UNIT STALL WARN/WIND	BAE SYSTEMS	8757,B767	27-32-52	AEG Seville
286T1104-SERIES	WARNING ELECT UNIT STALL WARN/WIND		B-767-B-757		AEG Seville
2860022-101	Vent Relief Valve		C-130		AEG Seville
2860022-102	Vent Relief Valve		C-130		AEG Seville
286465-7	GENERATOR	HONEYWELL	B737-300,B737-400,B757-300,B757-400,B767-300,B767-400,B777-300,B777-400,B787-300,B787-400,B797-300,B797-400	49-41-21	AEG Bilbao
286465-7A	STARTER GENERATOR	S-GEN	B737,CFM56-7B,LEAP-1B	49-41-21	AEG Seville
286465-7B	STARTER GENERATOR	HONEYWELL	B737,CFM56-7B,LEAP-1B	49-41-21	AEG Seville
286465-9	STARTER/GENERATOR	HONEYWELL	B737-600,B737,CFM56-7B,LEAP-1B	49-41-21	AEG Seville
286555-1	AC GENERATOR	HONEYWELL	UNK		AEG Bilbao
286555-1A	AC GENERATOR		UNK		AEG Bilbao
286555-1B	AC GENERATOR		UNK		AEG Bilbao
286555-1C	AC GENERATOR		UNK		AEG Bilbao
286555-1D	AC GENERATOR		UNK		AEG Bilbao
286555-1E	AC GENERATOR		UNK		AEG Bilbao
29-1206246-00	DELAY VALVE	MESSIER-DOWTY	A340	32-30-99	AEG Seville
2940025-102	Engine Feed Shutoff Valve			28-21-29	AEG Seville
2940049-100	Alt Tank Refuel Shutoff Valve			28-23-33	AEG Seville
2944T00-SERIES	POWER DRIVE UNIT	TELAIR	A319, A320, A321	26-51-18	AEG Seville
2955T00-SERIES	POWER DRIVE UNIT	TELAIR	A330, A340	26-51-19	AEG Seville
2C0453C7H	AC GEN		UNK		AEG Bilbao
2LA002607-22	Service Light		CRJ-700	33-31-12	AEG Seville
2LA002760-39	Strobe Light (Red)		A320,CRJ Regional Jet-200,A300,A310,DC-10,M.D. 11	33-42-15	AEG Seville
2LA006109-00	Cargo Compartment Light		A300,CRJ-700,B737	33-20-06	AEG Seville
2LA00611	Dome Light			33-20-08	AEG Seville
2LA00612	Dome Light			33-20-08	AEG Seville
2LA00616	Dome Emergency Light And Ceiling Light			33-52-09	AEG Seville
2LA006165-20	Flight Crew Reading Light		A320,CRJ Regional Jet-200,CRJ700	33-11-22	AEG Seville
2LA006177-65	Passenger Service Unit		CRJ Regional Jet-200,ATR 72	33-22-11	AEG Seville
2LA006303-01	TAIL STROBE LIGHT	HELLA	A318,B747,A320,A321,A330,A340,A350,A380,B737-400	33-42-21	AEG Seville
2LA006303-06	TAIL STROBE LIGHT	HELLA	A318,A319,A320,A321,A330,A340,A350,A380,B737-400	33-42-21	AEG Seville
2LA006308-01	WING STROBE LIGHT	HELLA	A318,A319,A320,A321,A330,A340,A350,A380,B737-400	33-42-31	AEG Seville
2LA006308-05	WING STROBE LIGHT	HELLA	A318,A319,A320,A321,A330,A340,A350,A380,B737-400	33-42-31	AEG Seville
2LA006414-01	Warning Emergency Light, 10W & 768W, LH & RH		A320-200,B737,A320,A321,A318,A319	33-25-01	AEG Seville
2LA006467-00	Warning Light, red & Warning Light		A321,A319,A320,A318	33-25-02	AEG Seville
2LA006469-00	Warning Light, white "SLIDE ARMED"			33-25-12	AEG Seville
2LA006938	Flight Attendant Call Light			33-25-12	AEG Seville
2LA006178-02	Wing Strobe Light		CRJ Regional Jet-200,C-130,CRJ-700	33-42-26	AEG Seville
2LA006181-01	Rear Pos. Strobe Light		A300,CRJ900 Regional Jet,CRJ Regional Jet	33-42-27	AEG Seville
2LA006181-22	Rear Pos. Strobe Light		A300,CRJ Regional Jet-200,C-130,CRJ-700	33-42-27	AEG Seville
2LA006419-70	Tail Light		CRJ-700,CRJ Regional Jet-200,CRJ900	33-42-28	AEG Seville
2LA006419-71	Tail Light		CRJ Regional Jet-200,CRJ900	33-42-28	AEG Seville
2LA006616-22	Navigation Light		CRJ-700,B727	33-42-29	AEG Seville
2LA006616-22	Navigation Light		CRJ-700,B767	33-42-29	AEG Seville
2LA006636-11	Passenger Service Unit		CRJ Regional Jet-200,CRJ-700	33-22-11	AEG Seville
2LA006636-12	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Seville
2LA006636-21	Passenger Service Unit		B737,CRJ Regional Jet-200	33-22-11	AEG Seville
2LA006636-22	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Seville
2LA006636-31	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Seville
2LA006636-32	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Seville
2LA006636-41	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Seville
2LA006636-42	Passenger Service Unit		CRJ Regional Jet-200	33-22-11	AEG Seville
2LA006823-70	Cargo Compartment Light		CRJ-700,F100	33-31-13	AEG Seville
2LA007353-45	Passenger Service Unit		B737	33-22-11	AEG Seville
2LA083633-00	Chart Holder Light Assy, Housing Assy		A320,A318,A321,A319,A300,A330,A310	33-11-23	AEG Seville
2LA465010-00	STROBE LIGHT	GOODRICH	CRJ Regional Jet-200,A318,B737-900,B737-400	33-42-24	AEG Seville
2LA465010-06	STROBE LIGHT	GOODRICH LIGHTING	A300,A320,A319,A380,A340,A350,A320,A310	33-42-24	AEG Seville
2LA465010-21	STROBE LIGHT	GOODRICH LIGHTING	A319,A300,A340,A330,A320,A310	33-42-24	AEG Seville
2LA465030-73	Wing Inspection Light		CRJ-700,L-1011	33-40-72	AEG Seville
2LA465030-74	Wing Inspection Light		CRJ-700,SAAB 340	33-40-72	AEG Seville

3LA65032-70	Cargo Loading Light		CRJ Regional Jet-200, CRJ-700	33-32-70	AEG Seville
3LA65063-70	Tail Strobe Light		CRJ-700, CRJ90 Regional Jet-400	33-42-70	AEG Seville
30-0191	Wing-Position Navigational Light		Dash 8,DHC8,B727	33-42-34	AEG Seville
30-0191-10	Wing-Position Navigational Light		B727/Dash 8,DHC8/Dash 8-100(DHC8/Dash 8-200)MD-80 & MD-82	33-42-34	AEG Seville
30-0191-11	Wing-Position Navigational Light		Dash 8,B727,DHCH8	33-42-34	AEG Seville
30-0191-12	Wing-Position Navigational Light		Dash 8,B727,DHCH8	33-42-34	AEG Seville
30-0191-6	Wing-Position Navigational Light		Dash 8,DHC8,B727	33-42-34	AEG Seville
30-0191-6	Wing-Position Navigational Light		Dash 8,B727,DHCH8	33-42-34	AEG Seville
30-0191-7	Wing-Position Navigational Light		Dash 8,B727,DHCH8	33-42-34	AEG Seville
30-0191-8	Wing-Position Navigational Light		MD-80 & MD-82 Dash 8-B727,DHCH8	33-42-34	AEG Seville
30-0191-9	Wing-Position Navigational Light		B727/Dash 8,DHC8/Dash 8-100(DHC8/Dash 8-200)MD-80 & MD-82	33-42-34	AEG Seville
30-0234	Wing Position Navigation Light			33-41-76	AEG Seville
30089-1471	BACKPLATE DAMPENER	NONE SPECIED	UNK		AEG Seville
30089-1480	PLATE DAMPENER	NONE SPECIED	UNK		AEG Seville
30076-2460	BACKPLATE DAMPENER	NONE SPECIED	UNK	24	AEG Seville
30076-2460	BACKPLATE DAMPENER	NONE SPECIED	UNK		AEG Bilbao
30081-001	DC GENERATOR	SMITHS	BRASILIA	24-30-90	AEG Bilbao
30081-010	DC GENERATOR	SMITHS GRIMES AEROSPACE	BRASILIA	24-30-90	AEG Bilbao
30-0881-1	STROBE LIGHT		B737-200,B777,A300	33-48-11	AEG Seville
300-90496-0601	CIRCUIT CARD ASSEMBLY	BENDIX	UNK		AEG Seville
30-0906	STROBE LIGHT	GRIMES AEROSPACE	B737	33-40-69	AEG Seville
30-0906-1	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-10	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-101	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-103	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-104	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-106	WING POS LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-106	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-107	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-109	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-110	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-111	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-113	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-116	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-116	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-117	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B737-900ER/B737 MAX 8/B737 MAX 9	33-40-69	AEG Seville
30-0906-118	STROBE LIGHT	HONEYWELL/GRIMES	B737-200/B737-300/B737-400/B737-500/B737-600/B737-700/B737-800/B737-900/B73		

30-1467-17M	Aircraft Navigational Flashtube Position Light		Gullstream II,Gullstream II,CLC	33-40-90	AEG Seville
30-1467-19	Aircraft Navigational Flashtube Position Light		A301,DA40,CRJ Dash 8-100,CRJ Dash 8-400,ATR 72-600,CRJ Dash 8-400	33-40-90	AEG Seville
30-1467-19M	Aircraft Navigational Flashtube Position Light		Gullstream II,Gullstream II,CLC	33-40-90	AEG Seville
30-1467-21	Aircraft Navigational Flashtube Position Light		A301,DA40,CRJ Dash 8-100,CRJ Dash 8-400,ATR 72-600,CRJ Dash 8-400	33-40-90	AEG Seville
30-1467-23	Aircraft Navigational Flashtube Position Light		Gullstream II,Gullstream II,CLC	33-40-90	AEG Seville
30-1467-3	Aircraft Navigational Flashtube Position Light		A301,DA40,CRJ Dash 8-100,CRJ Dash 8-400,ATR 72-600,CRJ Dash 8-400	33-40-90	AEG Seville
30-1467-5	Aircraft Navigational Flashtube Position Light		Gullstream II,Gullstream II,CLC	33-40-90	AEG Seville
30-1467-6	Aircraft Navigational Flashtube Position Light		A301,DA40,CRJ Dash 8-100,CRJ Dash 8-400,ATR 72-600,CRJ Dash 8-400	33-40-90	AEG Seville
30-1467-7	Aircraft Navigational Flashtube Position Light		Gullstream II,Gullstream II,CLC	33-40-90	AEG Seville
30-1467-9	Aircraft Navigational Flashtube Position Light		A301,DA40,CRJ Dash 8-100,CRJ Dash 8-400,ATR 72-600,CRJ Dash 8-400	33-40-90	AEG Seville
30-1738-3	WING POSITION LIGHT	GRIMES AEROSPACE	C-295	ATR 30-1738	AEG Seville
30-1738-4	LIGHT-RIGHT POSITION(NIR)	GRIMES AEROSPACE	CN-235	ATR 30-1738	AEG Seville
30-1739	Wing Inspection Floodlight			33-42-37	AEG Seville
30-1739-1	Wing Inspection Floodlight		Dash 8	33-42-37	AEG Seville
30-1739-2	Wing Inspection Floodlight		Dash 8	33-42-37	AEG Seville
30-1742-5	Emergency Egress Light		Dash 8,(DHCI)Dash 8-400	33-50-71	AEG Seville
30-1742-6	Emergency Egress Light		Dash 8,(DHCI)Dash 8-400	33-50-71	AEG Seville
30-1764	Aircraft Navigational Light			33-42-35	AEG Seville
30-1764-1	Aircraft Navigational Light		B767	33-42-35	AEG Seville
30-1764-3	Aircraft Navigational Light		B767	33-42-35	AEG Seville
30-1777-1	Emergency Light		B737	33-50-73	AEG Seville
30-1777-3	Emergency Light		B737	33-50-73	AEG Seville
30-1777-5	Emergency Light		B737	33-50-70	AEG Seville
30-1777-5	Emergency Light		B737	33-50-73	AEG Seville
30-1777-7	Emergency Light		B737	33-50-73	AEG Seville
30-1840	Floodlight			33-42-18	AEG Seville
30-1840-5	Floodlight		Dash 8,(DHCI)Dash 8-100,(DHCI)Dash 8-400,ATR 72-600,CRJ Dash 8-400	33-42-18	AEG Seville
302063-000	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	EATON	737,777	29-11-00	AEG Seville
302063-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	EATON	737,777	29-11-00	AEG Seville
30-2481-3	NAVIGATION LIGHT	#N/A	737, 777		AEG Seville
30-2481-5	NAVIGATION LIGHT	HONEYWELL/GRIMES	B767,B737,B737-300,B737-600,B777,B737	33-42-06	AEG Seville
30-2606-3	UPPER FUSELAGE ANTI-COLLISION LIGHT	GRIMES AERO	BOEING 737-800/900	33-42-03	AEG Seville
30-2606-3	LOWER AIRCRAFT ANTI-COLLISION FUSELAGE STROBE LIGHT	GRIMES AERO - HONEYWELL	BOEING 737-800/900	33-42-04	AEG Seville
30-2654	Wing Position Light			33-42-14	AEG Seville
30-2654-1	Wing Position Light		(DHCI)Dash 8-400,Dash 8,B737	33-42-14	AEG Seville
30-2654-2	Wing Position Light		(DHCI)Dash 8-400,Dash 8	33-42-14	AEG Seville
30-2656	Tail Position Navigational Light			33-42-13	AEG Seville
30-2656-1	Tail Position Navigational Light		B737	33-42-13	AEG Seville
30-2656-3	Tail Position Navigational Light			33-42-13	AEG Seville
30-2657	Floodlight			33-42-12	AEG Seville
30-2657-1	Floodlight			33-42-12	AEG Seville
30-2657-2	Floodlight			33-42-12	AEG Seville
30-2657-3	Floodlight			33-42-12	AEG Seville
30-2657-4	Floodlight			33-42-12	AEG Seville
30-2658	Wing Inspection Light			33-42-11	AEG Seville
30-2658-1	Wing Inspection Light			33-42-11	AEG Seville
30-2658-2	Wing Inspection Light			33-42-11	AEG Seville
30-2658-3	Wing Inspection Light			33-42-11	AEG Seville
30-2658-4	Wing Inspection Light			33-42-11	AEG Seville
30-2681-3	ELECTRICAL TAIL LOGO FLOODLIGHT	HONEYWELL	A340	33-42-30	AEG Seville
30-2610	Integral Anticollision Strobe Light		DHCB,Dash 8	33-44-30	AEG Seville
30-2610-1	STROBE LIGHT	GRIMES/HONEYWELL	Dash8,CRJ	33-44-30	AEG Seville
30-2623	Flashing Ground Recognition Light			33-51-54	AEG Seville
30-2623-1	Flashing Ground Recognition Light		DHCB	33-51-54	AEG Seville
30-2623-3	Flashing Ground Recognition Light		DHCB	33-51-54	AEG Seville
30-2683-1	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747,B727,B737-300,B737-200,B737	33-42-36	AEG Seville
30-2683-10	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747,ATR 72,ATR 42,B727,B737	33-42-36	AEG Seville
30-2683-11	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL	B747,B727,ATR 72,ATR 42,B737	33-42-36	AEG Seville
30-2683-12	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL	B747,B727,B737-300,B737-200,B737	33-42-36	AEG Seville
30-2683-13	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL	B747,B727,B737-300,B737-200,B737	33-42-36	AEG Seville
30-2683-14	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL	B747,B737-300,B737-200,B727	33-42-36	AEG Seville
30-2683-2	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747,B737-300,B737-200,B727,B737	33-42-36	AEG Seville
30-2683-5	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747,B727,ATR 72,ATR 42,B737	33-42-36	AEG Seville
30-2683-6	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747,B727,B737-200,B737	33-42-36	AEG Seville
30-2683-9	WING POSITION NAVIGATIONAL LIGHT	HONEYWELL GRIMES	B747,B727,B777,B737	33-42-36	AEG Seville
30-2722-01	STROBE LIGHT ASSY		UNK		AEG Seville
3029683-001	HYDRAULIC MOTORPUMP ASSEMBLY	EATON	A321A319,A340,A330,A320	29-21-20	AEG Seville
3029981-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	EATON AEROS	B727,CRJ Regional Jet-100,MD80,J18B,DC-3,MD-80,MD-90	29-10-03,29	AEG Seville
303174-001	Reservoir Level Switch Assembly				AEG Seville
3031843-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	VICKERS	A320 NEO	29-11-34	AEG Seville
3031843-002	HYDRAULIC PUMP	EATON AEROSPACE	A320 NEO	29-11-34	AEG Seville
303316-100	UPLOCK ASSEMBLY	EATON	A300, A300-600, A310, A318, A319, A320, A321, A320XLR, A321XLR, A320neo, A321neo	49-41-25	AEG Bilbao
304643-4	APU Ignition Unit, Ignition Exciter		GTCP36-150RJ		AEG Seville
3056554-01	Ignition Cable Assembly CH53536			74-20-29	AEG Seville
3069-1471	BACKPLATE DAMPENER		UNK		AEG Bilbao
31073-082	AILERON SERVOCONTROL	LUCAS/GOODRICH	B757,A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-083	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-084	AILERON SERVOCONTROL	LUCAS/GOODRICH	B757,A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-085	AILERON SERVOCONTROL	LUCAS/GOODRICH	B757,A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-087	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-088	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-090	AILERON SERVOCONTROL	LUCAS/GOODRICH	B757,A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-093	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-094	AILERON SERVOCONTROL	LUCAS/GOODRICH	B737,A318,A321,B747,A320,A300,A320-221	27-14-51	AEG Seville
31073-097	AILERON SERVOCONTROL	LUCAS/GOODRICH	B737,A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-098	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-099	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-100	AILERON SERVOCONTROL	LUCAS/GOODRICH	A318,A321,A320,A319,A300	27-14-51	AEG Seville
31073-101	AILERON SERVOCONTROL	LUCAS/GOODRICH	B737,A318,A321,A319,A300,A320-221,A320-221XLR,A321XLR	27-14-51	AEG Seville
31076-840	ELEVATOR SERVOCONTROL	GOODRICH ACTUATION	A318, A319, A320, A321	27-34-52	AEG Seville
31077-100	INBOARD SPOILER ACTUATOR	GOODRICH ACTUATION	A321A319,A318,A320-221,A320-221XLR,A321XLR	27-64-21	AEG Seville
31077-111	INBOARD SPOILER ACTUATOR	GOODRICH ACTUATION	F-16,A321A318,A320-232,A320,A319	27-64-21	AEG Seville
31077-200	INBOARD SPOILER ACTUATOR	GOODRICH ACTUATION	A321A320,A319	27-64-21	AEG Seville
31077-211	INBOARD SPOILER ACTUATOR	GOODRICH ACTUATION	A318,A321,A319,A320,A320-232	27-64-21	AEG Seville
3164 SERIES	AC GENERATOR	LEAR SIEGLER	UNK		AEG Bilbao
3164-1360	ROTOR EXCITER	LEAR SIEGLER	UNK	24	AEG Bilbao
3164-1420	STATOR PM	LEAR SIEGLER	UNK	24	AEG Bilbao
3164-5632	ROTOR	LEAR SIEGLER	UNK	24	AEG Bilbao
3220-1020	STATOR	LEAR SIEGLER	UNK	24	AEG Bilbao
322424-04	Ignition Cable Assembly CH53456-2			74-20-09	AEG Seville
32B8101-1	ISFD DEDICATED BATTERY CHARGER (DBC)	ACME ELECTRIC	B737, B757, B767	24-31-05	AEG Seville
3340-1032	STATOR MAIN	LUCAS	UNK	24	AEG Bilbao
3342-001	ALTERNATOR	GOODRICH MONROE	CRJ-700,CN-235	24-21-05	AEG Bilbao
3342-003	GENERATOR-AC26KVA	GOODRICH MONROE	CN-235	24-21-05	AEG Bilbao
3342-004	GENERATOR-AC	GOODRICH MONROE	C-295,CN-235	24-20-57	AEG Bilbao
3342-006	AC GENERATOR	LUCAS	CN-235, C-295	24	AEG Bilbao
3342-007	AC GENERATOR	IRW AERONAUTICAL SYSTEMS, INC	C-295	24-20-57	AEG Bilbao
3342-382	ROTOR ASSEMBLY	DYNAMIC AIR	CN-235, C-295	24	AEG Bilbao
342-003	AC GENERATOR (26KVA)		UNK		AEG Bilbao
3-1442	Nose-wheel		Dash 8,DHCB	32-40-17	AEG Seville
3-1480-10p1Opt20p1	Main Wheel Assembly			32-45-68	AEG Seville
3-1480-20p1Opt20p1	Main Wheel Assembly			32-45-68	AEG Seville
3-1573	Main Wheel Assembly			32-48-32	AEG Seville
3-1576	MLG Wheel Assembly			32-48-34	AEG Seville
316A1801-14	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	THE BOEING	CRJ Regional Jet-200,CFM56-3,B737-400,B737-400,ATR 72-600,CRJ Regional Jet-440,ATR 72-600,ATR 72-600,ATR 72-600	78-31-02	AEG Seville
316A1801-15	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	THE BOEING	CRJ Regional Jet-200,CFM56-3,B737-400,B737-400,ATR 72-600,CRJ Regional Jet-440,ATR 72-600,ATR 72-600	78-31-02	AEG Seville
316A1801-18	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	THE BOEING	CRJ Regional Jet-200,CFM56-3,B737-400,B737-400,ATR 72-600,CRJ Regional Jet-440,ATR 72-600,ATR 72-600	78-31-02	AEG Seville
316A1801-19	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	THE BOEING	CFM56-3,B737-400,B737-400,ATR 72-600,CRJ Regional Jet-200,CFM56-3,B737-400,B737-400,ATR 72-600	78-31-02	AEG Seville

316A1801-22	THRUST REVERSER LOCKING ACTUATOR	THE BOEING	CFM56-3.B767.B737-800.B737-400.B737-400	78-31-02	AEG Sevilla
316A1801-23	THRUST REVERSER HYDRAU	THE BOEING	CFM56-3.B767.B737-800.B737-400.B737-400	78-31-02	AEG Sevilla
316A1801-26	THRUST REVERSER LOCKING ACTUATOR	THE BOEING	CFM56-3.B767.B737-800.B737-400.B737-400	78-31-02	AEG Sevilla
316A1801-27	THRUST REVERSER HYDRAU	THE BOEING	CFM56-3.B737-800.B737-400.B737-400	78-31-02	AEG Sevilla
316A2800-1	THRUST REVERSER NON-LOCKING ACTUATOR	THE BOEING	B-737	78-31-18	AEG Sevilla
316A2800-2	THRUST REVERSER NON-LOCKING ACTUATOR	THE BOEING	B-737	78-31-18	AEG Sevilla
316A2801-1	THRUST REVERSER LOCKING ACTUATOR	THE BOEING	B-737	78-31-19	AEG Sevilla
316A2801-4	THRUST REVERSER LOCKING ACTUATOR	THE BOEING	B-737	78-31-19	AEG Sevilla
316A2801-5	THRUST REVERSER LOCKING ACTUATOR	THE BOEING	B-737	78-31-19	AEG Sevilla
31-7611-1	NAVIGATIONAL LIGHT SUBASSEMBLY	HONEYWELL	B767.B747-100.B777	33-41-77	AEG Sevilla
31-7611-2	NAVIGATIONAL LIGHT SUBASSEMBLY	HONEYWELL	B767.B747-100.B777-200.B777	33-41-77	AEG Sevilla
3181-194-901	VACUUM AND PRESURE	FOKKER AIRCRAFT BV	UNKN	28	AEG Sevilla
3181-233-901	VACUUM AND PRESURE	FOKKER SERVICES BV	UNKN	28	AEG Sevilla
3202232-1	2 In Dia Check Valve, Pressure Regulating Valve		CRJ Regional Jet-100,CRJ Regional Jet-200	21-50-73	AEG Sevilla
3202894-1	2&Frac12 Diameter Check Valve		A300MD-11A310.B747.B767/CRJ Regional Jet-300,CRJ Regional Jet-440	36-14-79	AEG Sevilla
32032-1900	HUB DAMPENER		UNKN		AEG Bilbao
321-400-703-0	DOOR OPENING HYDRAULIC ACTUATOR	ROHR	C-130.B777/CFM56-58,CFM56-58	78-36-51	AEG Sevilla
321-400-704-0	DOOR OPENING HYDRAULIC ACTUATOR	ROHR	C-130.B777/CFM56-58,CFM56-58	78-36-51	AEG Sevilla
321-400-705-0	DOOR OPENING HYDRAULIC ACTUATOR	ROHR	C-130.B777/CFM56-58,CFM56-58	78-36-51	AEG Sevilla
3238470-1	Actuator Ball Screw		B747-400	78-32-73	AEG Sevilla
3238470-2	Actuator Ball Screw		B747-400	78-32-73	AEG Sevilla
326-0083-01	Toilet Control Cable Assembly		UNKN	38-31-07	AEG Sevilla
3282970-2	STOP MECHANISM	HONEYWELL	CFM56-5MD-11	75-31-22	AEG Sevilla
3282970-3	STOP MECHANISM	HONEYWELL	CFM56-5MD-11	75-31-22	AEG Sevilla
3282970-4	STOP MECHANISM	HONEYWELL INT'L	CFM56-5MD-11	75-31-22	AEG Sevilla
3282970-5	STOP MECHANISM	HONEYWELL	CFM56-5A	75	AEG Sevilla
3282990-2	Two Inch Diameter Shutoff Butterfly Valve		CRJ Regional Jet-200,CRJ Regional Jet-300		AEG Sevilla
3282990-3	Two Inch Diameter Shutoff Butterfly Valve		CRJ Regional Jet-200,CRJ Regional Jet-300		AEG Sevilla
3291024-5	Shutoff Valve		B777A330	80-12-19	AEG Sevilla
3291024-6	Shutoff Valve		A330.B777	80-12-19	AEG Sevilla
3291220-4	Load Control Valve		CF-34-80,REZZURU,CRJ Regional Jet-100,CRJ Regional Jet-200,CRJ Regional Jet-300,CRJ Regional Jet-440	49-54-03	AEG Sevilla
3302196-13	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	Hercules-L-100,C-130	32	AEG Sevilla
3302196-15	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130	451-57-3	AEG Sevilla
3302196-19	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	Hercules-L-100,C-130	32	AEG Sevilla
3303691-1	STRUT ASSEMBLY NOSE LANDING GEAR	LOCKHEED	Hercules-L-100,C-130	32	AEG Sevilla
33-066-1	NORMAL ANTISKID VALVE MODULE (AVM)	OWING AEROSPACE	B777.B757-200.B747-400.B767.B757.B747	32-42-51	AEG Sevilla
33-066-2	NORMAL ANTISKID VALVE MODULE (AVM)	OWING AEROSPACE	B777.B747-400.B767.B757.B747	32-42-51	AEG Sevilla
33-067-1	ALTERNATE ANTISKID VALVE MODULE (AVM)	HYDRO AIRE	B777.B767.B757.B747	32-42-51	AEG Sevilla
33-067-2	ALTERNATE ANTISKID VALVE MODULE (AVM)	HYDRO AIRE	B777.B757-200.B747-400.B767.B757.B747	32-42-51	AEG Sevilla
3314203-3	STRUT ASSY NOSE LANDING GEAR	LOCKHEED	C-130	32	AEG Sevilla
3314498-1	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	MD-90,Hercules-L-100,C-130	32	AEG Sevilla
3314498-7	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	Hercules-L-100,C-130	32	AEG Sevilla
3316000-16	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130	32	AEG Sevilla
332-0002-01	Waste Drain Valve		B737.B727.B747.DHC8.B757	38-31-05	AEG Sevilla
332-0000X	Waste Drain Valve			38-30-06	AEG Sevilla
332-0010X	Waste Drain Valve			38-30-06	AEG Sevilla
332-0020X	Waste Drain Valve			38-30-06	AEG Sevilla
332-0030X	Waste Drain Valve			38-30-06	AEG Sevilla
3367-10	Ballast Unit		A321A318	33-24-97	AEG Sevilla
3367-11	Ballast Unit			33-24-97	AEG Sevilla
33793-3	RECEIVER, TRANSMITTER	NONE SPECIFIED	UNKN		AEG Sevilla
3382-10	Lampholder			33-22-01(TDS)	AEG Sevilla
33823-2	CONTROL, RADAR SET		UNKN		AEG Sevilla
33824-1	INDICATOR, AZIMUTH		UNKN		AEG Sevilla
3386-20	Fluorescent Lamp Fixture			33-22-02(TDS)	AEG Sevilla
3386-30	Fluorescent Lamp Fixture			33-22-02(TDS)	AEG Sevilla
33A44-1612-010	CONTROL BOX		UNKN		AEG Sevilla
34265-1	COCKPIT LIGHT	GRIMES	A350.B737-300.B747-200.B737-400	33-10-23	AEG Sevilla
34265-10	COCKPIT LIGHT	HONEYWELL	A350.A340.A321.B737-300.B747-200.B737-400	33	AEG Sevilla
34265-11	COCKPIT LIGHT	HONEYWELL	A350.A340.A321.B737-400	33	AEG Sevilla
34265-12	COCKPIT LIGHT	HONEYWELL	A350.A340.A321.B737-300.B747-200.B737-400	33	AEG Sevilla
34265-13	COCKPIT LIGHT	GRIMES	A350.B737-300.B747-200.B737-400	33-10-23	AEG Sevilla
34265-14	COCKPIT LIGHT	GRIMES	A350.B737-300.B747-200.B737-400	33-10-23	AEG Sevilla
34265-16	COCKPIT LIGHT	GRIMES	A350.A321.B737-300.B747-200.B737-400	33-10-23	AEG Sevilla
34265-16	COCKPIT LIGHT	GRIMES	A350.B737-300.B747-200.B737-400	33-10-23	AEG Sevilla
34265-17	COCKPIT LIGHT	GRIMES	A350.B737-300.B747-200.B737-400	33-10-23	AEG Sevilla
34265-2	COCKPIT LIGHT	GRIMES	A350.B737-300.B747-200.B737-400	33-10-23	AEG Sevilla
34265-3	COCKPIT LIGHT	GRIMES	A350.B737-300.B747-200.B737-400	33-10-23	AEG Sevilla
34265-4	COCKPIT LIGHT	HONEYWELL	A350.A340.A321.B737-300.B747-200.B737-400	33	AEG Sevilla
34265-6	COCKPIT LIGHT	GRIMES	A350.B737-300.B747-200.B737-400	33-10-23	AEG Sevilla
34265-6	COCKPIT LIGHT	HONEYWELL	B707.A350.A340.A321.B737-300.B747-200	33	AEG Sevilla
34265-7	COCKPIT LIGHT	HONEYWELL	A350.A340.A321.B737-300.B747-200	33	AEG Sevilla
34265-8	COCKPIT LIGHT	HONEYWELL	A350.A321.B737-300.B747-200	33-10-23	AEG Sevilla
34265-9	COCKPIT LIGHT	HONEYWELL	A350.A340.A321.B737-300.B747-200	33	AEG Sevilla
34-61-11	-	#N/D			AEG Sevilla
34765-6	CONTROL RADAR SET		UNKN		AEG Sevilla
34784010001			CRJ1000	21-51-94	AEG Sevilla
34784010001	Air Cycle Machine			21-51-94	AEG Sevilla
360448-5	STARTER		UNKN		AEG Sevilla
360571-6	STARTER		UNKN		AEG Sevilla
360880-6	VARIABLE DISPLACEMENT HYDRAULIC PUMP	EATON / 42983	B707.DC-10-40.A310-300.B737-600J-1001.B747-200.B747-300.B747-400.B767-300	29-11-03	AEG Sevilla
360880-7	VARIABLE DISPLACEMENT HYDRAULIC PUMP	EATON / 42983	A310-300J-1001.B747-200.B747-300.B747-400	29-11-04	AEG Sevilla
36-62916-498	GEAR ASSY NOSE	BEECHCRAFT	UNKN		AEG Sevilla
368800-1	NOSE LANDING GEAR UNLOCK ASSEMBLY	HONEYWELL	Hercules-L-100,C-130	16L1-3-10-3	AEG Sevilla
368800-5	NOSE LANDING GEAR UNLOCK ASSEMBLY	HONEYWELL	Hercules-L-100,C-130	16L1-3-10-3	AEG Sevilla
368800-9	NOSE LANDING GEAR UNLOCK ASSEMBLY	LOCKHEED	Hercules-L-100,C-130	16L1-3-10-3	AEG Sevilla
36H	EXTINTOR	KIDDE GRAVINER	UNKN	26-24-01	AEG Sevilla
3603100-1	FUEL CONTROL ASSEMBLY	GARRET	C-130.B727	49	AEG Sevilla
3603100-2	FUEL CONTROL ASSEMBLY	GARRET	C-130	49	AEG Sevilla
3603100-9	FUEL CONTROL ASSEMBLY	HONEYWELL	F-15,C-130.B727	49	AEG Sevilla
36061812-17	ELECTRICAL ENGINE STARTER	INTERNATIONAL INC.	B-737-100/-200/-300/-400/-500		AEG Sevilla
3609088-1	Valve Assembly			49-90-45	AEG Sevilla
3609180-8	FUEL CONTROL ASSEMBLY	ALLIED SIGNAL	F-15,MD-11.B767.B747.A310.A300.B737	49	AEG Sevilla
3612671-1	Valve Assembly		A300-	49-90-45	AEG Sevilla
3614400-1	TRANSDUCER ASSEMBLY	HONEYWELL	A300.GTCCP331.B767.B767.A310.A300.B707	49-51-93	AEG Sevilla
3614400-2	TRANSDUCER ASSEMBLY	HONEYWELL	A300-600.B767.B757.A310.A300.B707	49-51-93	AEG Sevilla
3614400-4	TRANSDUCER ASSEMBLY	HONEYWELL	A300-600.B767.B757.A310.A300.B707	49-51-93	AEG Sevilla
3614400-6	TRANSDUCER ASSEMBLY	HONEYWELL	A300-600.B767.B757.A310.A300	49-51-93	AEG Sevilla
3614400-7	TRANSDUCER ASSEMBLY	HONEYWELL	A300-600.GTCP331.B767.B757.A310.A300	49-51-93	AEG Sevilla
3616853-1	Valve Assy	INTERNATIONAL		49-90-47	AEG Sevilla
3616293-1	Valve Assembly			49-90-45	AEG Sevilla
3617750-1	FCU APU	HONEYWELL	B737-300.B737-400.B737-400	49	AEG Sevilla
3617750-2	TURBINE TYPE FUEL CONTROL UNIT	ABBOTT	B737-300.B737-400.B737-400	49	AEG Sevilla
3617750-3	TURBINE TYPE FUEL CONTROL UNIT	ABBOTT	300.B737.B737.MD-80.DC-9	49	AEG Sevilla
3617750-4	TURBINE TYPE FUEL CONTROL UNIT	HONEYWELL	DC-8.B727.B737.MD-80.DC-9	49	AEG Sevilla
366-028	Refuel/Defuel Panel			28-24-05	AEG Sevilla
366-029	Refuel/Defuel Indicator			28-24-06	AEG Sevilla
366-209	Integrated Refuel Panel			28-41-72	AEG Sevilla
367-040	Standard Electronic Module Assembly			28-40-88	AEG Sevilla
367-118	Fuel Quantity Computer			28-41-47	AEG Sevilla
367-119	High Level Control Unit			28-24-07	AEG Sevilla
368-106	INTERRUPTOR, PULSADO		UNKN		AEG Sevilla
36E135-2C	STARTER		UNKN		AEG Sevilla
370438-1	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Sevilla
37168 SERIES	FUEL CONTROL UNIT		UNKN		AEG Sevilla
37168-10	FUEL CONTROL UNIT	HONEYWELL	UNKN		AEG Sevilla
37-391	Servovalve Assembly		B757	32-43-70	AEG Sevilla
37-409	3-Way Servovalve Assembly			32-48-33	AEG Sevilla

380268-1	PNEUMATIC AND SHAFT POWER GAS TURBINE ENGINE	HONEYWELL	UNK		AEG Seville
380-97-1	380-97-1	BF GOODRICH	A330	32-48-36	AEG Seville
381006-101	MODULE CONTROL VALVE THRUST REVERSER	PARKER	B737-300,B737-400,B737-	29-10-26	AEG Seville
381006-103	MODULE CONTROL VALVE THRUST REVERSER	PARKER	B737-300,B737-400,B737-	29-10-26	AEG Seville
381006-104	MODULE CONTROL VALVE THRUST REVERSER	PARKER	B737-300,B737-400,B737-	29-10-26	AEG Seville
381006-105	MODULE CONTROL VALVE THRUST REVERSER	PARKER	CFM56-3,B737-300,B737-400,B737-	29-10-26	AEG Seville
381006-106	MODULE CONTROL VALVE THRUST REVERSER	PARKER	CFM56-3,B737-300,B737-400,B737-	29-10-26	AEG Seville
381006-107	MODULE CONTROL VALVE THRUST REVERSER	PARKER	CFM56-3,B737-300,B737-400,B737-	29-10-26	AEG Seville
381006-108	MODULE CONTROL VALVE THRUST REVERSER	PARKER	CFM56-3,B737-300,B737-400,B737-	29-10-26	AEG Seville
381006-109	MODULE CONTROL VALVE THRUST REVERSER	PARKER	CFM56-3,B737-300,B737-400,B737-	29-10-26	AEG Seville
38116-1-7	ENGINE, GAS, TURBINE	HONEYWELL	C-130	49	AEG Seville
38116-1-8	AUXILIARY POWER UNIT	HONEYWELL	C-130	49	AEG Seville
381800-1001	LEADING EDGE SLAT ACTUATOR ASSEMBLY	PARKER	B737-300,B737-400,B737-683,B737	27-80-06	AEG Seville
381800-1003	LEADING EDGE SLAT ACTUATOR ASSEMBLY	PARKER	B737-300,B737-400,B737	27-80-06	AEG Seville
381800-1005	LEADING EDGE SLAT ACTUATOR ASSEMBLY	PARKER	B737-400,B737-8AN,B737-683,B737	27-80-06	AEG Seville
38210-394	VARIOMETRE	THALES	UNK	34	AEG Seville
3830166-2	Valve Assembly			49-90-45	AEG Seville
3830166-2	Valve Assembly			49-90-45	AEG Seville
3830169-1	Valve Assembly			49-90-45	AEG Seville
3862160-9	APU COOLING FAN	AIRESEARCH/HONEYWELL	GTCP331-250H,GTCP331-200ER,B737-400,B737-300,B737-400,B737-300	49-51-69	AEG Seville
386303X	Exit Sign Assy			33-20-04	AEG Seville
38-791800	Hydraulic Fuse, Volumetric, With Bypass		C-130	32-41-05	AEG Seville
38-793600	Valve, Solenoid, 5"-Way, 2-Position, Normally Closed		C-130	32-41-15	AEG Seville
3880410-14	Valve Assy		A300,MD-11,A310,B747,B767	49-90-43	AEG Seville
388068-1	SHUTTLE ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Seville
388068-10	SHUTTLE ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Seville
388068-9	SHUTTLE ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Seville
3880620-2	Valve Assembly			49-90-45	AEG Seville
3880620-3	Valve Assembly			49-90-45	AEG Seville
388134-5	NC Solenoid Valve			49-30-93	AEG Seville
3882360-SERIES	FUEL CONTROL UNIT		UNK		AEG Seville
3882600-12	FUEL CONTROL UNIT	AIRESEARCH	GTCP331-250H,GTCP331-200ER,B737-400,B737-300,B737-400,B737-300	49	AEG Seville
3882600-14	FUEL CONTROL UNIT	AIRESEARCH	GTCP331-250H,GTCP331-200ER,B737-400,B737-300,B737-400,B737-300	49	AEG Seville
3882600-16	FUEL CONTROL UNIT	HONEYWELL	GTCP331-250H,GTCP331-200ER,B737-400,B737-300,B737-400,B737-300	49	AEG Seville
3882600-17	FUEL CONTROL UNIT	AIRESEARCH	GTCP331-250H,GTCP331-200ER,B737-400,B737-300,B737-400,B737-300	49	AEG Seville
3882600-X	FUEL CONTROL UNIT	HONEYWELL	GTCP331-250H,GTCP331-200ER,B737-400,B737-300,B737-400,B737-300	49	AEG Seville
3882650-1	FLOW DIVIDER AND DRAIN VALVE ASSEMBLY	ALLIEDSIGNAL	MD-11,B737-400,B737-300,B737-400,B737-300	49-31-63	AEG Seville
3882650-2	FLOW DIVIDER AND DRAIN VALVE ASSEMBLY	ALLIEDSIGNAL	MD-11,B737-400,B737-300,B737-400,B737-300	49-31-63	AEG Seville
3882650-3	FLOW DIVIDER AND DRAIN VALVE ASSEMBLY	ALLIEDSIGNAL	MD-11,B737-400,B737-300,B737-400,B737-300	49-31-63	AEG Seville
3882730-10	Fuel Control Assy			49-30-91	AEG Seville
3882826-1	FUEL CONTROL ASSEMBLY	HONEYWELL	A319,MD-80,B737,A320	49-30-97	AEG Seville
3882826-2	FUEL CONTROL ASSEMBLY	HONEYWELL	A319,MD-80,B737,A320	49-30-97	AEG Seville
3882826-3	FUEL CONTROL ASSEMBLY	HONEYWELL	A319,MD-80,B737,A320	49-30-97	AEG Seville
3882826-4	FUEL CONTROL ASSEMBLY	HONEYWELL	A319,MD-80,B737,A320	49-30-97	AEG Seville
3882826-5	FUEL CONTROL ASSEMBLY	HONEYWELL	A319,MD-80,B737,A320	49-30-97	AEG Seville
3882826-6	FUEL CONTROL ASSEMBLY	HONEYWELL	A319,MD-80,B737,A320	49-30-97	AEG Seville
3882826-8	FUEL CONTROL ASSEMBLY	HONEYWELL	A319,MD-80,B737,A320,A320-200	49-30-97	AEG Seville
3882826-9	FUEL CONTROL ASSEMBLY	HONEYWELL	A319,MD-80,B737,A320,A320-200	49-30-97	AEG Seville
3883220-3	ACTUATOR IGIV	HONEYWELL	B737,A320,MD-80-83,A320-200	49-50-02	AEG Seville
3883240-3	FUEL CONTROL ASSEMBLY	HONEYWELL	MD-11,B737-400,B737-300,B737-400,B737-300	49-31-65	AEG Seville
3883240-6	FUEL CONTROL ASSEMBLY	HONEYWELL	MD-11,B737-400,B737-300,B737-400,B737-300	49-31-65	AEG Seville
3883240-6	FUEL CONTROL ASSEMBLY	HONEYWELL	GTCP331-350C,A310,A330	49-31-65	AEG Seville
3883240-7	FUEL CONTROL ASSEMBLY	HONEYWELL	GTCP331-350C,A340,A330	49	AEG Seville
3883266-2	TORQUE MOTOR	HONEYWELL	A330/A340	49-31-65	AEG Seville
3883266-3	TORQUE MOTOR	HONEYWELL	A330/A340	49-31-65	AEG Seville
3883266-4	TORQUE MOTOR	HONEYWELL	A330/A340	49-31-65	AEG Seville
3883266-x	TORQUE MOTOR	HONEYWELL	A330/A340	49-31-65	AEG Seville
3883297-	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Seville
3883297-2	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Seville
3883297-4	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Seville
3883297-5	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Seville
3883297-6	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Seville
3883297-7	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Seville
3883297-9	FLOW DIVIDER ASSY	HONEYWELL	A320 A330/ A340	49-31-67	AEG Seville
3883730-X	FUEL CONTROL UNIT				AEG Seville
3883900-1	FUEL CONTROL UNIT	HONEYWELL			AEG Seville
3883900-X	FUEL CONTROL UNIT				AEG Seville
3883964-3	FUEL CONTROL UNIT	HONEYWELL			AEG Seville
3883964-4	FUEL CONTROL UNIT	HONEYWELL			AEG Seville
3883964-X	FUEL CONTROL UNIT				AEG Seville
38-841-01	Sensor Test System			32-60-04	AEG Seville
3884629-3	Oil Cooler Fan			49-51-79	AEG Seville
3884629-4	Oil Cooler Fan			49-51-79	AEG Seville
3884629-5	Oil Cooler Fan			49-51-79	AEG Seville
3888272-2	STARTER	HONEYWELL	A310,GTCP331-350C,B767,A340,A330	49-41-10	AEG Seville
3888272-3	APU STARTER	HONEYWELL	MD-11,B747,A300,A310,GTCP331-350C,A340,A330	49-41-10	AEG Seville
3888272-4	STARTER	ALLIEDSIGNAL	GTCP331-350C,A310,B767,A340,A330	49-41-10	AEG Seville
3888272-X	STARTER	ALLIEDSIGNAL/THALES	GTCP331-350C	49-41-10	AEG Seville
3890010-102	PRESSURE RELIEF VALVE	PARKER	B717,B717/B737-500,B737-400,B737-300,B737-400,B737-300	32-40-04	AEG Seville
3890010-103	PRESSURE RELIEF VALVE	PARKER HANNIFIN	B717,B717/B737-500,B737-400,B737-300,B737-400,B737-300	32-40-04	AEG Seville
38E93-4			VALVULA B717SH	19328	AEG Seville
38E96-2C	Regulator and Relief Valve		A320	38U-23-85TB	AEG Seville
38E96-2D	Regulator and Relief Valve		11U100,11U100-1,11U100-2,11U100-3,11U100-4,11U100-5,11U100-6,11U100-7,11U100-8,11U100-9,11U100-10,11U100-11,11U100-12,11U100-13,11U100-14,11U100-15,11U100-16,11U100-17,11U100-18,11U100-19,11U100-20,11U100-21,11U100-22,11U100-23,11U100-24,11U100-25,11U100-26,11U100-27,11U100-28,11U100-29,11U100-30,11U100-31,11U100-32,11U100-33,11U100-34,11U100-35,11U100-36,11U100-37,11U100-38,11U100-39,11U100-40,11U100-41,11U100-42,11U100-43,11U100-44,11U100-45,11U100-46,11U100-47,11U100-48,11U100-49,11U100-50,11U100-51,11U100-52,11U100-53,11U100-54,11U100-55,11U100-56,11U100-57,11U100-58,11U100-59,11U100-60,11U100-61,11U100-62,11U100-63,11U100-64,11U100-65,11U100-66,11U100-67,11U100-68,11U100-69,11U100-70,11U100-71,11U100-72,11U100-73,11U100-74,11U100-75,11U100-76,11U100-77,11U100-78,11U100-79,11U100-80,11U100-81,11U100-82,11U100-83,11U100-84,11U100-85,11U100-86,11U100-87,11U100-88,11U100-89,11U100-90,11U100-91,11U100-92,11U100-93,11U100-94,11U100-95,11U100-96,11U100-97,11U100-98,11U100-99,11U100-100	38U-23-85TB	AEG Seville
38E96-2E	Regulator and Relief Valve		PW100,11U100-1,11U100-2,11U100-3,11U100-4,11U100-5,11U100-6,11U100-7,11U100-8,11U100-9,11U100-10,11U100-11,11U100-12,11U100-13,11U100-14,11U100-15,11U100-16,11U100-17,11U100-18,11U100-19,11U100-20,11U100-21,11U100-22,11U100-23,11U100-24,11U100-25,11U100-26,11U100-27,11U100-28,11U100-29,11U100-30,11U100-31,11U100-32,11U100-33,11U100-34,11U100-35,11U100-36,11U100-37,11U100-38,11U100-39,11U100-40,11U100-41,11U100-42,11U100-43,11U100-44,11U100-45,11U100-46,11U100-47,11U100-48,11U100-49,11U100-50,11U100-51,11U100-52,11U100-53,11U100-54,11U100-55,11U100-56,11U100-57,11U100-58,11U100-59,11U100-60,11U100-61,11U100-62,11U100-63,11U100-64,11U100-65,11U100-66,11U100-67,11U100-68,11U100-69,11U100-70,11U100-71,11U100-72,11U100-73,11U100-74,11U100-75,11U100-76,11U100-77,11U100-78,11U100-79,11U100-80,11U100-81,11U100-82,11U100-83,11U100-84,11U100-85,11U100-86,11U100-87,11U100-88,11U100-89,11U100-90,11U100-91,11U100-92,11U100-93,11U100-94,11U100-95,11U100-96,11U100-97,11U100-98,11U100-99,11U100-100	38U-23-85TB	AEG Seville
38E96-3A	Regulator and Relief Valve		A320	38U-23-85TB	AEG Seville
38E96-6A	Regulator and Relief Valve		B767	38U-23-85TB	AEG Seville
38H	EXTINTOR	KIDDE GRAVINER	UNK	26-24-01	AEG Seville
39-249	DUAL PRESSURE CONTROL VALVE	CRANE/HYDRO-AIRE	MD-80,MD80,DC-9	32-22-42-30,32-40-30	AEG Seville
39-249-1	DUAL PRESSURE CONTROL VALVE	CRANE/HYDRO-AIRE	MD-80,MU-90,MU-90C,MU-90D,MU-90E,MU-90F,MU-90G,MU-90H,MU-90I,MU-90J,MU-90K,MU-90L,MU-90M,MU-90N,MU-90O,MU-90P,MU-90Q,MU-90R,MU-90S,MU-90T,MU-90U,MU-90V,MU-90W,MU-90X,MU-90Y,MU-90Z	32-22-42-30	AEG Seville
39-249-2	DUAL PRESSURE CONTROL VALVE	CRANE/HYDRO-AIRE	MD-80,MU-90,MU-90C,MU-90D,MU-90E,MU-90F,MU-90G,MU-90H,MU-90I,MU-90J,MU-90K,MU-90L,MU-90M,MU-90N,MU-90O,MU-90P,MU-90Q,MU-90R,MU-90S,MU-90T,MU-90U,MU-90V,MU-90W,MU-90X,MU-90Y,MU-90Z	32-22-42-30	AEG Seville
3930-0100-0000	HOUSING ASSY	ACA		21	AEG Seville
39-363	HYD. VALVE	CRANE HYDRO-AIRE	B-727, B-737	32-40-52	AEG Seville
394324 SERIES	FLOW DIVIDER AND DRAIN		UNK		AEG Seville
394390 SERIES	FLOW DIVIDER AND DRAIN		UNK		AEG Seville
394408 SERIES	FLOW DIVIDER AND DRAIN		A300 A310 B747 B767 MD11		AEG Seville
39-483	DUAL PRESSURE CTRL VALVE	CRANE/HYDRO-AIRE	B737	32-40-69	AEG Seville
39-671	Valve		Dash 8,C-130	32-42-76	AEG Seville
396800-10	MOTOR GEAR HYDRAULIC	ARGO-TECH	CFM56-5,A321,A319,A320,A318,CFM56-3,CFM56-3A,CFM56-3B,CFM56-3C,CFM56-3D,CFM56-3E,CFM56-3F,CFM56-3G,CFM56-3H,CFM56-3I,CFM56-3J,CFM56-3K,CFM56-3L,CFM56-3M,CFM56-3N,CFM56-3O,CFM56-3P,CFM56-3Q,CFM56-3R,CFM56-3S,CFM56-3T,CFM56-3U,CFM56-3V,CFM56-3W,CFM56-3X,CFM56-3Y,CFM56-3Z	75-31-11	AEG Seville
396800-11	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5,A321,A319,A320,A318,CFM56-3,CFM56-3A,CFM56-3B,CFM56-3C,CFM56-3D,CFM56-3E,CFM56-3F,CFM56-3G,CFM56-3H,CFM56-3I,CFM56-3J,CFM56-3K,CFM56-3L,CFM56-3M,CFM56-3N,CFM56-3O,CFM56-3P,CFM56-3Q,CFM56-3R,CFM56-3S,CFM56-3T,CFM56-3U,CFM56-3V,CFM56-3W,CFM56-3X,CFM56-3Y,CFM56-3Z	75-31-11	AEG Seville
396800-12	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5,A321,A319,A320,A318,CFM56-3,CFM56-3A,CFM56-3B,CFM56-3C,CFM56-3D,CFM56-3E,CFM56-3F,CFM56-3G,CFM56-3H,CFM56-3I,CFM56-3J,CFM56-3K,CFM56-3L,CFM56-3M,CFM56-3N,CFM56-3O,CFM56-3P,CFM56-3Q,CFM56-3R,CFM56-3S,CFM56-3T,CFM56-3U,CFM56-3V,CFM56-3W,CFM56-3X,CFM56-3Y,CFM56-3Z	75-31-11	AEG Seville
396800-5	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5,A321,A319,A318,A320	75	AEG Seville
396800-6	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5,A321,A319,A318,A320	75	AEG Seville
396800-7	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5,A321,A319,A320,A318,CFM56-3,CFM56-3A,CFM56-3B,CFM56-3C,CFM56-3D,CFM56-3E,CFM56-3F,CFM56-3G,CFM56-3H,CFM56-3I,CFM56-3J,CFM56-3K,CFM56-3L,CFM56-3M,CFM56-3N,CFM56-3O,CFM56-3P,CFM56-3Q,CFM56-3R,CFM56-3S,CFM56-3T,CFM56-3U,CFM56-3V,CFM56-3W,CFM56-3X,CFM56-3Y,CFM56-3Z	75-31-11	AEG Seville
396800-8	MOTOR GEAR HYDRAULIC	ARGO-TECH	CFM56-5,A321,A319,A320,A318,CFM56-3,CFM56-3A,CFM56-3B,CFM56-3C,CFM56-3D,CFM56-3E,CFM56-3F,CFM56-3G,CFM56-3H,CFM56-3I,CFM56-3J,CFM56-3K,CFM56-3L,CFM56-3M,CFM56-3N,CFM56-3O,CFM56-3P,CFM56-3Q,CFM56-3R,CFM56-3S,CFM56-3T,CFM56-3U,CFM56-3V,CFM56-3W,CFM56-3X,CFM56-3Y,CFM56-3Z	75-31-11	AEG Seville
396800-9	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	CFM56-5,A321,A319,A320,A318,CFM56-3,CFM56-3A,CFM56-3B,CFM56-3C,CFM56-3D,CFM56-3E,CFM56-3F,CFM56-3G,CFM56-3H,CFM56-3I,CFM56-3J,CFM56-3K,CFM56-3L,CFM56-3M,CFM56-3N,CFM56-3O,CFM56-3P,CFM56-3Q,CFM56-3R,CFM56-3S,CFM56-3T,CFM56-3U,CFM56-3V,CFM56-3W,CFM56-3X,CFM56-3Y,CFM56-3Z	75-31-11	AEG Seville
396800-SERIES	BLEED VALVE FUEL GEAR MOTOR	ARGO-TECH	707, E3, E8, E6	75	AEG Seville
39-771	Control Valve		CL-601	32-43-29	AEG Seville
398724-1-1	Three inch Diameter Electric Buttery Shutoff Valve		CU Regional JER-100,CU Regional JER-100-1,CU Regional JER-100-2,CU Regional JER-100-3,CU Regional JER-100-4,CU Regional JER-100-5,CU Regional JER-100-6,CU Regional JER-100-7,CU Regional JER-100-8,CU Regional JER-100-9,CU Regional JER-100-10,CU Regional JER-100-11,CU Regional JER-100-12,CU Regional JER-100-13,CU Regional JER-100-14,CU Regional JER-100-15,CU Regional JER-100-16,CU Regional JER-100-17,CU Regional JER-100-18,CU Regional JER-100-19,CU Regional JER-100-20,CU Regional JER-100-21,CU Regional JER-100-22,CU Regional JER-100-23,CU Regional JER-100-24,CU Regional JER-100-25,CU Regional JER-100-26,CU Regional JER-100-27,CU Regional JER-100-28,CU Regional JER-100-29,CU Regional JER-100-30,CU Regional JER-100-31,CU Regional JER-100-32,CU Regional JER-100-33,CU Regional JER-100-34,CU Regional JER-100-35,CU Regional JER-100-36,CU Regional JER-100-37,CU Regional JER-100-38,CU Regional JER-100-39,CU Regional JER-100-40,CU Regional JER-100-41,CU Regional JER-1		

3E2071	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Seville
3E2090	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Seville
3E2334	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Seville
3E2342	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Seville
3E2346	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Seville
3E2414	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Seville
3E2466	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Seville
3E2467	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Seville
3E3203-1	Fill Adapter And Cap Assembly			38-11-31	AEG Seville
3E3209-1	Fill/Drain Valve Assembly		Challenger 600,CRJ-700	38-11-25	AEG Seville
3E3291-1	Air Filter			38-40-11	AEG Seville
3E3292-1	Regulator, Pressure		B757	38-40-04	AEG Seville
40206-2-4659	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Seville
40206-3	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Seville
40206-3-4659	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Seville
40206-3-Q4659	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Seville
40206-3-Q4659X	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Seville
40206-4	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Seville
40206-4-4659	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Seville
40206-5	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Seville
40206-5-4659	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Seville
40206-6	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Seville
40206-6-Q4659	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Seville
40206-7-4659	LANDING LIGHT	GRIMES AEROSPACE	UNK	33-41-51	AEG Seville
40206-7-Q4659	LANDING LIGHT	GRIMES	UNK	33-41-51	AEG Seville
4020736904	Pressure Regulating Valve Assembly		CRJ Regional Jet-100	75-22-00	AEG Seville
4042750P02	Alternator Stator/Alternator Rotor Vc.			74-12-00	AEG Seville
4048-10	Fluorescent Lamp Fixture			33-22-03	AEG Seville
4048-11	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Seville
4048-20	Fluorescent Lamp Fixture			33-22-03	AEG Seville
4048-20	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Seville
4048-21	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Seville
4048-30	Fluorescent Lamp Fixture			33-22-03	AEG Seville
4048-30	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Seville
4048-31	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Seville
4048-40	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Seville
4048-41	Fluorescent Lamp Fixture			33-22-03(TDS)	AEG Seville
4048-SERIES	Restraint System Assembly				AEG Seville
4049-10	Fluorescent Lamp Fixture			33-22-04	AEG Seville
4049-10	Lamp Carrier			33-22-04(TDS)	AEG Seville
4049-204049-21	Lamp Carrier			33-22-04(TDS)	AEG Seville
4049-30	Fluorescent Lamp Fixture			33-22-04	AEG Seville
4049-30	Lamp Carrier			33-22-04(TDS)	AEG Seville
4049-314049-40	Lamp Carrier			33-22-04(TDS)	AEG Seville
4049-40	Fluorescent Lamp Fixture			33-22-04	AEG Seville
4049-41	Lamp Carrier			33-22-04(TDS)	AEG Seville
4060781903	B-Sump Vent Regulator Valve		CRJ Regional Jet-100	75-21-00	AEG Seville
4060781904	B-Sump Vent Regulator Valve		CRJ Regional Jet-100	75-21-00	AEG Seville
407009-1	INDICATOR AZIMUTH		UNK		AEG Seville
407010001	Air Jet Pump			21-30-38	AEG Seville
4096733P07	High Voltage Igniter			74-21-39	AEG Seville
41000740-103	THRUST REVERSER VALVE ASSEMBLY	HRTEXTRO	DC9MD80	78-30-01	AEG Seville
41000740-104	THRUST REVERSER VALVE ASSEMBLY	HRTEXTRO - "MODULTON"	A300, A320, A330	78-30-01	AEG Seville
4101099F	FAN	A310, A320 STANDARD		49-52-04	AEG Seville
4106DA	LANDING GEAR VALVE	SARGENT	C-180,B737-300,B737-400,B737-700,B737-800	33-30-01	AEG Seville
4106T93G01	B-Sump Vent Regulator		Challenger 600	75-21-01	AEG Seville
4120706P02	Starter Control Valve		CRJ-700,CRJ900 Regional Jet-900	80-12-29	AEG Seville
4120714P02	Vibration Accelerometer		CF34-8C,MD-11	77-31-01	AEG Seville
4120716P01	Oil Pressure Transmitter		CF34-10E,CF34-8C,CF34-8E,CRJ-700	77-41-02	AEG Seville
4120719P02	Oil Level / Temperature Sensor		B747,CF34-8C,CF34-8C1	79-32-42	AEG Seville
4121767P02	Operability Bleed Valve			80-12-39	AEG Seville
4123716P01	Sump Seal Valve		CRJ Regional Jet-100,CF34-8E,CRJ-300,MD80	75-22-01	AEG Seville
4123717P02	Obsolete		CF34-8C,CF34-8E	80-12-40 - obsolete	AEG Seville
4123717P02	Operability Bleed Fuel Actuated Valve		CF34-8C,CF34-8E	80-12-41	AEG Seville
4123717P03	Obsolete		CF34-8C,CF34-8E	80-12-40 - obsolete	AEG Seville
4123717P03	Operability Bleed Fuel Actuated Valve		CF34-8C,CF34-8E	80-12-41	AEG Seville
4123717P04	Operability Bleed Fuel Actuated Valve		CF34-8C,CF34-8E	80-12-41	AEG Seville
4124716P06	Fuel Injector			73-11-07	AEG Seville
412700-27-324	Rudder Shutoff Valve			27-324	AEG Seville
4147769P01	Main Fuel Control			73-21-03	AEG Seville
4147769P02	Main Fuel Control			73-21-03	AEG Seville
4147769P03	Main Fuel Control			73-21-03	AEG Seville
4147769P04	Main Fuel Control			73-21-03	AEG Seville
4167743P01	Sump Seal Shutoff Valve		CRJ Regional Jet-100,CF34-8C5	75-22-02	AEG Seville
4210C02	Single Pole Contactor		Challenger 300	24-64-01	AEG Seville
42-206	CONTROL BOX ASSEMBLY	HYDRO-AIRE		32-32-40-51	AEG Seville
4269-31	Lavatory Drain Plug Assembly		B737	38-33-03	AEG Seville
42-791-1A	Unit Assembly, Anti, Skid Control			32-42-83	AEG Seville
42-867	Unit Assembly, Anti, Skid Control			32-42-83	AEG Seville
42-926-1	Anti Skid Control Unit			32-43-53	AEG Seville
42R764-1	Temperature Transducer			28-42-16	AEG Seville
42R765-1	Temperature Transducer			28-42-16	AEG Seville
430084-1	CAJA		UNK		AEG Seville
430201-1	UNISON STATOR	UNISON IND	A320		AEG Seville
4323-3	Lock Assembly			52-50-12	AEG Seville
4323-7	Lock Assembly			52-50-12	AEG Seville
438023-2	INDICATOR TORQUEMET	TEXAS INSTRUMENTS	UNK		AEG Seville
44090-3941-03	ANEMOMETRE	THALES	UNK	34	AEG Seville
44220-1	Fuel Control Unit, APU		UH60,MD-80,B737-200,DC-8,DC-10,MD-90	49-31-77	AEG Seville
4428-180-80-10	Flap Position Indicator		UH60,MD-80,B737-200,DC-8,DC-10,MD-90	27-50-10	AEG Seville
4428-180-80-11	Flap Position Indicator		UH60,MD-80,B737-200,DC-8,DC-10,MD-90	27-50-10	AEG Seville
443147-2	INDICATOR TORQUEMET	TEXAS INSTRUMENTS	UNK		AEG Seville
449-2	Power Supply Unit		CRJ Regional Jet-100,CRJ Regional Jet-200	24-30-03	AEG Seville
44E16-1A	Water Separator			44U-23-851A	AEG Seville
44E16-1B	Water Separator			44U-23-851A	AEG Seville
44E16-2A	Water Separator		Dash 8	44U-23-851A	AEG Seville
44E16-2B	Water Separator		Dash 8	44U-23-851A	AEG Seville
44E16-1A	Water Separator		Dash 8	44U-23-851A	AEG Seville
46-0087-1	RETRACTABLE LANDING LIGHT ASSEMBLY	HONEYWELL GRIMES AEROSPACE - HONEYWELL	DC-9, MD-80, MD-90,DC10	33-40-08	AEG Seville
46-0087-3	RETRACTABLE LANDING LIGHT ASSEMBLY	HONEYWELL/GRIMES	MD-80, MD-90, DC-9	33	AEG Seville
46-0083-1	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL/GRIMES	B707,B737-300,B777,B757-200,B757,B737	33-40-15	AEG Seville
46-0083-3	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL/GRIMES	B707,B737-300,B777,B757-200,B757,B737	33-40-15	AEG Seville
46-0083-5	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL AEROSPACE	B707,B737-300,B777,B757-200,B757,B737	33-40-15	AEG Seville
46-0083-7	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL/GRIMES	F100,F50,B737-300,B777,B757-200,B757,B737	33-40-15	AEG Seville
46-0212-1	AIRCRAFT RETRACTABLE LANDING LIGHT	HONEYWELL	C-212, CN-235	33	AEG Seville
46-0360-4	RETRACTABLE LANDING LIGHT	HONEYWELL	A330, A340	33	AEG Seville
4604616A	FCU	TRIUMPH ACCESSORY SERVICES			AEG Seville
4604616B	FCU	TRIUMPH ACCESSORY SERVICES			AEG Seville
4627201-16	STOP/LOCK	TRW AERONAUTICAL SYSTEMS GROUP/GENERAL	B757, B767	25-53-08	AEG Seville
463665 / MPEV3-011	PUMP-HYDR MOTOR DRIVEN		CN-235, CN-295		AEG Seville
463665 / MPEV3-011	PUMP-HYDR MOTOR DRIVEN		CN-235, CN-295		AEG Seville
463665 / MPEV3-011	PUMP-HYDR MOTOR DRIVEN		CN-235, CN-295		AEG Seville
46-52122-405242CW	ACTUATOR FLAP 2/VALVE 6		UNK		AEG Seville
4664-646-1	TRANSMITTER POSITION	HONEYWELL	P-3		AEG Seville
4664M378	Crewmember PBE			PRM-02	AEG Seville
468X008	Lavatory Floor Assy			53-10-04	AEG Seville
468X01X	Lavatory Door Assy			52-50-01	AEG Seville
46165-1	Electrical Harness Assembly- MLG			32-61-03	AEG Seville
46165-3	Electrical Harness Assembly- MLG			32-61-03	AEG Seville

463X001	Cockpit Door Assy			52-50-02	AEG Seville
46460-3	Stabilizer Brace Electrical Harness Assembly MLG			32-40-02	AEG Seville
46460-6	Stabilizer Brace Electrical Harness Assembly MLG		C-130	32-40-02	AEG Seville
46460-7	Stabilizer Brace Electrical Harness Assembly MLG			32-40-02	AEG Seville
46460-3	Stabilizer Brace Electrical Harness Assembly MLG			32-40-02	AEG Seville
46460-6	Stabilizer Brace Electrical Harness Assembly MLG			32-40-02	AEG Seville
46460-7	Stabilizer Brace Electrical Harness Assembly MLG		C-130	32-40-02	AEG Seville
466X00X	Bulkhead Panel Assy			53-10-01	AEG Seville
46847-3	Lever Assembly Alternate Extension System MLG		(DHQ)Dash 8-Q400	32-34-02	AEG Seville
46847-6	Lever Assembly Alternate Extension System MLG		(DHQ)Dash 8-Q400	32-34-02	AEG Seville
4780-6	Electrical Harness Assembly NLG			32-40-03	AEG Seville
4780-7	Electrical Harness Assembly NLG			32-40-03	AEG Seville
4780-9	Electrical Harness Assembly NLG			32-40-03	AEG Seville
4781-5	Electrical Harness Assembly NLG			32-40-03	AEG Seville
4782-5	Electrical Harness Assembly NLG			32-40-03	AEG Seville
47201-1	Electrical Harness Assembly NLG			32-40-03	AEG Seville
47201-01	Fan Speed Pickup		B767	74-31-02	AEG Seville
47201-3	Electrical Harness Assembly NLG			32-40-03	AEG Seville
47202-1	Electrical Harness Assembly NLG			32-40-03	AEG Seville
47202-3	Electrical Harness Assembly NLG			32-40-03	AEG Seville
472897-01	Controller, Fire Detector				AEG Seville
47300-1	Drag Strut Assembly NLG			32-21-03	AEG Seville
47300-3	Drag Strut Assembly NLG			32-21-03	AEG Seville
47300-6	Drag Strut Assembly NLG		(DHQ)Dash 8-Q400	32-21-03	AEG Seville
47300-7	Drag Strut Assembly NLG		(DHQ)Dash 8-Q400	32-21-03	AEG Seville
47300-9	Drag Strut Assembly NLG		(DHQ)Dash 8-Q400	32-21-03	AEG Seville
473872-01	Fire Detection and Extinguishing System Control				AEG Seville
473872-02	Fire Detection and Extinguishing System Control				AEG Seville
473872-03	Fire Detection and Extinguishing System Control				AEG Seville
47390-1	Electrical Harness Assembly NLG			32-40-03	AEG Seville
47391-1	Electrical Harness Assembly NLG			32-40-03	AEG Seville
47397-1	Fire Detectors		CF-34-BC,CF-5-50,CF-6-80C2,CF-165-3,CF-16A-7B,100A,3,100B1,624,1,130		AEG Seville
474660-2,474660-20	M3000 Discrete Cabin Smoke Detector				AEG Seville
474660-X	Model 3000 Discrete Cabin Smoke Detectors				AEG Seville
4768A0000-02	Power Control Unit			27-25-01	AEG Seville
4760A0000K02	Rudder Control Unit (RCU)			27-25-03	AEG Seville
4760A0000K03	Rudder Control Unit (RCU)			27-25-03	AEG Seville
476W2220-1H	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-1B	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-1E	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-1G	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-1H	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-1J	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-1L	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-1M	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2B	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2C	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2E	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2H	ATTENDANT HANDESET CRADLE ASSEMBLY	BAE SYSTEMS	A330, A340	23-42-02	AEG Seville
476W2220-2J	ATTENDANT HANDESET CRADLE ASSEMBLY	BAE SYSTEMS	A330, A340	23-42-02	AEG Seville
476W2220-2K	ATTENDANT HANDESET CRADLE ASSEMBLY	BAE SYSTEMS	A330, A340	23-42-02	AEG Seville
476W2220-2L	ATTENDANT HANDESET CRADLE ASSEMBLY	BAE SYSTEMS	A330, A340	23-42-02	AEG Seville
476W2220-2Q	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2R	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2S	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2T	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2U	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2V	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2W	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2X	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2Y	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-2Z	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3A	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3B	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3C	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3D	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3E	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3F	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3G	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3H	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3I	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3J	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3K	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3L	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3M	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
476W2220-3N	ATTENDANT HANDESET CRADLE ASSEMBLY	BOEING	B-737, B-767, B-777	23-42-02	AEG Seville
47830-1	Door Actuator Assembly		(DHQ)Dash 8-Q400,C-130	32-31-11	AEG Seville
47840-7	Nose Landing Gear FWD Doors Linkage		(DHQ)Dash 8-Q400	32-22-01	AEG Seville
47840-9	Nose Landing Gear FWD Doors Linkage		(DHQ)Dash 8-Q400	32-22-01	AEG Seville
47860-3	Nose Landing Gear FWD Doors Linkage		(DHQ)Dash 8-Q400	32-22-01	AEG Seville
47860-4	Nose Landing Gear FWD Doors Linkage		(DHQ)Dash 8-Q400	32-22-01	AEG Seville
4812 SERIES	MOTOR PUMP FILTER UNIT ASSY		A330, A340		AEG Seville
48180-6	Steering Control Manifold Assembly NLG		(DHQ)Dash 8-Q400	32-51-02	AEG Seville
48180-7	Steering Control Manifold Assembly NLG		(DHQ)Dash 8-Q400	32-51-02	AEG Seville
48180-9	Steering Control Manifold Assembly NLG		(DHQ)Dash 8-Q400	32-51-02	AEG Seville
48286-SERIES	AIRCRAFT DIRECT CURRENT MOTORS		A330, A340		AEG Seville
48315-3	MOTOR FIELD	HONEYWELL	A330, A340		AEG Seville
48344-1-SERIES	ENGINE STARTER MOTOR	ALLIEDSIGNAL	A330, A340		AEG Seville
48378-SERIES	ENGINE STARTER MOTOR	AIRESEARCH	A330, A340	49	AEG Seville
48610-1	CAM Mechanism Assembly Alternate Extension		(DHQ)Dash 8-Q400	32-34-03	AEG Seville
49000-1TTO-3B	Dressed Shock Strut Assembly MLG			32-11-05	AEG Seville
49060-3TO-20	Dressed Shock Strut Assembly MLG			32-11-06	AEG Seville
49103-1-3-6-7-9-TI-13	Wiring Harness Assembly-MLG			32-61-01	AEG Seville
49300-3TO-10	Side Stay Assembly, Main Landing Gear			32-11-12	AEG Seville
49313-1-3-6-7-9-TI-13	Wiring Harness Assembly-MLG			32-61-01	AEG Seville
49400-3TO-7	Lock Actuator Assembly			32-11-13	AEG Seville
49600-9TO-18	Uplock Assembly MLG			32-11-14	AEG Seville
49600-6-7-TI-13	Retraction Actuator Assembly- MLG			32-11-28	AEG Seville
49660-1-3	Pressure Switch/Restrictor Assembly- MLG			32-32-06	AEG Seville
49700-3	Auxiliary Actuator Assembly- MLG		B737,CRJ-700,CRJ900 Regional Jet-900,CRJ-190	32-11-18	AEG Seville
49800-3	MLG Damper Assembly		B737,CRJ-700,CRJ900 Regional Jet-900	32-10-02	AEG Seville
49901-1	Tail Bumper Skid Assembly		B737,CRJ-700,CRJ900 Regional Jet-900	32-71-10	AEG Seville
49906-3-6-7	Shock Absorber Assembly Tail Bumper			32-71-01	AEG Seville
49913-6	Tail Bumper Strike Indicator Assembly		B737,CRJ-700,CRJ900 Regional Jet-900	32-71-15	AEG Seville
49960-1	Shock Absorber Assembly Tail Bumper		CRJ-700,CRJ900 Regional Jet-900	32-71-02	AEG Seville
49961-1	Tail Bumper Skid Assembly		CRJ-700,CRJ900 Regional Jet-900	32-71-11	AEG Seville
49962-1	Tail Bumper Strike Indicator Assembly		CRJ900 Regional Jet	32-71-16	AEG Seville
4E1213	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1283	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1294	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1311	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1327	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1360	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1387	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1660-2	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1639	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1749-2	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E1908-1	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
4E2360-2	Brush Assemblies Electrothermal Propeller De-icing Systems			30-60-01	AEG Seville
60-0024-17	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340		AEG Seville
60-0024-23	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340		AEG Seville
60-0024-26	LIGHT TAXI	HONEYWELL	C-295		AEG Seville
60-0024-3	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340	33-41-38	AEG Seville
60-0024-6	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340	33-41-38	AEG Seville
60-0024-7	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340	334138	AEG Seville
60-0024-9	AIRCRAFT LANDING & TAXING LIGHT	HONEYWELL	A330, A340	334138	AEG Seville
600040-03	BATTERY	SAFT	A320,F.28,F.27,C-295	34-47-27	AEG Seville
60-076-1	LIGHT, TAKE-OFF	GRIMES AERO - MPM/MSM/MLL	A330,A318,A321,A320,A319,A320-200	33-46-12	AEG Seville
60-0263	Taxiling Light			33-42-10	AEG Seville
60-0263-1	Taxiling Light		C-130	33-42-10	AEG Seville

5004236-2	BRAKE ASSEMBLY	ARCORAY T-BRACING	A330, A340	32-43-47	AEG Sewline
5004236-3	BRAKE ASSEMBLY	ARCORAY T-BRACING	A330, A340	32-43-47	AEG Sewline
5004484-1	BRAKE ASSEMBLY	ARCORAY T-BRACING	C-212	32-43-47	AEG Sewline
5004484-2	BRAKE ASSEMBLY	ARCORAY T-BRACING	C-212	32-43-47	AEG Sewline
5004484-3	BRAKE ASSEMBLY	ARCORAY T-BRACING	C-212	32-43-47	AEG Sewline
5005686-1	HUB ASSY	MEGGITT	C-212	32-40-90	AEG Sewline
500702-6211	AXIAXE FAN	HAMILTONI	DC-9, MD-80	21-50-10	AEG Sewline
5009904-6	BREAK UNIT	ABS	F100		AEG Sewline
50-102616-01	NLG RETRACTION ACTUATOR ASSY		A340-600		AEG Sewline
50-102617-01	NLG RETRACT ACTUATOR ASSY		A340-600		AEG Sewline
50-10261034-00	NLG RETRACTION ACTUATOR ASSY		A340-600		AEG Sewline
501-1078-07	EMERGENCY POWER SUPPLY	JET ELECTRONICS AND TECHNOLOGY	A330, A340	24-20-03	AEG Sewline
501-13776-004	STARTER MOTOR	PLESSEY DYNAMICS	A330, A340	80	AEG Sewline
501-13776-005	STARTER MOTOR	PLESSEY DYNAMICS	A330, A340	80	AEG Sewline
501-13776-006	STARTER MOTOR	PLESSEY DYNAMICS	A330, A340	80	AEG Sewline
501-14661	STARTER MOTOR		A330, A340		AEG Sewline
501-14661-004	MOTOR-STARTER	EATON	A320,CFM56-5A,CFM56-5B	49-41-07	AEG Sewline
501-14972-001	END BELL		A330, A340		AEG Sewline
501-1247-03	Stick Pusher System		CRJ Regional Jet-200,C-130	27-30-10	AEG Sewline
501057-1	SLEEVE-AXLE.MLG	A320	A320		AEG Sewline
501057-1R	SLEEVE-AXLE.MLG	A320	A321		AEG Sewline
50-1026222-00	AFT PNTLE PIN LH	AIRBUS	A340-500		AEG Sewline
50-1026222-00	AFT PNTLE PIN RH	AIRBUS	A340/500		AEG Sewline
5013642-1	CRJ700 Brake Assy		CRJ-700	32-44-77	AEG Sewline
5020-1	CVR Audio Mixer			23-71-05	AEG Sewline
50-201602-00	LOWER TORQUE LINK	SAFRAN	A330	32-12-61	AEG Sewline
50-201602-01	UPPER TORQUE LINK	SAFRAN	A330	32-12-61	AEG Sewline
50-2016025-00	BRAKE ROD	SAFRAN	A330	32-12-61	AEG Sewline
50-2016026-00	RETRACTION LINK (LH)	SAFRAN	A330	32-12-61	AEG Sewline
50-2016027-00	RETRACTION BRACKET (LH)	SAFRAN	A330	32-12-61	AEG Sewline
50-2016026-00	RETRACTION LINK (RH)	SAFRAN	A330	32-12-61	AEG Sewline
50-2016027-00	RETRACTION BRACKET (RH)	SAFRAN	A330	32-12-61	AEG Sewline
50-2017001-00	MAIN FITTING LH	SAFRAN	A330	32-12-61	AEG Sewline
50-2017002-00	SHORTENING LINK (LOWER)	SAFRAN	A330	32-12-61	AEG Sewline
50-2017003-00	SHORTENING LINK (UPPER)	SAFRAN	A330	32-12-61	AEG Sewline
50-2018001-00	MAIN FITTING (RH)	SAFRAN	A330	32-12-61	AEG Sewline
50-2019008-00	RECOIL NUT	SAFRAN	A330		AEG Sewline
50-21001-00	RETRACTION ACTUATOR CYLINDER	SAFRAN	A330	32-31-90	AEG Sewline
50-21002-00	RETRACTION ACTUATOR PISTON ROD	SAFRAN	A330	32-31-90	AEG Sewline
50-21003-00	RETRACTION ACTUATOR PISTON HEA	SAFRAN	A330	32-31-90	AEG Sewline
50-21004-00	RETRACTION ACTUATOR PLANDY	SAFRAN	A330	32-31-90	AEG Sewline
50-210702-00	BOGIE BEAM	#N/D	A330		AEG Sewline
50-2107001-00	UPPER SIDE STAY	SAFRAN	A330	32-12-66	AEG Sewline
50-2107004-00	LOWER CARDAN PIN	SAFRAN	A330	32-12-66	AEG Sewline
502630-1	Control Cable Assembly			38-10-16	AEG Sewline
502630-2	Control Cable Assembly			38-10-16	AEG Sewline
502740-2-3-4	Galley Water Tank			38-10-11	AEG Sewline
502820-1	Electrical Control Panel Assembly			38-10-14	AEG Sewline
50304AR3	WATER BOILER	NORDSKOG	B737	25-31-356	AEG Sewline
503066-2	Indicator Panel Assembly			38-10-13	AEG Sewline
503060-1	Aft Lavatory Tank Assembly Water Pumping			38-10-12	AEG Sewline
503060-2	Aft Lavatory Tank Assembly Water Pumping			38-10-12	AEG Sewline
5030999-5811	LH MAIN LANDING GEAR	LINK			AEG Sewline
5030999-5812	RH MAIN LANDING GEAR	LINK			AEG Sewline
5030999-5819	LH MAIN LANDING GEAR	LINK			AEG Sewline
5030999-5820	RH MAIN LANDING GEAR	LINK			AEG Sewline
50-4506002-00	SLIDING TUBE	SAFRAN	A320		AEG Sewline
50-4506030-01	MAIN FITTING (LH)	SAFRAN	A320		AEG Sewline
50-4506001-01	MAIN FITTING (RH)	SAFRAN	A320		AEG Sewline
50-4506030-01	MAIN FITTING (RH)	SAFRAN	A320		AEG Sewline
505-902	Photoluminescent Floor Proximity Emergency Escape Route Marking			33-52-13	AEG Sewline
505-9031	Photoluminescent Floor Proximity Emergency Escape Route Marking			33-52-13	AEG Sewline
5059-2	VALVES:HYDRAULIC SHUTTLE				

0146-1-6MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER		UNK		AEG Seville
0146-1-7MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER		UNK		AEG Seville
01474-108-1	TACHOMETER IND	THALES	A330, A340	77	AEG Seville
01474-108-2	TACHOMETER IND	THALES	A330, A340	77	AEG Seville
01833-102-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Seville
01833-103-1	INDICATOR TEMPERATURE	THALES	A330, A340	77	AEG Seville
01833-104-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Seville
01833-106-1	INDICATOR TEMPERATURE	THALES	A330, A340	77	AEG Seville
01833-107-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Seville
01833-109-1	TEMPERATURE IND		A330, A340		AEG Seville
01833-111-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Seville
01833-121-1	TEMPERATURE IND	THALES	A330, A340	77	AEG Seville
0174-1	VALVE, HYDRAULIC FLOW REGULATOR, ALTIMETER	PNEUDRAU	B747,B737,B727	29-20-07	AEG Seville
0174-2	VALVE, HYDRAULIC FLOW REGULATOR, ALTIMETER	PNEUDRAU	B747,B737,B727	29-20-07	AEG Seville
01760-1	Solenoid Operated (M/G) Hydraulic Valve			32-30-02	AEG Seville
0190-1	Brake Volumetric Fuse - Overhaul manual			32-40-03	AEG Seville
021100	ACTUATOR ELECTRO-ME		UNK		AEG Seville
022-0656-003	INDICATOR SUBASSY	ROCKWELL COLLINS	BEECH	34	AEG Seville
022-2651-002	CONTROL EQUIP RADAR	ROCKWELL COLLINS	CN-235	23	AEG Seville
022-2938-001	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS	A330, A340	34	AEG Seville
022-4404-001	Primary Servo And Servo Mounts				AEG Seville
022-6222-100	ADF RECEIVER	ROCKWELL COLLINS	B737	34-53-77	AEG Seville
022-6623-006	CONTROL NAVIGATION	ROCKWELL COLLINS	DHC-8, DHC-8-100, DHC-8-200, DHC-8-300	23-80-10	AEG Seville
02461 SERIES	LIQUID COOLED MOTOR	UNKNOWN	A330, A340	29-20-16	AEG Seville
02490-7B	Valve, Bleed Air Check			36-10-21	AEG Seville
026438-1SERIES1	Mode Selectors			21-60-61	AEG Seville
026848-1	SELECTOR CABIN ZONE TEMP	HONEYWELL AEROMARINE	B747,B757	21-61-02	AEG Seville
026848-1 SERIES	CABIN ZONE TEMPERATURE SELECTOR		A330, A340		AEG Seville
0271-1	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	B737-600,B737-100,B737-500,B737-700,B737-800,B737-900,B737-1000,B737-1100,B737-1200,B737-1300,B737-1400,B737-1500,B737-1600,B737-1700,B737-1800,B737-1900,B737-2000,B737-2100,B737-2200,B737-2300,B737-2400,B737-2500,B737-2600,B737-2700,B737-2800,B737-2900,B737-3000,B737-3100,B737-3200,B737-3300,B737-3400,B737-3500,B737-3600,B737-3700,B737-3800,B737-3900,B737-4000,B737-4100,B737-4200,B737-4300,B737-4400,B737-4500,B737-4600,B737-4700,B737-4800,B737-4900,B737-5000,B737-5100,B737-5200,B737-5300,B737-5400,B737-5500,B737-5600,B737-5700,B737-5800,B737-5900,B737-6000,B737-6100,B737-6200,B737-6300,B737-6400,B737-6500,B737-6600,B737-6700,B737-6800,B737-6900,B737-7000,B737-7100,B737-7200,B737-7300,B737-7400,B737-7500,B737-7600,B737-7700,B737-7800,B737-7900,B737-8000,B737-8100,B737-8200,B737-8300,B737-8400,B737-8500,B737-8600,B737-8700,B737-8800,B737-8900,B737-9000,B737-9100,B737-9200,B737-9300,B737-9400,B737-9500,B737-9600,B737-9700,B737-9800,B737-9900,B737-10000	32-40-04	AEG Seville
0272-1	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAULICS	DC-9,B737-600,B737-100,B737-500,B737-700,B737-800,B737-900,B737-1000,B737-1100,B737-1200,B737-1300,B737-1400,B737-1500,B737-1600,B737-1700,B737-1800,B737-1900,B737-2000,B737-2100,B737-2200,B737-2300,B737-2400,B737-2500,B737-2600,B737-2700,B737-2800,B737-2900,B737-3000,B737-3100,B737-3200,B737-3300,B737-3400,B737-3500,B737-3600,B737-3700,B737-3800,B737-3900,B737-4000,B737-4100,B737-4200,B737-4300,B737-4400,B737-4500,B737-4600,B737-4700,B737-4800,B737-4900,B737-5000,B737-5100,B737-5200,B737-5300,B737-5400,B737-5500,B737-5600,B737-5700,B737-5800,B737-5900,B737-6000,B737-6100,B737-6200,B737-6300,B737-6400,B737-6500,B737-6600,B737-6700,B737-6800,B737-6900,B737-7000,B737-7100,B737-7200,B737-7300,B737-7400,B737-7500,B737-7600,B737-7700,B737-7800,B737-7900,B737-8000,B737-8100,B737-8200,B737-8300,B737-8400,B737-8500,B737-8600,B737-8700,B737-8800,B737-8900,B737-9000,B737-9100,B737-9200,B737-9300,B737-9400,B737-9500,B737-9600,B737-9700,B737-9800,B737-9900,B737-10000	32-40-05	AEG Seville
0273-1	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	DC-9,B737-600,B737-100,B737-500,B737-700,B737-800,B737-900,B737-1000,B737-1100,B737-1200,B737-1300,B737-1400,B737-1500,B737-1600,B737-1700,B737-1800,B737-1900,B737-2000,B737-2100,B737-2200,B737-2300,B737-2400,B737-2500,B737-2600,B737-2700,B737-2800,B737-2900,B737-3000,B737-3100,B737-3200,B737-3300,B737-3400,B737-3500,B737-3600,B737-3700,B737-3800,B737-3900,B737-4000,B737-4100,B737-4200,B737-4300,B737-4400,B737-4500,B737-4600,B737-4700,B737-4800,B737-4900,B737-5000,B737-5100,B737-5200,B737-5300,B737-5400,B737-5500,B737-5600,B737-5700,B737-5800,B737-5900,B737-6000,B737-6100,B737-6200,B737-6300,B737-6400,B737-6500,B737-6600,B737-6700,B737-6800,B737-6900,B737-7000,B737-7100,B737-7200,B737-7300,B737-7400,B737-7500,B737-7600,B737-7700,B737-7800,B737-7900,B737-8000,B737-8100,B737-8200,B737-8300,B737-8400,B737-8500,B737-8600,B737-8700,B737-8800,B737-8900,B737-9000,B737-9100,B737-9200,B737-9300,B737-9400,B737-9500,B737-9600,B737-9700,B737-9800,B737-9900,B737-10000	32-40-05	AEG Seville
0273-5	HYDRAULIC FUSE, VOLUMETRIC	PNEUDRAU	DC-9,B737-600,B737-100,B737-500,B737-700,B737-800,B737-900,B737-1000,B737-1100,B737-1200,B737-1300,B737-1400,B737-1500,B737-1600,B737-1700,B737-1800,B737-1900,B737-2000,B737-2100,B737-2200,B737-2300,B737-2400,B737-2500,B737-2600,B737-2700,B737-2800,B737-2900,B737-3000,B737-3100,B737-3200,B737-3300,B737-3400,B737-3500,B737-3600,B737-3700,B737-3800,B737-3900,B737-4000,B737-4100,B737-4200,B737-4300,B737-4400,B737-4500,B737-4600,B737-4700,B737-4800,B737-4900,B737-5000,B737-5100,B737-5200,B737-5300,B737-5400,B737-5500,B737-5600,B737-5700,B737-5800,B737-5900,B737-6000,B737-6100,B737-6200,B737-6300,B737-6400,B737-6500,B737-6600,B737-6700,B737-6800,B737-6900,B737-7000,B737-7100,B737-7200,B737-7300,B737-7400,B737-7500,B737-7600,B737-7700,B737-7800,B737-7900,B737-8000,B737-8100,B737-8200,B737-8300,B737-8400,B737-8500,B737-8600,B737-8700,B737-8800,B737-8900,B737-9000,B737-9100,B737-9200,B737-9300,B737-9400,B737-9500,B737-9600,B737-9700,B737-9800,B737-9900,B737-10000	32-40-05	AEG Seville
0274-1	HYDRAULIC FUSE, VOLUMETRIC	BOEING	B737-600,B737-100,B737-500,B737-700,B737-800,B737-900,B737-1000,B737-1100,B737-1200,B737-1300,B737-1400,B737-1500,B737-1600,B737-1700,B737-1800,B737-1900,B737-2000,B737-2100,B737-2200,B737-2300,B737-2400,B737-2500,B737-2600,B737-2700,B737-2800,B737-2900,B737-3000,B737-3100,B737-3200,B737-3300,B737-3400,B737-3500,B737-3600,B737-3700,B737-3800,B737-3900,B737-4000,B737-4100,B737-4200,B737-4300,B737-4400,B737-4500,B737-4600,B737-4700,B737-4800,B737-4900,B737-5000,B737-5100,B737-5200,B737-5300,B737-5400,B737-5500,B737-5600,B737-5700,B737-5800,B737-5900,B737-6000,B737-6100,B737-6200,B737-6300,B737-6400,B737-6500,B737-6600,B737-6700,B737-6800,B737-6900,B737-7000,B737-7100,B737-7200,B737-7300,B737-7400,B737-7500,B737-7600,B737-7700,B737-7800,B737-7900,B737-8000,B737-8100,B737-8200,B737-8300,B737-8400,B737-8500,B737-8600,B737-8700,B737-8800,B737-8900,B737-9000,B737-9100,B737-9200,B737-9300,B737-9400,B737-9500,B737-9600,B737-9700,B737-9800,B737-9900,B737-10000	32-40-04	AEG Seville
027962-2	Duct Temperature Sensor			21-60-60	AEG Seville
027964-1	Temperature Selector			21-60-62	AEG Seville
030ALOTY00	Accumulator Unit			33-13-97	AEG Seville
0373-1	VALVE, FLOW REGULATOR, HYDRAULIC	PNEUDRAU	B737-600,B737-100,B737-500,B737-700,B737-800,B737-900,B737-1000,B737-1100,B737-1200,B737-1300,B737-1400,B737-1500,B737-1600,B737-1700,B737-1800,B737-1900,B737-2000,B737-2100,B737-2200,B737-2300,B737-2400,B737-2500,B737-2600,B737-2700,B737-2800,B737-2900,B737-3000,B737-3100,B737-3200,B737-3300,B737-3400,B737-3500,B737-3600,B737-3700,B737-3800,B737-3900,B737-4000,B737-4100,B737-4200,B737-4300,B737-4400,B737-4500,B737-4600,B737-4700,B737-4800,B737-4900,B737-5000,B737-5100,B737-5200,B737-5300,B737-5400,B737-5500,B737-5600,B737-5700,B737-5800,B737-5900,B737-6000,B737-6100,B737-6200,B737-6300,B737-6400,B737-6500,B737-6600,B737-6700,B737-6800,B737-6900,B737-7000,B737-7100,B737-7200,B737-7300,B737-7400,B737-7500,B737-7600,B737-7700,B737-7800,B737-7900,B737-8000,B737-8100,B737-8200,B737-8300,B737-8400,B737-8500,B737-8600,B737-8700,B737-8800,B737-8900,B737-9000,B737-9100,B737-9200,B737-9300,B737-9400,B737-9500,B737-9600,B737-9700,B737-9800,B737-9900,B737-10000	32-51-01	AEG Seville
0373-2	VALVE FLOW REGULATOR HYDRAULIC	PNEUDRAU	B737-600,B737-100,B737-500,B737-700,B737-800,B737-900,B737-1000,B737-1100,B737-1200,B737-1300,B737-1400,B737-1500,B737-1600,B737-1700,B737-1800,B737-1900,B737-2000,B737-2100,B737-2200,B737-2300,B737-2400,B737-2500,B737-2600,B737-2700,B737-2800,B737-2900,B737-3000,B737-3100,B737-3200,B737-3300,B737-3400,B737-3500,B737-3600,B737-3700,B737-3800,B737-3900,B737-4000,B737-4100,B737-4200,B737-4300,B737-4400,B737-4500,B737-4600,B737-4700,B737-4800,B737-4900,B737-5000,B737-5100,B737-5200,B737-5300,B737-5400,B737-5500,B737-5600,B737-5700,B737-5800,B737-5900,B737-6000,B737-6100,B737-6200,B737-6300,B737-6400,B737-6500,B737-6600,B737-6700,B737-6800,B737-6900,B737-7000,B737-7100,B737-7200,B737-7300,B737-7400,B737-7500,B737-7600,B737-7700,B737-7800,B737-7900,B737-8000,B737-8100,B737-8200,B737-8300,B737-8400,B737-8500,B737-8600,B737-8700,B737-8800,B737-8900,B737-9000,B737-9100,B737-9200,B737-9300,B737-9400,B737-9500,B737-9600,B737-9700,B737-9800,B737-9900,B737-10000	32-51-01	AEG Seville
04110-010-1	ALTIMETRO BAROMETRICO	THALES	BELL HELIC EUROCOPTER	34,34-10-03/02	AEG Seville
0430497-1	EXCITER ROTOR	HONEYWELL	B737-700		AEG Bilbao
0430680-1	STATOR RESOLVER	HONEYWELL	A330, A340		AEG Bilbao
0430680-2	ROTOR RESOLVER	HONEYWELL	UNK		AEG Bilbao
0430680-3	STATOR RESOLVER	HONEYWELL	A330, A340	24	AEG Bilbao
0430696-1	MAGNET-PERMANENT, GENERATOR	HONEYWELL	A330, A340		AEG Bilbao
0430603-1	END BELL	HONEYWELL	S330, S340		AEG Bilbao
0430612-1	EXCITER STATOR	HONEYWELL	A330, A340		AEG Bilbao
0430621-1	MAIN ROTOR ASSY	HONEYWELL	UNK		AEG Bilbao
0430621-2	MAIN ROTOR ASSY	HONEYWELL	UNK		AEG Bilbao
0430621-3	MAIN ROTOR ASSY	HONEYWELL	UNK		AEG Bilbao
0430624-1	ROTOR	HONEYWELL	B737		AEG Bilbao
0430624-2	ROTOR	HONEYWELL	B737	REWIND	AEG Bilbao
0430624-3	ROTOR AC GENERATOR	HONEYWELL	A330, A340		AEG Bilbao
0430624-4	AC GENERATOR ROTOR	HONEYWELL	A330, A340		AEG Bilbao
0430657-1	RESISTOR BOBBIN	HONEYWELL	A330, A340		AEG Bilbao
043001-2	STATOR AND HOUSING ASSY	HONEYWELL	A330, A340		AEG Bilbao
043006-1	EXCITER ROTOR	HONEYWELL	A330, A340		AEG Bilbao
043006-2	EXCITER ROTOR		A330, A340		AEG Bilbao
046772-1	VACUUM BLOWER	HONEYWELL	A330,B737-900,B737-800,B737-700,B737-600,B737-500,B737-400,B737-300,B737-200,B737-100,B737-00	38-32-06	AEG Seville
046772-2	VACUUM BLOWER	HONEYWELL	B737-600,B737-500,B737-400,B737-300,B737-200,B737-100,B737-00	38-32-06	AEG Seville
046408-1	CABIN AIR RECIRCULATION FAN	ALLIEDSIGNAL	BELT, B-737-500; B-737-900; B-737-300; B-737-600; B-737-700; B-737-800; B-737-100; B-737-200; B-737-400; B-737-1000; B-737-1100; B-737-1200; B-737-1300; B-737-1400; B-737-1500; B-737-1600; B-737-1700; B-737-1800; B-737-1900; B-737-2000; B-737-2100; B-737-2200; B-737-2300; B-737-2400; B-737-2500; B-737-2600; B-737-2700; B-737-2800; B-737-2900; B-737-3000; B-737-3100; B-737-3200; B-737-3300; B-737-3400; B-737-3500; B-737-3600; B-737-3700; B-737-3800; B-737-3900; B-737-4000; B-737-4100; B-737-4200; B-737-4300; B-737-4400; B-737-4500; B-737-4600; B-737-4700; B-737-4800; B-737-4900; B-737-5000; B-737-5100; B-737-5200; B-737-5300; B-737-5400; B-737-5500; B-737-5600; B-737-5700; B-737-5800; B-737-5900; B-737-6000; B-737-6100; B-737-6200; B-737-6300; B-737-6400; B-737-6500; B-737-6600; B-737-6700; B-737-6800; B-737-6900; B-737-7000; B-737-7100; B-737-7200; B-737-7300; B-737-7400; B-737-7500; B-737-7600; B-737-7700; B-737-7800; B-737-7900; B-737-8000; B-737-8100; B-737-8200; B-737-8300; B-737-8400; B-737-8500; B-737-8600; B-737-8700; B-737-8800; B-737-8900; B-737-9000; B-737-9100; B-737-9200; B-737-9300; B-737-9400; B-737-9500; B-737-9600; B-737-9700; B-737-9800; B-737-9900; B-737-10000	21-20-18	AEG Seville
046408-2	CABIN AIR RECIRCULATION FAN	ALLIEDSIGNAL	B737-600,B737-500,B737-400,B737-300,B737-200,B737-100,B737-00	21-20-18	AEG Seville
046408-X	CABIN AIR RECIRCULATION FAN	AIRESEARCH	B737, B747	21	AEG Seville
046423-2	ROTOR & SHAFT ASSY	HONEYWELL	A330, A340		AEG Bilbao
046423-3	ROTOR & SHAFT ASSY	HONEYWELL	A330, A340		AEG Bilbao
046468-2	IMPELLER-FAN	UNKNOWN	UNK		AEG Seville
046705-1	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11,B757	21-25-12	AEG Seville
046705-2	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11,B757	21-25-12	AEG Seville
046705-3	CABIN AIR RECIRCULATION FAN LH	AIRESEARCH	B747,MD-90,MD-11,B757,B757-200	21-25-12	AEG Seville
046705-4	CABIN AIR RECIRCULATION FAN	AIRESEARCH	MD-11,B757	21-25-12	AEG Seville
04809-416-1	PRESSURE INDICATOR	THALES	A330, A340	29	AEG Seville
04809-418-1	PRESSURE INDICATOR	JAEGER	A330, A340	29	AEG Seville
04809-428-1	INDICPRESSION CARB	THALES	UNK	28-49-06	AEG Seville
04809-506-1	INDIC PRESSION HUI	THALES	A330, A340	63	AEG Seville
66-0294	INDICATOR LIGHT	GRIMES	UNK	33-10-03	AEG Seville
66-0294-1	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-200,B737-600,B737-300,B737-100	33-10-03	AEG Seville
66-0294-11	INDICATOR LIGHT ASSEMBLY	HONEYWELL	B737-200,B737-600,B737-300,B737-100	33-10-03	AEG Seville
66-0294-13					

66-08082-2	INBOARD FLAP DRIVE TIE GEARBOX	BOEING	8707	27-06-54	AEG Seattle
66-08082-3	INBOARD FLAP DRIVE TIE GEARBOX ASSEMBLY	BOEING	8707	27-06-54-27	AEG Seattle
66-0804-1	MAIN GEAR DAMPER ASSEMBLY	BOEING	8737	32-30-61	AEG Seattle
66-0804-2	MAIN GEAR DAMPER ASSEMBLY	BOEING	8737	32-30-61	AEG Seattle
66-0804-3	MAIN GEAR DAMPER ASSEMBLY	BOEING	8737	32-30-61	AEG Seattle
66-0804-4	MAIN GEAR DAMPER ASSEMBLY	BOEING	8737	32-30-61	AEG Seattle
66-0804-5	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	8737	32-30-61	AEG Seattle
66-0804-10	FLIGHT SPOILER POWER CONTROL UNIT	BOEING	DC-8,B737-500,B737-400,B737-300,B737-200,B737-100,B737-600,B737-700,B737-800,B737-900,B737-1000,B737-1100,B737-1200,B737-1300,B737-1400,B737-1500,B737-1600,B737-1700,B737-1800,B737-1900,B737-2000,B737-2100,B737-2200,B737-2300,B737-2400,B737-2500,B737-2600,B737-2700,B737-2800,B737-2900,B737-3000,B737-3100,B737-3200,B737-3300,B737-3400,B737-3500,B737-3600,B737-3700,B737-3800,B737-3900,B737-4000,B737-4100,B737-4200,B737-4300,B737-4400,B737-4500,B737-4600,B737-4700,B737-4800,B737-4900,B737-5000,B737-5100,B737-5200,B737-5300,B737-5400,B737-5500,B737-5600,B737-5700,B737-5800,B737-5900,B737-6000,B737-6100,B737-6200,B737-6300,B737-6400,B737-6500,B737-6600,B737-6700,B737-6800,B737-6900,B737-7000,B737-7100,B737-7200,B737-7300,B737-7400,B737-7500,B737-7600,B737-7700,B737-7800,B737-7900,B737-8000,B737-8100,B737-8200,B737-8300,B737-8400,B737-8500,B737-8600,B737-8700,B737-8800,B737-8900,B737-9000,B737-9100,B737-9200,B737-9300,B737-9400,B737-9500,B737-9600,B737-9700,B737-9800,B737-9900,B737-10000,B737-10100,B737-10200,B737-10300,B737-10400,B737-10500,B737-10600,B737-10700,B737-10800,B737-10900,B737-11000,B737-11100,B737-11200,B737-11300,B737-11400,B737-11500,B737-11600,B737-11700,B737-11800,B737-11900,B737-12000,B737-12100,B737-12200,B737-12300,B737-12400,B737-12500,B737-12600,B737-12700,B737-12800,B737-12900,B737-13000,B737-13100,B737-13200,B737-13300,B737-13400,B737-13500,B737-13600,B737-13700,B737-13800,B737-13900,B737-14000,B737-14100,B737-14200,B737-14300,B737-14400,B737-14500,B737-14600,B737-14700,B737-14800,B737-14900,B737-15000,B737-15100,B737-15200,B737-15300,B737-15400,B737-15500,B737-15600,B737-15700,B737-15800,B737-15900,B737-16000,B737-16100,B737-16200,B737-16300,B737-16400,B737-16500,B737-16600,B737-16700,B737-16800,B737-16900,B737-17000,B737-17100,B737-17200,B737-17300,B737-17400,B737-17500,B737-17600,B737-17700,B737-17800,B737-17900,B737-18000,B737-18100,B737-18200,B737-18300,B737-18400,B737-18500,B737-18600,B737-18700,B737-18800,B737-18900,B737-19000,B737-19100,B737-19200,B737-19300,B737-19400,B737-19500,B737-19600,B737-19700,B737-19800,B737-19900,B737-20000,B737-20100,B737-20200,B737-20300,B737-20400,B737-20500,B737-20600,B737-20700,B737-20800,B737-20900,B737-21000,B737-21100,B737-21200,B737-21300,B737-21400,B737-21500,B737-21600,B737-21700,B737-21800,B737-21900,B737-22000,B737-22100,B737-22200,B737-22300,B737-22400,B737-22500,B737-22600,B737-22700,B737-22800,B737-22900,B737-23000,B737-23100,B737-23200,B737-23300,B737-23400,B737-23500,B737-23600,B737-23700,B737-23800,B737-23900,B737-24000,B737-24100,B737-24200,B737-24300,B737-24400,B737-24500,B737-24600,B737-24700,B737-24800,B737-24900,B737-25000,B737-25100,B737-25200,B737-25300,B737-25400,B737-25500,B737-25600,B737-25700,B737-25800,B737-25900,B737-26000,B737-26100,B737-26200,B737-26300,B737-26400,B737-26500,B737-26600,B737-26700,B737-26800,B737-26900,B737-27000,B737-27100,B737-27200,B737-27300,B737-27400,B737-27500,B737-27600,B737-27700,B737-27800,B737-27900,B737-28000,B737-28100,B737-28200,B737-28300,B737-28400,B737-28500,B737-28600,B737-28700,B737-28800,B737-28900,B737-29000,B737-29100,B737-29200,B737-29300,B737-29400,B737-29500,B737-29600,B737-29700,B737-29800,B737-29900,B737-30000,B737-30100,B737-30200,B737-30300,B737-30400,B737-30500,B737-30600,B737-30700,B737-30800,B737-30900,B737-31000,B737-31100,B737-31200,B737-31300,B737-31400,B737-31500,B737-31600,B737-31700,B737-31800,B737-31900,B737-32000,B737-32100,B737-32200,B737-32300,B737-32400,B737-32500,B737-32600,B737-32700,B737-32800,B737-32900,B737-33000,B737-33100,B737-33200,B737-33300,B737-33400,B737-33500,B737-33600,B737-33700,B737-33800,B737-33900,B737-34000,B737-34100,B737-34200,B737-34300,B737-34400,B737-34500,B737-34600,B737-34700,B737-34800,B737-34900,B737-35000,B737-35100,B737-35200,B737-35300,B737-35400,B737-35500,B737-35600,B737-35700,B737-35800,B737-35900,B737-36000,B737-36100,B737-36200,B737-36300,B737-36400,B737-36500		

66-46138-24	MLO REACTION LINK ASSEMBLY	BOENQ	B737-400	32-17-1	AEQ Sewilla
66-46138-16	MLO LINK ASSY UPPER DOWNLOCK	BOENQ	B737-100	32-17-1	AEQ Sewilla
66-46138-20	MLO LINK ASSY UPPER DOWNLOCK	BOENQ	B737-100	32-17-1	AEQ Sewilla
66-46139-12	MLO LINK ASSY LOWER DOWNLOCK	BOENQ	B737-400	32-17-1	AEQ Sewilla
66-46139-9	MLO LINK ASSY LOWER DOWNLOCK	BOENQ	B737-100	32-17-1	AEQ Sewilla
66-46141-10	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-11	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-12	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-16	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-36	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-37	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-38	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-39	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-20	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-21	UPLCK ASSY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-22	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-23	UPLCK ASSY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-24	UPLCK ASSY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-25	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-26	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-6	MLO UPLCK ASSEMBLY	BOENQ	B737-100	32-17-01	AEQ Sewilla
66-46141-6	MLO UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-7	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46141-9	MAIN GEAR UPLCK ASSEMBLY	BOENQ	B737	32-17-01	AEQ Sewilla
66-46160-11	SUPPORT TUBE	BOENQ	B737-400	32-11-1	AEQ Sewilla
66-46160-7	MLO SUPPORT TUBE ORIFICE	BOENQ	B737-100	36	AEQ Sewilla
66-46160-8	MLO SUPPORT TUBE ORIFICE	BOENQ	B737-100	32	AEQ Sewilla
66-46200-1	NOSE GEAR MINOR COMPONENTS	BOENQ	B737	32-01-03	AEQ Sewilla
66-46200-1	NOSE GEAR MINOR COMPONENTS	BOENQ	B737	32-01-03	AEQ Sewilla
66-46200-7	NOSE GEAR MINOR COMPONENTS	BOENQ	B737	32-01-03	AEQ Sewilla
66-46200-9	NOSE GEAR MINOR COMPONENTS	BOENQ	B737	32-01-03	AEQ Sewilla
66-46200-27	NLG STEERING PLATE UPPER (DRL)	BOENQ	B737-100	32-21-1	AEQ Sewilla
66-46200-33	NLG STEERING PLATE UPPER (DRL)	BOENQ	B737-300	32-21-58	AEQ Sewilla
66-46200-34	NLG STEERING PLATE LOWER (DRL)	BOENQ	B737-300	32-21-58	AEQ Sewilla
66-46201-8	NLG OUTER CYLINDER	BOENQ	B737-100	32	AEQ Sewilla
66-46209-1	NLG METERING PIN	BOENQ	B737-100	32	AEQ Sewilla
66-46221-4	NLG GLAND NUT ASSEMBLY	BOENQ	B737-300	32-21-1	AEQ Sewilla
66-46225-11	NLG TUBE ORIFICE SUPPORT UPPER	BOENQ	B737-300	32-21-58	AEQ Sewilla
66-46225-9	NLG TUBE ORIFICE SUPPORT UPPER	BOENQ	B737-300	32-21-1	AEQ Sewilla
66-46230-1	BRACE ASSEMBLY LOWER DRAG	BOENQ	B737	32-01-03	AEQ Sewilla
66-46230-11	BRACE ASSEMBLY LOWER DRAG	BOENQ	B737	32-01-03	AEQ Sewilla
66-46230-13	BRACE ASSEMBLY LOWER DRAG	BOENQ	B737	32-01-03	AEQ Sewilla
66-46230-16	BRACE ASSEMBLY LOWER DRAG	BOENQ	B737	51.32-01-03	AEQ Sewilla
66-46230-17	BRACE ASSEMBLY LOWER DRAG	BOENQ	B737	32-01-03	AEQ Sewilla
66-46230-19	BRACE ASSEMBLY LOWER DRAG	BOENQ	B737	32-01-03	AEQ Sewilla
66-46230-6	BRACE ASSEMBLY LOWER DRAG	BOENQ	B737	32-01-03	AEQ Sewilla
66-46230-7	BRACE ASSEMBLY LOWER DRAG	BOENQ	B737	32-01-03	AEQ Sewilla
66-46232-1	NOSE GEAR MINOR COMPONENTS	BOENQ	B737	32-01-03	AEQ Sewilla
66-46232-3	NOSE GEAR MINOR COMPONENTS	BOENQ	B737	32-01-03	AEQ Sewilla
66-46232-6	NOSE GEAR MINOR COMPONENTS	BOENQ	B737	32-01-03	AEQ Sewilla
66-46232-6	NOSE GEAR MINOR COMPONENTS	BOENQ	B737	32-01-03	AEQ Sewilla
66-46245-1	LOCK LINK INSTALLATION	BOENQ	B737	32-01-03	AEQ Sewilla
66-46245-10	LOCK LINK INSTALLATION	BOENQ	B737	32-34-13	AEQ Sewilla
66-46245-11	LOCK LINK INSTALLATION	BOENQ	B737	32-34-13	AEQ Sewilla
66-46245-12	LOCK LINK INSTALLATION	BOENQ	B737	32-34-13	AEQ Sewilla
66-46245-13	LOCK LINK INSTALLATION	BOENQ	B737	32-34-13	AEQ Sewilla
66-46245-14	LOCK LINK INSTALLATION	BOENQ	B737	32-34-13	AEQ Sewilla
66-46245-3</					

[illegible]

66960-1	Ground Spoiler Selector Solenoid Valve			27-60-21	AEG Seville
66960-3	Ground Spoiler Selector Solenoid Valve			27-60-21	AEG Seville
66960-1	Solenoid Valve, Unloading, Flight Spoiler Servo			27-58-31	AEG Seville
66960-3	Solenoid Valve, Unloading, Flight Spoiler Servo			27-58-31	AEG Seville
66C2676-2	NLG OUTER CYLINDER	BOEING	B737-300	32	AEG Seville
66C26707-1	NLG STEM ORIFICE SUPPORT TUBE	BOEING	B737-300	32	AEG Seville
66C26707-2	NLG STEM ORIFICE SUPPORT TUBE	BOEING	B737-300	32-21-58	AEG Seville
66C26864-3	OUTBOARD GROUND SPOILER ACTUATOR	BOEING	B737-900,B737-800,B737-700,B737-400,B737-300,B737-200,B737-100,B737-000	27-62-71	AEG Seville
66C-26864-3	OUTBOARD GROUND SPOILER ACTUATOR	BOEING	A330, A340		AEG Seville
66C27350-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
66C27350-11	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
66C27350-12	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
66C27350-5	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
66C27350-7	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
66C27350-9	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
66C27601-1	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Seville
66C27601-2	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Seville
66C27601-3	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Seville
66C27608-1	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Seville
66C27608-2	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Seville
66C27608-3	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION	BOEING	737	27-55-59	AEG Seville
66C27631-1	DOOR BRACKET	BOEING	B737	32	AEG Seville
66C27631-3	DOOR BRACKET	BOEING	B737	32-01-03	AEG Seville
66C3099-1	NLG LOCK ACTUATOR	BOEING	B737-500,B737-400,B737-300,B737-200,B737-100,B737-000	32-32-30-33	AEG Seville
66C3099-2	NOSE GEAR LOCK ACTUATOR ASSEMBLY	THE BOEING	B737-500,B737-400,B737-300,B737-200,B737-100,B737-000	32-32-30-33	AEG Seville
66C3786-1	DOOR BRACKET	BOEING	B737	32-01-03	AEG Seville
66C3786-4	DOOR BRACKET	BOEING	B737	32-01-03	AEG Seville
66C32960-1	MLG METERING PIN	BOEING	B737-500,B737-400,B737-300,B737-200,B737-100,B737-000	32-11-11	AEG Seville
66C32960-2	MLG METERING PIN	BOEING	B737-400	32	AEG Seville
66C32966-1	MAIN GEAR ACTUATOR ASSY	BOEING	B737	32-30-13	AEG Seville
66C32966-3	ACTUATOR, MLG RETRACT	BOEING	B737	32-30-13	AEG Seville
66C32966-4	ACTUATOR, MLG RETRACT	BOEING	B737	32-30-13	AEG Seville
66C32966-6	MAIN GEAR ACTUATOR ASSY	BOEING	B737	32-30-13	AEG Seville
66C33706-1	MLG BOLT ASSY REACTION LINK	BOEING	B737-400	32-17-11	AEG Seville
66C33706-3	MLG BOLT ASSY REACTION LINK	BOEING	B737-400	32	AEG Seville
66C37063-9	RUDDER PCU	BOEING	MD-80-83,B737	27-20-01	AEG Seville
66C38068-10	L/E ACTUATOR	BOEING	B737-300,B737-400,B737-500,B737-600,B737-700,B737-800,B737-900	27-81-47	AEG Seville
66C38069-13	ACTUATOR ASSY	BOEING	B747, B737	27-81-47	AEG Seville
66C38069-14	LEADING EDGE SLAT HYD ACT ASSEM	BOEING	B737-500,B737-400,B737-300,B747,B737	27-81-47	AEG Seville
66C38069-16	ACTUATOR ASSY	BOEING	B747, B737	27-81-47	AEG Seville
66006-01	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	A330, A340	29-10-30	AEG Seville
66007-01	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER AEROSPACE	A330, A340	29-10-31	AEG Seville
66068-05	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	C-130,B737-400	29-11-30	AEG Seville
66068-06	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	B737-500,B737-400,B737-300,B737-200,B737-100,B737-000	29-11-30	AEG Seville
66068-07	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	B727,B747-400,B777,B707,B767,B757,B747	29-11-30	AEG Seville
66068-08	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER HANNIFIN	B747-400,B737,B727,B777,B767,B757,B747	29-11-30	AEG Seville
6607A1-73	SWITCH, PRESSURE	EATON AEROSPACE LLC	F27 F28	28	AEG Seville
6608201-X	STARTER GENERATOR		Learjet		AEG Seville
6608268-X	STARTER GENERATOR		Learjet		AEG Seville
6608468-XXX	STARTER GENERATOR		Learjet		AEG Seville
6608612-XXX	STARTER GENERATOR		Learjet		AEG Seville
66132-03	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	Trent-800,B757,B747,B737,B777,B767	29-11-36	AEG Seville
66132-04	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	Trent-800,B757,B747,B737,B777	29-11-36	AEG Seville
66133-02	PUMP MOTOR PACKAGE	PARKER	B727,B767,B747,B777,B777-222	29-11-37	AEG Seville
66133-03	PUMP MOTOR PACKAGE	PARKER	B727,B747-400,B767,B747,B777,B777-200,B777-200	29-11-37	AEG Seville
66133-04	PUMP MOTOR PACKAGE	PARKER	B727,B747-400,B767,B747,B777	29-11-37,29	AEG Seville
66173-03	HYDRAULIC PUMP	PARKER	Learjet,Learjet 45,Dash 8,(DHCI)Dash 8-400	29	AEG Seville
66190-02	Variable Delivery Hydraulic Pump				AEG Seville
66190-03	Variable Delivery Hydraulic Pump				AEG Seville
66190-04	Variable Delivery Hydraulic Pump				AEG Seville
66190-05	Variable Delivery Hydraulic Pump				AEG Seville
66196-01	Pump Motor Package			29-20-41	AEG Seville
66198-01	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	B727,A330,A340,CFM56-5C	29-00-00	AEG Seville
66198-02	API9V-21-02 ENGINE DRIVEN	PARKER	B727,A330,A340,CFM56-5C	29-00-00	AEG Seville
66198-03	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER	A330,A340,CFM56-5C	29-00-00	AEG Seville
66760-1	FLAP AND SLAT HYDRAULIC	EATON AEROSPACE	B737,B727,B767,B757	27-51-05	AEG Seville
66760-2	FLAP AND SLAT HYDRAULIC	EATON AEROSPACE	B737,B727,B767,B757	27-51-05	AEG Seville
66760-3	FLAP AND SLAT HYDRAULIC	EATON AEROSPACE	B737,B727,B757-200,B767,B757	27-51-05	AEG Seville
66760-4	FLAP AND SLAT HYDRAULIC	EATON	B737,B727,B757-200,B767,B757	27-51-05	AEG Seville
66760-6	FLAP AND SLAT HYDRAULIC	EATON AEROSPACE	B737,B727,B757-200,B767,B757	27-51-05	AEG Seville
6700-300-80-10	AC Power Monitor			24-60-01	AEG Seville
6700-300-80-10	AC Power Monitor			24-60-01-4	AEG Seville
6700-400-80-10	DC Power Monitor			24-60-02	AEG Seville
6700-400-80-11	DC Power Monitor			24-60-02	AEG Seville
670760-107	ACTUATOR ELECTRO -ME	LOCKHEED	UNK		AEG Seville
670764-103	GENERATOR TACHOMETE	LOCKHEED MARTIN	UNK		AEG Seville
6800-1	Battery Temp Monitor			24-60-03-4	AEG Seville
6800-100-80-10	Battery Temp Monitor			24-60-03	AEG Seville
68-04-774	Brush Assemblies Electrothermal Propeller De-			30-60-01	AEG Seville
6806307L	VIBRATOR, IGNITION CO		UNK		AEG Seville
69-14106-1	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Seville
69-14106-2	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Seville
69-14106-3	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Seville
69-14106-4	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Seville
69-14106-6	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Seville
69-14106-7	LANDING GEAR HYDRAULIC TRANSFE	BOEING	B737	32-40-01	AEG Seville
692646-17	Solenoid Valve			49-30-67	AEG Seville
69-36386-1	AFT LOCK MECHANISM SHAFT	BOEING	B737	32-01-03	AEG Seville
69-36386-2	AFT LOCK MECHANISM SHAFT	BOEING	B737	32-01-03	AEG Seville
69-36391-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-36391-2	DRAG BRACE,PIN	BOEING	B737	32-01-03	AEG Seville
69-36394-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-36394-2	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-36394-3	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-36394-4	NLG PIN DRAG BRACE UPPER	BOEING	B737-500,B737-400,B737-300,B737-200,B737-100,B737-000	32-01-03	AEG Seville
69-36396-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-36396-2	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-36396-3	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-36396-4	LWR DRAG BRACE BOLT	BOEING	B737	32-01-03	AEG Seville
69-36396-6	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-36600-3	MAIN GEAR LOCK ACTUATOR ASSEMB	BOEING	B737	32-30-21	AEG Seville
69-36600-4	MAIN GEAR LOCK ACTUATOR ASSEMB	BOEING	B737	32-30-21	AEG Seville
69-36600-6	MAIN GEAR LOCK ACTUATOR ASSEMB	BOEING	B737	32-30-21	AEG Seville
69-36600-6	MAIN GEAR LOCK ACTUATOR ASSEMB	BOEING	B737	32-30-21	AEG Seville
69-36622-3	NLG ORIFICE PLATE UPPER	BOEING	B737-100	32-21-58	AEG Seville
69-37307-112	ENGINE APU FIRE MODULE	BOEING	B737	26-10-45	AEG Seville
69-38709-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-38709-3	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-38709-6	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-38710-1	NOSE GEAR MINOR COMPONENTS	BOEING	B737	32-01-03	AEG Seville
69-39473-6	MLG BOLT ASSY LOWER DRAG STRUT	BOEING	B737-100	32	AEG Seville
69-39473-6	MLG BOLT ASSY LOWER DRAG STRUT	BOEING	B737-100	32	AEG Seville
69-41629-1	MLG BOLT DOWNLOCK LINK PIVOT	BOEING	B737-100	32	AEG Seville
69-42196-4	FORWARD TRUNION BEARING BOLT	BOEING	B737	32	AEG Seville
69-42196-6	FORWARD TRUNION BEARING BOLT	BOEING	B737	32	AEG Seville
696001-9A	STRUT ASSEMBLY MAIN LANDING GEAR	LOCKHEED	C-130 HERCULES	32	AEG Seville
69-61833-4	MLG BOLT TEE FITTING ATTACHMEN	BOEING	B737-500,B737-400,B737-300,B737-200,B737-100,B737-000	32	AEG Seville
69-63800-1	BUNGIE SPRING ASSEMBLY	BOEING	B737	32-01-03	AEG Seville
69-63800-4	BUNGIE SPRING ASSEMBLY	BOEING	B737	32-01-03	AEG Seville

[illegible]

72091-21DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-23DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-25DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-27DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-29DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-2DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-31DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-33DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-35DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-37DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-3DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72091-7DXX	FAUCET ASSEMBLY	ADAMS RITE		33-11-14	AEG Seville
72095-1	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320	38	AEG Seville
72095-3	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320, A330, A340	38-12-73	AEG Seville
72095-5	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320,A330	38	AEG Seville
72095-7	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320	38	AEG Seville
72095-9	MODULE CONTROL ASSEMBLY	ADAMS RITE	A320	38	AEG Seville
721429A	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721429B	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721429C	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721429D	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721429E	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-27-02	AEG Bilbao
721432A	ROTOR ASSEMBLY	SUNDSTRAND	A330, A340	24-26-03	AEG Bilbao
721432B	ROTOR ASSEMBLY	SUNDSTRAND	A330, A340	24-26-03	AEG Bilbao
721432C	ROTOR ASSEMBLY	SUNDSTRAND	A330, A340	24-26-03	AEG Bilbao
721432D	ROTOR	SUNDSTRAND	A330, A340	24-26-03	AEG Bilbao
721432E	ROTOR ASSEMBLY	HAMILTON	UNK	24-26-03	AEG Bilbao
721863B	Uplock			24-15-53	AEG Seville
721863C	Uplock			24-15-53	AEG Seville
722-635-1	Oil Level Detector			79-34-01	AEG Seville
722-635-3	Oil Level Detector			79-34-01	AEG Seville
72266-3	FUEL BOOSTER CANISTER PUMP	LEAR ROMEC	A330, A340	28-20-24	AEG Seville
72306039-1	WINGTIP ANTI-COLLISION LIGHT ASSEMBLY	HONEYWELL	B737-600,B737	33-43-86	AEG Seville
72306039-2	WINGTIP ANTI-COLLISION LIGHT ASSEMBLY	HONEYWELL	B737-600,B737	33-43-86	AEG Seville
72306039-3	WINGTIP ANTI-COLLISION LIGHT ASSEMBLY	HONEYWELL	B737-600,B737	33	AEG Seville
72306039-4	WINGTIP ANTI-COLLISION LIGHT ASSEMBLY	HONEYWELL	B737-600,B737	33	AEG Seville
72390-2	FUEL BOOSTER CANISTER PUMP	LEAR ROMEC	A330, A340	28-20-24	AEG Seville
7-26-4	INDICATOR, HOMIG		UNK		AEG Seville
726506Y1	EXCITER ROTOR		UNK		AEG Bilbao
727792C	IDG	SUNDSTRAND	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792D	IDG	HAMILTON	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792E	IDG	HAMILTON	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792F	IDG	SUNDSTRAND	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792G	IDG	HAMILTON	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792H	IDG	HAMILTON	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792J	IDG	HAMILTON	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792K	IDG	HAMILTON	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792L	IDG	HAMILTON	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792M	IDG	HAMILTON	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727792N	IDG	HAMILTON	B767,B777,L747-300,B737-800,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
727810A	AUXILIARY GENERATOR	HAMILTON	B747,B737,B767,B757,CF6-80C2,B211-635	24-21-00	AEG Bilbao
727810B	AUXILIARY GENERATOR	HAMILTON	B747,B737,B767,B757,CF6-80C2,B211-635	24-21-00	AEG Bilbao
727810C	AUXILIARY GENERATOR	SUNDSTRAND	B747,B737,B767,B757,CF6-80C2,B211-635	24-21-00	AEG Bilbao
728431B	Ejector Jack: ADG Charge Pump			24-15-52	AEG Seville
728431C	Ejector Jack: ADG Charge Pump			24-15-52	AEG Seville
728843-SERIES	ROTOR BALANCE ASSEMBLY	HAMILTON	A330, A340	24	AEG Bilbao
728843D	ROTOR	SUNDSTRAND	B757, B767, B747, A300	24-26-01	AEG Bilbao
728843E	ROTOR	SUNDSTRAND	B757, B767, B747, A300	24-26-01	AEG Bilbao
728843F	ROTOR	SUNDSTRAND	B757, B767, B747, A300	24-26-01	AEG Bilbao
728843G	ROTOR	SUNDSTRAND	B757, B767, B747, A300	24-26-01	AEG Bilbao
728843GY6	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B757, B767, B747, A300	REWIND	AEG Bilbao
728843H	ROTOR	SUNDSTRAND	B757, B767, B747, A300,A310	24-26-01	AEG Bilbao
728843-SERIES	ROTOR BALANCE ASSEMBLY		UNK		AEG Bilbao
728915B	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN	HAMILTON	B737,B757	24	AEG Bilbao
728915C	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN	HAMILTON	B737,B757	24	AEG Bilbao
728915D	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN	HAMILTON	B737,B757	24	AEG Bilbao
728915E	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN	HAMILTON	B737,B757	24	AEG Bilbao
728915-SERIES	WOUND ASSEMBLY		UNK		AEG Bilbao
729346A	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B757, B767	24-27-03	AEG Bilbao
729346B	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B757, B767	24-27-03,24	AEG Bilbao
729346C	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B757, B767	24-27-03,24	AEG Bilbao
729346D	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B757, B767	24-27-03	AEG Bilbao
729346E	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B757, B767	24-27-03	AEG Bilbao
729346F	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B757, B767	24-27-03	AEG Bilbao
729356B-SERIES	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
729356B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B757,B767,B747,A300	24-26-01	AEG Bilbao
729356C	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B757,B767,B747,A300	24-26-01	AEG Bilbao
729356D	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B757,B767,B747,A300	24-26-01	AEG Bilbao
729356E	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B757,B767,B747,A300	24-26-01	AEG Bilbao
729356F	ROTOR	HAMILTON	A300-600,B737,A310,A300,B747,B767,B757	24-26-01	AEG Bilbao
729356G	ROTOR	SUNDSTRAND	A300-600,B737,A310,A300,B747,B767,B757	24-26-01	AEG Bilbao
729356-SERIES	ROTOR BALANCE ASSEMBLY		B757,B767,B747,A300		AEG Bilbao
729722A	AUXILIARY GENERATOR	SUNDSTRAND	A300, A310	24-00-00	AEG Bilbao
729722B	AUXILIARY GENERATOR	SUNDSTRAND	A300, A310,B757	24-00-00	AEG Bilbao
729722C	AUXILIARY GENERATOR	SUNDSTRAND	A300, A310,B757	24-00-00	AEG Bilbao
729825A	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825B	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825C	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825D	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825E	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825F	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825G	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825H	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825J	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825K	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825L	INTEGRATED DRIVE GENERATOR	HAMILTON	B747,B767,B757,CF6-80A,CF6-80B,CZ,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
729825M	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757,B767,B747,B737,CF6-80A,B721F-60A,B721F-60B	24-00-00	AEG Bilbao
7301-1	Temperature Switch and Associated valves				AEG Seville
730989-1-0	Anti-Ice Controller			30-41-02	AEG Seville
7-3141-3	MAIN LANDING GEAR DOOR AC	SARGENT	DC-9,B737-500,B737-400,B737-300,B747-300,B747-400,B747-400	32-30-05	AEG Seville
731488D	PORT PLATE ASSEMBLY	HAMILTON	B767	24	AEG Bilbao
731489C	PORT PLATE ASSEMBLY	SUNDSTRAND	UNK	24	AEG Bilbao
731633B	Constant Speed Drive				AEG Bilbao
732691-SERIES	AIR COOLING FAN	HAMILTON STANDARD	A330, A340	21	AEG Seville
732691C	AIR COOLING FAN	HAMILTON	B767, B747	21-58-02	AEG Seville
732691E	FAN	HAMILTON	B747, B767,B757	21-58-02	AEG Seville
732691F	FAN	HAMILTON	B747, B767,B757	21-58-02	AEG Seville
732691G	AIR COOLING FAN	SUNDSTRAND	B747, B767,B757	21-58-02	AEG Seville
732691-SERIES	AIR COOLING FAN	SUNDSTRAND	A330, A340		AEG Seville
732678A	Governor And Support				AEG Seville
733742-SERIES	STATOR HOUSING	HAMILTON	A330, A340	24-17-09	AEG Bilbao
734177A	Flap Power Drive Unit			27-50-02	AEG Seville
734177B	Flap Power Drive Unit			27-50-02	AEG Seville
734177C	Flap Power Drive Unit			27-50-02	AEG Seville
734177D	Flap Power Drive Unit			27-50-02	AEG Seville
734177E	Flap Power Drive Unit			27-50-02	AEG Seville
734177F	Flap Power Drive Unit			27-50-02	AEG Seville
736492-SERIES	STATOR HOUSING	HAMILTON	A330, A340	24-17-09	AEG Bilbao
738165B	AC GENERATOR	SUNDSTRAND	A330, A340		AEG Bilbao

738168A	AC GENERATOR	SUNDSTRAND	A330, A340		AEG Bilbao
738229A	STATOR ASSEMBLY - AC GENERATOR	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
738290-SERIES	STATOR HOUSING ASSEMBLY		A330, A340		AEG Bilbao
738299 SERIES	ROTOR BALANCE ASSEMBLY	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
738299A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A330, A340	24-26-04	AEG Bilbao
738299B	ROTOR	SUNDSTRAND	B77	24-26-04	AEG Bilbao
738299-SERIES	ROTOR BALANCE ASSEMBLY		B77		AEG Bilbao
738316A	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
738690 SERIES	INPUT HOUSING ASSEMBLY		A330, A340		AEG Sevilla
738690-SERIES	INPUT HOUSING ASSEMBLY		A330 A340		AEG Sevilla
739915A	INTEGRATED DRIVE GENERATOR	HAMILTON	BOEING 747-300, 747-400, BOEING 767	24-00-00	AEG Bilbao
739915B	INTEGRATED DRIVE GENERATOR	HAMILTON	BOEING 747-300, 747-400, BOEING 767	24-00-00	AEG Bilbao
739915C	INTEGRATED DRIVE GENERATOR	HAMILTON	BOEING 747-300, 747-400, BOEING 767	24-00-00	AEG Bilbao
739915D	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	BOEING 747-300, 747-400, BOEING 767	24-00-00	AEG Bilbao
739927B	CSD	HAMILTON SUNDSTRAND	F-15	24	AEG Bilbao
741434A	ELECTRICAL HARNESS		A330, A340		AEG Sevilla
741434B	ELECTRICAL HARNESS		A330, A340		AEG Sevilla
741756 SERIES	STATOR HOUSING ASSEMBLY		A330, A340		AEG Bilbao
741756A	STATOR HOUSING ASSEMBLY	HAMILTON SUNDSTRAND	A330, A340		AEG Bilbao
741756A	Stator Housing Assembly			24-27-08	AEG Sevilla
742001 SERIES	ROTOR BALANCE ASSEMBLY		A330, A340		AEG Bilbao
742001A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A330, A340	24-26-04	AEG Bilbao
742001B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
742001SERIES	ROTOR BALANCE ASSEMBLY	HAMILTON SUNDSTRAND	A330, A340	24	AEG Bilbao
744041A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B747,B767,B757,CF6-80,CF6-80CZ,8B211-601A,8B211-601B,8B211-601C,8B211-601D,8B211-601E	24-00-00	AEG Bilbao
744041B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B747,B767,B757,CF6-80,CF6-80CZ,8B211-601A,8B211-601B,8B211-601C,8B211-601D,8B211-601E	24-00-00	AEG Bilbao
7-44853-1	Pitch & Roll Disc, Assy				AEG Sevilla
7-44853-17	Pitch & Roll Disc, Assy				AEG Sevilla
7-44853-19	Pitch & Roll Disc, Assy				AEG Sevilla
7-44853-3	Pitch & Roll Disc, Assy				AEG Sevilla
7-44854-6	Pilot Brake Control Assy			32-40-05	AEG Sevilla
7-44854-7	Pilot Brake Control Assy			32-40-05	AEG Sevilla
7-44854-9	Pilot Brake Control Assy			32-40-05	AEG Sevilla
7-44855-26	Co-Pilot Brake Control			32-40-06	AEG Sevilla
7-44855-27	Co-Pilot Brake Control			32-40-06	AEG Sevilla
7-44855-29	Co-Pilot Brake Control			32-40-06	AEG Sevilla
7-44855-31	Co-Pilot Brake Control			32-40-06	AEG Sevilla
7-44855-33	Co-Pilot Brake Control			32-40-06	AEG Sevilla
7-44855-35	Co-Pilot Brake Control			32-40-06	AEG Sevilla
7-44856-11	Parking Brake Control			32-45-02	AEG Sevilla
7-44856-13	Parking Brake Control			32-45-02	AEG Sevilla
7-44856-15	Parking Brake Control			32-45-02	AEG Sevilla
7-44856-17	Parking Brake Control			32-45-02	AEG Sevilla
7-44856-9	Parking Brake Control			32-45-02	AEG Sevilla
7-44857-1	ADG Release Control Assy				AEG Sevilla
7-44857-13	ADG Release Control Assy				AEG Sevilla
7-44857-2	ADG Release Control Assy				AEG Sevilla
7-44857-3	ADG Release Control Assy				AEG Sevilla
7-45167-1	Lav. Drain Control Assy			38-30-15	AEG Sevilla
7-45167-2	Lav. Drain Control Assy			38-30-15	AEG Sevilla
7-45167-3	Lav. Drain Control Assy			38-30-15	AEG Sevilla
745329A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B747-300,B747-300,B767,B747,CF6-80,CF6-80CZ,8B211-601A,8B211-601B,8B211-601C,8B211-601D,8B211-601E	24-00-00	AEG Bilbao
745329B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B747-300,B747-300,B767,B747,CF6-80,CF6-80CZ,8B211-601A,8B211-601B,8B211-601C,8B211-601D,8B211-601E	24-00-00	AEG Bilbao
745329C	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B747-300,B747-300,B767,B747,CF6-80,CF6-80CZ,8B211-601A,8B211-601B,8B211-601C,8B211-601D,8B211-601E	24-00-00	AEG Bilbao
745329D	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B747-300,B747-300,B767,B747,CF6-80,CF6-80CZ,8B211-601A,8B211-601B,8B211-601C,8B211-601D,8B211-601E	24-00-00	AEG Bilbao
745329E	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B747-300,B747-300,B767,B747,CF6-80,CF6-80CZ,8B211-601A,8B211-601B,8B211-601C,8B211-601D,8B211-601E	24-00-00	AEG Bilbao
745329F	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B747-300,B747-300,B767,B747,CF6-80,CF6-80CZ,8B211-601A,8B211-601B,8B211-601C,8B211-601D,8B211-601E	24-00-00	AEG Bilbao
7-45401-1	Belows Kit On Raf Manual Release Control			45401-32-01	AEG Sevilla
7-45401-1	Luminescent Decal On Raf Manual Release Control Assembly			45401-32-02	AEG Sevilla
7-45416-19	Manual Release Control Assy				AEG Sevilla
7-45416-23	Manual Release Control Assy				AEG Sevilla
7-45416-29	Manual Release Control Assy				AEG Sevilla
7-45600-1	Flap Control Lever Assembly			27-50-00	AEG Sevilla
7-45600-2	Flap Control Lever Assembly			27-50-00	AEG Sevilla
7-45600-3	Flap Control Lever Assembly			27-50-00	AEG Sevilla
7-45601-1	Flight Spoiler Lever Control Assembly			27-61-01	AEG Sevilla
7-45602-1	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
7-45602-1A	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
7-45602-1B	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
7-45602-3	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
7-45602-5	Landing Gear Control Handle Assembly			32-31-01	AEG Sevilla
745777 SERIES	STATOR HOUSING	HAMILTON SUNDSTRAND	A330, A340	24-17-09	AEG Bilbao
747194A	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
747194B	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
747194C	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
747194D	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
747194E	IDG	HAMILTON	B757,B747-300,B747-400,B767,B747	24-11-77	AEG Bilbao
747194F	IDG	HAMILTON SUNDSTRAND	B757,B747-300,B747-400,B767,B767	24-11-77	AEG Bilbao
747-6780-1-0	AC MOTOR WITH BRAKE ASSEMBLY		A330, A340	25-55-49	AEG Sevilla
747740 SERIES	STATOR HOUSING	HAMILTON SUNDSTRAND	A330, A340	24-17-31	AEG Bilbao
747740A	STATOR HOUSING	SUNDSTRAND	A339,A320	24-17-31	AEG Bilbao
747740B	STATOR HOUSING	SUNDSTRAND	A339,A320	24-17-31	AEG Bilbao
747740C	STATOR HOUSING	SUNDSTRAND	A339,A320	24-17-31	AEG Bilbao
747740D	STATOR HOUSING	SUNDSTRAND	A339,A320	24-17-31	AEG Bilbao
747740E	STATOR HOUSING	SUNDSTRAND	A339,A320	24-17-31	AEG Bilbao
747740F	STATOR HOUSING	SUNDSTRAND	A339,A320	24-17-31	AEG Bilbao
747740G	STATOR HOUSING	HAMILTON	A320	24-17-31	AEG Bilbao
747768 SERIES	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
747768C	ROTOR	SUNDSTRAND	B737,A310,A300,B747,B767,B757	24-26-01	AEG Bilbao
747768D	ROTOR	SUNDSTRAND	A300-600,B737,A310,A300,B747,B767,B757	24-26-01	AEG Bilbao
747768-SERIES	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	757, 767, 747, A300		AEG Bilbao
7600-0011-03	Power Supply				AEG Sevilla
7600-0011-04	Power Supply				AEG Sevilla
7600-0011-05	Power Supply				AEG Sevilla
7600-0011-06	Power Supply				AEG Sevilla
7600-0011-07	Power Supply				AEG Sevilla
7600-00184-01	Power Supply				AEG Sevilla
760659-1	Overtemperature Switch			21-61-29	AEG Sevilla
760659-16	Overtemperature Switch			21-61-29	AEG Sevilla
760659-17	Overtemperature Switch			21-61-29	AEG Sevilla
760659-3	Overtemperature Switch			21-61-29	AEG Sevilla
760659-4	Overtemperature Switch			21-61-29	AEG Sevilla
760659-6	Overtemperature Switch			21-61-29	AEG Sevilla
760659-8	Overtemperature Switch			21-61-29	AEG Sevilla
760662-2	Separator Assy, Water			21-51-29	AEG Sevilla
760662-8	Separator Assy, Water			21-51-29	AEG Sevilla
760665-1	Overtemperature Switch			21-61-29	AEG Sevilla
760665-10	Overtemperature Switch			21-61-29	AEG Sevilla
760665-9	Overtemperature Switch			21-61-29	AEG Sevilla
761202A	ELECTRICAL HARNESS	HAMILTON SUNDSTRAND	A-320, A321	24-18-12	AEG Sevilla
761202B	ELECTRICAL HARNESS	HAMILTON SUNDSTRAND	A-320, A321	24-18-12	AEG Sevilla
761202C	ELECTRICAL HARNESS	HAMILTON SUNDSTRAND	A-320, A321	24-18-12	AEG Sevilla
761202D	ELECTRICAL HARNESS	HAMILTON SUNDSTRAND	A-320, A321	24-18-12	AEG Sevilla
761202E	ELECTRICAL HARNESS	HAMILTON SUNDSTRAND	A-320, A321	24-18-12	AEG Sevilla
761344A	ROTOR ASSEMBLY, EXCITER	SUNDSTRAND	A330, A340	24	AEG Bilbao
762063A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11	24-26-08	AEG Bilbao
762167 SERIES	INTEGRATED DRIVE GENERATOR	HAMILTON SUNDSTRAND	A340	24-11-81	AEG Bilbao
762167B	INTEGRATED DRIVE GENERATOR	HAMILTON	A340,CFM56-5C	24-21-00	AEG Bilbao
762167C	INTEGRATED DRIVE GENERATOR	HAMILTON	A340,CFM56-5C	24-21-00	AEG Bilbao
762167D	IDG	HAMILTON	A330,A340,CFM56-5C	24-21-00	AEG Bilbao

702168A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	Trent-700,A330	24-11-82	AEG Bilbao
702168B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B777,Trent-700,A330,CFM56-5C	24-21-00	AEG Bilbao
702168C	INTEGRATED DRIVE GENERATOR	HAMILTON	A330-200, A330-300, A330 NEO	30279	AEG Bilbao
702168D	INTEGRATED DRIVE GENERATOR	HAMILTON	A330-200, A330-300, A330 NEO	30279	AEG Bilbao
702686 SERIES	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340	24-17-33	AEG Bilbao
70329A	EXCITER ROTOR	SUNDSTRAND	B757	24	AEG Bilbao
70329AY1	EXCITER ROTOR		B757,B767		AEG Bilbao
70329B	EXCITER ROTOR	SUNDSTRAND	B757	24	AEG Bilbao
70329-SERIES	ROTOR ASSEMBLY EXCITER		B757,B767		AEG Bilbao
703367A	ROTOR BALANCE ASSEMBLY	HAMILTON	A340	24-26-09	AEG Bilbao
703490A	STATOR AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A340	24-17-35	AEG Bilbao
703490B	STATOR AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A340	24-17-35	AEG Bilbao
703490C	STATOR AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A340	24-17-35	AEG Bilbao
704681-1	Cabin/Duct Temperature Sensor			21-61-24	AEG Sevilla
704691-1	Cabin/Duct Temperature Sensor			21-61-24	AEG Sevilla
705077A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	A330,CFM56-5C	24-21-00	AEG Bilbao
705077B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	A330	24-11-82	AEG Bilbao
705057A	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
705067B	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
705067C	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
705067D	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
705067E	ELECTRICAL HARNESS ASSEMBLY	SUNDSTRAND	A330, A340	24-18-16	AEG Sevilla
705369A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757/B757-900,B757-800,B757-700,B757-500,B757-400,B757-300,B757-200,B757-100,B757-00	24-00-00	AEG Bilbao
705369B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757/B757-900,B757-800,B757-700,B757-500,B757-400,B757-300,B757-200,B757-100,B757-00	24-00-00	AEG Bilbao
705369C	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757/B757-900,B757-800,B757-700,B757-500,B757-400,B757-300,B757-200,B757-100,B757-00	24-00-00	AEG Bilbao
705369D	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757/B757-900,B757-800,B757-700,B757-500,B757-400,B757-300,B757-200,B757-100,B757-00	24-00-00	AEG Bilbao
705469B	IDG	HAMILTON	CRJ Regional Jet-100,CRJ Regional Jet-300,Challenger A6A,Challenger	24-00-00	AEG Bilbao
705469B	Integrated Drive Generator			24-21-08	AEG Sevilla
705469C	IDG	HAMILTON	CRJ Regional Jet-100,CRJ Regional Jet-300,Challenger A6A,Challenger	24-00-00	AEG Bilbao
705469C	Integrated Drive Generator			24-21-08	AEG Sevilla
705469D	IDG	HAMILTON	CRJ Regional Jet-100,CRJ Regional Jet-300,Challenger A6A,Challenger	24-00-00	AEG Bilbao
705469D	Integrated Drive Generator			24-21-08	AEG Sevilla
705469E	IDG	HAMILTON	CRJ Regional Jet-100,CRJ Regional Jet-300,Challenger A6A,Challenger	24-00-00	AEG Bilbao
705469E	Integrated Drive Generator			24-21-08	AEG Sevilla
706704A	Pump And Motor			24-14-14	AEG Sevilla
706901 SERIES	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
706901D	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11	24-26-10	AEG Bilbao
706901E	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
706901F	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
706901G	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11,B777	24-26-10	AEG Bilbao
706901H	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
706901J	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11,B777	24-26-10	AEG Bilbao
706901K	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	MD-11,B777	24-26-10	AEG Bilbao
706901L	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilbao
706066B	EXCITER ROTOR	SUNDSTRAND	A330	24	AEG Bilbao
706680A	APU GENERATOR	HAMILTON	B767,B767-400,B777-222,B777,Cf6-80C2	24-21-00	AEG Bilbao
706820 SERIES	STATOR HOUSING	HAMILTON	A330, A340	24-17-09	AEG Bilbao
706970 SERIES	STATOR HOUSING ASSEMBLY	SUNDSTRAND	A330, A340		AEG Bilbao
706971A	EXCITER AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A330	24-17-37	AEG Bilbao
706971B	EXCITER AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A330	24-17-37	AEG Bilbao
706971C	EXCITER AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A330	24-17-37	AEG Bilbao
706971D	EXCITER AND PMG HOUSING ASSEMBLY	SUNDSTRAND	A330	24-17-37	AEG Bilbao
707030 SERIES	ROTOR BALANCE ASSEMBLY	HAMILTON	A330, A340	24	AEG Bilbao
707030F	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	UNK	24-26-10	AEG Bilbao
707030G	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	UNK	24-26-10	AEG Bilbao
707030H	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	UNK	24-26-10	AEG Bilbao
707066A	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
707066B	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
707066C	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
707066D	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
707066E	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
707066F	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
707066G	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
707066H	VSCF GEN	SUNDSTRAND	B777	24-25-20	AEG Bilbao
707068 SERIES	STATOR HOUSING ASSEMBLY	HAMILTON	A330, A340		AEG Bilbao
707068B	STATOR HOUSING ASSEMBLY	HAMILTON	A330, A340	24	AEG Bilbao
707622B	EXCITER ROTOR	SUNDSTRAND	A330, A340	24	AEG Bilbao
708861B	EXCITER ROTOR ASSEMBLY	HAMILTON	UNK	24	AEG Bilbao
708922A	INTEGRATED DRIVE GENERATOR	HAMILTON	A330, A340	24	AEG Bilbao
709467 SERIES	STATOR HOUSING	SUNDSTRAND	A330, A340	24-17-09	AEG Bilbao
701674A	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE	B737N3/Boeing 737 MAX	24-11-85	AEG Bilbao
701674B	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE	B737N3/Boeing 737 MAX	24-11-85	AEG Bilbao
701674B	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE	B737N3/Boeing 737 MAX	24-11-85	AEG Bilbao
701341A	ADG GCU			24-23-10	AEG Sevilla
7013-551-91-13	TERMOMETER	THALES	A330, A340	77	AEG Sevilla
7013-551-91-14	T4 INDICATOR		A330, A340		AEG Sevilla
701674A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757-900,B757-800,B757-700,B757-500,B757-400,B757-300,B757-200,B757-100,B757-00	24	AEG Bilbao
701674B	INTEGRATED DRIVE GENERATOR	HAMILTON	B757-900,B757-800,B757-700,B757-500,B757-400,B757-300,B757-200,B757-100,B757-00	24-00-00	AEG Bilbao
702067A	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
702067B	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
702067C	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
702067D	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
702067E	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
702067F	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
702067G	STATOR HOUSING ASSEMBLY	SUNDSTRAND	B737	24-17-41	AEG Bilbao
70209A	STATOR ASSEMBLY - MAIN GENERATOR	SUNDSTRAND	A330, A340	24	AEG Bilbao
702309 SERIES	ROTOR	HAMILTON	737	24-26-12	AEG Bilbao
702309A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737	24-26-12	AEG Bilbao
702309AY3	ROTOR	SUNDSTRAND	737		AEG Bilbao
702309B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
702309C	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
702309D	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
702309E	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
702309F	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B737-600,B737	24-26-12	AEG Bilbao
702309Y3	ROTOR	HAMILTON	737		AEG Bilbao
702367A	GENERATOR MAIN FIELD WOUND ASSEMBLY	SUNDSTRAND	A330, A340	24	AEG Bilbao
702367B	GENERATOR MAIN FIELD WOUND ASSEMBLY	SUNDSTRAND	B737-600		AEG Bilbao
702677A	STATOR	SUNDSTRAND	A330, A340	24	AEG Bilbao
702620A	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
702620B	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
702620C	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
702620D	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
702620E	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
702620F	VSCF	SUNDSTRAND	B777	24-25-20	AEG Bilbao
702888B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	BR700-710,B717	24	AEG Bilbao
703226-01	DIODE PACK	HAMILTON	B737		AEG Bilbao
703226-12	SEMICONDUCTOR	SUNDSTRAND	B737		AEG Bilbao
703226-13	DIODE PACK	HAMILTON	B737		AEG Sevilla
703226-14	DIODE PACK	SUNDSTRAND	B737		AEG Bilbao
703776A	ELECTRICAL HARNESS	SUNDSTRAND	B767	24-18-02,24	AEG Sevilla
704204A	PMG STATOR	HAMILTON	B737	24	AEG Bilbao
704685-2	SWITCH AIRSPEED	HAMILTON	UNK	38282	AEG Sevilla
704801-2	PRECOOLER		UNK		AEG Sevilla
704930 SERIES	STATOR HOUSING ASSEMBLY		A330, A340		AEG Bilbao
704939A	IDG	SUNDSTRAND	Trent-800,B777-300,B777-200,B777	24-11-83	AEG Bilbao
704939B	IDG	SUNDSTRAND	Trent-800,B777-300,B777-200,B777	24-11-83	AEG Bilbao
706078-B	INSERT		UNK		AEG Bilbao
706088A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757/B757-900,B757-800,B757-700,B757-500,B757-400,B757-300,B757-200,B757-100,B757-00	24-00-00	AEG Bilbao
706088B	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B757/B757-900,B757-800,B757-700,B757-500,B757-400,B757-300,B757-200,B757-100,B757-00	24-00-00	AEG Bilbao

7660880	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B737/B737-300/B737-800/B737-700/B737-400	24-00-00	AEG Bilboe
766277A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	CRJ900 Regional Jet A300-600-3000	24-21-12	AEG Bilboe
766277A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	CRJ900 Regional Jet A300-600-3000	24-21-12	AEG Bilboe
766283A	Generator Control Unit			24-23-25	AEG Seville
766283B	Generator Control Unit			24-23-25	AEG Seville
766283C	Generator Control Unit			24-23-25	AEG Seville
766361A	Inboard Flap Actuator Assembly			27-52-07	AEG Seville
766361B	Inboard Flap Actuator Assembly			27-52-07	AEG Seville
766361C	Inboard Flap Actuator Assembly			27-52-07	AEG Seville
766361D	Inboard Flap Actuator Assembly			27-52-07	AEG Seville
766363A	Midboard Right Flap Actuator Assembly			27-52-19	AEG Seville
766363B	Midboard Right Flap Actuator Assembly			27-52-19	AEG Seville
766363C	Midboard Right Flap Actuator Assembly			27-52-19	AEG Seville
766363D	Midboard Right Flap Actuator Assembly			27-52-19	AEG Seville
766365A	Midboard Left Flap Actuator Assembly			27-52-20	AEG Seville
766365B	Midboard Left Flap Actuator Assembly			27-52-20	AEG Seville
766365C	Midboard Left Flap Actuator Assembly			27-52-20	AEG Seville
766365D	Midboard Left Flap Actuator Assembly			27-52-20	AEG Seville
766369A	Outboard Left Flap Actuator Assembly			27-52-22	AEG Seville
766369B	Outboard Left Flap Actuator Assembly			27-52-22	AEG Seville
766369C	Outboard Left Flap Actuator Assembly			27-52-22	AEG Seville
766388A	Outboard Slat Actuator Assembly			27-81-18	AEG Seville
766388B	Outboard Slat Actuator Assembly			27-81-18	AEG Seville
766388C	Outboard Slat Actuator Assembly			27-81-18	AEG Seville
766461 SERIES	STATOR HOUSING		A330, A340		AEG Bilboe
766461A	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilboe
766461B	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilboe
766461C	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilboe
767091A	7.5 HP 6-POLE AC MOTOR	HAMILTON	B737,CRJ-700	29-20-42	AEG Seville
767100 SERIES	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400	24	AEG Bilboe
767100A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilboe
767100B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilboe
767100C	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilboe
767100D	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilboe
767100E	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilboe
767100F	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilboe
767100G	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400,B767	24-26-14	AEG Bilboe
767100H	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777,B767-400	24	AEG Bilboe
767100J	ROTOR BALANCE ASSEMBLY	HAMILTON	UNK		AEG Bilboe
767114B	WOUND GENERATOR MAIN FIELD	HAMILTON	B767-400	24	AEG Bilboe
767114C	WOUND GENERATOR, MAIN FIELD	HAMILTON	UNK	24-26-10	AEG Bilboe
767114D	WOUND GENERATOR, MAIN FIELD	HS	UNK		AEG Bilboe
767146A	INTEGRATED DRIVE GENERATOR	SUNDSTRAND	B767-400,B767,B777,B777-200	24-21-11	AEG Bilboe
767173 SERIES	STATOR HOUSING		A330, A340		AEG Bilboe
767173A	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilboe
767173B	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilboe
767173C	STATOR HOUSING	SUNDSTRAND	A319,A320	24-17-31	AEG Bilboe
767188 SERIES	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24	AEG Bilboe
767188A	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilboe
767188B	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilboe
767188C	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	B777	24-26-10	AEG Bilboe
767192E	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A320,B737	24-26-15	AEG Bilboe
767192G	ROTOR BALANCE ASSEMBLY	SUNDSTRAND	A320,B737	24-26-15	AEG Bilboe
768094-1	Probes			28-41-04	AEG Seville
768271-2	Probes			28-41-04	AEG Seville
768272-3	Probes			28-41-04	AEG Seville
768273-2	Probes			28-41-04	AEG Seville
768274-3	Probes			28-41-04	AEG Seville
768282-4	Probes			28-41-04	AEG Seville
768283-2	Probes			28-41-04	AEG Seville
768284-2	Probes			28-41-04	AEG Seville
768616A	Mid Slat Actuator Assembly			27-81-20	AEG Seville
768616B	Mid Slat Actuator Assembly			27-81	

799746-2	Overtemperature Switch				21-61-29	AEQ Seville
80000000-12	STAB TRIM LIM SW & POS XMTR	MOOG COMPONENT				
8000028100	TAN LIGHT	ZODIAC - TELEFLEX		B767,B757	27-41-01	AEQ Seville
8000032900	TAKE OFF LIGHT	A320 NEO			33-46-02	AEQ Seville
8000038700	AUTOTRANSFORMER, EQUIPPED	A318,B737,A321,A320,A319			33-46-01	AEQ Seville
8000350000	AUTOTRANSFORMER, EQUIPPED	ECE - TELEFLEX SYN		A330, A340	33-43-03	AEQ Seville
8000350000/84155	Overboard Discharge Connectors				32-30-56	AEQ Seville
80003500Series	Spoller Cable Tension Regulator				27-60-01	AEQ Seville
80-044-03	Score Sensors and Target				27-60-02	AEQ Seville
80-044-04	Score Sensors and Target				27-60-02	AEQ Seville
80-047-01	Score Sensors and Target				27-60-02	AEQ Seville
80-0535-1	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-13	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-16	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-19	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-23	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-26	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-29	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-31	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-33	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-35	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-37	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-39	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
80-0535-9	Caution - Advisory Annunciator Panel Assembly				33-10-53	AEQ Seville
800600Series	Oil Cooler Actuator				79-21-31	AEQ Seville
801400-1Series	Cable Tension Regulator				27-31-11	AEQ Seville
801400-2Series	Cable Tension Regulator				27-31-16	AEQ Seville
801-RUT-XXX	Photoluminescent Floor Proximity Emergency Egress Path Markings				33-52-13	AEQ Seville
8-020-10	Proximity Sensor				27-60-02	AEQ Seville
80286-4	Ducts				21-52-43	AEQ Seville
806224-1	Fan Housing				21-52-46	AEQ Seville
808445-1	Overtemperature Switch				21-61-29	AEQ Seville
81000-15001	LOGO LIGHT ASSEMBLY	KOITO MFG CO		B757,B767,B737	33-45-01	AEQ Seville
81000-15002	LOGO LIGHT ASSEMBLY	KOITO MFG CO		B767,B737	33-45-01	AEQ Seville
81000-15003	LOGO LIGHT ASSEMBLY	KOITO MFG CO		B767,B737	33-45-01	AEQ Seville
81000-15004	LOGO LIGHT ASSEMBLY	KOITO MFG CO		B767,B737	33-45-01	AEQ Seville
81000-15005	LOGO LIGHT ASSEMBLY	KOITO MFG CO		B767,B737	33-45-01	AEQ Seville
81000-15006	LOGO LIGHT ASSEMBLY	KOITO MFG CO		B767,B737	33-45-01	AEQ Seville
81000-17601	LIGHT ASSY	KIOTO		B737, B747	33	AEQ Seville
81000-17602	MAP LIGHT	KOITO MFG CO		B737	33-11-01	AEQ Seville
81000-37601	LOGO LIGHT ASSY	KOITO MFG CO		B-737	33-45-04	AEQ Seville
81000-37602	LOGO LIGHT ASSY	KOITO MFG CO		B-737	33-45-04	AEQ Seville
81000-37703	WING ILLUMINATION LIGHT ASSEMBLY	KOITO MFG CO		B767,B757,B747,B737	33-41-02	AEQ Seville
81000-37704	WING ILLUMINATION LIGHT ASSEMBLY	KOITO MFG CO		B737	33-41-02	AEQ Seville
81000-37801	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		A300,B737	33-51-04	AEQ Seville
81000-37802	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		A300,B737	33-51-04	AEQ Seville
81000-37901	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		A321,A320,A319,A318,B737	33-51-04	AEQ Seville
81000-38201	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		A321,A320,A319,A318,B737	33-51-04	AEQ Seville
81000-38202	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		A321,A320,A319,A318,B737	33-51-04	AEQ Seville
81000-38203	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		A321,A320,A319,A318,B737	33-51-04	AEQ Seville
81000-38204	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		C-130,B737	33-51-04	AEQ Seville
81000-38301	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		C-130,B737	33-51-04	AEQ Seville
81000-41601	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B88,B737-200,B727,B737	33-51-04	AEQ Seville
81000-41602	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO		B727,B777,B767,B757,B747,B737	33-51-04	AEQ Seville
81-026-01	Battery Charger				24-31-08	AEQ Seville

81207367/84/56	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207367/85	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207367/85/56	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207367/86	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207408/88	FINISHED ROTOR ASSEMBLY	GOODRICH AEROSPACE	A330	24-23-53	AEG Bilbao
81207408283	ROTOR	LUCAS	A330		AEG Bilbao
81207425/53/54/55	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/51	ROTOR ASSEMBLY, FINISHED	GOODRICH AEROSPACE	A330, A340	24-23-51	AEG Bilbao
81207425/51/52	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207425/51/52/53	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207425/51/52/53/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/51/52/53/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/51/52/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/51/52/54/55	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/51/52/55	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/51/53	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207425/51/53/54	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207425/51/53/54/55	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207425/51/53/56	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/51/54	FINISHED ROTOR ASSEMBLY	GOODRICH	A320	24-23-51	AEG Bilbao
81207425/51/54/56	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207425/51/56	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/52	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207425/52/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/52/53/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/52/53/54/55	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/52/53/56	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/52/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/52/54/55	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207425/52/56	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207426/53	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207426/53/54	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207426/53/54/55	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207426/53/56	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207426/54	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207426/54/56	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207426/56	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207426-51	ROTOR ASSEMBLY FINISHED		UNK		AEG Bilbao
81207474/58	FINISHED ROTOR ASSEMBLY	GOODRICH AEROSPACE	A330, A340	REWIND	AEG Bilbao
81207486/51	STATOR ASSEMBLY, MAIN WOUND	GOODRICH	A330, A340		AEG Bilbao
81207486/51/52/53	STATOR, MAIN, WOUND ASSEMBLY		A330 A340		AEG Bilbao
81207486-51	STATOR ASSEMBLY MAIN WOUND		A330 A340		AEG Bilbao
81207640/51	STATOR ASSEMBLY, MAIN WOUND	GOODRICH	A330, A340		AEG Bilbao
81207640-51	STATOR ASSEMBLY MAIN WOUND		A330 A340		AEG Bilbao
81207642/57	ROTOR ASSEMBLY, FINISHED	GOODRICH	A330, A340		AEG Bilbao
81207642/58	ROTOR ASSEMBLY, FINISHED	GOODRICH	A330, A340	24-23-53	AEG Bilbao
81207671/57/58	FINISHED ROTOR ASSEMBLY		A330, A340		AEG Bilbao
81207671/5788	ROTOR		A330, A340		AEG Bilbao
81207671/58	FINISHED ROTOR ASSEMBLY	GOODRICH AEROSPACE	A330, A340	24-23-53	AEG Bilbao
8120769/51/52	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
8120769/51/52/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
8120769/51/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
8120769/52	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
8120769/52/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
8120769/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
8120769/51	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207697/51	FINISHED ROTOR ASSEMBLY	SAFRAN	A320		AEG Bilbao
81207697/51/52	FINISHED ROTOR ASSEMBLY	SAFRAN	A320		AEG Bilbao
81207697/51/52/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207697/51/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207697/52	FINISHED ROTOR ASSEMBLY	SAFRAN	A320		AEG Bilbao
81207697/52/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207697/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/51	FINISHED ROTOR ASSEMBLY	LUCAS	A320		AEG Bilbao
81207660/51/52	FINISHED ROTOR ASSEMBLY	GOODRICH	A320	24-23-55	AEG Bilbao
81207660/51/52/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/51/52/53/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/51/52/54	FINISHED ROTOR ASSEMBLY		A320	24-23-51	AEG Bilbao
81207660/51/53	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/51/53/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/51/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/52	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207660/52/53	FINISHED ROTOR ASSEMBLY	DEFAULT	A320		AEG Bilbao
81207660/52/53/54	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207660/52/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207660/53	FINISHED ROTOR ASSEMBLY	SAFRAN	A320	24-23-51	AEG Bilbao
81207660/53/54	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207660/54	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
81207690/51	STATOR ASSEMBLY, MAIN WOUND	GOODRICH	A330, A340		AEG Bilbao
81207690-51	STATOR ASSEMBLY MAIN WOUND		A330 A340		AEG Bilbao
81207704/58	ROTOR ASSEMBLY, FINISHED		A330, A340	24-23-53	AEG Bilbao
81207736/51	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207736/51/52	FINISHED ROTOR ASSEMBLY	GOODRICH	A320		AEG Bilbao
81207736/52/52	FINISHED ROTOR ASSEMBLY		A320		AEG Bilbao
812626010001	Dual Heat Exchanger			21-51-93	AEG Sevilla
8127697/51	APU GEN ROTOR		A320		AEG Bilbao
8127697/51/52	APU GEN ROTOR		A320		AEG Bilbao
8127697/52	APU GEN ROTOR		A320		AEG Bilbao
812CA01	3 PDT Contactor 100 A			24-21-31	AEG Sevilla
816CA01	Contactor			24-21-29	AEG Sevilla
8160-530	STARTER GENERATOR	THALES AVIONICS ELECTRICAL SYSTEMS	CN-235, C-295	24	AEG Sevilla
816101-2	Temperature Controller			21-61-73	AEG Sevilla
816101-4	Temperature Controller			21-61-73	AEG Sevilla
8171-1	DISMABLE ELECTRONIC FLUORESCENT LAMP	AUTECH	A320,B737-300,B747- 300,B747-400,B777-300ER	33-20-01	AEG Sevilla
8171-1 MOD A	DISMABLE ELECTRONIC FLUORESCENT LAMP	AVTECH	A330, A340	33-20-01	AEG Sevilla
8171-1A	DISMABLE ELECTRONIC FLUORESCENT LAMP		747	33	AEG Sevilla
8178-1	BALLAST	AVTECH	165,B737-300,BAU-11,B747- 300,B747-400,B777-300ER,BAU-11,B777- 300ER	33-20-05	AEG Sevilla
8184-1	BALLAST UNIT	AUTECH	13,B737-300,B747-300ER,BAU-11,B777- 300ER	33-20-08	AEG Sevilla
8184-1 MOD A	BALLAST UNIT	AVTECH	B757,B767,B747,B777,B737	33-20-08	AEG Sevilla
8184-1 MODA	BALLAST UNIT	AVTECH	737, 757, 767		AEG Sevilla
8184-1A	ELECTRONIC BALLAST	AVTECH	737, 757, 767	33-20-08	AEG Sevilla
8184-1MODA	BALLAST	AVTECH	B737-300,B747-200,B777,B767,B757	33	AEG Sevilla
81881B-1	Water Separator-Aircraft Air Conditioning System			21-73-04	AEG Sevilla
81881B-2	Water Separator-Aircraft Air Conditioning System			21-73-04	AEG Sevilla
820029-1-000	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-001	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-002	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-003	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-004	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-006	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-1-006	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-4-006	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
820029-4-006	EMS800-1 Engine Monitoring System			77-32-11	AEG Sevilla
8204-16-0000-01	STEAM OVEN ASSY	SELL	A340,A330,A319,A310,A300,A321,A318,A32 A-	25-36-86	AEG Sevilla
8204-16-0000-XX	STEAM OVEN ASSY	SELL	A330, A340		AEG Sevilla
8204-66-0000-01	STEAM OVEN ASSY	SELL	A319,A321,A318,A320	25-36-86	AEG Sevilla
8204-66-0000-XX	STEAM OVEN ASSY	SELL	A330, A340		AEG Bilbao

8200607-1	BRUSH BLOCK HOUSING ASSEMBLY	HAMILTON CINUSINSTRUMENTS	A330, A340	61	AEG Sevilla
8200909-1	Fan Inlet Diffuser Housing			21-53-11	AEG Sevilla
8200916-1	Ducts			21-52-43	AEG Sevilla
8200971-1	Ducts			21-52-43	AEG Sevilla
8200918-1	Ducts			21-52-43	AEG Sevilla
8200921-1	Ducts			21-52-43	AEG Sevilla
8200922-1	Ducts			21-52-43	AEG Sevilla
8200926-2	Check Valve			21-53-09	AEG Sevilla
8200932-1	Ducts			21-52-43	AEG Sevilla
8200934-2	Check Valve			21-23-08	AEG Sevilla
8200938-1	Ducts			21-52-43	AEG Sevilla
8200940-1	Ducts			21-52-43	AEG Sevilla
8200941-1	Ducts			21-52-43	AEG Sevilla
8200942-1	Ducts			21-52-43	AEG Sevilla
8200943-1	Ducts			21-52-43	AEG Sevilla
8200944-1	Ducts			21-52-43	AEG Sevilla
8200946-1	Ducts			21-52-43	AEG Sevilla
8200948-2	Check Valve			21-53-14	AEG Sevilla
8200967-1	Check Valve			21-53-07	AEG Sevilla
8200973-1	Pressure Switch			36-15-05	AEG Sevilla
8200973-2	Pressure Switch			36-15-05	AEG Sevilla
8200973-4	Pressure Switch			36-15-05	AEG Sevilla
8200976-1	Oil Cooler Ejector			79-21-01	AEG Sevilla
8210-161-X	Overspeed Governor Assembly			61-20-16	AEG Sevilla
8210-180	Gear Pump Assembly			61-20-20	AEG Sevilla
82108-2	DC Rotary Actuator			21-25-02	AEG Sevilla
82161-1	Ducts			21-52-43	AEG Sevilla
821480-1	Fog Nozzle			21-74-03	AEG Sevilla
821489-1	Ducts			21-52-43	AEG Sevilla
821545-1	Ducts			21-52-43	AEG Sevilla
821547-1	Ducts			21-52-43	AEG Sevilla
8-240	Proximity Switch			52-70-02	AEG Sevilla
8241016-003	ADVISORY SIGN/PASSENGER WARNING PANEL	BOMBARDIER	UNK		AEG Sevilla
8241016-006	ADVISORY SIGN/PASSENGER WARNING PANEL	BOMBARDIER	DASH8	31-51-26	AEG Sevilla
8241016-007	ADVISORY SIGN/PASSENGER WARNING PANEL	BOMBARDIER	A330, A340	31-51-26	AEG Sevilla
8241016-961	ADVISORY SIGN/PASSENGER WARNING PANEL	BOMBARDIER	UNK		AEG Sevilla
8260E02Y00	External Power Monitor PCB			24-51-47	AEG Sevilla
8260E02Y01	External Power Monitor PCB			24-51-47	AEG Sevilla
8260-180	STARTER GENERATOR	AUXLEC	CN-235-C-295	24	AEG Sevilla
83000-0602	HEAT CONTROL UNIT	KOITO MFG CO	B747,B737	30	AEG Sevilla
83000-0603	HEAT CONTROL UNIT	KOITO MFG CO	B747,B737	30	AEG Sevilla
83000-0604	HEAT CONTROL UNIT	KOITO MFG CO	B747,B737	30	AEG Sevilla
83000-06001	HEAT CONTROL UNIT	KOITO	747,B737	30-40-03	AEG Sevilla
83000-060605	WINDOW HEAT CONTROL UNIT	KOITO	747,B737	30-40-04	AEG Sevilla
83000-0644	HEAT CONTROL UNIT	KOITO MFG CO	B747,B737	30	AEG Sevilla
8300E02Y00	Left Dc Power Center PCB			24-62-17	AEG Sevilla
8300E02Y01	Left Dc Power Center PCB			24-62-17	AEG Sevilla
8318-06601	TRANSFORMER	CILL	UNK		AEG Sevilla
83-216-01	Tire Pressure Sensor/Fill Valve			32-49-12	AEG Sevilla
836760-401	ALTERNATING CURRENT MOTOR	WEBER AIRCRAFT	MD-80,DC-10	38-30-41	AEG Sevilla
8360E02Y00	Right Dc Power Center PCB			24-63-19	AEG Sevilla
8360E02Y01	Right Dc Power Center PCB			24-63-19	AEG Sevilla
8-372-01	PROXIMITY SENSOR	CRANE	A320/A330/A340	32-10-03	AEG Sevilla
8-372-02	PROXIMITY SENSOR	CRANE AEROSPACE	A310,A330,A321,A319,A320	32-10-03	AEG Sevilla
8-372-04	PROXIMITY SENSOR	CRANE AEROSPACE	A350,A340,A310,A320	32-10-03	AEG Sevilla
8-372-05	PROXIMITY SENSOR	CRANE	A320, A321, A330	32	AEG Sevilla
8396-2	HSTA			27-42-06	AEG Sevilla
8-405-06	Proximity Switch			52-70-02	AEG Sevilla
8-405-08	Proximity Switch			52-70-02	AEG Sevilla
8-405-34	Proximity Switch			52-70-02	AEG Sevilla
8-405-36	Proximity Switch			52-70-02	AEG Sevilla
8-405-44	Proximity Switch			52-70-02	AEG Sevilla
8-405-46	Proximity Switch			52-70-02	AEG Sevilla
8-410	Proximity Switch			32-61-11	AEG Sevilla
8-411	Sensor			32-61-21	AEG Sevilla
8423-001	ACCUMULATOR HYDRAULIC	YORK	C-130	29-40A	AEG Sevilla
8423-030	ACCUMULATOR HYDRAULIC	YORK INDUSTRIES	C-130	29-100	AEG Sevilla
8423-030-1	ACCUMULATOR HYDRAULIC	YORK INDUSTRIES	C-130	29-100	AEG Sevilla
8426-030	ACCUMULATOR HYDRAULIC				

8-950-03 MOD A	BATTERY CHARGER	CRANE	B767,B757,B737	24-31-04	AEG Seville
8-953-01	PROXIMITY SENSOR	CRANE	A320/A330/A340	32-10-03	AEG Seville
8-960-01	Proximity Sensor Assembly			32-61-14	AEG Seville
8-963-02	Proximity Sensor Electronics Unit			32-61-23	AEG Seville
8-963-03	Proximity Sensor Electronics Unit			32-61-23	AEG Seville
8-963-04	Proximity Sensor Electronics Unit			32-61-23	AEG Seville
896380 SERIES	TORQUE LIMITER ASSEMBLY		UNK		AEG Bilbao
897990 SERIES	FUEL PUMP ASSEMBLY		A300 A310 B747 B767 MD11		AEG Seville
8DJ100WAD22	INDICATOR		UNK		AEG Seville
8DJ100WAD3	TITIND	GE	C-130	77	AEG Seville
8DJ179	T INDICATOR	AMETEX	UNK		AEG Seville
8DJ185WAA1	EGT INDICATOR	AMETEX	DC-10	77-21-04	AEG Seville
8DJ181CQW4	INDICATOR	AMETEX	DC-10,MU-80,DC-9,DC-8,B707,Hercules-L	77-10-19	AEG Seville
8DJ181CFA4	INDICATOR	AMETEX	DC-10,MU-80,DC-9,DC-8,B707,Hercules-L	77-10-19	AEG Seville
8ES002769-03	POWER SUPPLY UNIT, BEACON LIGHTS (	GOODRICH HELLA	310, A 320, A 319, A 330, A 320, A 330	33-42-12	AEG Seville
8ES002769-03	Power Supply Unit			33-42-12	AEG Seville
8ES006046-	POWER SUPPLY UNIT	HELLA	B747,A340,A330,A320	33	AEG Seville
8ES006046 SERIES	ENERGY BOX	HELLA	A330, A340	33-42-40	AEG Seville
8ES006046-00	POWER SUPPLY UNIT	HELLA	A319, A320, A321, A330, A340	33-42-40	AEG Seville
8ES006046-SERIES	POWER SUPPLY UNIT	HELLA	A320-100, A330, A340, A320	33	AEG Seville
8ES006238-13	POWER UNIT, SINGLE (REPL. F. -03)	GOODRICH HELLA	A320	33-22-25	AEG Seville
8ES006238-	POWER UNIT	AERONACE LIGHTNING	A319, A320, A321, A320-100		AEG Seville
8ES006238-13	POWER UNIT, TRIPLE (REPL. F. -03)	GOODRICH HELLA	A320	33-22-25	AEG Seville
8ES006238-SERIES	POWER UNIT	AERONACE LIGHTNING	A319, A320, A321, A320-100		AEG Seville
8ES006304-	POWER SUPPLY UNIT		A319, A321, A330, A340, A320		AEG Seville
8ES006304 SERIES	ENERGY BOX	HELLA	A319, A321, A330, A340, A320		AEG Seville
8ES006304-00	POWER SUPPLY UNIT, SINGLE FLASH	HELLA	A320	33-42-20	AEG Seville
8ES006304-SERIES	POWER SUPPLY UNIT	HELLA	A319, A321, A330, A340, A320	33	AEG Seville
8ES006309	ENERGY BOX	HELLA	A330, A340	33	AEG Seville
8ES006309 SERIES	ENERGY BOX	HELLA KG	A330, A340		AEG Seville
8ES006309-00	POWER SUPPLY UNIT	HELLA	A320	33-42-30	AEG Seville
8ES006421-09	CONTROLLER, POWER SUPPLY UNIT, STR	HELLA	EMB	33-40-09	AEG Seville
8ES006421-09	CONTROLLER, POWER SUPPLY UNIT, STR			33-40-09	AEG Seville
8ES006794-SERIES	Power Supply Unit			33-40-12	AEG Seville
8ES007046-01	Power Supply Unit			33-40-30	AEG Seville
8ES007666-22	Control Indication Unit			33-42-50	AEG Seville
8ES403701-02	TRANSFORMER ASSEMBLY	HELLA	A350,B777,A321,A340,A330,A320,A319	33-41-16	AEG Seville
8ES403703-02	TRANSFORMER ASSEMBLY	HELLA	A319,B777,A321,A330,A320-100,A340-100,A320-095,A340,A320,A320,A320	33-41-16	AEG Seville
8ES406568-00	TRANSFORMER ASSEMBLY	HELLA	A350,A321,B777,A340,A330,A320,A319	33-41-16	AEG Seville
8ES46502-	POWER SUPPLY UNIT		A319, A321, A330, A340, A320		AEG Seville
8ES46502 SERIES	POWER SUPPLY UNIT	HELLA	A319, A321, A330, A340, A320	33	AEG Seville
8ES46502-00	POWER SUPPLY UNIT	HELLA	A320	33-42-41	AEG Seville
8ES46502-06	POWER SUPPLY UNIT	GOODRICH HELLA	A318, A319, A320, A321, A330, A340, A380	33	AEG Seville
8ES46502-SERIES	POWER SUPPLY UNIT	HELLA	A319, A321, A330, A340, A320	33	AEG Seville
8ES46548-00	Power Supply Unit, Hid			33-40-70	AEG Seville
8ES465438-07	POWER SUPPLY UNIT	GOODRICH HELLA	A340 A330	33.33-43-30	AEG Seville
8ES465440-06	POWER SUPPLY UNIT	GOODRICH	A320	33.33-43-20	AEG Seville
8Z4872-016	ICE PROTECTION PANEL ASSEMBLY	BOMBARDIER	A320	30	AEG Seville
8Z4873-016	ICE PROTECTION PANEL ASSEMBLY	BOMBARDIER	A320	30	AEG Seville
90001201-1	Brake Assembly			32-45-12	AEG Seville
90006543P	Brake			32-44-94	AEG Seville
900096-1	Accumulator				AEG Seville
90087-401	Faucet Assembly			38-10-14	AEG Seville
9008D07-1	ALTERNATING CURRENT MOTOR	ABX/GMBH	A300	29-20-05	AEG Seville
9008D15-2	Alternating Current Motor			29-20-10	AEG Seville
900G002Y01	Left DC Power Center			24-63-10	AEG Seville
90-10072-1	ENTRY DOOR SNUBBER ASSEMBLY	THE BOEING	B737, B727, B707	52-11-02	AEG Seville
90-10072-2	SNUBBER	THE BOEING	B737,DC10	52-41-01	AEG Seville
901020-1	STRUT ASSEMBLY, MLG SHOCK	LOCKHEED	P3 ORION		AEG Seville
901977-101	SHOCK STRUT ASSEMBLY	LOCKHEED	P3 ORION		AEG Seville
901918-106	SHOCK STRUT ASSEMBLY	HEROUX	P3 ORION		AEG Seville
901918-6	SHOCK STRUT ASSEMBLY	HEROUX	P3 ORION		AEG Seville
90421-2	CONNECTORS		UNK		AEG Seville
909269-3	CARTRIDGE	LOCKED MARTIN	P3 ORION, P3 CONVERSION		AEG Seville
912072-1	CARTRIDGE	LOCKHEED	A330, A340		AEG Seville
912W010001	Manual Controller			21-30-39	AEG Seville
912W020001	Manual Controller			21-30-39	AEG Seville
916F716-1	SEMICONDUCTOR DEVICE SET	WESTINGHOUSE	A330, A340	24	AEG Seville
916F716-2	SEMICONDUCTOR DEVICE SET	HAMILTON CLIMSTRAND	A330, A340	24	AEG Seville
9168ModelNumber666	Pump			668D3	AEG Seville
9201000-198	VALVE REGULATING		UNK		AEG Seville
9201000-206	GA CONTENTS TRANSMITTER		UNK		AEG Seville
92148B030401	Cabin Indication Module			21-30-33	AEG Seville
92148C010101	Cabin Indication Module			21-30-33	AEG Seville
92148D010101	Cabin Indication Module			21-30-33	AEG Seville
930070-5	Hydraulic Fluid To Air Heat Exchanger				AEG Seville
933402 / MPEV3-011-	PUMP-HYDR MOTOR DRIVEN		CN-235, CN-295		AEG Seville
933402 / MPEV3-011-	PUMP-DC ELEC MOTOR		CN-235, CN-295		AEG Seville
937958-103	STRUT ASSEMBLY, MLG SHOCK	LOCKHEED AERONAUTICAL	P3 ORION		AEG Seville
93835-SCON-900121-	50 Cubic Inch Hydraulic Accumulator Assembly				AEG Seville
93835-SCON-900122	100 Cubic Inch Hydraulic Accumulator Assembly				AEG Seville
9387M1P01	ROTOR ASSEMBLY	PACIFIC SCIENTIFIC	A320	73-21-81	AEG Bilbao
9387M1P02	ROTOR ASSEMBLY	PACIFIC SCIENTIFIC	A320	73-21-81	AEG Bilbao
9387M1P03	FADEC GEN ROTOR	PACIFIC SCIENTIFIC	A330	73-21-81	AEG Bilbao
9387M1P0 SERIES	STATOR		B737 A320		AEG Bilbao
9387M1P01	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC	DC-10	73-21-81	AEG Bilbao
9387M1P02	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC	DC-10	73-21-81	AEG Bilbao
9387M1P04	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC	DC-10	73-21-81	AEG Bilbao
9387M1P06	STATOR AND HOUSING ASSEMBLY	GE	DC-10	73-21-81	AEG Bilbao
9387M1P06	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC	A330, A340, A320	73-21-81	AEG Bilbao
9387M1P07	FADEC GEN STATOR	PACIFIC SCIENTIFIC	CFM56/CF6	73-21-81	AEG Bilbao
9387M1P08	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC	A340	73-21-81	AEG Bilbao
9387M1P09	STATOR AND HOUSING ASSEMBLY	PACIFIC SCIENTIFIC	A330, A340	73-21-81	AEG Bilbao
9401D020000	Double Rotary Actuator			21-30-40	AEG Seville
9406A010000	Electrical Actuator			21-31-34	AEG Seville
940732	HYDRAULIC MOTORPUMP ASSEMBLY	EATON	B737	29-11-26	AEG Seville
940D412-2	EXCITER ROTOR	WESTINGHOUSE	A330, A340	24-20-74	AEG Bilbao
943D367	SEMICONDUCTOR DEVICE SET		A330, A340		AEG Seville
943D367-SERIES	SEMICONDUCTOR DEVICE SET	HAMILTON CLIMSTRAND	A330, A340	24	AEG Seville
943D724-4	STATOR EXCITER		A330, A340		AEG Bilbao
946173-3	Pressure Manifold Assy				AEG Seville
946173-3	Pressure Manifold Assy				AEG Seville
946174-1	Return Filter Manifold				AEG Seville
946174-1	Return Filter Manifold				AEG Seville
946175-1	Case Drain Filter				AEG Seville
946175-1	Case Drain Filter				AEG Seville
9-464-06	FUEL FLOW / FUEL USED INDICATOR	ELDEC CORPORATION	CN235		AEG Seville
9-464-40 MOD B	INDICATOR, LIQUID QTY		CN-235, C-295		AEG Seville
9-464-40 MOD D	INDICATOR, RATE OF FL		CN-235, C-295		AEG Seville
946F177	SEMICONDUCTOR DEVICE SET		A330, A340		AEG Seville
946F177-1	SEMICONDUCTOR	WESTINGHOUSE	B737	24-20-77	AEG Bilbao
946F177-SERIES	SEMICONDUCTOR DEVICE SET		A330, A340		AEG Seville
946J498-2	AC GENERATOR	HAMILTON CLIMSTRAND	UNK		AEG Bilbao
946J698-1	AC GENERATOR	HAMILTON CLIMSTRAND	UNK		AEG Bilbao
947F226-3	EXCITER ARMATURE CAPACITOR AND DIODE ASSEMBLY	HAMILTON CLIMSTRAND	A330, A340	846-8-11-	AEG Bilbao
948F463-4	10 KVA GENERATOR	HAMILTON CLIMSTRAND	UNK	846-5-10-	AEG Bilbao
949F283	SEMICONDUCTOR DEVICE SET		A330, A340		AEG Seville
96060X	Port/STBD Door Surround Assembly			53-10-08	AEG Seville
9606111-601	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	[DHC]Dash 8-400,[DHC]Dash 8-300,[DHC]Dash 8-200,[DHC]Dash 8-100	26	AEG Seville

9606111-602	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-603	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-604	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-605	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-606	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-607	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-608	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-609	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-610	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-611	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-612	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-613	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-614	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-615	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-616	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-617	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-618	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-619	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-620	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-621	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-622	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-623	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-624	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-625	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-626	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-627	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-628	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-629	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-630	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-631	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
9606111-632	PASSENGER SERVICE UNIT	ZODIAC AEROSPACE	(DHC)Dash 8-400(DHC)Dash 8-300(DHC)Dash 8-200(DHC)Dash 8-100	25	AEG Sevilla
960F235-5	ARMATURE ASSEMBLY		A330, A340		AEG Bilbao
9642732-2	CONTROL VALVE ASSEMBLY	ABS	C-212	32	AEG Sevilla
9642732-1	WHEEL LANDING GEAR	MEGGITT AIRCRAFT BRAKING SYSTEMS	UNKN		AEG Sevilla
96B0604L	SKID CONTROL VALVE UNIT		B737	32-48-02	AEG Sevilla
96-94064-0001	DOUBLE SEAT		C-295		AEG Sevilla
96-94064-0001B01	SEAT DOUBLE ASSY	AIRBUS	C-295		AEG Sevilla
96-94064-0001B06	DOUBLE SEAT		A330, A340		AEG Sevilla
96-94064-0001E03	SEAT DOUBLE ASSY	AIRBUS	C-295		AEG Sevilla
96-94064-0002	SEAT DOUBLE ASSY	AIRBUS	C-295		AEG Sevilla
96-94064-0003	SEAT DOUBLE ASSY		UNKN		AEG Sevilla
96-94064-0003B01	SEAT DOUBLE ASSY	AIRBUS	C-295		AEG Sevilla
96-94064-0003B05	SEAT DOUBLE ASSY	AIRBUS	C-295		AEG Sevilla
96-94064-0003E03	SEAT DOUBLE ASSY	AIRBUS	C-295		AEG Sevilla
9600-16-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Sevilla
9600-26-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Sevilla
9600-32-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Sevilla
9600-40-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Sevilla
9600-44-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Sevilla
9600-51-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Sevilla
9600-56-0000	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Sevilla
96042-1	Engine Vibration Isolation System			71-20-57	AEG Sevilla
96042-6	Engine Vibration Isolation System			71-20-57	AEG Sevilla
96042-6	Engine Vibration Isolation System			71-20-57	AEG Sevilla
96042-7	Engine Vibration Isolation System			71-20-57	AEG Sevilla
96042-8	Engine Vibration Isolation System			71-20-57	AEG Sevilla
960448-1	System 1 Hydraulic Fluid Reservoir				AEG Sevilla
960449-1	Reservoir Assembly, Hydraulic System 2				AEG Sevilla
960460-1	Reservoir Assembly, Hydraulic System No. 2				AEG Sevilla
96109-31-105	CORE, EMS, PPU, FWD, SIDE	HUTCHINSON	A400M		AEG Bilbao
96109-31-107	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	HUTCHINSON	A400M		AEG Bilbao
96109-31-109	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	HUTCHINSON	A400M		AEG Bilbao
96109-32-105	CORE, EMS, PPU, FWD, TOP	HUTCHINSON	A400M		AEG Bilbao
96109-32-107	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	HUTCHINSON	A400M		AEG Sevilla
96109-32-109	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	HUTCHINSON	A400M		AEG Bilbao
96109-33-101	AFT MOUNT - PYLON FASTENERS	HUTCHINSON	A400M		AEG Bilbao
96109-33-103	AFT MOUNT - PYLON FASTENERS	HUTCHINSON	A400M		AEG Bilbao
96109-33-106	AFT MOUNT - PYLON FASTENERS	HUTCHINSON	A400M		AEG Bilbao
96127	HYDRAULIC MOTOR/PUMP ASSEMBLY	EATON	B737	29-11-26	AEG Sevilla
96C380-2	STATOR MOTOR	WESTINGHOUSE	B737	29	AEG Sevilla
970600-7	Cable Tension Regulator (Alleron Control)				AEG Sevilla
970600-7SERIES	Cable Tension Regulator(Alleron Control)				AEG Sevilla
970600-8	Cable Tension Regulator (Alleron Control)				AEG Sevilla
970600-8SERIES	Cable Tension Regulator(Alleron Control)				AEG Sevilla
976264-1	System 3 Reservoir Bleed/Relief Valve				AEG Sevilla
976264-1	Hydraulic Firewall Shutoff Valve Assembly				AEG Sevilla
976267-1	Valve - Flow Limiter				AEG Sevilla
976274-1	Dump Thermal Relief Valve				AEG Sevilla
976306-1	Electric Motor Operated Actuator				AEG Sevilla
979669-1	Modulating & Shutoff Valve			21-40-55	AEG Sevilla
979626-3-1	2 In. Dis Shutoff Valve			36-11-19	AEG Sevilla
979626-3-5	2 In. Dis Shutoff Valve			36-11-19	AEG Sevilla
979968-X	Modulating & Shutoff Valve			21-40-55	AEG Sevilla
980-6116-X	Microphone Monitor			25-70-43	AEG Sevilla
9808-20	INDICATOR VOR		UNKN		AEG Sevilla
98400347E	5/8 IN. NON RETURN VALVE	FLY REFUELLING LTD	C-295	28-22-03	AEG Sevilla
9900-26-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9900-26-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9900-40-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9900-40-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9900-44-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9900-44-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9900-51-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9900-51-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9900-56-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9900-56-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	A330	33	AEG Sevilla
9901-26-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B-737	33	AEG Sevilla
9901-26-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B-737	33	AEG Sevilla
9901-40-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B-737	33	AEG Sevilla
9901-40-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B-737	33	AEG Sevilla
9901-44-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B-737	33	AEG Sevilla
9901-44-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B-737	33	AEG Sevilla
9910069-3	AIR MIXER MOTOR		UNKN		AEG Sevilla
996CA01Y00	3 PDT No Power Relay			24-51-11	AEG Sevilla
9A1164	BRAKE ASSEMBLY	GRIMES	A330, A340		AEG Sevilla
9B72-1	STATOR	UNKNNOOWN	UNKN		AEG Bilbao
9C35	Auxiliary Fuel Pump Assembly			28-21-14	AEG Sevilla
9EL41061	Light Cover			33-42-53	AEG Sevilla
9EL465051	Wing Tip Lens			33-42-54	AEG Sevilla
9EL465737-10	Wing Tip Lens			33-42-23	AEG Sevilla
9EL465738-10	Wing Tip Lens			33-42-23	AEG Sevilla
A09-1146-017	SM-710/SM-725 Linear Actuator				AEG Sevilla
A09-1146-043	SM-300 Servo Drive Assembly				AEG Sevilla
A09-1147-007	Flight Guidance Computer				AEG Sevilla
A09-1147-068	FZ-800 Flight Guidance Computer				AEG Sevilla
A2633002	VALVE-BRAKE SEL	MESSIER	A321A318A340A330A320A319A3200A33	32-42-11	AEG Sevilla
A2633002-1	SELECTOR VALVE	MESSIER	A321A318A340A330A320A319A3200A320, 0, 211A319, 319,	32-42-11	AEG Sevilla
A2633003	SELECTOR VALVE	MESSIER	A321A318A340A320A330A319A300	32-42-11	AEG Sevilla
A2633003-1	SELECTOR VALVE	MESSIER-BUGATTI	A321A319A340A320A330A318A300	32-42-11	AEG Sevilla

A26316	PARKING BRAKE VALVE	MESSIER	B747,A310,A321,A320,A300	32-45-14	AEG Seville
A26316020	HYDRAULICALLY OPERATED PARKING BRAKE VALVE	MESSIER BUGATTI-POMINI	A330,B747,A310,A300,A320,A340	32-32-45-18	AEG Seville
A26316020-1	HYDRAULICALLY OPERATED PARKING BRAKE VALVE	MESSIER BUGATTI-POMINI	A330,B747,A310,A300,A320,A340-313	32-32-45-18	AEG Seville
A26316020-2	PARKING BRAKE VALVE	MESSIER	A321,A300,B747,A340,A330,A320,A310	32-45-14	AEG Seville
A26316-1	VALVE	MESSIER	A321,A319,B747,A310,A300,A320-221,A320-020,A300	32-45-14	AEG Seville
A26434021	EMERGENCY BRAKE DUAL DISTRIBUTOR	MESSIER BUGATTI-POMINI	A300,A321,A320,A319,A318	32-43-16	AEG Seville
A26434021-001	EMERGENCY BRAKE DUAL DISTRIBUTOR	MESSIER BUGATTI-POMINI	A300,A321,A320,A319,A318	32-43-16	AEG Seville
A26434021-1	EMERGENCY BRAKE DUAL DISTRIBUTOR	MESSIER BUGATTI-POMINI	A300,A321,A320,A319,A318	32-32-43-16	AEG Seville
A26434021-2	EMERGENCY BRAKE VALVE	MESSIER BUGATTI-POMINI	A300,A330,A321,A320,A319,A318,A330-340,A340-313	32-32-43-16	AEG Seville
A26460-2	AUTOMATIC SELECTOR	MESSIER	A321,A319,A310,A300,B767,A320	32-42-13	AEG Seville
A26461-1	AUTOMATIC SELECTOR	MESSIER	A300,A321,A319,A318,B767,A320	32-42-13	AEG Seville
A26461-102	AUTOMATIC SELECTOR	MESSIER	A321,A319,A318,B767,A310,A300,A320	32-42-13	AEG Seville
A26461-103	SELECTOR VALVE	MESSIER	A321,A319,A318,A310,A300,B767,A320-020,A300	32-42-13	AEG Seville
A26461-104	AUTOMATIC SELECTOR	MESSIER	A321,A319,A318,B767,A320-020,A300,A300	32-42-13	AEG Seville
A26461-1-1	AUTOMATIC SELECTOR	MESSIER	A300,A321,A319,A318,B767,A320	32-42-13	AEG Seville
A3372-1	Hold Open Rod			71-10-63	AEG Seville
A33982	AXLE SLEEVE	MESSBU	A318,A320	32	AEG Seville
A3410-2	FAN COWL HOLD OPEN ROD	NORCO	A321,A320,A319	71-10-62,71	AEG Seville
A34440	AXEL SLEEVE	MESSIER SERVICES	A318,A320	32	AEG Seville
A36399	AXLE SLEEVE	MESSIER SERVICES	A318,A320	32	AEG Seville
A3650-7	Cowling Hold-Open Struts			71-10-66	AEG Seville
A3650-8	Cowling Hold-Open Struts			71-10-66	AEG Seville
A381701	Fed F/A Panel			33-23-01	AEG Seville
A-440	HORIZONTE ARTI		UNK		AEG Seville
A44700	Spoiler Servo Actuator Assembly			27-60-02	AEG Seville
A865650-1	COMPRESSOR	JAMCO	A330, A340		AEG Seville
A865650-31	COMPRESSOR	JAMCO	A330, A340		AEG Seville
A863790-11	FAN MOTOR		A330, A340		AEG Seville
A007701-8806	ACTUATOR ASSY-SIDE CARGO DOOR	BOEING	DC-10-30CF (KC-10A) Extender,MD-10,DC-10,EMB-11	52-52-34-01	AEG Seville
AC028766	VALVE REDUCING	MEGGITT AIRCRAFT DRAWING SVCTEARE	F-27	19	AEG Seville
ACP263000X	Audio Control Panel			23-51-62	AEG Seville
ACP2788AA	AUDIO CONTROL PANEL		A330 A320 A319 A321 A340 A350,A318,A380,B747,A340,A330,A321,A320,A310	23-51-22	AEG Seville
ACP2788AA02	AUDIO CONTROL PANEL	TEAM	A330 A320 A319 A321 A340	23-51-22	AEG Seville
ACP2788AB	AUDIO CONTROL PANEL		DC-10,DC-18,B747	23-51-22	AEG Seville
ACP2788AB06	AUDIO CONTROL PANEL	TEAM	200,A318,B747,A321,A330,A340,A380,B747,DC-10,DC-18,B747-200,B747-200,A330-240,A340,A380,A320,A310,A310	23-51-22	AEG Seville
ACP2788AC	AUDIO CONTROL PANEL		A330 A320 A319 A321 A340	23-51-22	AEG Seville
ACP2788AC01	AUDIO CONTROL PANEL	TEAM	A380,A318,A321,A340,A330,B747,A320	23-51-54	AEG Seville
ACP2788AD01	AUDIO CONTROL PANEL	COBHAM	A318,A321,A340,A330,A320-200,A319,A320	23-51-54	AEG Seville
ACP2788AE01	AUDIO CONTROL PANEL	COBHAM	A380,A318,A321,A340,A330,B747,A320	23-51-55	AEG Seville
ACP2788AF01	AUDIO CONTROL PANEL	TEAM	200,A318,A340,A380,B747,A340,318,A310	23-51-01	AEG Seville
ACP2788AF01 Amdt A	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt B	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt C	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt D	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt E	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt F	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt G	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt H	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt J	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt K	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt L	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
ACP2788AF01 Amdt M	AUDIO CONTROL PANEL	TEAM	A318, A319, A320, A321, A330, A340, A380		AEG Seville
AD-2768	AIRCRAFT BATTERY	AERO	A320	24-38-51	AEG Seville
ADA68630	Filter, Hydraulic Aircraft, 3000 Psi				AEG Seville
ADA686301	Filter, Hydraulic Aircraft, 3000 Psi				AEG Seville
ADA686313	Return Filter Manifold				AEG Seville
ADB089-4	Case Drain Filter				AEG Seville
ADC361-61	Filter, Pressure, Hydraulic				AEG Seville
AEO04907-01V10	Command Processor/Input Module				AEG Seville
AEO04908-01V10	Analogue Acquisition Module				AEG Seville
AEO04909-01	Arinc 429 Module				AEG Seville
AEO04910-01	Output Common Services Module				AEG Seville
AEO04911-01/200270C	Monitor Processor/Input Module				AEG Seville
AEO406A00	Lav/Galley Fan Exhaust			21-23-11	AEG Seville
AEO406A01	Lav/Galley Fan Exhaust			21-23-11	AEG Seville
AEO406A03	Lav/Galley Fan Exhaust			21-23-11	AEG Seville
AEO503AA1	Galley Fan			21-23-10	AEG Seville
AEO607B01	Lavatory And Galley Fan			21-23-16	AEG Seville
AEO804A04	Cockpit Display Fan			21-23-17	AEG Seville
AEO804A04	Cockpit Display Fan			21-23-17	AEG Seville
AEO804AA1	Cockpit Fan			21-24-00	AEG Seville
AEO804AA2	Cockpit Fan			21-24-00	AEG Seville
AEO804C01	Cockpit Fan			21-24-00	AEG Seville
AEI022A03	Re Circulation Fan			21-21-19	AEG Seville
AEI070A01	Avionics Cooling Fan			21-23-15	AEG Seville
AEI10CA1	Exhaust Fan			21-24-02	AEG Seville
AEI6021000	BRAKE COOLING FAN	TECHNOFA	B747,A321,A320,A319,A310,A300	32-48-22	AEG Seville
AEI6021001	UNIVERSAL BRAKE COOLING FAN	TECHNOFA	B747,A321,A320,A319,A318,A310,A300	32-48-22	AEG Seville
AEI6021002	MOTOR ASSY BRAKE FAN	TECHNOFA	B747,A340-6000,A340-6000,A340-6000,A320,A320,A319,A318,A310,A300	32-48-22	AEG Seville
AEI602102AMDTA	BRAKE COOLING FAN	TECHNOFAN	A300-800,A310,A318,A319,A320,A321,A320,A310,A300	32-48-22	AEG Seville
AEI602102AMDTB	BRAKE COOLING FAN	SAFRAN	A300-800,A310,A318,A319,A320,A321,A320,A310,A300	32-48-22	AEG Seville
AEI71600AMDTA	Recirculation Fan			21-23-03	AEG Seville
AET716800	Air Intake Fan			21-20-10	AEG Seville
AET716C00	In Process of Realization			AET716C00	AEG Seville
AEX0-0697000	9G Divider Net			50-22-67	AEG Seville
AE8579E	Swivels			32-40-02	AEG Seville
AE85762E	Swivels			32-40-02	AEG Seville
AE85763E	Landing Gear Swivel			32-40-01	AEG Seville
AE85763E	Swivels			32-40-02	AEG Seville
AE86642E	Swivels			32-40-02	AEG Seville
AE8213-16	Hydraulic Return Manifold				AEG Seville
AE8216-1011	Pressure Filter Manifold				AEG Seville
AGI013AA02	LIGHT		UNK		AEG Seville
AG34-109	DRIVE SHAFT		UNK		AEG Seville
AG34-109	GENERATOR ROTOR ASSY		UNK		AEG Seville
AGE13141,AGE13638,A	Reprogrammable Voltage Regulator			Bulletin 1154	AEG Seville
AH62443	WHEEL	UNKNOOWN	Jet stream 3100	32	AEG Seville
AH9033	WHEEL, MLG	DUNLOP	CASA 235	32	AEG Seville
AHA1802	BRAKE UNIT	DUNLOP	CN-235	32-32-41-71	AEG Seville
AHM8337	SHUTTLE VALVE	MEGGITT	C-295	32	AEG Seville
AK2642CLO3/04	Attendant Keyboard			23-31-36	AEG Seville
AL00102	Linear Actuator				AEG Seville
AL006	Linear Actuator				AEG Seville
AL007	Linear Actuator				AEG Seville
AL00701	Linear Actuator				AEG Seville
AMT	Advanced Maintenance Terminal User Manual			23-35-40	AEG Seville
ANVSMT	ANVS MT Software User Manual for Windows 10			23-35-46	AEG Seville
AP-763	Nondestructive Testing Manual With Procedures			32-42-03	AEG Seville
AP-763	Nondestructive Testing Manual			32-42-04	AEG Seville
AP-763	Nondestructive Testing Manual			32-42-05	AEG Seville
AP-763	Nondestructive Testing Manual			32-42-06	AEG Seville
AP-763	Nondestructive Testing Manual			32-42-07	AEG Seville
AP9VM-2-06	MOTOR DRIVEN HYDRAULIC PUMP	PARKER	B787		AEG Seville
AR-207	FUEL RATE INDICATOR	SENIOR FLEXONICS	A330, A340	12	AEG Seville
AR2611	Latch Assembly			52-51-04	AEG Seville
AR2628	Lock Assembly			52-50-08	AEG Seville
AR9013-11WDX00X	FAUCET ASSEMBLY	ADAMS RITE		38-20-31	AEG Seville
AR9013-6W1D102	FAUCET ASSEMBLY	ADAMS RITE		38-20-31	AEG Seville
AR9013-6W2D102	FAUCET ASSEMBLY	ADAMS RITE		38-20-31	AEG Seville

C24703001-3	PARKING BRAKE SELECTOR VALVE	MESSIER BUGATTI	A318,B727,M6	32-47-24	AEG Seville
C24703001-4	PARKING BRAKE SELECTOR VALVE	MESSIER BUGATTI	A318,B707,M6	32-47-24	AEG Seville
C24703003	PARKING BRAKE SELECTOR VALVE	MESSIER	B707,B747,A320,A320,A320,A320,A320,A320	32-47-24	AEG Seville
C24703000-2	UPLOCK ASSEMBLY	MESSIER-BUGATTI	A321A320,A319,A318	32-37-09	AEG Seville
C24703000-3	UPLOCK ASSY-DOOR	MESSIER-BUGATTI	A321A320,A319,A318	32-37-09	AEG Seville
C24703000-4	UPLOCK ASSEMBLY	MESSIER-BUGATTI	A321A320,A319,A318	32-37-09	AEG Seville
C24703000-5	UPLOCK ASSEMBLY	MESSIER-BUGATTI	A321A320,A319,A318	32-37-09	AEG Seville
C24703001-4	UPLOCK ASSEMBLY	MESSIER-BUGATTI	A321A319,A318,B727,A320	32-37-08	AEG Seville
C24703001-6	NLG UPLOCK ASSY	MESSIER	A330,A321A319,A318,B727,A320,A320-221A319,A318	32-37-08	AEG Seville
C24703000	NLG DOOR UPLOCK ASSY	MESSIER	A330,A321A319,A318,A320	32-37-09	AEG Seville
C24703000-1	UPLOCK ASSEMBLY	MESSIER-BUGATTI	A321A320,A319,A318,A320-221A320-232	32-37-09	AEG Seville
C24703000-2	UPLOCK ASSEMBLY	MESSIER	A321A318,A330,A320,A319	32-37-09	AEG Seville
C24703000-3	UPLOCK ASSEMBLY	MESSIER BUGATTI SA	A321A318,A330,A320,A320-200,A319	32-37-09	AEG Seville
C24736000	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI	B707,A319,A320,A318	32-57-01	AEG Seville
C24736000-0-1	SERVO CONTROL	MESSIER-BUGATTI	A319,A320,A318	32-57-01	AEG Seville
C24736000-0-2	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI	A319,A320,A318	32-57-01	AEG Seville
C24736000-1	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI	A318,A320,A319	32-57-01	AEG Seville
C24736000-2	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI	A318,A320,A319	32-57-01	AEG Seville
C24736001	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A320,A318	32-57-01	AEG Seville
C24736001-0-1	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A320,A318	32-57-01	AEG Seville
C24736001-0-2	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI	A319,A320,A318	32-57-01	AEG Seville
C24736001-1	SERVO CONTROL	MESSIER-BUGATTI	A319,A320,A318,A320-221	32-57-01	AEG Seville
C24736001-2	HYDRAULIC CONTROL UNIT	MESSIER-BUGATTI	A319,A320,A318,A320-232	32-57-01	AEG Seville
C24736001-3	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI	A319,A320,A318	32-57-01	AEG Seville
C2473600-1	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI	A319,A318,A310,A320	32-57-01	AEG Seville
C24747000	VALVE, SELECTOR	MESSIER	A318,A321A319,A320	32-32-57-04,32-57	AEG Seville
C24747000-1	VALVE, SELECTOR	MESSIER	A318,A321A319,A320	32-32-57-04,32-57	AEG Seville
C2483701	HOUSING/BRAKE MANIFOLD	MESSIER-BUGATTI	A318,A321A319,A320-232,B747,A320	32-47-45	AEG Seville
C2483701-1	MANIFOLD-NORMAL BRAKE ASSY	MESSIER-BUGATTI	A318,A321A319,B747,A320	32-47-45	AEG Seville
C2483701-3	BRAKE MANIFOLD ASSY	MESSIER	A318,A321A319,B747,A320	32-47-45	AEG Seville
C2483701-4	MANIFOLD ASSY	MESSIER-BUGATTI	A318,A321A319,A320-232,B747,A320	32-47-45	AEG Seville
C24998000	SWIVEL SELECTOR VALVE	MESSIER-BUGATTI	C-130,A318,A321A319,A340,A330,A320	32-57-15	AEG Seville
C2-96000-8	ACTUATOR, WINDSHIELD WIPER	NAVIER	A330, A340	29	AEG Seville
C51LM0020	RESERVOIR FILLING VALVE	GOODRICH AIRLIFTATION SYSTEMS S.O.A.	C-130,A310,A320-190,A320,A318,A320-221A320-232,A319,A320,A320,A320	29-16-67	AEG Seville
C68C01	Fuel Shroud System			28-20-02	AEG Seville
C93R13-601	Canister			28-24-09	AEG Seville
C93R25-601	Canister			28-13-45	AEG Seville
C93R38-608	Crossflow Pump Canister			28-23-03	AEG Seville
C99-26-001	Crossflow Inlet Screen			28-13-49	AEG Seville
CA304A	Fuel Shroud System			28-20-02	AEG Seville
CA306A	Fuel Shroud System			28-20-02	AEG Seville
CA445	Fuel Shroud System			28-20-02	AEG Seville
CA446	Fuel Shroud System			28-20-02	AEG Seville
CA447	Fuel Shroud System			28-20-02	AEG Seville
CA448	Fuel Shroud System			28-20-02	AEG Seville
CAU3932A**	Remote Control Audio Unit			23-51-71	AEG Seville
CDK463	Flight Deck Access System Cabotage Door			52-51-16	AEG Seville
CD8P7000-1	Aft Cargo Tie Down			50-22-17	AEG Seville
CE400160-0001	FUEL TRANSFER EJECTOR PUMP	CESA	C-295	28-22-01	AEG Seville
CE400160-0001 Amdt	FUEL TRANSFER EJECTOR PUMP	CESA	C-295	28-22-01	AEG Seville
CE400160-0001 Amdt A			C-295		AEG Seville
CGFP-02	REPAIR MANUAL FOR FLOOR PANELS OF CL-440,CL441,CL442,CL-440,B-1,CL-430B-1,CL443			CGFP-02	AEG Seville
CM4-030	Floor Panels Repairs			53-00-47	AEG Seville
CP1200-2	CONTROL PENDANT		CN-235, C-295		AEG Seville
CR49044	LEG ASSY-NLG	SAFRAN LANDING SYSTEM	A340		AEG Seville
CR49046	LEG ASSY-NLG	SAFRAN LANDING SYSTEM	A340		AEG Seville
CR49219	LEG ASSY-NLG	SAFRAN LANDING SYSTEM	A340		AEG Seville
CR49220	LEG ASSY-NLG	SAFRAN LANDING SYSTEM	A340		AEG Seville
CR49221	LEG ASSY-NLG	SAFRAN LANDING SYSTEM	A340		AEG Seville
CYC-AP600207-101,C	Fiberglass Ducts			21-54-59	AEG Seville
D102740	MOTOR TYPE 160-45-511	AIRSCREW HOWDEN	A330, A340	32-32-43-05	AEG Seville
D106300-4	ARMATURE	STEINHEIL OPTRONIK	A330, A340		AEG Seville
D23064000	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-10	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-11	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-12	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-13	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-14	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-16	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-16	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-17	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-18	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-19	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-2	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-20	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-21	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-3	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-4	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-5	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-6	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-7	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-8	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064000-9	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-1	LEG STRUCTURE	MESSIER DOWTY SA	A321A319,A318,A320	32	AEG Seville
D23064001-10	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-11	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-12	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-13	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-14	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-16	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-2	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-3	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-5	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-6	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-7	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-8	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064001-9	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23064006	LEG STRUCTURE	MESSIER DOWTY SA	A320,A321	32-27-18	AEG Seville
D23064006-1	LEG STRUCTURE	MESSIER DOWTY SA	A320,A321	32-27-18	AEG Seville
D23064006-2	LEG STRUCTURE	MESSIER DOWTY SA	A320,A321	32-27-18	AEG Seville
D23064006-3	LEG STRUCTURE	MESSIER DOWTY SA	A321A320,A320-200	32	AEG Seville
D23064006-4	LEG STRUCTURE	MESSIER DOWTY SA	A320,A321	32-27-18	AEG Seville
D23064006-5	LEG STRUCTURE	MESSIER DOWTY SA	A320,A321	32-27-18	AEG Seville
D23064006-6	LEG STRUCTURE	MESSIER DOWTY SA	A320,A321	32-27-18	AEG Seville
D23066000	LEG FITTINGS	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23066000-1	LEG FITTINGS	MESSIER DOWTY SA	A321A319,A318,A320	32	AEG Seville
D23066000-2	LEG FITTINGS	MESSIER DOWTY SA	A321A319,A318,A320	32	AEG Seville
D23066000-3	D23066000-3	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23066000-6	LEG FITTINGS	SAFRAN LANDING SYST	A320	32	AEG Seville
D23067000	SHOCK ABSORBER	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23067006	SHOCK ABSORBER	MESSIER DOWTY SA	A321A319,A318,A320,A320-221	32	AEG Seville
D23074000	FORESTAY	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23074000-1	FORESTAY	MESSIER DOWTY SA	A321A320,A319,A318	32-37-02	AEG Seville
D23074000-2	FORESTAY	MESSIER DOWTY SA	A321A320,A319,A318	32-37-02	AEG Seville
D23074000-3	FORESTAY	MESSIER DOWTY SA	A321A319,A318,A320,A320-221	32-21-23	AEG Seville
D23074000-4	FORESTAY	MESSIER DOWTY SA	A321A320,A319,A318	32	AEG Seville
D23074000-6	FORESTAY	MESSIER	A321A320,A319,A318	32	AEG Seville

023074000-6	FORESTAY	SAFRAN LANDING SYST	A320	32-37-02	AEG Seattle
023075000-1	LOCK LINK	MESSIER	A321/A320 A319 A318	32	AEG Seattle
023075000-2	LOCK LINK	MESSIER	A321/A320 A319 A318	32	AEG Seattle
023075000-3	LOCK LINK	MESSIER	A321 A319 A318 A320 A320-221	32	AEG Seattle
023077000-1	LOCK SPRING	MESSIER DOWTY SA	A321 A319 A318 A320 A320-221	32-21-18	AEG Seattle
023079000-9	FORESTAY ASSY	SAFRAN	A318	32	AEG Seattle
023080000	SWIVEL BEARING	MESSIER-BUGATTI	A321 A319 A318 A320 A320-232 A320-200	32	AEG Seattle
023081020	SWIVEL BEARING	MESSIER-DOWTY	A321 A319 A318 A320 A320-221 A320-200	32	AEG Seattle
023176000	ELECTRICAL BOX	MESSIER	A321 A320 A319	32-32-57-09	AEG Seattle
023176000-1	ELECTRICAL BOX	MESSIER	A321 A320 A319	32-32-57-09	AEG Seattle
023176900	BOX ELECTRICAL NLG	MESSIER	A340 A330 A321 A320 A319	32-32-57-09	AEG Seattle
023176910-1	ELECTRICAL BOX	MESSIER	A319 A320 A321 A320 A330 A340	32-32-57-09	AEG Seattle
023177000	ELECTRICAL BOX	MESSIER	A340 A318 A321 A320 A319	32-57-17	AEG Seattle
023177010	ELECTRICAL BOX, NLG	MESSIER	F700 A320-200 A321 A3220 A319 A318	32-57-17	AEG Seattle
023177500	ELECTRICAL BOX	MESSIER	A321 A320 A319 A318	32-57-17	AEG Seattle
023177610	ELECTRICAL BOX	MESSIER	A321 A320 A319 A318	32-57-17	AEG Seattle
023177700	ELECTRICAL BOX	MESSIER	F700 A321 A320 A319 A318	32-57-17	AEG Seattle
023177710	ELECTRICAL BOX	MESSIER	A340 A321 A320 A319 A318	32-57-17	AEG Seattle
02320000 SERIES	IM UPPER HARNESS	SAFRAN LANDING	A318/A319/A320/A321	32-07-01	AEG Seattle
023200000	IM UPPER ELECTRICAL HARNESS	MESSIER-BUGATTI	A321 A320 A319 A318	32-07-01	AEG Seattle
023200000-1	IM UPPER ELECTRICAL HARNESS	MESSIER-BUGATTI	A321 A320 A319 A318	32-07-01	AEG Seattle
023200001	IM UPPER ELECTRICAL HARNESS	MESSIER-DOWTY SA	A321 A319 A318 A320	32-27-17,32-07-01	AEG Seattle
023200000 SERIES	2M UPPER HARNESS	SAFRAN LANDING	A318/A319/A320/A321	32-07-01	AEG Seattle
023200000	UPPER ELECTRICAL HARNESS 2M	MESSIER SERVICES	A318	32-07-02	AEG Seattle
023200000-1	UPPER ELECTRICAL HARNESS 2M	MESSIER SERVICES	A318	32-07-02	AEG Seattle
023200001	UPPER ELECTRICAL HARNESS 2M	MESSIER SERVICES	A320 A318/A319/A320/A321	32-07-01	AEG Seattle
023201000	2M UPPER HARNESS	SAFRAN	A321 A319 A318 A320	32-07-01	AEG Seattle
023201010-1	UPPER ELECTRICAL HARNESS	SAFRAN	A321 A320 A319 A318	32-07-01	AEG Seattle
023201010-1	UPPER ELECTRICAL HARNESS	SAFRAN LANDING	A318/A319/A320/A321	32-07-01	AEG Seattle
023201000 SERIES	LOWER HARNESS	SAFRAN LANDING	A318/A319/A320/A321	32-07-03	AEG Seattle
023201000	LOWER ELECTRICAL HARNESS	SAFRAN	A321 A320 A319 A318	32-07-03	AEG Seattle
023201000-1	LOWER ELECTRICAL HARNESS	SAFRAN	A321 A320 A319 A318	32-07-03	AEG Seattle
023201000-1	LOWER ELECTRICAL HARNESS	MESSIER-DOWTY SA	A321 A319 A318 A320	32-07-03,32-27-17	AEG Seattle
023204000 SERIES	INTERMEDIATE HARNESS	SAFRAN LANDING	A318/A319/A320/A321	32-07-04	AEG Seattle
023204000	INTERMEDIATE ELECTRICAL HARNES	MESSIER-BUGATTI	A321 A320 A319 A318	32-07-04	AEG Seattle
023204000-1	INTERMEDIATE ELECTRICAL HARNESS	MESSIER-BUGATTI	A321 A320 A319 A318	32-07-04	AEG Seattle
023204001	INTERMEDIATE ELECTRICAL HARNESS	MESSIER-DOWTY SA	A321 A319 A318 A320	32-07-04,32-07-01	AEG Seattle
023204010 SERIES	INTERMEDIATE HARNESS	SAFRAN LANDING	A318/A319/A320/A321	32-07-07	AEG Seattle
023205000 SERIES	IM UPPER HARNESS	SAFRAN LANDING	A318/A319/A320/A321	32-07-05	AEG Seattle
023205000 SERIES	LOWER HARNESS	SAFRAN LANDING	A318/A319/A320/A321	32-07-06	AEG Seattle
023276000	LEG (NLG)	MESSIER DOWTY SA	A320 A319 A318 A321	32	AEG Seattle
023276000-1	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-10	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-11	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-12	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-13	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-14	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-15	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-16	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-17	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-18	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-19	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-2	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-20	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-21	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-22	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-24	NOSE LANDING GEAR LEG	MESSIER	A321 A320 A319 A318	32-27-41	AEG Seattle
023276000-4	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-5	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-6	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-7	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-8	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276000-9	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001	LEG (NLG)	MESSIER DOWTY SA	A320 A319 A318 A321	32	AEG Seattle
023276001-1	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001-10	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001-11	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001-12	LEG (NLG)	MESSIER DOWTY SA	A321 A319 A318 A320	32	AEG Seattle
023276001-16	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001-18	NOSE LANDING GEAR LEG	MESSIER	A321 A320 A319 A318	32-27-41	AEG Seattle
023276001-2	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001-3	LEG (NLG)	MESSIER DOWTY SA	A321 A319 A318 A320	32	AEG Seattle
023276001-4	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001-5	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001-7	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001-8	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276001-9	LEG (NLG)	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-01	AEG Seattle
023276006	NOSE LANDING GEAR	MESSIER DOWTY SA	A321 A319 A318 A320	32-27-17	AEG Seattle
023276006-1	NOSE LANDING GEAR	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-17	AEG Seattle
023276006-16	NLG ASSY	SAFRAN LANDING SYST	A321 A320	32	AEG Seattle
023276006-2	NOSE LANDING GEAR	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-17	AEG Seattle
023276006-3	NOSE LANDING GEAR	MESSIER DOWTY SA	A321 A319 A318 A320	32-27-17	AEG Seattle
023276006-4	NOSE LANDING GEAR	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-17	AEG Seattle
023276006-5	NOSE LANDING GEAR	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-17	AEG Seattle
023276006-6	NOSE LANDING GEAR	MESSI	A321 A320 A319 A318	32-27-17	AEG Seattle
023276006-7	GEAR, NOSE LANDING	MESSIER DOWTY SA	A321 A320 A319 A318	32-27-17	AEG Seattle
023278000 SERIES	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023278000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	52-30-14	AEG Seattle
023278100 SERIES	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023278100	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023278200 SERIES	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023278200	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000 SERIES	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A319/A320/A321	32-27-17	AEG Seattle
023281000	TOWING FITTING	SAFRAN LANDING	A318/A3		

023443100-3	LEG FITTING	SAFRAN	A330		AEG Seville
023443100-4	LEG FITTING	SAFRAN	A330		AEG Seville
023443100-5	LEG FITTING	SAFRAN	A330		AEG Seville
023443100-6	LEG FITTING	SAFRAN	A330		AEG Seville
023443100-7	LEG FITTING	SAFRAN	A330		AEG Seville
023443200	LEG FITTING	SAFRAN	A330	32-23-17	AEG Seville
023446100 SERIES	UPPER ELECTRICAL LOOM	SAFRAN LANDING	A330-2001-3000	32-09-67	AEG Seville
023446100 SERIES	UPPER ELECTRICAL LOOM	SAFRAN LANDING	A330-2001-3000	32-09-70	AEG Seville
023447000	UPPER ELECTRICAL LOOM	SAFRAN LANDING	A330-2001-3000	32-09-68	AEG Seville
023447050	UPPER ELECTRICAL LOOM	SAFRAN LANDING	A330-2001-3000	32-09-71	AEG Seville
023449000	STEERING ACTUATOR	MESSIER - BUGATTI	A340,A330	32-53-01	AEG Seville
023582000-1	MAIN FITTING SHOCK ABSORBER	MESSIER DOWTY	A330	32-23-21	AEG Seville
023582000-10	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-105	MAIN FITTING SHOCK ABSORBER	MESSIER-DOWTY	A330	32-23-22	AEG Seville
023582000-106	MAIN FITTING SHOCK ABSORBER	MESSIER-DOWTY	A330	32-23-22	AEG Seville
023582000-107	MAIN FITTING SHOCK ABSORBER	MESSIER-DOWTY	A330	32-23-22	AEG Seville
023582000-108	MAIN FITTING SHOCK ABSORBER	SAFRAN LANDING	A330	32-23-22	AEG Seville
023582000-109	MAIN FITTING SHOCK ABSORBER	SAFRAN LANDING	A330	32-23-22	AEG Seville
023582000-11	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-110	MAIN FITTING SHOCK ABSORBER	SAFRAN LANDING	A330	32-23-22	AEG Seville
023582000-111	MAIN FITTING SHOCK ABSORBER	SAFRAN LANDING	A330	32-23-22	AEG Seville
023582000-112	MAIN FITTING SHOCK ABSORBER	MESSIER-DOWTY	A330	32-23-22	AEG Seville
023582000-113	MAIN FITTING SHOCK ABSORBER	MESSIER-DOWTY	A330	32-23-22	AEG Seville
023582000-114	MAIN FITTING SHOCK ABSORBER	MESSIER-DOWTY	A330	32-23-61	AEG Seville
023582000-12	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-13	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-2	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-21	AEG Seville
023582000-205	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-206	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-207	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-208	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-209	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-210	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-211	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-212	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-213	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-214	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582000-3	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-21	AEG Seville
023582000-306	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-307	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-308	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-309	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-310	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-311	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-312	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-313	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582000-4	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-21	AEG Seville
023582000-5	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-6	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-7	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-8	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582000-9	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582200	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582200-1	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582200-2	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582200-3	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582210	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582210-1	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582210-2	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-22	AEG Seville
023582210-3	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-1	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-10	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-105	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-106	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-107	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-108	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-109	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-110	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-111	MAIN FITTING SHOCK ABSORBER		A330		AEG Seville
023582300-2	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-205	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-206	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-207	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-208	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-209	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-210	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-211	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330		AEG Seville
023582300-3	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-306	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-307	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-308	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-309	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-310	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-4	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-5	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-6	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-7	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-8	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023582300-9	MAIN FITTING SHOCK ABSORBER	SAFRAN	A330	32-23-24	AEG Seville
023586000	BOX & ELECTRICAL HARNESS TOWBA	MESSIER DOWTY SA	A330	32-57-12	AEG Seville
023586000-100	BOX & ELECTRICAL HARNESS TOWBA	MESSIER-DOWTY	A340,A330	32-57-21	AEG Seville
023591620-6	BARREL STRUCTURE	MESSIER	A321,A320,A319,A318		AEG Bilbao
0235916000	FORESTAY ASSEMBLY	MESSIER DOWTY SA	A321,A319,A318,A320	32	AEG Seville
023507000-1	LEG FITTINGS	MESSIER DOWTY SA	A321,A319,A318,A320	32	AEG Seville
023611000	NLG LOCKING SPRING	MESSIER-DOWTY	A321,A319,A318,B747,A320	32-27-27	AEG Seville
0236270 SERIES	1M UPPER HARNESS	SAFRAN LANDING	A318/A319/A320/	32-07-09	AEG Seville
023627000	1M UPPER HARNESS	MESSIER-DOWTY SA	A330,A321,A319,A318,A320	32-07-09	AEG Seville
0236290 SERIES	INTERMEDIATE HARNESS	SAFRAN LANDING	A318/A319/A320/	32-07-13	AEG Seville
0236300 SERIES	LOWER HARNESS	SAFRAN LANDING	A318/A319/A320/	32-07-12	AEG Seville
023630000	LOWER HARNESS	MESSIER-DOWTY SA	A330,A321,A319,A318,A320	32-07-12	AEG Seville
0236800 SERIES	2M UPPER HARNESS	SAFRAN LANDING	A318/A319/A320/	32-07-10	AEG Seville
024006000	ALTERNATE BRAKE MANIFOLD ASSY	SAFRAN	A318 - A321	32	AEG Seville
024006000-1	ALTERNATE BRAKE MANIFOLD ASSY	SAFRAN	A318 - A321	32	AEG Seville
024006000	ALTERNATE BRAKE MANIFOLD ASSEMBLY	SAFRAN	A318, A319, A320, A321	32-47-54	AEG Seville
024006000-1	ALTERNATE BRAKE MANIFOLD ASSEMBLY	SAFRAN	A318, A319, A320, A321	32-47-54	AEG Seville
024029000-3	NORMAL BRAKE MANIFOLD ASSEMBLY	F6137	A340	32	AEG Seville
026481083	LANDING GEAR CUT-OUT VALVE	LUCAS AEROSPACE	A340	32	AEG Seville
026481084	CUT OUT VALVE	LUCAS AEROSPACE	A340	32	AEG Seville
0321661000000	NUT ASSY - PINTLE PIN	AIRBUS	A321,A320	32	AEG Seville
0322101600000	ROD ASSY	AIRBUS INDUSTRIE	A320	32-22-11	AEG Seville
0322101600100	ROD ASSY	AIRBUS INDUSTRIE	A320	32-22-11	AEG Seville
0322101600400	ROD ASSY	AIRBUS INDUSTRIE	A320	32-22-11	AEG Seville
0465-07-001	ENGINE FIRE SHUT-OFF SWITCH	AVIONICS SIMULATION PRODUCTS, LORDE	B747-200,B767,B757,A320,B747-400	26-21-15	AEG Seville
0465-08-001	ENGINE FIRE SHUT-OFF SWITCH	AVIONICS SIMULATION PRODUCTS, LORDE	B747-200,B767,B757	26-21-15	AEG Seville
06528000100651	ELEVATOR ASSY	AIRBUS	B737,A318,A319,A320,A320,A321	65-55-21-15	AEG Seville
069881	APEX PIN	UNKNOWN	A320	32	AEG Seville
06000-6	HYDRAULIC ACTUATOR WINDSHIELD WIPER	MARQUET	A330, A340	REF-41	AEG Seville
061366	AXLES NUT	AIRBUS	A320	32	AEG Seville

[illegible]

FE290	PCU Elevator Input Bungee				27-31-03	AEG Seville
FE300000008	Cable Tension Regulator				27-31-12	AEG Seville
FE300000009	Cable Tension Regulator				27-31-12	AEG Seville
FE336000000	Load Limiter				27-21-01	AEG Seville
FE336000000	Elevator Force- Sensor Rod				27-30-02	AEG Seville
FE336000002	Elevator Force- Sensor Rod				27-30-02	AEG Seville
FE336000003	Elevator Force- Sensor Rod				27-30-02	AEG Seville
FE337000000	Rudder Force- Sensor Rods				27-20-04	AEG Seville
FE338000000	Aileron Quadrant Assy					AEG Seville
FE338001000	Aileron Quadrant Assy					AEG Seville
FE338500000	Aileron Force- Sensor Rods					AEG Seville
FE338500001	Aileron Force- Sensor Rods					AEG Seville
FE338500002	Aileron Force- Sensor Rods					AEG Seville
FE338500004	Aileron Force- Sensor Rods					AEG Seville
FE338500005	Aileron Force- Sensor Rods					AEG Seville
FE338500000	Aileron Link					AEG Seville
FE339	Aileron Quadrant Assy					AEG Seville
FE340000000	Electronic Control Unit					AEG Seville
FV295	Flap Actuator Ballscrew				27-50-03	AEG Seville
FV295000000	Flap Actuator Ballscrew				27-50-03	AEG Seville
Q4-1605-1429	LIGHT ANTI-COLLISION		ATR-42, ATR-72			AEG Seville
Q5944	CONTROL INTERCOM	GABLES	UNK			AEG Seville
Q7490-33	FLIGHT ID/ATC/TCAS Control Panel	GABLES ENGINEERING	A330, A340		34	AEG Seville
Q836-4-20	QUANTITY MEASURING FUSE ASSEMB	PARKER	B737		32-40-01	AEG Seville
Q8400A37-24	LIGHT	GRIMES	ATR		33-40-21	AEG Seville
Q-8400A-37-24	AIRCRAFT NAVIGATIONAL ROTATING	GRIMES	A330, A340		33	AEG Seville
Q-8895-1	LANDING LIGHT	GRIMES	A330, A340		33-04-0133-6-1	AEG Seville
Q-8895-4569	LANDING LIGHT	HONEYWELL	A330, A340		33-04-01	AEG Seville
Q463612	BARREL	MESSIER	A321,A320,A319,A318,A320-221		32-21-17	AEG Seville
Q463843-1	BODDY ASSY	K0654	A330		32-33-30	AEG Seville
Q464715	FLANGE UPPER BUSHED	MESSIER-DOWTY	A330		32-23-12	AEG Seville
Q464717	LINK LOWER BUSHED TORQUE	MESSIER-DOWTY	A330		32-23-12	AEG Seville
Q91620AA0	Check Valve				36-11-27	AEG Seville
Q91620AA1	Check Valve				36-11-27	AEG Seville
QCU16461	Generator Control Unit				24-20-15	AEG Seville
QG451-2008-5	Plenum				21-52-01	AEG Seville
QG436-1008-5	Cross-Bleed Valve				36-12-06	AEG Seville
QG436-1008-7	Cross-Bleed Valve				36-12-06	AEG Seville
QG436-2003-1	Pack Inlet Flow Sensor				21-51-20	AEG Seville
QG436-2004-1	Pack Inlet Pressure Sensor				21-51-21	AEG Seville
QG436-2016-3	Temperature Sensor				21-52-25	AEG Seville
QG436-2029-1	Bulkhead Check Valve				21-21-17	AEG Seville
QG436-2033-1	Anti Icing Pressure Sensor				21-52-41	AEG Seville
QG436-4004-6	Wai Isolation Valve					AEG Seville
QG436-4004-7	Wai Isolation Valve					AEG Seville
QG670-80001-1	High Pressure Valve				36-12-10	AEG Seville
QG670-80001-3	High Pressure Valve				36-12-10	AEG Seville
QG670-80002-5	High Pressure Valve				36-11-91	AEG Seville
QG670-80002-7	High Pressure Valve				36-11-91	AEG Seville
QG670-80006-1	Temperature Sensor				36-12-11	AEG Seville
QG670-80006-3	Temperature Sensor				36-12-11	AEG Seville
QG670-80013-3	Temperature Sensor					AEG Seville
QG670-80013-5	Temperature Sensor					AEG Seville
QG670-80013-7	Temperature Sensor					AEG Seville
QG670-80013-9	Temperature Sensor					AEG Seville
QG670-96*****	Underfloor Low Pressure Ducting - LXT Series				21-51-64	AEG Seville
QG670-96003-3	Flow Control Valve				21-51-62	AEG Seville
QG670-96003-5	Flow Control Valve				21-51-62	AEG Seville
QG670-96009			CRJ 700/900		21-52-53	AEG Seville
QG670-96009-1	Air Cycle Machine				21-52-53	AEG Seville
QG670-96009-3	Air Cycle Machine				21-52-53	AEG Seville
QG670-96009-5	Air Cycle Machine				21-52-53	AEG Seville
QG670-96019-1	Ram Air Valve				21-53-70	AEG Seville
QG670-96026-3	Air Conditioning System Controller				21-60-24	AEG Seville
QG670-96026-5	Air Conditioning System Controller				21-60-24	AEG Seville
QG670-96027-3	Avionics Cooling Fan				21-23-15	AEG Seville
QG670-96028-3	Lavatory And Galley Fan				21-23-16	AEG Seville
QG670-96033-5	Low Flow Sensor				21-23-19	AEG Seville
QG670-98003-3	Outflow Valve				21-31-28	AEG Seville
QG670-98003-5	Outflow Valve				21-31-28	AEG Seville
QG670-98005-1	Safety Valve				21-31-30	AEG Seville
QG670-98006-1	Pressure Equalization Valve				21-51-66	AEG Seville
QG690-96*****	Underfloor Low Pressure Ducting - LXT Series				21-51-64	AEG Seville
QG690-96026-1	Air Conditioning System Controller				21-60-24	AEG Seville
QG690-96026-3	Air Conditioning System Controller				21-60-24	AEG Seville
QG698-96026-1	Air Conditioning System Controller				21-51-60	AEG Seville
QG698-96048-1	Left Precooler Assembly				36-12-31	AEG Seville
QG698-96048-2	Right Precooler Assembly				36-12-32	AEG Seville
QG698-98001-1	Cabin Pressure Control Panel				21-31-70	AEG Seville
QG698-98005-1	Safety Valve				21-31-69	AEG Seville
HD-66	HEADSET CABIN INTERCOMM	DAVID CLARK	C-212, CN-235, C-295		23-50-00	AEG Seville
HS412-19	Handle Assy, Galley				52-41-03	AEG Seville
HS412-21	Handle Assy, Galley				52-41-03	AEG Seville
HS412-25	Handle Assy, Galley				52-41-03	AEG Seville
HS412-29	Handle Assy, Galley				52-41-03	AEG Seville
HS412-31	Handle Assy, Galley				52-41-03	AEG Seville
HS412-5	Handle Assy, Galley				52-41-03	AEG Seville
HS412-7	Handle Assy, Galley				52-41-03	AEG Seville
HS414-23	Flush Handle Latch Assembly				52-11-03	AEG Seville
HS414-25	Flush Handle Latch Assembly				52-11-03	AEG Seville
HS414-29	Flush Handle Latch Assembly				52-11-03	AEG Seville
HS414-33	Flush Handle Latch Assembly				52-11-03	AEG Seville
HS414-37	Flush Handle Latch Assembly				52-11-03	AEG Seville
HS414-9	Flush Handle Latch Assembly				52-11-03	AEG Seville
HS416-23	Flush Handle Latch Assembly				52-31-03	AEG Seville
HS416-31	Flush Handle Latch Assembly				52-31-03	AEG Seville
HS417-1	Handle Assy, Alt Comp1				52-43-03	AEG Seville
HS417-5	Handle Assy, Alt Comp1				52-43-03	AEG Seville
HS417-7	Handle Assy, Alt Comp1				52-43-03	AEG Seville
HS419-27	Flush Handle Latch Assembly				52-22-03	AEG Seville
HS419-31	Flush Handle Latch Assembly				52-22-03	AEG Seville
HS419-33	Flush Handle Latch Assembly				52-22-03	AEG Seville
HS419-35	Flush Handle Latch Assembly				52-22-03	AEG Seville
HS419-37	Flush Handle Latch Assembly				52-22-03	AEG Seville
HS445-1	Flush Handle Latch Assembly				52-42-03	AEG Seville
HS445-3	Flush Handle Latch Assembly				52-42-03	AEG Seville
HS445-5	Flush Handle Latch Assembly				52-42-03	AEG Seville
H3939-1	Flush Handle Latch Assembly				52-11-07	AEG Seville
H3939-3	Flush Handle Latch Assembly				52-11-07	AEG Seville
H3939-5	Flush Handle Latch Assembly				52-11-07	AEG Seville
H3939-7	Flush Handle Latch Assembly				52-11-07	AEG Seville
HA663-1	Pressure Relief Latch Assembly				52-44-01	AEG Seville
HA663-3	Pressure Relief Latch Assembly				52-44-01	AEG Seville
HP1333200	Brake Control Valve				32-41-02	AEG Seville
HTF9178	2 IN Butterfly Valve				21-20-03	AEG Seville
ID663BU	INDICATOR, BEARING		UNK			AEG Seville
ID9-464-40	INDICATOR, LIQUID QTY		UNK			AEG Seville
JP992AAA02	Jack Panel				23-51-76	AEG Seville
JP935AA02	Jack Panel				23-51-77	AEG Seville

J93958AA03	Jack Panel				23-51-78	AEG Seville
K97-63-607	Refuel/Defuel Adapter				28-25-05	AEG Seville
K97-63-617	Refuel/Defuel Adapter				28-25-05	AEG Seville
K98963-202	Refuel Adapter Cap				28-24-22	AEG Seville
L83A13-434	Water Drain Valve					AEG Seville
L85-38-601	Check Valve				28-21-04	AEG Seville
L92815-602	Transfer Shut-Off Valve Cartridge				28-19-43	AEG Seville
L92815-605	Transfer Shut-Off Valve Cartridge				28-19-43	AEG Seville
L93538-601	Shut-Off Valve Housing				28-25-07	AEG Seville
L94138-661	Valve Module				28-25-06	AEG Seville
L94138-663	Valve Module				28-25-06	AEG Seville
L96-26-601	Check Valve				28-22-04	AEG Seville
L97-63-601	Pressure Relief Valve					AEG Seville
L97-63-602	Pressure Relief Valve					AEG Seville
L97-63-605	Pressure Relief Valve					AEG Seville
L97-63-606	Pressure Relief Valve					AEG Seville
L988623	Magnetic Level Indicator				28-41-15	AEG Seville
L988624	Magnetic Level Indicator				28-41-15	AEG Seville
L988625	Magnetic Level Indicator				28-41-15	AEG Seville
LM108	Light DimmerPower Supply Unit				24-30-06	AEG Seville
LI-16-0465	Remote Magnetic Compensator (Installation Drawn)				LI-15-0455	AEG Seville
LM320SA12	BRACKET SIDE			C-212, CN-235		AEG Seville
LM320-SA12	BRACKET-SIDE			UNK		AEG Seville
LM320-SA12	FRONT SIDE MOUNTING ASSEMBLY			A330, A340	71	AEG Seville
LM320SA13	BRACKET-ENGINE FRONT TOP			CN-235		AEG Seville
LM320-SA13	FRONT TOP MOUNTING ASSEMBLY			A330, A340		AEG Seville
LM320SA14	BRACKET-UPPER		LOIRD CORP AEROSPACE PRODUCTS	CN-235		AEG Seville
LM320SA18	MOUNTING-REAR			CN-235		AEG Seville
LM-320-SA18	FRONT LEFT AND RIGHT SIDE MOUNT BRACKET ASSEMBLY			A330, A340		AEG Seville
LM320SA19	MOUNTING-REAR			CN-235, C-295		AEG Seville
LM-320-SA19	MOUNTING-REAR			A330, A340		AEG Seville
LM-351	Engine Mounts				71-20-01	AEG Seville
LM-351F	Engine Mounts				71-20-18	AEG Seville
LT-100	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Seville
LT103	POWER SUPPLY	KGS ELECTRONICS		UNK		AEG Seville
LT-103	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Seville
LT100CCYY-2000	GuideU				33-51-07	AEG Seville
LT62A	CONVERTER	KGS ELECTRONICS		C-212, CN-235, C-295		AEG Seville
LT-62A	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00,24,33	AEG Seville
LT-63	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Seville
LT63A	CONVERTER			UNK		AEG Seville
LT-70	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Seville
LT-73	DC TO DC CONVERTER	KGS ELECTRONICS		A330, A340	24-30-00	AEG Seville
M36M2-10	Starter Motor				49-40-00	AEG Seville
M4641P-2AwithMotor	Vaneaxial Fan				M4641P-2A	AEG Seville
M73291	AIR COOLING FAN	HAMILTON ELEMENTARY		A330, A340	21	AEG Seville
M73291 SERIES	AIR COOLING FAN	HAMI		A330, A340	21	AEG Seville
M73291DF	FAN ASSEMBLY-AIR COOLING	SUNDSTRAND		B747, B767,DASH8	21-58-02	AEG Seville
M76220C	VSCF	SUNDSTRAND		B777	24-25-20	AEG Bilbao
M764385A	Outboard Slat Actuator Assembly				27-81-18	AEG Seville
M76816A	Mid Slat Actuator Assembly				27-81-20	AEG Seville
MCP-016	Inspection Criteria For D11 Seage Head Assembly				MCP-016	AEG Seville
M20SERIES	Crew Oxygen Mask				SPM-20-10	AEG Seville
MM-0113ASCO113Series	Blowers				MM-0113	AEG Seville
MODEL 6318	ALTERNATING CURRENT GENERATOR			A330, A340		AEG Bilbao
Model6590-1	Vertical Accelerometer				Model 5690-1	AEG Seville
Model811B	Clock				Model 811B	AEG Seville
Model818	Clock, newer version of 811B				Model 818-1	AEG Seville
Model1636-F-1&1A	High Temp. Ovens				Model 1636-F-1 & 1A	AEG Seville
MPEV3-01I-BUG2B	PUMP-HYDR.MOTOR DRIV	EATON		C-295,CN-235,MD-1,LT6767,B747,A310,A330	29-20-10-49	AEG Seville
MPEV3-01I-BUG2C	PUMP-HYDR.MOTOR DRIV	EATON		C-295,CN-235	29	AEG Seville
MPEV3-012-2B	HYDRAULIC PUMP	EATON		Challenger,CRJ-700,CRJ regional jet-700,CRJ-2 (Regional Jet), 700, CRJ-2 700, A310,	29-10-45	AEG Seville
MR-10021NAA	Crewmember PBE				PRM-02	AEG Seville
MR-10022NAA	Crewmember PBE				PRM-02	AEG Seville
MS1421874-12	REMACHE			UNK		AEG Seville
MS17401-1	ALTIMETER PRESSURE	MILITARY		UNK		AEG Seville
MS3452	CONECTOR RECEPTACULO	MATRIX		UNK		AEG Seville
MT830	Maintenance Terminal User Manual for M1630 Electronic Unit 970-8374 v.01, Controller, Alt v.0					AEG Seville
N639-8071	DH-1030-115/3-1200-SS IID				23-35-45	AEG Seville
N639-8074	DH-1030-24-3-CS IID				24-20-07	AEG Seville
N639-8075	DH-1030-24-600-CS IB				24-20-08	AEG Seville
N717-8017	GC-1010-24-5D III				24-20-06	AEG Seville
N719-8106	BP-1010-24-8D				24-30-02	AEG Seville
N719-8106	BP-1010-24-8E				24-30-X	AEG Seville
NA8610D43	CARDAN BRACKET BOLT	STANDARD		A320-221	24-31-03	AEG Seville
NC6-3-1A	ROTOR			UNK	32-11-20	AEG Seville
NN-233C	D.C. SPDT Contactor					AEG Bilbao
NN449B	Relay					AEG Seville
NP139321	Cockpit Windshield				24-30-02	AEG Seville
NP139322	Cockpit Side Window				56-11-01	AEG Seville
NP-167901	Main windshield				56-11-02	AEG Seville
NP-167902-13	Left Hand Window, Right Hand Window				56-10-01	AEG Seville
NP-167902-14	Left Hand Window, Right Hand Window				56-10-16	AEG Seville
NP-184903	Cabin Windows				56-10-16	AEG Seville
NP-197501	Cabin Windows				56-20-01	AEG Seville
Obsolete	Obsolete				56-20-01	AEG Seville
PT1487	RELAY, ELECTROMAGNETIC	NONE		UNK	33-41-41	AEG Seville
P610385	Electric Fan					AEG Seville
P93A26-602	Bi-Crossflow Pump Cartridge				24-31-03	AEG Seville
P93C33-604	APU Fuel-Fuel Pump				28-13-47	AEG Seville
P99C26-603	Fuel Booster Pump				28-24-08	AEG Seville
PA83921*	Digital Passenger Announcement System				28-20-77	AEG Seville
PA83921AB02	Digital Passenger Announcement System				23-30-10	AEG Seville
PBMS	PBMS Software User Manual				23-30-10	AEG Seville
PBMS	PBMS Software User Manual for Windows 10 operating system (Physical & Virtual Environment)				23-35-48	AEG Seville
PL1100LH00	GuideU				23-35-49	AEG Seville
PL1300LH00	GuideU				33-51-07	AEG Seville
PL1400LH00	GuideU				33-51-07	AEG Seville
PL1600LH00	GuideU				33-51-07	AEG Seville
PL1600LH00	GuideU				33-51-07	AEG Seville
PL1900LH00	GuideU				33-51-07	AEG Seville
PL1901LH00	GuideU				33-51-07	AEG Seville
PL17X000YYLZZZZ	GuideU				33-51-07	AEG Seville
PL17X000YYWZZZZ	GuideU				33-51-07	AEG Seville
PL17X00CCYYZ	GuideU				33-51-07	AEG Seville
PL8-900LH88	GuideU				33-51-07	AEG Seville
PMP3V-3-05	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER		B757/B767	29-19-30	AEG Seville
PMP3V-3-06	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER		B757/B767	29-19-30	AEG Seville
PMP3V-3-07	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER		B747,B757/B767/B777	29-19-30	AEG Seville
PMP3V-3-08	VARIABLE DELIVERY HYDRAULIC PUMP	PARKER		B747,B757/B767/B777	29-19-30	AEG Seville
PU90-42R33	Smoke Detector					AEG Seville
PV3-044-48	HYDRAULIC PUMP	EATON		CRJ,CRJ200	29-10-44	AEG Seville
R8126	Bumper				24-20-XX	AEG Seville
R856423	BRUSH			UNK		AEG Seville
R8C6	U.P.S. SALA FUSION			UNK		AEG Seville
RC850-1L	INDICATOR AIR SPEED	AEROSONIC		UNK		AEG Seville
RR63160	Centrif Fuel Boost Pump				28-21-00	AEG Seville
S271260-1	INDICATOR PRESSURE OXYG	KRATOS		UNK		AEG Seville
S274120-10	ANTISKID	GE		B757, B767, B737	32-42-01	AEG Seville

527W813-11	FUSE ASSEMBLY, FLOW RATE	TRIUMPH ACTUATION	B-777		AEG Seville
5281A001-101	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE	B737NG/Boeing 737 MAX	24-11-85.	AEG Bilbao
5281A001-103	IDG INTEGR DRIVE GENERATOR	COLLINS AEROSPACE	B737NG/Boeing 737 MAX	24-11-85.	AEG Bilbao
5281W101-20	INTEGRATED DRIVE GENERATOR	COLLINS AEROSPACE	B777	24-21-11	AEG Bilbao
5281W401-1	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-10	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-11	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-12	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-14	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-16	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-16	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-17	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-20	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-21	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-22	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-23	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-4	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-6	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-6	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-7	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-8	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5281W401-9	VSCF GENERATOR	COLLINS AEROSPACE	B777	24-25-20	AEG Bilbao
5282T03-3	BATTERY CHARGER	CRANE / ELDEC	747-400	24-31-04	AEG Seville
5283A313-103	NAVIGATION LIGHT	BOEING	B737-300,B737-600,B777,B757	33-42-06	AEG Seville
5283A326-1	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5283A326-10	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5283A326-2	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5283A326-3	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5283A326-4	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5283A326-6	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5283A326-6	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5283A326-7	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5283A326-8	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5283A326-9	EXTERIOR EMERGENCY LIGHTS	KOITO MFG CO	B737	33-61-04	AEG Seville
5369-100	ACCUMULATORS	TELEDYNE	A330, A340	75-23-100	AEG Seville
5369-50	ACCUMULATORS	TELEDYNE	A330, A340	75-23-50	AEG Seville
5400V3	Flight Attendant Panel			25	AEG Seville
5417A501-609	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Seville
5417A501-610	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Seville
5417A501-611	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Seville
5417A501-612	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Seville
5417A501-613	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Seville
5417A501-614	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Seville
5417A501-615	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Seville
5417A501-616	CEILING LIGHT ASSEMBLY	B/E AEROSPACE	B737	33	AEG Seville
5417T102-1	WASTE SYSTEM VACUUM BLOWER	THE BOEING	BOEING 777-200	38-32-02	AEG Seville
54-3300966	ACTUATOR	LIEBHERR	A340,A330	32-31-19	AEG Seville
54-3300966 AMDT. A	NOSE LANDING GEAR DOOR ACTUATOR		A-330, A-340		AEG Seville
54-3300966 AMDT. A	NOSE LANDING GEAR DOOR ACTUATOR		A-330, A-340		AEG Seville
54-3300966 AMDT. B	NOSE LANDING GEAR DOOR ACTUATOR		A-330, A-340		AEG Seville
5462-26	ACCUMULATORS	SPRAGUE	A330, A340	9H1-2-14-	AEG Seville
5462-50	ACCUMULATORS	SPRAGUE	A330, A340	9H1-2-14-	AEG Seville
5463-100	ACCUMULATORS	TELEDYNE	A330, A340	75-23-100	AEG Seville
5463-50	ACCUMULATORS	TELEDYNE	A330, A340	75-23-50	AEG Seville
5477-100	ACCUMULATORS	TELEDYNE	A330, A340	75-23-100	AEG Seville
5477-200	ACCUMULATORS	TELEDYNE	A330, A340	75-23-200	AEG Seville
5477-60	ACCUMULATORS	TELEDYNE	A330, A340	75-23-50	AEG Seville
5612-26	ACCUMULATORS	TELEDYNE	A330, A340	75-23-25	AEG Seville
5613-100	ACCUMULATORS	MIL	A330, A340	9H1-2-14-	AEG Seville
5613-200	ACCUMULATORS	SPRAGUE	A330, A340	9H1-2-14-	AEG Seville
5613-50	ACCUMULATORS	MIL	A330, A340	9H1-2-14-	AEG Seville
5618-A	ACCUMULATORS	SPRAGUE	A330, A340		AEG Seville
5A8261-019	FLUID PRESS REG VALVE	AERONAUTICAL INSTITUTE INC.	UNK		AEG Seville
5CD130	Passenger Address and Cabin Interphone System			23-30-02	AEG Seville
5D1682	ROTOR BALANCE ASSEMBLY	HAMILTON SUNDRETS AMPL	B777	24-26-10	AEG Bilbao
5EDL-OC28	Torque Indicator			77-10-31	AEG Seville
5EL-OC19EX	Inter turbine Temperature Indicator			77-20-24	AEG Bilbao
5EL-OC29DA	NH% RPM Indicator			77-12-01	AEG Bilbao
5EL-OC29DF	NH% RPM Indicator			77-12-01	AEG Bilbao
5EL-OC29DJ	NL% RPM Indicator			77-12-04	AEG Bilbao
5EL-OC29DK	NL% RPM Indicator			77-12-04	AEG Bilbao
5eries2	Left AC Contactor Box Galley Opt 2			24-23-03	AEG Seville
5eries2	Left AC Contactor Box (No Galley Option)			24-24-06	AEG Seville
5eries2	Right AC Contactor Box (No Galley Option)			24-24-07	AEG Seville
5eries3	Left AC Contactor Box Galley Opt 2			24-23-03	AEG Seville
5eries3	Left AC Contactor Box (No Galley Option)			24-24-06	AEG Seville
5eries3	Right AC Contactor Box (No Galley Option)			24-24-07	AEG Seville
5eries4	Left AC Contactor Box Galley Opt 2			24-23-03	AEG Seville
5eries4	Left AC Contactor Box (No Galley Option)			24-24-06	AEG Seville
5eries4	Right AC Contactor Box (No Galley Option)			24-24-07	AEG Seville
5ETL-OC420F	Cabin Pressure Indicator			21-30-03	AEG Seville
5ETL-OC420G	CABIN PRESSURIZATION INDICATOR	AMETEK	CN-235, 757	21	AEG Seville
5ETL-OC420Y	CABIN PRESSURIZATION INDICATOR	AMETEK	UNK	21	AEG Seville
5H570-60660	Spring Loaded Sensor Assembly			52-70-10	AEG Seville
5L40955	WASHER-LOCK	SAFRAN	A330		AEG Seville
5OP6-01-06	Permissible Tube Connection system Installation And Connection			SOP6-01-05	AEG Seville
5OP604-008	Permissible Lift Tool Maintenance Procedures			SOP604-008	AEG Seville
5OP604-030	Permissible Lift Tool Maintenance Procedures And Service Schedules			SOP604-030	AEG Seville
5P	Standard Practices				AEG Seville
5PC-10V	Static Inverter			24-20-43	AEG Seville
5RD1-OC12F	Dual Hydraulic Quantity Ind			29-30-19	AEG Seville
5T-106AB	TRANSMITTER DUCT PRESSURE	AMETEK	B727, A300, B737, B747	36,31-02-02,31	AEG Seville
5T-107R	HYDRAULIC PRESSURE TRANSMITTER	AMETEK	B737, B727,B767, B777	36,31-02-02,31	AEG Seville
5T-109C	SYNCHRO TRANSMITTER DIAPHRAGM ACTUATION	AMETEK	C-130,MD80,DC-8,DC-9	31-1-59	AEG Seville
5TM3768V08-4 / 7	REMACHE/PASADOR		UNK		AEG Seville
5Y1620A00	Low Pressure Ground Connection			21-20-34	AEG Seville
5Y1620A00	Low Pressure Ground Connection			21-20-34	AEG Seville
5Y1620C00	Low Pressure Ground Connection			21-20-02	AEG Seville
5YLZ60970	Windshield Temperature Controller			F-16495	AEG Seville
799A38-602	Fwd Scavenge Ejector			28-13-21	AEG Seville
799B38-601	Transfer Ejector			28-13-01	AEG Seville
7RU3602	Transformer Rectifier Unit			24-31-01	AEG Seville
7Y1741	Pitch Feel Unit			27-30-02	AEG Seville
7Y1910	Pitch Feel Simulator			27-30-03	AEG Seville
7Y1910-50A	Pitch Feel Simulator			27-30-03	AEG Seville
7Y1910-51A	Pitch Feel Simulator			27-30-03	AEG Seville
7Y2148-10A	Isolating Control Valve			78-32-09	AEG Seville
7Y2148-11A	Isolating Control Valve			78-32-09	AEG Seville
7Y2149-16A	Directional Control Valve			78-32-01	AEG Seville
7Y2149-20A	Directional Control Valve			78-32-01	AEG Seville
7Y2160-16A	Lock Control Valve			78-32-15	AEG Seville
7Y2161-16A	Locking Actuator			78-32-03	AEG Seville
7Y2161-16A	Locking Actuator			78-32-03	AEG Seville
7Y2162-16A	Feedback Actuator			78-32-05	AEG Seville
7Y2162-16A	Feedback Actuator			78-32-05	AEG Seville
7Y2162A60	Feedback Actuator			78-32-05	AEG Seville
7Y2162B60	Feedback Actuator			78-32-05	AEG Seville
7Y2163-01A	Manual Drive			78-32-11	AEG Seville
7Y2231-01A	Stow Switch			78-31-01	AEG Seville

TY232-01A	Control Microswitch			78-31-03	AEG Seville
TY2614	Pitch Feel Unit			27-30-07	AEG Seville
TYPE200-CV	AUTOTRANSFORMADOR VARIABLE		A330, A340		AEG Milano
VI-4560-2	HYD VALVE FUSE	CIRCLE SEAL CONTROLS	B767	32-32-01	AEG Seville
VY99A3-001	Motive Flow Venturi			28-22-07	AEG Seville
VA4T0	EXTRACTION FAN	AOA	A330, A330F, A340, AST	21-21-18	AEG Seville
VD3810	MIXED FLOW FAN	AOA	A300-800, A310, A319, A320, A321, A330, A340, A350, A359, A350L	21-21-12	AEG Seville
VD3820	MIXED FLOW FAN	AOA	A300, A300-800, A310, A319, A320, A321, A330, A340, A350, A359, A350L	21-21-11	AEG Seville
VD3820-01	MIXED FLOW FAN	AOA	A310, A319, A320, A321, A330, A340, A350, A359, A350L	21-21-11	AEG Seville
VD3820MM001	MIXED FLOW FAN	AOA, APPARATELBAU GUTING	A300, A300-800, A310, A319, A320, A321, A330, A340, A350, A359, A350L	21-21-11	AEG Seville
VP0615AA0	Shut-Off Valve			21-24-03	AEG Seville
VP0615B00	Shut-Off Valve			21-24-03	AEG Seville
VP0615E00	Shut-Off Valve			21-24-03	AEG Seville
VP0615E00	Shut-Off Valve			21-24-03	AEG Seville
VP1240BA0	Dual Position Valve			21-21-10	AEG Seville
VP1240C00	Dual Position Valve			21-21-10	AEG Seville
VP1240D00	Inboard Valve			21-24-04	AEG Seville
VP1240E00	Dual Position Valve			21-21-10	AEG Seville
VR3910	EXTRACTION FAN	AOA	A320 NEO	21	AEG Seville
WE3888446-1	Igniter Accessory			49-41-24	AEG Seville
WE3888446-1	Igniter Accessory			X	AEG Seville
WE3888474-1	Harness Assembly			49-15-01	AEG Seville
WHEEL RIMS	WHEEL RIMS, SHOCK ABSORBERS, MOTOR MOUNTING & MOTOR/SHOCK DISCS		A330, A340		AEG Seville
WC3050569-1	Gearbox			49-27-40	AEG Seville
WL 102AM51	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Seville
WL 102AM52	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Seville
WL 102AM53	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Seville
WL 102AM54	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Seville
WL 102AM55	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Seville
WL 102AM56	ALTIMETER AIRSPEED INDICATOR	GENERAL ELECTRIC	A330, A340		AEG Seville
Z212H000710	CONTROL UNIT	AIRBUS	A321A319 A318 A320	30-70-01	AEG Seville
Z212H000710	CONTROL UNIT	AIRBUS	A321A319 A318 A320 A320-221A320-232	30-70-01	AEG Seville
Z212H000710	CONTROL UNIT	AIRBUS	A321A319 A318 A320	30-70-01	AEG Seville
Z212H0003710	CONTROL UNIT	AIRBUS	A321A319 A318 A320	30-70-01	AEG Seville
Z212H00040710	CONTROL UNIT	AIRBUS	A321A319 A318 A320	30-70-0125	AEG Seville
Z212H0006710	CONTROL UNIT	KID SYSTEME	A321A319 A318 A320	30-70-01	AEG Seville
Z212H0007710	CONTROL UNIT	AIRBUS	A320 A319	30-70-016700330-70-01	AEG Seville
Z212H0009710	CONTROL UNIT	AIRBUS	A321A319 A318 A320	30-70-01	AEG Seville
Z212H0010710	CONTROL UNIT	AIRBUS	A321A319 A318 A320	30-70-01	AEG Seville
Z220H00000710	CONTROL UNIT DRAINMAST	AIRBUS	A321A319 A320 B737	30-71-04	AEG Seville
Z220H0007710	CONTROL UNIT DRAINMAST	AIRBUS	A321A319 A320 B737	30-71-04	AEG Seville
Z220H0002710	CONTROL UNIT DRAINMAST	AIRBUS	A319 A310 A320 B737 A320-221A320-232 A320-200	30-71-04	AEG Seville